

```

; *****
; ** An Assembly File to generate a 16K Custom ROM for the ZX Spectrum **
; *****

; THE 16K "SEA CHANGE" ZX MINIMAL ROM

; -----
; Last updated: 23-FEB-2003
; -----

; Mission Statement
; -----
; To produce a user-friendly operating system for a colour computer to exploit
; the hardware available in the early 1980s. Apart from a few sensible
; alphabetical restrictions, there should be no other limitations other than
; available memory. All the computer's unused memory should be placed at the
; disposal of the user after each statement has executed. Whenever the
; interpreter is expecting a number or a string, then an expression of the
; same type can be substituted ad infinitum.

; This is a "Concept Computer" and the ROM may not recognize the format of
; programs saved from a conventional ZX Spectrum whether they have been saved
; as tapes or snapshots.
; This implementation does not try to maintain common routine addresses such
; as $09F4. Nor are the System Variables compatible with the BASIC manual.
; With the exception of those programs written in BASIC, third-party software
; is unlikely to run on this platform.

; This program is a re-arrangement of other people's code, including the
; open standard "Sinclair Network Standard" and remains the copyright of
; Amstrad PLC and Sinclair Research Ltd.

; TASM cross-assembler directives.
; ( comment out, perhaps, for other assemblers - see Notes at end. )

#define DEFB .BYTE
#define DEFW .WORD
#define DEFM .TEXT
#define ORG .ORG
#define EQU .EQU
#define equ .EQU

ORG 0000

; *****
; ** Part 1. RESTART ROUTINES AND TABLES **
; *****

; -----
; THE 'START'
; -----
; At switch on, the Z80 chip is in Interrupt Mode 0.
; It needs to be placed in Interrupt Mode 1.
; This location can also be 'called' to reset the machine.
; Typically with PRINT USR 0.

I0000

START      DI                ; Disable Interrupts.
           XOR      A        ; Signal coming from START.
           LD       DE,$FFFF ; Set pointer to top of possible physical RAM.
           JP      START_NEW ; Jump forward to common code at START_NEW.

```

```

; -----
; THE OLD 'ERROR' RESTART
; -----
; Note. The ERROR restart is to be moved to L0030.
; An instruction fetch on address $0008 may page in a peripheral ROM such as
; the Sinclair Interface 1 or Disciple Disk Interface. This would now be
; disastrous as none of the routines it uses in this ROM are where they used
; to be. Also the network and RS232 are now controlled from this ROM.
; The shadow ROM could also paged by an instruction fetch on address $1708.
; Since this restart is unused, just stick a return here. Leave room for an
; error report but for now use location nine for release number.
; The command PRINT PEEK 9 gives release number.

```

L0008

```

RESTART8  RET                ;+ Disabled.

          DEFB  74            ;+ unused - but for now has release number.

          DEFB  $FF, $FF, $FF ;+ unused
          DEFB  $FF, $FF, $FF ;+ unused

```

```

; -----
; THE 'PRINT CHARACTER' RESTART
; -----
; The A register holds the code of the character that is to be sent to
; the output stream of the current channel. The alternate register set is
; used to output a character in the A register so there is no need to
; preserve any of the current main registers (HL, DE, BC).
; This restart is used 21 times.

```

L0010

```

PRINT_A   JP    PRINT_A_2    ; Jump forward to continue at PRINT_A_2.

```

; ---

```

;;;      DEFB  $FF, $FF, $FF ; was unused.
;;;      DEFB  $FF, $FF      ; was unused.

```

```

; This 5-byte routine is part of the new FORMAT command and has been moved
; here to exploit spare space. (JS)

```

```

FORMAT_T  LD    A,C           ;+ Get user-supplied TAB width
          LD    ($5BB8),A     ;+ Set it
          RET                ;+ Return.

```

```

; -----
; THE 'COLLECT CHARACTER' RESTART
; -----
; The contents of the location currently addressed by CH_ADD are fetched.
; A return is made if the value represents a character that has
; relevance to the BASIC parser. Otherwise CH_ADD is incremented and the
; tests repeated. CH_ADD will be addressing somewhere -
; 1) in the BASIC program area during line execution.
; 2) in workspace if evaluating, for example, a string expression.
; 3) in the edit buffer if parsing a direct command or a new BASIC line.
; 4) in workspace if accepting input but not that from INPUT LINE.

```

L0018

```

GET_CHAR  LD    HL, ($5B5D)   ; Fetch the address from CH_ADD.
          LD    A, (HL)      ; Use it to pick up the current character.

```

```

TEST_CHAR CALL  SKIP_OVER      ; Routine SKIP_OVER tests if the character is
                                ; relevant.
                                RET  NC      ; Return if it is significant.

; -----
; THE 'COLLECT NEXT CHARACTER' RESTART
; -----
; As the BASIC commands and expressions are interpreted, this routine is
; called repeatedly to step along the line. It is used 83 times.

L0020

NEXT_CHAR CALL  CH_ADD__1      ; Routine CH_ADD+1 fetches the next immediate
                                ; character.

                                JR  TEST_CHAR ; Jump back to TEST_CHAR until a valid
                                ; character is found.

; ---

; -----
; THE 'STOP' COMMAND
; -----
; Command Syntax: STOP
; One of the shortest and least used commands. As with 'OK' not an error.
; This has been moved here as two bytes were unused.

STOP      RST  30H      ; ERROR_1
          DEFB  $08      ; Error Report: STOP statement

;;;      DEFB  $FF,$FF  ; was unused
          DEFB  $FF      ; unused.

; -----
; THE 'CALCULATE' RESTART
; -----
; This restart enters the Spectrum's internal, floating-point,
; stack-based, FORTH-like language.
; It is further used recursively from within the calculator.
; It is used on 77 occasions.

L0028

FP_CALC   JP  CALCULATE      ; Jump forward to the CALCULATE routine.

; ---

;;;      DEFB  $ff, $ff, $ff  ; Spare - note that on the ZX81, space being a
;;;      DEFB  $ff, $ff      ; little cramped, these same locations were
;;;                                ; used for the five-byte 'end-calc' operator.
;;;                                ; Note. This idea may be re-visited!

; -----
; THE 'END_CALC' SUBROUTINE
; -----
; (offset: $38 'end-calc')
; The end-calc literal terminates a mini-program written in the Spectrum's
; internal language.

end_calc  POP  AF          ;+ Drop the calculator return address RE_ENTRY
          EXX             ;+ Switch to the other set.

```

```

EX      (SP),HL          ;+ Transfer H'L' to machine stack for the
                        ;+ return address.
                        ;+ When exiting recursion, then the previous
                        ;+ pointer is transferred to H'L'.

EXX                      ;+ Switch back to main set.
RET                      ;+ Return.

; -----
; THE 'RST 30H' ERROR RESTART
; -----
; This restart is to be used for error handling without paging in Interfacel
; while, at the same time, allowing access to its hardware.
; The error pointer is made to point to the position of the error to enable
; the editor to highlight the error position if it occurred during syntax
; checking. It is used at 37 places in the program although not all errors
; pass through here.

L0030

ERROR_1  LD      HL,($5B5D)      ;+ Fetch the character address from CH_ADD.
         LD      ($5B5F),HL     ;+ Copy it to the error pointer X_PTR.

         JR      ERROR_2        ;+ Forward to continue at ERROR_2.

; -----
; THE 'MASKABLE INTERRUPT' ROUTINE
; -----
; This routine increments the Spectrum's three-byte FRAMES counter
; fifty times a second (sixty times a second in the USA ).
; Both this routine and the called KEYBOARD subroutine use
; the IY register to access system variables and flags so a user-written
; program must disable interrupts to make use of the IY register.

L0038                      ; Note Interrupts are automatically disabled.

MASK_INT  PUSH   AF              ; Save the registers that will be used.
         PUSH   HL              ;

;;;          LD      HL,($5B78)   ; Fetch the first two bytes at FRAMES1.
;;;          INC     HL           ; Increment lowest two bytes of counter.
;;;          LD      ($5B78),HL   ; Place back in FRAMES1.
;;;          LD      A,H          ; Test if the result was zero.
;;;          OR      L            ;
;;;          JR      NZ,KEY_INT   ; Forward, if not, to KEY_INT
;;;
;;;          INC     (IY+$40)     ; otherwise increment FRAMES3 the third byte.

; Note. the above code has been replaced with this neater and shorter
; sequence which also avoids using the IY register.

         LD      HL,$5B78        ;+ Address FRAMES
         INC     (HL)            ;+ Increment low byte of counter.
         JR      NZ,KEY_INT      ;+ Forward, if not back to zero, to KEY_INT.

         INC     L               ;+ Increment address using 4 clock cycles.
         INC     (HL)            ;+ Increment middle counter.
         JR      NZ,KEY_INT      ;+ Forward, if not back to zero, to KEY_INT.

         INC     L               ;+ All the FRAMES addresses have same high byte.
         INC     (HL)            ;+ Increment last counter.

; Now save the rest of the main registers and read and decode the keyboard.

```

```

KEY_INT  PUSH  BC          ; Save the other main registers.
         PUSH  DE          ;
         CALL  KEYBOARD    ; Routine KEYBOARD executes a stage in the
                           ; process of reading a key-press.
                           ; Only registers HL, DE, BC and AF can be used.

         POP   DE          ; Restore all four registers.
         POP   BC          ;

         POP   HL          ;
         POP   AF          ;

         EI              ; Enable Interrupts.
         RET             ; Return.

```

```

; -----
; THE 'ERROR_2' ROUTINE
; -----

```

```

; A continuation of the code at ERROR_1.
; The error code is stored and, after clearing down the calculator stack, an
; indirect jump is made to the Error Stack Pointer to handle the error.

```

```

ERROR_2  POP   HL          ; Drop the return address - the location after
                           ; the error restart.
         LD    L, (HL)     ; Fetch the error code that follows.

```

```

; Note. this entry point is used when out of memory at REPORT_4.
; The L register has been loaded with the report code but X_PTR is not
; updated.

```

```

ERROR_3  LD    (IY+$00),L  ; Store it in the system variable ERR_NR.
         LD    SP, ($5B3D) ; ERR_SP points to an error handler on the
                           ; machine stack. There may be a hierarchy
                           ; of routines.
                           ; To MAIN_4 initially at base.
                           ; or REPORT_G on line entry.
                           ; or ED_ERROR when editing.
                           ; or ED_FULL during ed-enter.
                           ; or IN_VAR_1 during runtime input etc.

         JP   SET_STK     ; Jump to SET_STK to clear the calculator
                           ; stack and reset MEM to usual place in the
                           ; systems variables area and then indirectly to
                           ; one of the addresses above.

```

```

; -----
; SPARE
; -----

```

```

         DEFB  $FF, $FF, $FF, ;+ Spare
         DEFB  $FF, $FF, $FF, ;+
         DEFB  $FF, $FF, $FF, ;+

```

L0066

```

; -----
; THE 'NON-MASKABLE INTERRUPT' ROUTINE
; -----

```

```

; There was no NMI switch on the standard Spectrum.
; There was however a well-developed NMI routine, reproduced here with one
; major difference. On the original Spectrum the branch to the address held
; in the NMIADD System Variables was taken if the address was zero and not,

```

```

; as expected, if the address was non-zero.
;
; Sinclair Research said that, since they had never advertised the NMI, they
; had no plans to fix the error "until the opportunity arose". In fact, the
; location NMIADD was later used by Interface 1 for other purposes.
; On later Amstrad Spectrums, and the Brazilian Spectrum, the logic of this
; routine was reversed but not as at first intended.
;
; The original functionality is resurrected in full here. The clue is the
; rather clumsy initialization of CHARS in the code at RAM_SET . The
; NMIADD System variable now holds the address NMI_PTR by default and the
; code there provides for a Warm Reset which re-initializes the system
; without losing the BASIC program.
;
; In all probability the NMI button would have been on the advertized
; RS232/Network board.
;
; Software houses who didn't want their programs broken into could presumably
; set NMIADD to zero to defeat hackers.

```

```

NMI      PUSH  AF          ; Save the
        PUSH  HL          ; registers.
        LD   HL,($5BB0)   ; Fetch the system variable NMIADD.
        LD   A,H          ; Test address
        OR   L            ; for zero.

;;;     JR   NZ,NMI_2      ;- Skip to NO_NMI if both bytes default N Z!
        JR   Z,NMI_2      ;+ Skip to NO_NMI if both bytes default ZERO.
        JP   (HL)         ; else jump to routine.

NMI_2    POP   HL          ; Restore the
        POP   AF          ; registers.

NMI_END  RETN            ; Return to previous interrupt state.

; -----
; THE 'CH ADD + 1' SUBROUTINE
; -----
; This subroutine is called from RST 20, and three times from elsewhere
; to fetch the next immediate character following the current valid character
; address and update the associated system variable.
; The entry point TEMP_PTR1 is used from the SCANNING routine.
; Both TEMP_PTR1 and TEMP_PTR2 are used by the READ command routine.

CH_ADD__1 LD   HL,($5B5D) ; fetch address from CH_ADD.

TEMP_PTR1 INC   HL        ; increase the character address by one.

TEMP_PTR2
        LD   A,(HL)       ; load character to A from HL.

TEMP_PTR3 LD   ($5B5D),HL ; update CH_ADD with character address.

        RET               ; and return.

; -----
; THE 'SKIP OVER' SUBROUTINE
; -----
; This subroutine is called once from RST 18 to skip over white-space and
; other characters irrelevant to the parsing of a BASIC line etc.
; Initially the A register holds the character to be considered and HL holds
; its address which will not be within quoted text when a BASIC line is

```

```

; parsed.
; Although the 'tab' and 'at' characters will not appear in a BASIC line,
; they could be present in a string expression, and in other situations.
; Note. although white-space is usually placed in a program to indent loops
; and make it more readable, it can also be used for the opposite effect and
; spaces may appear in variable names although the parser never sees them.
; It is this routine that helps make the variables 'Anum bEr5 3BUS' and
; 'a number 53 bus' appear the same to the parser.

```

```

SKIP_OVER CP    $21          ; test if higher than space.
          RET    NC          ; return with carry clear if higher.

          CP    $0D          ; carriage return ?
          RET    Z          ; return, if so, also with carry clear.

          ; all other characters have no relevance
          ; to the parser and must be returned with
          ; carry set.

          CP    $10          ; test if 0-15d
          RET    C          ; return, if so, with carry set.

          CP    $18          ; test if 24-32d
          CCF          ; complement carry flag.
          RET    C          ; return, if so, with carry set.

          ; now leaves 16d-23d

          INC    HL          ; all above have at least one extra character
          ; to be stepped over.

          CP    $16          ; controls 22d ('at') and 23d ('tab') have two.
          JR    C,SKIPS      ; forward to SKIPS with ink, paper, flash,
          ; bright, inverse or over controls.
          ; Note. the high byte of tab is for RS232 only.

          INC    HL          ; step over the second character of 'at'/'tab'.

SKIPS     SCF          ; set the carry flag

          JR    TEMP_PTR3    ;+ back to similar code above.

;;;      LD    ($5B5D),HL    ; update the CH_ADD system variable.
;;;      RET          ; return with carry set.

```

```

; -----
; THE 'TOKEN' TABLES
; -----
; The tokenized characters 134d (RND) to 255d (COPY) are expanded using
; this table. The last byte of a token is inverted to denote the end of
; the word. The first is an inverted step-over byte.

```

```

TKN_TABLE DEFB  '?'+$80
          DEFB  "RN"
          DEFB  'D'+$80
          DEFB  "INKEY"
          DEFB  '$'+$80
          DEFB  'P','I'+$80
          DEFB  'F','N'+$80
          DEFB  "POIN"
          DEFB  'T'+$80
          DEFB  "SCREEN"
          DEFB  '$'+$80

```

```

DEFM "ATT"
DEFB 'R'+$80
DEFB 'A','T'+$80
DEFM "TA"
DEFB 'B'+$80
DEFM "VAL"
DEFB '$'+$80
DEFM "COD"
DEFB 'E'+$80
DEFM "VA"
DEFB 'L'+$80
DEFM "LE"
DEFB 'N'+$80
DEFM "SI"
DEFB 'N'+$80
DEFM "CO"
DEFB 'S'+$80
DEFM "TA"
DEFB 'N'+$80
DEFM "AS"
DEFB 'N'+$80
DEFM "AC"
DEFB 'S'+$80
DEFM "AT"
DEFB 'N'+$80
DEFB 'L','N'+$80
DEFM "EX"
DEFB 'P'+$80
DEFM "IN"
DEFB 'T'+$80
DEFM "SQ"
DEFB 'R'+$80
DEFM "SG"
DEFB 'N'+$80
DEFM "AB"
DEFB 'S'+$80
DEFM "PEE"
DEFB 'K'+$80
DEFB 'I','N'+$80
DEFM "US"
DEFB 'R'+$80
DEFM "STR"
DEFB '$'+$80
DEFM "CHR"
DEFB '$'+$80
DEFM "NO"
DEFB 'T'+$80
DEFM "BI"
DEFB 'N'+$80

```

```

; The previous 32 function-type words are printed without a leading space
; The following have a leading space if they begin with a letter

```

```

DEFB 'O','R'+$80
DEFM "AN"
DEFB 'D'+$80
DEFB $3C,'='+$80 ; <=
DEFB $3E,'='+$80 ; >=
DEFB $3C,$3E+$80 ; <>
DEFM "LIN"
DEFB 'E'+$80
DEFM "THE"
DEFB 'N'+$80
DEFB 'T','O'+$80

```


DEFM "STE"
DEFB 'P'+\$80
DEFM "DEF F"
DEFB 'N'+\$80
DEFM "CA"
DEFB 'T'+\$80
DEFM "FORMA"
DEFB 'T'+\$80
DEFM "MOV"
DEFB 'E'+\$80
DEFM "ERAS"
DEFB 'E'+\$80
DEFM "OPEN "
DEFB '#'+\$80
DEFM "CLOSE "
DEFB '#'+\$80
DEFM "MERG"
DEFB 'E'+\$80
DEFM "VERIF"
DEFB 'Y'+\$80
DEFM "BEE"
DEFB 'P'+\$80
DEFM "CIRCL"
DEFB 'E'+\$80
DEFM "IN"
DEFB 'K'+\$80
DEFM "PAPE"
DEFB 'R'+\$80
DEFM "FLAS"
DEFB 'H'+\$80
DEFM "BRIGH"
DEFB 'T'+\$80
DEFM "INVERS"
DEFB 'E'+\$80
DEFM "OVE"
DEFB 'R'+\$80
DEFM "OU"
DEFB 'T'+\$80
DEFM "LPRIN"
DEFB 'T'+\$80
DEFM "LLIS"
DEFB 'T'+\$80
DEFM "STO"
DEFB 'P'+\$80
DEFM "REA"
DEFB 'D'+\$80
DEFM "DAT"
DEFB 'A'+\$80
DEFM "RESTOR"
DEFB 'E'+\$80
DEFM "NE"
DEFB 'W'+\$80
DEFM "BORDE"
DEFB 'R'+\$80
DEFM "CONTINU"
DEFB 'E'+\$80
DEFM "DI"
DEFB 'M'+\$80
DEFM "RE"
DEFB 'M'+\$80
DEFM "FO"
DEFB 'R'+\$80
DEFM "GO T"
DEFB 'O'+\$80

```

DEFM "GO SU"
DEFB 'B'+$80
DEFM "INPU"
DEFB 'T'+$80
DEFM "LOA"
DEFB 'D'+$80
DEFM "LIS"
DEFB 'T'+$80
DEFM "LE"
DEFB 'T'+$80
DEFM "PAUS"
DEFB 'E'+$80
DEFM "NEX"
DEFB 'T'+$80
DEFM "POK"
DEFB 'E'+$80
DEFM "PRIN"
DEFB 'T'+$80
DEFM "PLO"
DEFB 'T'+$80
DEFM "RU"
DEFB 'N'+$80
DEFM "SAV"
DEFB 'E'+$80
DEFM "RANDOMIZ"
DEFB 'E'+$80
DEFB 'I','F'+$80
DEFM "CL"
DEFB 'S'+$80
DEFM "DRA"
DEFB 'W'+$80
DEFM "CLEA"
DEFB 'R'+$80
DEFM "RETUR"
DEFB 'N'+$80
DEFM "COP"
DEFB 'Y'+$80

```

```

; -----
; THE 'KEY' TABLES
; -----

```

```

; These six look-up tables are used by the keyboard reading routine
; to decode the key values.
;

```

```

; The first table contains the maps for the 39 keys of the standard
; 40-key Spectrum keyboard. The remaining key [SHIFT $27] is read directly.
; The keys consist of the 26 upper-case alphabetic characters, the 10 digit
; keys and the space, ENTER and symbol shift key.
; Unshifted alphabetic keys have $20 added to the value.
; The keywords for the main alphabetic keys are obtained by adding $A5 to
; the values obtained from this table.

```

```

MAIN_KEYS DEFB $42          ; B
          DEFB $48          ; H
          DEFB $59          ; Y
          DEFB $36          ; 6
          DEFB $35          ; 5
          DEFB $54          ; T
          DEFB $47          ; G
          DEFB $56          ; V
          DEFB $4E          ; N
          DEFB $4A          ; J
          DEFB $55          ; U
          DEFB $37          ; 7

```

```

DEFB $34 ; 4
DEFB $52 ; R
DEFB $46 ; F
DEFB $43 ; C
DEFB $4D ; M
DEFB $4B ; K
DEFB $49 ; I
DEFB $38 ; 8
DEFB $33 ; 3
DEFB $45 ; E
DEFB $44 ; D
DEFB $58 ; X
DEFB $0E ; SYMBOL SHIFT
DEFB $4C ; L
DEFB $4F ; O
DEFB $39 ; 9
DEFB $32 ; 2
DEFB $57 ; W
DEFB $53 ; S
DEFB $5A ; Z
DEFB $20 ; SPACE
DEFB $0D ; ENTER
DEFB $50 ; P
DEFB $30 ; 0
DEFB $31 ; 1
DEFB $51 ; Q
DEFB $41 ; A

```

```

; The 26 unshifted extended mode keys for the alphabetic characters.
; The green keywords on the original keyboard.

```

```

E_UNSHIFT DEFB $E3 ; READ
          DEFB $C4 ; BIN
          DEFB $E0 ; LPRINT
          DEFB $E4 ; DATA
          DEFB $B4 ; TAN
          DEFB $BC ; SGN
          DEFB $BD ; ABS
          DEFB $BB ; SQR
          DEFB $AF ; CODE
          DEFB $B0 ; VAL
          DEFB $B1 ; LEN
          DEFB $C0 ; USR
          DEFB $A7 ; PI
          DEFB $A6 ; INKEY$
          DEFB $BE ; PEEK
          DEFB $AD ; TAB
          DEFB $B2 ; SIN
          DEFB $BA ; INT
          DEFB $E5 ; RESTORE
          DEFB $A5 ; RND
          DEFB $C2 ; CHR$
          DEFB $E1 ; LLIST
          DEFB $B3 ; COS
          DEFB $B9 ; EXP
          DEFB $C1 ; STR$
          DEFB $B8 ; LN

```

```

; The 26 shifted extended mode keys for the alphabetic characters.
; The red keywords below keys on the original keyboard.

```

```

EXT_SHIFT DEFB $7E ; ~
          DEFB $DC ; BRIGHT
          DEFB $DA ; PAPER

```

```

DEFB $5C          ; \
DEFB $B7          ; ATN
DEFB $7B          ; {
DEFB $7D          ; }
DEFB $D8          ; CIRCLE
DEFB $BF          ; IN
DEFB $AE          ; VAL$
DEFB $AA          ; SCREEN$
DEFB $AB          ; ATTR
DEFB $DD          ; INVERSE
DEFB $DE          ; OVER
DEFB $DF          ; OUT
DEFB $7F          ; (Copyright character)
DEFB $B5          ; ASN
DEFB $D6          ; VERIFY
DEFB $7C          ; |
DEFB $D5          ; MERGE
DEFB $5D          ; ]
DEFB $DB          ; FLASH
DEFB $B6          ; ACS
DEFB $D9          ; INK
DEFB $5B          ; [
DEFB $D7          ; BEEP

```

; The ten control codes assigned to the top line of digits when the shift
key is pressed.

```

CTL_CODES DEFB $0C          ; DELETE
           DEFB $07          ; EDIT
           DEFB $06          ; CAPS LOCK
           DEFB $04          ; TRUE VIDEO
           DEFB $05          ; INVERSE VIDEO
           DEFB $08          ; CURSOR LEFT
           DEFB $0A          ; CURSOR DOWN
           DEFB $0B          ; CURSOR UP
           DEFB $09          ; CURSOR RIGHT
           DEFB $0F          ; GRAPHICS

```

; The 26 red symbols assigned to the alphabetic characters of the keyboard.
; The ten single-character digit symbols are converted without the aid of
; a table using subtraction and minor manipulation.

```

SYM_CODES DEFB $E2          ; STOP
           DEFB $2A          ; *
           DEFB $3F          ; ?
           DEFB $CD          ; STEP
           DEFB $C8          ; >=
           DEFB $CC          ; TO
           DEFB $CB          ; THEN
           DEFB $5E          ; ^
           DEFB $AC          ; AT
           DEFB $2D          ; -
           DEFB $2B          ; +
           DEFB $3D          ; =
           DEFB $2E          ; .
           DEFB $2C          ; ,
           DEFB $3B          ; ;
           DEFB $22          ; "
           DEFB $C7          ; <=
           DEFB $3C          ; <
           DEFB $C3          ; NOT
           DEFB $3E          ; >
           DEFB $C5          ; OR
           DEFB $2F          ; /

```

```

DEFB $C9          ; <>
DEFB $60          ; pound
DEFB $C6          ; AND
DEFB $3A          ; :

```

```

; The ten keywords assigned to the digits in extended mode.
; The remaining red keywords below the keys.

```

```

E_DIGITS DEFB $D0      ; FORMAT
          DEFB $CE      ; DEF FN
          DEFB $A8      ; FN
          DEFB $CA      ; LINE
          DEFB $D3      ; OPEN #
          DEFB $D4      ; CLOSE #
          DEFB $D1      ; MOVE
          DEFB $D2      ; ERASE
          DEFB $A9      ; POINT
          DEFB $CF      ; CAT

```

```

;*****
;** Part 2. KEYBOARD ROUTINES **
;*****

```

```

; Using shift keys and a combination of modes the Spectrum 40-key keyboard
; can be mapped to 256 input characters

```

```

; -----
;
; PORT      0      1      2      3      4 -Bits-  4      3      2      1      0      PORT
;
; F7FE [ 1 ] [ 2 ] [ 3 ] [ 4 ] [ 5 ] | [ 6 ] [ 7 ] [ 8 ] [ 9 ] [ 0 ] EFFE
; ^ |
; FBFE [ Q ] [ W ] [ E ] [ R ] [ T ] | [ Y ] [ U ] [ I ] [ O ] [ P ] DFFE
; ^ |
; FDFE [ A ] [ S ] [ D ] [ F ] [ G ] | [ H ] [ J ] [ K ] [ L ] [ ENT ] BFFE
; ^ |
; FEFE [SHI] [ Z ] [ X ] [ C ] [ V ] | [ B ] [ N ] [ M ] [sym] [ SPC ] 7FFE
; ^ $27 | $18 v
; Start                                End
;      00100111                                00011000
;
; -----

```

```

; The above map may help in reading.
; The neat arrangement of ports means that the B register need only be
; rotated left to work up the left hand side and then down the right
; hand side of the keyboard. When the reset bit drops into the carry
; then all 8 half-rows have been read. Shift is the first key to be
; read. The lower six bits of the shifts are unambiguous.

```

```

; -----
; THE 'KEYBOARD SCANNING' ROUTINE
; -----

```

```

; From keyboard and s-inkey$
; Returns 1 or 2 keys in DE, most significant shift first if any
; key values 0-39 else 255

```

```

KEY_SCAN LD L,$2F          ; initial key value
          ; valid values are obtained by subtracting
          ; eight five times.
          LD DE,$FFFF      ; a buffer to receive 2 keys.
          LD BC,$FEFE      ; the commencing port address
          ; B holds 11111110 initially and is also

```

```

KEY_LINE  IN    A, (C)          ; used to count the 8 half-rows
                                ; read the port to A - bits will be reset
                                ; if a key is pressed else set.
                                ; complement - pressed key-bits are now set
                                ; apply 00011111 mask to pick up the
                                ; relevant set bits.

                                JR    Z,KEY_DONE      ; forward to KEY_DONE if zero and therefore
                                ; no keys pressed in row at all.

                                LD    H,A            ; transfer row bits to H
                                LD    A,L            ; load the initial key value to A

KEY_3KEYS INC    D              ; now test the key buffer
                                RET    NZ           ; if we have collected 2 keys already
                                ; then too many so quit.

KEY_BITS  SUB    $08           ; subtract 8 from the key value
                                ; cycling through key values (top = $27)
                                ; e.g. 2F> 27>1F>17>0F>07
                                ;      2E> 26>1E>16>0E>06
                                SRL   H              ; shift key bits right into carry.
                                JR    NC,KEY_BITS    ; back, if not pressed, to KEY_BITS
                                ; but if pressed we have a value (0_39d)

                                LD    D,E            ; transfer a possible previous key to D
                                LD    E,A            ; transfer the new key to E
                                JR    NZ,KEY_3KEYS  ; back to KEY_3KEYS if there were more
                                ; set bits - H was not yet zero.

KEY_DONE  DEC    L              ; cycles 2F>2E>2D>2C>2B>2A>29>28 for
                                ; each half-row.
                                RLC   B              ; form next port address e.g. FEFE > FDFF
                                JR    C,KEY_LINE    ; back to KEY_LINE if still more rows to do.

                                LD    A,D            ; now test if D is still FF ?
                                INC   A              ; if it is zero we have at most 1 key
                                ; range now $01-$28 (1-40d)
                                RET    Z              ; return if one key or no key.

                                CP    $28           ; is it caps shift (was $27) ?
                                RET    Z              ; return if so.

                                CP    $19           ; is it symbol shift (was $18) ?
                                RET    Z              ; return also

                                LD    A,E            ; now test E
                                LD    E,D            ; but first switch
                                LD    D,A            ; the two keys.
                                CP    $18           ; is it symbol shift ?
                                RET    Z              ; return (with zero set if it was).
                                ; but with symbol shift now in D

; -----
; THE 'KEYBOARD' ROUTINE
; -----
;   Called from the interrupt 50 times a second.
;

KEYBOARD  CALL   KEY_SCAN      ; routine KEY_SCAN

                                RET    NZ           ; return if invalid combinations

;   Decrease the counters within the two key-state maps

```

```

; as this could cause one to become free.
; If the keyboard has not been pressed during the last five interrupts
; then both sets will be free.

        LD    HL,$5B00        ; point to KSTATE_0
K_ST_LOOP BIT 7,(HL)         ; is it free ? (i.e. $FF)
        JR    NZ,K_CH_SET    ; forward, if so, to K_CH_SET

        INC  HL              ; address the 5-counter
        DEC  (HL)           ; decrease the counter
        DEC  HL              ; step back

        JR    NZ,K_CH_SET    ; forward, if not at end of count, to K_CH_SET

        LD    (HL),$FF      ; else mark this particular map free.
K_CH_SET LD    A,L          ; make a copy of the low address byte.
;;;     LD    HL,$5B04      ;- point to KSTATE_4 (Note. ld l,$04 would do)
        LD    L,$04         ;+ point low order byte to KSTATE_4

        CP    L              ; have both sets been considered ?
        JR    NZ,K_ST_LOOP  ; back to K_ST_LOOP to consider this 2nd set
; Now the raw key (0-38d) is converted to a main key (uppercase).

        CALL K_TEST         ; routine K_TEST to get main key in A

        RET    NC           ; return if just a single shift

        LD    HL,$5B00      ; point to KSTATE_0
        CP    (HL)         ; does the main key code match ?
        JR    Z,K_REPEAT    ; forward, if so, to K_REPEAT

; If not consider the second key map for a repeat.
;;;     EX    DE,HL         ; save KSTATE_0 in DE
;;;     LD    HL,$5B04      ; point to KSTATE_4

        LD    L,$04         ;+ point to KSTATE_4
        CP    (HL)         ; does the main key code match ?
        JR    Z,K_REPEAT    ; forward, if so, to K_REPEAT

; Having excluded a repeating key we can now consider a new key.
; The second set is always examined before the first.

        BIT 7,(HL)         ; is the key map free ?
        JR    NZ,K_NEW      ; forward, if so, to K_NEW

;;;     EX    DE,HL         ; bring back KSTATE_0

        LD    L,$00         ;+ bring back KSTATE_0

        BIT 7,(HL)         ; is it free ?

        RET    Z           ; return if not.
; as we have a key but nowhere to put it yet.

; Continue or jump to here if one of the buffers was free.
K_NEW   LD    E,A          ; store key in E

```

```

LD      (HL),A          ; place in free location
INC     HL              ; advance to the interrupt counter
LD      (HL), $05       ; and initialize counter to 5
INC     HL              ; advance to the delay
LD      A, ($5B09)      ; pick up the system variable REPDEL
LD      (HL),A          ; and insert that for first repeat delay.
INC     HL              ; advance to last location of state map.

;;;
LD      C, (IY+$07)     ; pick up MODE   (3 bytes)
LD      D, (IY+$01)     ; pick up FLAGS (3 bytes)

PUSH    HL              ; save state map location
; Note. could now have used, to avoid IY,
; ld l, $41; ld c, (hl); ld l, $3B; ld d, (hl).
; six and two threes of course.

LD      L, $41          ;+ Avoid IY usage
LD      C, (HL)         ;+ Load C register with system variable MODE.
LD      L, $3B          ;+
LD      D, (HL)         ;+ Load D register with system variable FLAGS.

CALL    K_DECODE        ; routine K_DECODE

POP     HL              ; restore map pointer
LD      (HL),A          ; put the decoded key in last location of map.

K_END   LD      ($5B08),A ; update LASTK system variable.

;;;
SET     5, (IY+$01)     ; - update FLAGS - signal a new key.

LD      L, $3B          ;+ HL now addresses FLAGS
SET     5, (HL)         ;+ signal new key.

RET                                           ; return to interrupt routine.

; -----
; THE 'REPEAT KEY' BRANCH
; -----
; A possible repeat has been identified. HL addresses the raw key.
; The last location of the key map holds the decoded key from the first
; context. This could be a keyword and, with the exception of NOT, a repeat
; is syntactically incorrect and not really desirable.
; credit: Chris Thornton 1983.

K_REPEAT INC    HL          ; increment the map pointer to second location.
LD      (HL), $05       ; maintain interrupt counter at 5.
INC     HL              ; now point to third location.
DEC     (HL)            ; decrease the REPDEL value which is used to
; time the delay of a repeat key.

RET     NZ              ; return if not yet zero.

LD      A, ($5B0A)      ; Fetch the system variable value REPPER.
LD      (HL),A          ; For subsequent repeats REPPER will be used.

INC     HL              ; Advance
;
LD      A, (HL)         ; Pick up the key decoded possibly in another
; context.
; Note. should compare with $A5 (RND) and make
; a simple return if this is a keyword.
; e.g. cp $a5; ret nc; (3 extra bytes)

CP      $A5             ;+ Is repeat a keyword ?

```



```

RET    NC                ;+ Ignore if a keyword.

JR     K_END            ; Back, to accept key, at K_END

; -----
; THE 'KEY_TEST' ROUTINE
; -----
;   This is also called from s-inkey$
;   Begin by testing for a shift with no other.

K_TEST LD    B,D          ; Load most significant key to B - will be $FF
                        ; if not shift.
      LD    D,$00         ; Reset D to index into main table.
      LD    A,E          ; Load least significant key from E.
      CP    $27          ; Is it higher than 39d ?   i.e. FF
      RET   NC           ; return with just a shift (in B now).

      CP    $18          ; is it symbol shift ?
      JR    NZ,K_MAIN    ; forward, if not, to K_MAIN

;   but we could have just symbol shift and no other

      BIT   7,B          ; is other key $FF (i.e. not shift)
      RET   NZ           ; return with solitary symbol shift.

K_MAIN LD    HL,MAIN_KEYS ; address: MAIN_KEYS
      ADD   HL,DE        ; add offset 0-38
      LD    A,(HL)       ; pick up main key value
      SCF                ; set carry flag

      RET                ; return    (B has other key still)

; -----
; THE 'KEYBOARD DECODING' SUBROUTINE
; -----
;   This is also called from s-inkey$

K_DECODE LD    A,E       ; pick up the stored main key

K_DECODE2 CP    $3A      ; an arbitrary point between digits and letters
          JR    C,K_DIGIT ; forward to K_DIGIT with digits, space, enter.

          DEC   C        ; decrease MODE ( 0='KLC', 1='E', 2='G')

          JP    M,K_KLC_LET ; to K_KLC_LET if was zero

          JR    Z,K_E_LET  ; to K_E_LET if was 1 for extended letters.

;   Proceed with graphic codes.
;   Note. should not augment the keycode if code > 'U' ($55).
;   (s-inkey$ never gets into graphics mode.)

          CP    'V'       ;+ compare with non graphic keys
          JR    C,ADDIT   ;+ skip forward if this key has a UDG.

          XOR   A         ;+ set key value to zero.
          RET                ;+ return with 'no key'.

ADDIT  ADD    A,$4F      ; add offset to augment 'A' to graphics A say.
      RET                ; return.
                        ; Note. ( but [GRAPH] V gave RND, etc ).

```

```

; ---

; the jump was to here with extended mode with uppercase A-Z.
K_E_LET  LD    HL,E_UNSHIFT-$41; base address of E_UNSHIFT.
        INC    B                ; test B is it empty i.e. not a shift.
        JR    Z,K_LOOK_UP      ; forward, if neither shift, to K_LOOK_UP
        LD    HL,EXT_SHIFT-$41; Address: EXT_SHIFT base
K_LOOK_UP LD    D,$00          ; prepare to index.
        ADD    HL,DE           ; add the main key value.
        LD    A,(HL)          ; pick up other mode value.
        RET                    ; return.

; ---

; the jump was here with mode = 0
K_KLC_LET LD    HL,SYM_CODES-$41; prepare base of sym-codes
        BIT    0,B             ; shift=$27 sym-shift=$18
        JR    Z,K_LOOK_UP      ; back to K_LOOK_UP with symbol-shift
        BIT    3,D             ; test FLAGS is it 'K' mode (from OUT_CURS)
        JR    Z,K_TOKENS       ; skip, if so, to K_TOKENS
;;;
        BIT    3,(IY+$30)      ;- test FLAGS2 - consider CAPS LOCK ?
        LD    HL,$5B6A         ;+ Address sysvar FLAGS2 using HL not IY
        BIT    3,(HL)          ;+ test FLAGS2 - consider CAPS LOCK ?
        RET    NZ              ; return, if so, with main code.
        INC    B                ; is shift being pressed ?
        RET    NZ              ; return if shift pressed.
        ADD    A,$20           ; else convert the code to lower case.
        RET                    ; return.

; ---

; the jump was here for tokens
K_TOKENS ADD    A,$A5          ; add offset to main code so that 'A'
                                ; becomes 'NEW' etc.
        RET                    ; return.

; ---

; the jump was here with digits, space, enter and symbol shift (< $xx)
K_DIGIT  CP    $30             ; is it '0' or higher ?
        RET    C                ; return with space, enter and symbol-shift
        DEC    C                ; test MODE (was 0='KLC', 1='E', 2='G')
        JP    M,K_KLC_DGT      ; jump to K_KLC_DGT if was 0.
        JR    NZ,K_GRA_DGT     ; forward to K_GRA_DGT if mode was 2.

```

```

; continue with extended digits 0-9.

        LD    HL,E_DIGITS-$30 ; base of E_DIGITS
        BIT   5,B              ; test - shift=$27 sym-shift=$18
        JR    Z,K_LOOK_UP     ; back to K_LOOK_UP if sym-shift

        CP    $38              ; is character '8' ?
        JR    NC,K_8_and_9    ; to K_8_&_9 if greater than '7'

        SUB   $20              ; reduce to ink range $10-$17
        INC   B                ; shift ?
        RET   Z                ; return if not.

        ADD   A,$08           ; add 8 to give paper range $18 - $1F
        RET

; ---

K_8_and_9 SUB   $36           ; reduce to 02 and 03 bright codes
          INC   B              ; test if shift pressed.
          RET   Z              ; return if not.

          ADD   A,$FE         ; subtract 2 setting carry to give 0 and 1
          RET                   ; Return.

; ---

; graphics mode with digits

K_GRA_DGT LD    HL,CTL_CODES-$30; base address of CTL_CODES

          CP    $39           ; is key '9' ?
          JR    Z,K_LOOK_UP   ; back to K_LOOK_UP - changed to $0F, GRAPHICS.

          CP    $30           ; is key '0' ?
          JR    Z,K_LOOK_UP   ; back to K_LOOK_UP - changed to $0C, delete.

; for keys '0' - '7' we assign a mosaic character depending on shift.

          AND   $07           ; convert character to number. 0 - 7.
          ADD   A,$80         ; add offset - they start at $80

          INC   B              ; destructively test for shift
          RET   Z              ; and return if not pressed.

          XOR   $0F           ; toggle accumulator bits -gives range $88-$8F.
          RET                   ; return.

; ---

; now digits in 'KLC' mode

K_KLC_DGT INC   B              ; return with digit codes if neither
          RET   Z              ; shift key pressed.

          BIT   5,B            ; test for caps shift.

          LD    HL,CTL_CODES-$30; prepare base of table CTL_CODES.

          JR    NZ,K_LOOK_UP  ; back to K_LOOK_UP if shift pressed.

; must have been symbol shift

```

```

SUB    $10                ; for ASCII most will now be correct
                        ; on a standard typewriter.

CP    $22                ; but '@' is not - see below.
JR    Z,K_at_CHAR        ; forward, if so, to K_at_CHAR

CP    $20                ; character '_' is the other one that fails
RET   NZ                 ; return if not.

LD    A,$5F              ; substitute ASCII '_'
RET                                       ; return.

; ---

K_at_CHAR LD    A,$40        ; substitute ASCII '@'
RET                                       ; return.

```

```

; -----
; The Spectrum Input character keys. One or two are abbreviated.
; From $00 Flash 0 to $FF COPY. The routine above has decoded all these.

```

```

; | 00 Fl0| 01 Fl1| 02 Br0| 03 Br1| 04 In0| 05 In1| 06 CAP| 07 EDT|
; | 08 LFT| 09 RIG| 0A DWN| 0B UP | 0C DEL| 0D ENT| 0E SYM| 0F GRA|
; | 10 Ik0| 11 Ik1| 12 Ik2| 13 Ik3| 14 Ik4| 15 Ik5| 16 Ik6| 17 Ik7|
; | 18 Pa0| 19 Pa1| 1A Pa2| 1B Pa3| 1C Pa4| 1D Pa5| 1E Pa6| 1F Pa7|
; | 20 SP | 21 ! | 22 " | 23 # | 24 $ | 25 % | 26 & | 27 ' |
; | 28 ( | 29 ) | 2A * | 2B + | 2C , | 2D - | 2E . | 2F / |
; | 30 0 | 31 1 | 32 2 | 33 3 | 34 4 | 35 5 | 36 6 | 37 7 |
; | 38 8 | 39 9 | 3A : | 3B ; | 3C < | 3D = | 3E > | 3F ? |
; | 40 @ | 41 A | 42 B | 43 C | 44 D | 45 E | 46 F | 47 G |
; | 48 H | 49 I | 4A J | 4B K | 4C L | 4D M | 4E N | 4F O |
; | 50 P | 51 Q | 52 R | 53 S | 54 T | 55 U | 56 V | 57 W |
; | 58 X | 59 Y | 5A Z | 5B [ | 5C \ | 5D ] | 5E ^ | 5F _ |
; | 60 ukp| 61 a | 62 b | 63 c | 64 d | 65 e | 66 f | 67 g |
; | 68 h | 69 i | 6A j | 6B k | 6C l | 6D m | 6E n | 6F o |
; | 70 p | 71 q | 72 r | 73 s | 74 t | 75 u | 76 v | 77 w |
; | 78 x | 79 y | 7A z | 7B { | 7C | | 7D } | 7E ~ | 7F (c)|
; | 80 128| 81 129| 82 130| 83 131| 84 132| 85 133| 86 134| 87 135|
; | 88 136| 89 137| 8A 138| 8B 139| 8C 140| 8D 141| 8E 142| 8F 143|
; | 90 [A]| 91 [B]| 92 [C]| 93 [D]| 94 [E]| 95 [F]| 96 [G]| 97 [H]|
; | 98 [I]| 99 [J]| 9A [K]| 9B [L]| 9C [M]| 9D [N]| 9E [O]| 9F [P]|
; | A0 [Q]| A1 [R]| A2 [S]| A3 [T]| A4 [U]| A5 RND| A6 IK$| A7 PI |
; | A8 FN | A9 PNT| AA SC$| AB ATT| AC AT | AD TAB| AE VL$| AF COD|
; | B0 VAL| B1 LEN| B2 SIN| B3 COS| B4 TAN| B5 ASN| B6 ACS| B7 ATN|
; | B8 LN | B9 EXP| BA INT| BB SQ| BC SGN| BD ABS| BE PEK| BF IN |
; | C0 USR| C1 ST$| C2 CH$| C3 NOT| C4 BIN| C5 OR | C6 AND| C7 <= |
; | C8 >= | C9 <> | CA LIN| CB THN| CC TO | CD STP| CE DEF| CF CAT|
; | D0 FMT| D1 MOV| D2 ERS| D3 OPN| D4 CLO| D5 MRG| D6 VFY| D7 BEP|
; | D8 CIR| D9 INK| DA PAP| DB FLA| DC BRI| DD INV| DE OVR| DF OUT|
; | E0 LPR| E1 LLI| E2 STP| E3 REA| E4 DAT| E5 RES| E6 NEW| E7 BDR|
; | E8 CON| E9 DIM| EA REM| EB FOR| EC GTO| ED GSB| EE INP| EF LOA|
; | F0 LIS| F1 LET| F2 PAU| F3 NXT| F4 POK| F5 PRI| F6 PLO| F7 RUN|
; | F8 SAV| F9 RAN| FA IF | FB CLS| FC DRW| FD CLR| FE RET| FF CPY|

```

```

; Note that for simplicity, Sinclair have located all the control codes
; below the space character.
; ASCII DEL, $7F, has been made a copyright symbol.
; Also $60, '`', not used in BASIC but used in other languages, has been
; allocated the local currency symbol for the relevant country -
; ukp in most Spectrums.
; -----

```

```

;*****
;** Part 3. LOUDSPEAKER ROUTINES **
;*****

```

```

; Documented by Alvin Albrecht.

```

```

; -----
; THE 'BEEPER' SUBROUTINE
; -----

```

```

; Outputs a square wave of given duration and frequency
; to the loudspeaker.

```

```

; Enter with: DE = #cycles - 1
;             HL = tone period as described next
;

```

```

; The tone period is measured in T states and consists of
; three parts: a coarse part (H register), a medium part
; (bits 7..2 of L) and a fine part (bits 1..0 of L) which
; contribute to the waveform timing as follows:
;

```

```

;
;           coarse      medium      fine
; duration of low = 118 + 1024*H + 16*(L>>2) + 4*(L&0x3)
; duration of hi  = 118 + 1024*H + 16*(L>>2) + 4*(L&0x3)
; Tp = tone period = 236 + 2048*H + 32*(L>>2) + 8*(L&0x3)
;
;           = 236 + 2048*H + 8*L = 236 + 8*HL
;

```

```

; As an example, to output five seconds of middle C (261.624 Hz):

```

```

; (a) Tone period = 1/261.624 = 3.822ms
; (b) Tone period in T-States = 3.822ms*fCPU = 13378
;     where fCPU = clock frequency of the CPU = 3.5MHz
; (c) Find H and L for desired tone period:
;     HL = (Tp - 236) / 8 = (13378 - 236) / 8 = 1643 = 0x066B
; (d) Tone duration in cycles = 5s/3.822ms = 1308 cycles
;     DE = 1308 - 1 = 0x051B
;

```

```

; The resulting waveform has a duty ratio of exactly 50%.
;
;

```

```

BEEPER    DI                                ; Disable Interrupts so they don't disturb
; timing
          LD      A,L                        ;
          SRL    L                          ;
          SRL    L                          ; L = medium part of tone period
          CPL                                         ;
          AND    $03                        ; A = 3 - fine part of tone period
          LD    C,A                          ;
          LD    B,$00                        ;
          LD    IX,BE_IX_p_3                ; Address: BE_IX+3
          ADD   IX,BC                        ; IX holds address of entry into the loop
; the loop will contain 0-3 NOPs, implementing
; the fine part of the tone period.
          LD    A,($5B48)                    ; BORDCR
          AND    $38                        ; bits 5..3 contain border colour
          RRCA                                     ; border colour bits moved to 2..0
          RRCA                                     ; to match border bits on port #FE
          RRCA                                     ;
          OR     $08                        ; bit 3 set (tape output bit on port #FE)
; for loud sound output
BE_IX_p_3 NOP                                ;(4) optionally executed NOPs for small
; adjustments to tone period
BE_IX_p_2 NOP                                ;(4)

```

```

BE_IX_p_1 NOP ; (4)

BE_IX_p_0 INC B ; (4)
          INC C ; (4)

BE_H_L_LP DEC C ; (4) timing loop for duration of
          JR NZ, BE_H_L_LP ; (12/7) high or low pulse of waveform

          LD C, $3F ; (7)
          DEC B ; (4)
          JP NZ, BE_H_L_LP ; (10) JUMP to BE_H&L_LP

          XOR $10 ; (7) toggle output beep bit
          OUT ($FE), A ; (11) output pulse
          LD B, H ; (4) B = coarse part of tone period
          LD C, A ; (4) save port #FE output byte
          BIT 4, A ; (8) if new output bit is high, go
          JR NZ, BE_Again ; (2/7) to BE_Again

          LD A, D ; (4) one cycle of waveform has completed
          OR E ; (4) (low->low). if cycle countdown = 0
          JR Z, BE_END ; (12/7) go to BE_END

          LD A, C ; (4) restore output byte for port #FE
          LD C, L ; (4) C = medium part of tone period
          DEC DE ; (6) decrement cycle count
          JP (IX) ; (8) do another cycle

BE_Again LD C, L ; (4) C = medium part of tone period
          INC C ; (4) adds 16 cycles to make duration of high
= duration of low
          JP (IX) ; (8) do high pulse of tone

BE_END EI ; Enable Interrupts
        RET ;

```

```

; -----
; THE 'BEEP' COMMAND
; -----
; BASIC interface to BEEPER subroutine.
; Invoked in BASIC with:
;   BEEP dur, pitch
;   where dur = duration in seconds
;           pitch = # of semitones above/below middle C
;
; Enter with: pitch on top of calculator stack
;             duration next on calculator stack
;

```

```

BEEP RST 28H ;; FP_CALC
      DEFB $31 ;; duplicate ; duplicate pitch
      DEFB $27 ;; int ; convert to
integer
      DEFB $C0 ;; st-mem-0 ; store integer
pitch to memory 0
      DEFB $03 ;; subtract ; calculate
fractional part of pitch = fp_pitch - int_pitch
      DEFB $34 ;; stk-data ; push constant
      DEFB $EC ;; Exponent: $7C, Bytes: 4 ; constant =
0.05762265
      DEFB $6C, $98, $1F, $F5 ;; ($6C, $98, $1F, $F5)
      DEFB $04 ;; multiply ; compute:

```

```

        DEFB $A1          ; ;stk-one          ; 1 + 0.05762265 *
fraction_part(pitch)
        DEFB $0F          ; ;addition
        DEFB $38          ; ;end-calc          ; leave on calc
stack

        LD HL,$5B92      ; MEM-0: number stored here is in 16 bit
                        ; integer format (pitch)
                        ; 0, 0/FF (pos/neg), LSB, MSB, 0
                        ; LSB/MSB is stored in two's complement
                        ; In the following, the pitch is checked if
                        ; it is in the range -128<=p<=127
        LD A,(HL)        ; First byte must be zero, otherwise
        AND A            ; error in integer conversion
        JR NZ,REPORT_B  ; to REPORT_B
                        ; 'Integer out of range'

        INC HL           ;
        LD C,(HL)        ; C = pos/neg flag = 0/FF
        INC HL           ;
        LD B,(HL)        ; B = LSB, two's complement
        LD A,B           ;
        RLA              ;
        SBC A,A          ; A = 0/FF if B is pos/neg
        CP C             ; must be the same as C if the pitch
                        ; is -128<=p<=127
        JR NZ,REPORT_B  ; if no, error REPORT_B
                        ; 'Integer out of range'

        INC HL           ; if -128<=p<=127, MSB will be 0/FF if B is
                        ; pos/neg
        CP (HL)         ; verify this
        JR NZ,REPORT_B  ; if no, error REPORT_B
                        ; 'Integer out of range'

; Now we know -128<=p<=127

        LD A,B           ; A = pitch + 60
        ADD A,$3C        ; if -60<=pitch<=67,
        JP P,BE_I_OK     ; goto BE_I_OK

        JP PO,REPORT_B  ; if pitch <= 67 goto REPORT_B
                        ; lower bound of pitch set at -60

                        ; and A=pitch+60 -> 0<=A<=187

BE_I_OK LD B,$FA        ; 6 octaves below middle C

BE_OCTAVE INC B         ; increment octave
        SUB $0C         ; 12 semitones = one octave
        JR NC,BE_OCTAVE ; to BE_OCTAVE

        ADD A,$0C       ; A = # semitones above C (0-11)
        PUSH BC         ; B = octave displacement from middle C,
                        ; 2's complement: -5<=B<=10
        LD HL,semi_tone ; Address: semi-tone
        CALL LOC_MEM    ; routine LOC_MEM
                        ; HL = 5*A + $046E
        CALL STACK_NUM  ; routine STACK_NUM
                        ; read FP value (freq) from semitone table
                        ; (HL) and push onto calc stack

        RST 28H         ; ; FP_CALC
        DEFB $04        ; ;multiply mult freq by 1 + 0.0576 *

```

```

fraction_part(pitch) stacked earlier
                                ;;          thus taking into account fractional
part of pitch.                  ;;          the number 0.0576*frequency is the
distance in Hz to the next      ;;          note (verify with the frequencies
recorded in the semitone       ;;          table below) so that the
fraction_part of the pitch does ;;          indeed represent a fractional
distance to the next note.
    DEFB $38                      ;;end-calc HL points to first byte of fp num on
stack = middle frequency to generate

    POP    AF                      ; A = octave displacement from middle C, 2's
                                ; complement: -5<=A<=10
    ADD    A, (HL)                 ; increase exponent by A
                                ; (equivalent to multiplying by 2^A)
    LD     (HL), A                  ;

    RST    28H                     ;; FP_CALC
    DEFB  $C0                       ;;st-mem-0      store frequency in memory 0
    DEFB  $02                       ;;delete       remove from calc stack
    DEFB  $31                       ;;duplicate    duplicate duration (seconds)
    DEFB  $38                       ;;end-calc

    CALL   FIND_INT1                ; routine FIND_INT1 ; FP duration to A
    CP     $0B                      ; if dur > 10 seconds,
    JR     NC, REPORT_B             ; goto REPORT_B
                                ; 'Integer out of range'

    ;;; following calculation finds the tone period for HL and the cycle
count
    ;;; DE expected in the BEEPER subroutine. From the example in the
BEEPER comments,
    ;;;
    ;;; ((fCPU / f) - 236) / 8 = fCPU/8/f - 236/8 = 437500/f -29.5
    ;;; duration * frequency - 1
    ;;;
    ;;; the different constant (30.125) used in the calculation of HL
    ;;; w. This is probably an error.

    RST    28H                     ;; FP_CALC
    DEFB  $E0                       ;;get-mem-0      ; push frequency
    DEFB  $04                       ;;multiply      ; result1: #cycles =
duration * frequency
    DEFB  $E0                       ;;get-mem-0      ; push frequency
    DEFB  $34                       ;;stk-data      ; push constant
    DEFB  $80                       ;;Exponent $93, Bytes: 3 ; constant = 437500
    DEFB  $43, $55, $9F, $80        ;; ($55, $9F, $80, $00)
    DEFB  $01                       ;;exchange     ; frequency on top
    DEFB  $05                       ;;division    ; 437500 / frequency
    DEFB  $34                       ;;stk-data      ; push constant
    DEFB  $35                       ;;Exponent: $85, Bytes: 1 ; constant = 30.125
    DEFB  $71                       ;; ($71, $00, $00, $00)
    DEFB  $03                       ;;subtract    ; result2:
tone_period(HL) = 437500 / freq - 30.125
    DEFB  $38                       ;;end-calc

    CALL   FIND_INT2                ; routine FIND_INT2
    PUSH   BC                       ; BC = tone_period(HL)
    CALL   FIND_INT2                ; routine FIND_INT2, BC = #cycles to generate
    POP    HL                       ; HL = tone period
    LD     D, B                      ;

```



```

LD     E,C           ; DE = #cycles
LD     A,D           ;
OR     E             ;
RET    Z             ; if duration = 0, skip BEEP and avoid 65536
                        ; cycle boondoggle that would occur next
DEC    DE           ; DE = #cycles - 1
JP     BEEPER       ; jump back to BEEPER

; ---

REPORT_B  RST    30H           ; ERROR_1
          DEFB   $0A           ; Error Report: Integer out of range

; -----
; THE 'SEMI-TONE' TABLE
; -----
;
; Holds frequencies corresponding to semitones in middle octave.
; To move n octaves higher or lower, frequencies are multiplied by 2^n.

semi_tone  DEFB   $89, $02, $D0, $12, $86; 261.625565290      C
          DEFB   $89, $0A, $97, $60, $75; 277.182631135      C#
          DEFB   $89, $12, $D5, $17, $1F; 293.664768100      D
          DEFB   $89, $1B, $90, $41, $02; 311.126983881      D#
          DEFB   $89, $24, $D0, $53, $CA; 329.627557039      E
          DEFB   $89, $2E, $9D, $36, $B1; 349.228231549      F
          DEFB   $89, $38, $FF, $49, $3E; 369.994422674      F#
          DEFB   $89, $43, $FF, $6A, $73; 391.995436072      G
          DEFB   $89, $4F, $A7, $00, $54; 415.304697513      G#
          DEFB   $89, $5C, $00, $00, $00; 440.000000000      A
          DEFB   $89, $69, $14, $F6, $24; 466.163761616      A#
          DEFB   $89, $76, $F1, $10, $05; 493.883301378      B

;*****
;** Part 4. CASSETTE HANDLING ROUTINES **
;*****

; These routines begin with the service routines followed by a single
; command entry point.
; The first of these service routines is a curiosity.

; -----
; THE 'ZX81 NAME' ROUTINE
; -----
; This routine fetches a filename in ZX81 format and is not used by the
; cassette handling routines in this ROM.

;;; zx81-name
;;; L04AA:  CALL  SCANNING      ; routine SCANNING to evaluate expression.
;;;      LD    A,($5B3B)      ; fetch system variable FLAGS.
;;;      ADD   A,A            ; test bit 7 - syntax, bit 6 - result type.
;;;      JP    M,Report_C     ; to REPORT-C if not string result
;;;                               ; 'Nonsense in BASIC'.

;;;      POP   HL            ; drop return address.
;;;      RET   NC            ; return early if checking syntax.

;;;      PUSH  HL            ; re-save return address.
;;;      CALL  STK_FETCH      ; routine STK-FETCH fetches string parameters.
;;;      LD    H,D            ; transfer start of filename
;;;      LD    L,E            ; to the HL register.
;;;      DEC   C              ; adjust to point to last character and
;;;      RET   M              ; return if the null string.

```

```

;;;                                     ; or multiple of 256!

;;;      ADD   HL,BC                     ; find last character of the filename.
;;;                                     ; and also clear carry.
;;;      SET   7,(HL)                    ; invert it.
;;;      RET                                     ; return.

; =====
;
; PORT 254 ($FE)
;
;                                     spk mic { border }
;
; PORT  |_____|_____|_____|_____|_____|_____|_____|_____|
; 254   |_____|_____|_____|_____|_____|_____|_____|_____|
; $FE   |_____|_____|_____|_____|_____|_____|_____|_____|
;       | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
;
;
; -----
; THE NEW 'STACK TO LINE COLUMN' SUBROUTINE
; -----
; This new subroutine is used by S_ATTR and S_SCRNS essentially to call the
; routine below but, in addition, it produces a runtime error if the column
; is greater than 31 or the line is greater than 23.
; Both parameters must be positive as specified by the BASIC manual.

STK_TO_LC CALL BC_POSTVE      ;

          LD   A,B             ;
          CP   $17             ;
          JR   NC,REPORT_B     ;

          LD   A,C             ;
          CP   $1F             ;
          JR   NC,REPORT_B     ;

          RET                  ;

          DEFB 0,0,0,0        ; ballast 1

; -----
; THE 'SAVE BYTES' SUBROUTINE
; -----
; This routine saves a section of data. It is called from SA_CTRL to save the
; seventeen bytes of header data. It is also the exit route from that routine
; when it is set up to save the actual data.
; On entry -
; DE holds the length of data.
; IX points to the start.
; The accumulator is set to $00 for a header, $FF for data.

TAG1
L04C2:

SA_BYTES LD   HL,SA_LD_RET     ; address: SA/LD_RET
          PUSH HL              ; is pushed as common exit route.

          LD   HL,$1F80        ; a timing constant H=$1F, L=$80
          ; inner and outer loop counters
          ; a five second lead-in is used for a header.

          BIT  7,A             ; test one bit of accumulator. (AND A ?)

```

```

        JR     Z,SA_FLAG      ; skip to SA-FLAG if a header is being saved.
;   else is data bytes and a shorter lead-in is used.

        LD     HL,$0C98      ; another timing value H=$0C, L=$98.
                                ; a two second lead-in is used for the data.

SA_FLAG  EX     AF,AF'      ; save flag
        INC    DE           ; increase length by one.
        DEC    IX           ; decrease start.

        DI                    ; disable interrupts

        LD     A,$02        ; select red for border, microphone bit on.
        LD     B,A          ; also does as an initial slight counter value.

;   Note. the next location is trapped by emulators, see Z80.doc, in order to
;   save bytes to a real tape recorder. The address should be $04D8
;   However saving on emulators is not supported.

TAG2
L04D8:

SA_LEADER DJNZ  SA_LEADER   ; self loop to SA-LEADER for delay.
                                ; after initial loop, count is $A4 (or $A3)

        OUT    ($FE),A      ; output byte $02/$0D to tape port.

        XOR    $0F          ; switch from RED (mic on) to CYAN (mic off).

        LD     B,$A4        ; hold count. also timed instruction.

        DEC    L            ; originally $80 or $98.
                                ; but subsequently cycles 256 times.
        JR     NZ,SA_LEADER ; back to SA-LEADER until L is zero.

;   the outer loop is counted by H

        DEC    B            ; decrement count
        DEC    H            ; originally twelve or thirty-one.
        JP     P,SA_LEADER  ; back to SA-LEADER until H becomes $FF

;   now send a sync pulse. At this stage mic is off and A holds value
;   for mic on.
;   A sync pulse is much shorter than the steady pulses of the lead-in.

        LD     B,$2F        ; another short timed delay.

SA_SYNC_1 DJNZ  SA_SYNC_1   ; self loop to SA-SYNC-1

        OUT    ($FE),A      ; switch to mic on and red colour.
        LD     A,$0D        ; prepare mic off - cyan
        LD     B,$37        ; another short timed delay.

SA_SYNC_2 DJNZ  SA_SYNC_2   ; self loop to SA-SYNC-2

        OUT    ($FE),A      ; output mic off, cyan border.
        LD     BC,$3B0E     ; B=$3B time(*), C=$0E, YELLOW, MIC OFF.

;

        EX     AF,AF'      ; restore saved flag

```

```

; which is 1st byte to be saved.

LD    L,A          ; and transfer to L.
; the initial parity is A, $FF or $00.

JP    SA_START     ; JUMP forward to SA-START      ->
; the mid entry point of loop.

; -----
; During the save loop a parity byte is maintained in H.
; the save loop begins by testing if reduced length is zero and if so
; the final parity byte is saved reducing count to $FFFF.

SA_LOOP LD    A,D          ; fetch high byte
OR      E          ; test against low byte.
JR      Z,SA_PARITY     ; forward to SA-PARITY if zero.

LD      L,(IX+$00)     ; load currently addressed byte to L.

SA_LOOP_P LD    A,H          ; fetch parity byte.
XOR     L          ; exclusive or with new byte.

; -> the mid entry point of loop.

SA_START LD    H,A          ; put parity byte in H.
LD      A,$01         ; prepare blue, mic=on.
SCF     ; set carry flag ready to rotate in.
JP      SA_8_BITS     ; JUMP forward to SA-8-BITS      -8->

; ---

SA_PARITY LD    L,H          ; transfer the running parity byte to L and
JR      SA_LOOP_P     ; back to SA-LOOP-P
; to output that byte before quitting normally.

; ---

; The entry point to save yellow part of bit.
; A bit consists of a period with mic on and blue border followed by
; a period of mic off with yellow border.
; Note. since the DJNZ instruction does not affect flags, the zero flag is
; used to indicate which of the two passes is in effect and the carry
; maintains the state of the bit to be saved.

SA_BIT_2 LD    A,C          ; fetch 'mic on and yellow' which is
; held permanently in C.
BIT     7,B          ; set the zero flag. B holds $3E.

; The entry point to save 1 entire bit. For first bit B holds $3B(*).
; Carry is set if saved bit is 1. zero is reset NZ on entry.

SA_BIT_1 DJNZ  SA_BIT_1     ; self loop for delay to SA-BIT-1

JR      NC,SA_OUT       ; forward to SA-OUT if bit is 0.

; but if bit is 1 then the mic state is held for longer.

LD      B,$42         ; set timed delay. (66 decimal)

SA_SET  DJNZ  SA_SET       ; self loop to SA-SET
; (roughly an extra 66*13 clock cycles)

SA_OUT  OUT    ($FE),A     ; blue and mic on OR yellow and mic off.

```

```

        LD     B,$3E           ; set up delay
        JR     NZ,SA_BIT_2     ; back to SA-BIT-2 if zero reset NZ (first pass)

;   proceed when the blue and yellow bands have been output.

        DEC     B               ; change value $3E to $3D.
        XOR     A               ; clear carry flag (ready to rotate in).
        INC     A               ; reset zero flag i.e. NZ.

; -8->

SA_8_BITS RL     L             ; rotate left through carry
                                ; C<76543210<C
        JP     NZ,SA_BIT_1     ; JUMP back to SA-BIT-1
                                ; until all 8 bits done.

;   when the initial set carry is passed out again then a byte is complete.

        DEC     DE             ; decrease length
        INC     IX             ; increase byte pointer
        LD     B,$31           ; set up timing.

        LD     A,$7F           ; test the space key and
        IN     A,($FE)         ; return to common exit (to restore border)
        RRA                    ; if a space is pressed
        RET     NC             ; return to SA/LD-RET.  - - >

;   now test if byte counter has reached $FFFF.

        LD     A,D             ; fetch high byte
        INC     A               ; increment.
        JP     NZ,SA_LOOP      ; JUMP to SA-LOOP if more bytes.

        LD     B,$3B           ; a final delay.

SA_DELAY DJNZ    SA_DELAY      ; self loop to SA-DELAY

        RET                    ; return - - >

; -----
; THE 'SAVE/LOAD RETURN' ROUTINE
; -----
;   The address of this routine is pushed on the stack prior to any load/save
;   operation and it handles normal completion with the restoration of the
;   border and also abnormal termination when the break key or, to be more
;   precise, the space key is pressed during a tape operation.
;
; - - >

SA_LD_RET PUSH    AF           ; preserve accumulator throughout.

;;;      LD     A,($5B48)       ; fetch border colour from BORDCR.
;;;      AND     $38            ; mask off paper bits.
;;;      RRCA                    ; rotate
;;;      RRCA                    ; to the
;;;      RRCA                    ; range 0-7.
;;;      OUT     ($FE),A        ; change the border colour.

        CALL    BORD_REST      ;+ Use new routine to restore border colour.

        LD     A,$7F           ; read from port address $7FFE the
        IN     A,($FE)         ; row with the space key at outside.

        RRA                    ; test for space key pressed.

```

```

;;;      EI          ; enable interrupts
        JR      C,SA_LD_END ; forward, if not, to SA/LD-END

REPORT_Da RST      30H          ; ERROR-1
          DEFB    $0C          ; Error Report: BREAK - CONT repeats

; ---

SA_LD_END POP     AF          ; restore the accumulator.
          RET      ; return.

          DEFB    0,0,0,0,0,0,0,0 ; ballast 2

; -----
; THE 'LOAD BYTES' SUBROUTINE
; -----
; This routine is used to load bytes and on entry A is set to $00 for a
; header or to $FF for data. IX points to the start of receiving location
; and DE holds the length of bytes to be loaded.
; If, on entry the carry flag is set then data is loaded, if reset then it
; is to be verified only.

TAG3
L0556:

LD_BYTES INC      D          ; reset the zero flag without disturbing carry.
          EX      AF,AF'     ; preserve entry flags.
          DEC     D          ; restore high byte of length.

          DI          ; disable interrupts

          LD      A,$0F      ; make the border white and mic off. *****
          OUT    ($FE),A    ; output to port.

          LD      HL,SA_LD_RET ; Address: SA/LD-RET
          PUSH   HL         ; is saved on stack as terminating routine.

; the reading of the EAR bit (D6) will always be preceded by a test of the
; space key (D0), so store the initial post-test state.

          IN     A,($FE)    ; read the ear state - bit 6.
          RRA          ; rotate to bit 5.
          AND    $20       ; isolate this bit.
          OR     $02       ; combine with red border colour.
          LD     C,A       ; and store initial state long-term in C.

; Note. the next locations is trapped by emulators, see Z80.doc in order to
; load bytes from a tape recorder. No longer supported. Was L056A

TAG4
L056A:   CP      A          ; set the zero flag.

;

LD_BREAK RET     NZ        ; return if at any time space is pressed.

LD_START CALL    LD_EDGE_1 ; routine LD-EDGE-1
          JR     NC,LD_BREAK ; back to LD-BREAK with time out and no
          ; edge present on tape.

; but continue when a transition is found on tape.

```



```

; ---

; The loading loop loads each byte and is entered at the mid point.
LD_LOOP   EX    AF,AF'           ; restore entry flags and type in A.
          JR    NZ,LD_FLAG       ; forward to LD-FLAG if awaiting initial flag
          ; which is to be discarded.

          JR    NC,LD_VERIFY     ; forward, if not to be loaded, to LD-VERIFY

          LD    (IX+$00),L       ; place loaded byte at memory location.

          JR    LD_NEXT         ; forward to LD-NEXT

; ---

LD_FLAG   RL    C                ; preserve carry (verify) flag in long-term
          ; state byte. Bit 7 can be lost.

          XOR   L                ; compare type in A with first byte in L.
          RET   NZ              ; return if no match e.g. CODE vs. DATA.

; Continue when expected data type matches first byte received.

          LD    A,C              ; fetch byte with stored carry
          RRA                    ; rotate it to carry flag again
          LD    C,A              ; restore long-term port state.

          INC   DE                ; increment length ??
          JR    LD_DEC           ; forward to LD-DEC.
          ; but why not to location after ?
          ; Timing.

; ---

; For verification the byte read from tape is compared with that in memory.
LD_VERIFY LD    A,(IX+$00)       ; fetch byte from memory.
          XOR   L                ; compare with that on tape
          RET   NZ              ; return if not zero.

; Note. the report 'Verification has failed' could be added.

LD_NEXT   INC   IX                ; Increment the byte pointer.

LD_DEC    DEC   DE                ; decrement length.

          EX    AF,AF'           ; store the flags.
          LD    B,$B2            ; timing.

; when starting to read 8 bits the receiving byte is marked with bit at right.
; when this is rotated out again then 8 bits have been read.

LD_MARKER LD    L,$01           ; initialize as %00000001

LD_8_BITS CALL  LD_EDGE_2       ; routine LD-EDGE-2 increments B relative to
          ; gap between 2 edges.
          RET   NC              ; return with time-out.

          LD    A,$CB            ; the comparison byte.
          CP    B                ; compare to incremented value of B.
          ; if B is higher then bit on tape was set.
          ; if <= then bit on tape is reset.

```



```

        RL    L                ; rotate the carry bit into L.

        LD    B,$B0           ; reset the B timer byte.
        JP    NC,LD_8_BITS    ; JUMP back to LD-8-BITS

; when the carry flag is set, then the marker bit has been passed out and
; the received byte is complete.

        LD    A,H             ; fetch the running parity byte.
        XOR   L               ; include the new byte.
        LD    H,A            ; and store back in parity register.

        LD    A,D             ; check length of
        OR    E               ; expected bytes.
        JR    NZ,LD_LOOP     ; back, while there are more, to LD-LOOP

; When all bytes loaded then parity byte should be zero.

        LD    A,H             ; fetch the adjusted parity byte.
        CP    $01            ; set carry if zero.
        RET                    ; return
                                ; If no carry then error as checksum disagrees.

; -----
; Check signal being loaded
; -----
; An edge is a transition from one mic state to another.
; More specifically a change in bit 6 of value input from port $FE.
; Graphically it is a change of border colour, say, blue to yellow.
; The first entry point looks for two adjacent edges. The second entry point
; is used to find a single edge.
; The B register holds a count, up to 256, within which the edge (or edges)
; must be found. The gap between two edges will be more for a '1' than a '0'
; so the value of B denotes the state of the bit (two edges) read from tape.

; ->

LD_EDGE_2 CALL LD_EDGE_1      ; call routine LD-EDGE-1 below.
          RET    NC           ; return if space pressed or time-out.
                                ; else continue and look for another adjacent
                                ; edge which together represent a bit on the
                                ; tape.

; ->
; this entry point is used to find a single edge from above but also
; when detecting a read-in signal on the tape.

LD_EDGE_1 LD    A,$16        ; a delay value of twenty two.

LD_DELAY  DEC    A           ; decrement counter
          JR    NZ,LD_DELAY  ; loop back to LD-DELAY 22 times.

          AND    A           ; clear carry.

LD_SAMPLE INC    B           ; increment the time-out counter.
          RET    Z           ; return with failure when $FF passed.

          LD    A,$7F        ; prepare to read keyboard and EAR port
          IN    A,($FE)      ; row $7FFE. bit 6 is EAR, bit 0 is SPACE key.
          RRA                ; test outer key the space. (bit 6 moves to 5)
          RET    NC         ; return if space pressed. >>>

```

```

        XOR    C                ; compare with initial long-term state.
        AND    $20              ; isolate bit 5
        JR     Z,LD_SAMPLE      ; back to LD-SAMPLE if no edge.

; but an edge, a transition of the EAR bit, has been found so switch the
; long-term comparison byte containing both border colour and EAR bit.

        LD     A,C              ; fetch comparison value.
        CPL                    ; switch the bits
        LD     C,A              ; and put back in C for long-term.

        AND    $07              ; isolate new colour bits.
        OR     $08              ; set bit 3 - MIC off.
        OUT    ($FE),A          ; send to port to effect the change of colour.

        SCF                    ; set carry flag signaling edge found within
                                ; time allowed.
        RET                    ; return.

; -----
; THE 'SAVE, LOAD, VERIFY AND MERGE' COMMAND
; -----
; This is the single entry point for the four tape commands.
; The routine first determines in what context it has been called by
; examining the low byte of the Syntax table entry which was stored in T_ADDR.
; Subtracting $EO (the original arrangement) gives a value of
; $00 - SAVE
; $01 - LOAD
; $02 - VERIFY
; $03 - MERGE
; Note. as the Syntax table is in ROM then bit 7 of T_ADDR_hi must be reset
; This bit can be used to indicate a non-tape operation.
; As with all commands, the address STMT-RET is on the stack.

SAVE_ETC POP    AF                ; discard the address STMT-RET.

; Now reduce the low byte of the Syntax table entry to give command.

        LD     HL,$5B74          ; Address T_ADDR
        LD     A,(HL)           ; fetch value.
        SUB    P_SAVE +1 % 256  ; subtract the known offset.
        LD     (HL),A           ; and put back for future reference.

;;;     LD     A,($5B74)         ; fetch the low order address byte of T_ADDR.
;;;     SUB    P_SAVE +1 % 256  ; subtract the known offset.
;;;     LD     ($5B74),A         ; and put back for future reference.
;;;     CALL   SYNTAX_Z         ; checking syntax
;;;     JR     Z,SA_STRM        ;

        LD     A,$FD            ; select system channel 'K'
        CALL   CHN_O_SYN        ; and set as a default for tape message.

;;;     CALL   CHAN_SLCT        ; routine CHAN-OPEN

SA_STRM CALL   STR_ALTER        ;+ Allow for SAVE #8;

        JR     C,SA_EXP         ;+ forward if no stream specified.

; If a stream has been specified then check for a separator and set bit
; of T_ADDR_hi to show Tape is not being used as medium.
; e.g. SAVE #7,"marsupials" LOAD #15; "" SCREEN$

        CALL   CLASS_OC         ;+ check for a separator

```

```

        SET    7,(IY+$3B)      ;+ flag extended command by setting T_ADDR_hi
SA_EXP  CALL   EXPT_EXP        ; routine EXPT-EXP checks that a CLASS_0A
                                ; string expression follows and stacks the
                                ; parameters in run-time.

        CALL   SYNTAX_Z        ; routine SYNTAX-Z
        JR     Z,SA_DATA       ; forward, if checking syntax, to SA-DATA

;   In runtime create the workspace which is addressed by IX register.

        LD     BC,$0011        ; presume seventeen bytes for a SAVE header.

        LD     A,($5B74)       ; fetch command from T_ADDR_lo.
        AND    A                ; test for zero, the SAVE command.

        JR     Z,SA_SPACE      ; forward, if so, to SA-SPACE

        LD     C,$22           ; else double length to thirty four.

SA_SPACE CALL   BC_SPACES      ; BC_SPACES creates 17/34 bytes in workspace.

        PUSH   DE              ; transfer the start of the new space to the
        POP    IX              ; available index register.

;   Ten spaces are required for the default filename but it is simpler to
;   overwrite the first file-type indicator byte as well.

        LD     B,$0B           ; set counter to eleven.
        LD     A,$20           ; prepare a space.

SA_BLANK LD     (DE),A         ; set workspace location to space.
        INC    DE              ; next location.
        DJNZ  SA_BLANK        ; loop back to SA-BLANK till all eleven done.

        LD     (IX+$01),$FF     ; set first byte of ten character filename
                                ; to $FF as a default to signal a null string.

;   Now have $FF $20 $20...

        CALL   STK_FETCH        ; routine STK-FETCH fetches the filename
                                ; parameters from the calculator stack.
                                ; length of string in BC.
                                ; start of string in DE.

        LD     HL,$FFF6        ; prepare the value minus ten.
        DEC    BC              ; decrement length.
                                ; ten becomes nine, zero becomes $FFFF.
        ADD    HL,BC           ; trial addition.
        INC    BC              ; restore the true length.
        JR     NC,SA_NAME      ; forward, if length 1 - 10 to SA-NAME

;   The filename is more than ten characters in length or the null string.

        LD     A,($5B74)       ; fetch command from T_ADDR.
        AND    A                ; test for zero, the SAVE command.
;;;    JR     NZ,SA_NULL        ; forward, if not SAVE, to SA-NULL

        JP     Z,REPORT_F      ; forward, if command is SAVE, to report
                                ; 'Invalid file name'

;   This could be a null filename or one greater than ten characters in length
;   neither of which is acceptable for the SAVE command.

```

```

; The first ten characters of any other command parameter are acceptable.

;;; REPORT_Fa RST 30H ; ERROR-1
;;; DEF B $0E ; Error Report: Invalid file name

; continue with LOAD, MERGE, VERIFY and also SAVE within ten character limit.

SA_NULL LD A,B ; test length of filename
OR C ; for zero.
JR Z,SA_DATA ; forward, if zero, to SA-DATA
; using $FF indicator followed by spaces.

LD BC,$000A ; else trim length to ten.

; other paths rejoin here with BC holding length in range 1 - 10.

SA_NAME PUSH IX ; push start of file descriptor.
POP HL ; and pop into HL.

INC HL ; HL now addresses first byte of filename.
EX DE,HL ; transfer destination address to DE, start
; of string in command to HL.

LDIR ; copy up to ten bytes
; if less than ten then trailing spaces follow.

; the case for the null string rejoins here.

SA_DATA RST 18H ; GET-CHAR
CP $E4 ; is character after filename the token 'DATA' ?
JR NZ,SA_SCREEN ; forward, if not, to SA_SCREEN
; to consider SCREEN$

; continue to consider DATA.

LD A,($5B74) ; fetch command from T_ADDR
CP $03 ; is it 'VERIFY' ?

; VERIFY "d" DATA is not allowed.

JR Z,REPORT_Ca ; forward, if so, to REPORT-Ca.
; 'Nonsense in BASIC'

; continue with SAVE, LOAD, MERGE of DATA.

RST 20H ; NEXT-CHAR points to the array variable.
CALL LOOK_VARS ; routine LOOK-VARS searches variables area
; returning with carry reset if found or
; checking syntax.
; CH_ADD points to opening bracket.
SET 7,C ; this converts a simple string to a
; string array. The test for an array or string
; comes later.
JR NC,SA_V_OLD ; forward, if variable found, to SA-V-OLD

; This is the runtime path only.

LD HL,$0000 ; set destination to zero as not fixed.
LD A,($5B74) ; fetch command from T_ADDR
DEC A ; test for 1 - LOAD
JR Z,SA_V_NEW ; forward, with LOAD DATA, to SA-V-NEW
; to load a new array.

; otherwise the variable was not found in run-time with SAVE/MERGE.

```

```

REPORT_2a RST    30H          ; ERROR-1
          DEFB   $01          ; Error Report: Variable not found

;   continue with SAVE and LOAD of DATA

SA_V_OLD  JR     NZ,REPORT_Ca ; forward, if not an array, to REPORT_Ca
          ; 'Nonsense in BASIC'

          CALL   SYNTAX_Z     ; routine SYNTAX-Z
          JR     Z,SA_DATA_1  ; forward, if checking syntax, to SA-DATA-1

;   In runtime exclude a simple string by examining the VARS letter.
;   Note. the standard ROM allows these to be saved but errors when they are
;   subsequently loaded.
;   credit: Dr. Ian Logan in The Complete Spectrum ROM Disassembly.
;   solution: also by Dr. Ian Logan, in the Interface 1 ROM.

          BIT    7,(HL)       ;+ test VARS letter - is it a simple string ?
          JR     Z,REPORT_Ca  ;+ back, if so, to REPORT_Ca

;   Now transfer the array's details to the tape descriptor.

          INC    HL           ; step past single letter array variable name.
          LD     A,(HL)       ; fetch low byte of array length.
          LD     (IX+$0B),A   ; place in descriptor.
          INC    HL           ; point to high byte of array length.
          LD     A,(HL)       ; and transfer that
          LD     (IX+$0C),A   ; to descriptor.
          INC    HL           ; increase pointer within variable.

;   The two runtime paths converge here. There is no syntax path error.

SA_V_NEW  LD     (IX+$0E),C   ; place the character array letter, formed
          ; earlier, in the header.

          LD     A,$01        ; default the array type to numeric.
          BIT    6,C          ; test the result from the LOOK-VARS routine.
          JR     Z,SA_V_TYPE  ; forward, if numeric, to SA-V-TYPE

          INC    A            ; set type to 2 - a string array.

SA_V_TYPE LD     (IX+$00),A   ; place type 0, 1 or 2 in descriptor.

;   The syntax path rejoins here.

SA_DATA_1 EX    DE,HL        ; save var pointer in DE

;   Note. LOOK_VARS left CH_ADD pointing at '(' in, say, SAVE "name" DATA a().

          RST    20H         ; NEXT-CHAR

;;;      CP     $29          ; is character ')' ?
;;;      JR     NZ,SA_V_OLD  ; back, if not, to SA-V-OLD
;;;      RST    20H         ; NEXT-CHAR advances character address.

          CALL   RBRKT_NXT   ;+ check for right hand bracket and advances.

          CALL   CHECK_END   ; routine CHECK-END errors if not at end of
          ; the statement.

          EX    DE,HL        ; bring back variables data pointer.
          JR     RJ_SA_ALL    ; jump forward to SA-ALL.

;   ---

```

```

;
; ---

TST_COM_0 XOR   A           ; default comparison
TST_COM_0 CP    (IY+$3A)    ; compare A to T_ADDR_lo
TST_COM_0 RET   NZ          ; return if not.

REPORT_Ca RST   30H         ; ERROR-1
          DEFB  $0B         ; 'Nonsense in BASIC'

; the branch was here to consider a 'SCREEN$', the display file.

SA_SCREEN CP    $AA         ; is character the token 'SCREEN$' ?
          JR    NZ,SA_CODE  ; forward, if not, to SA_CODE

;;;
LD      A,($5B74)          ; fetch command from T_ADDR_lo
CP      $03                ; is it 'MERGE' ?
JR      NZ,SA_SCR_OK      ; skip forward, if not, to SA_SCR_OK
RST     30H                ; ERROR-1
DEFB    $0B                ; 'Nonsense in BASIC'

LD      A,$03              ;+ Produce an error
CALL    TST_COM            ;+ if command is 'MERGE'

; ---

; continue with SAVE/LOAD/VERIFY SCREEN$.

SA_SCR_OK RST   20H         ; NEXT-CHAR advances past command
          CALL  CHECK_END   ; routine CHECK-END errors if not at end of
                          ; statement.

; continue in runtime.

LD      HL,$4000           ;+ set start to display file start.

;;;
LD      (IX+$0B),$00       ; set descriptor length
LD      (IX+$0B),L         ;+ set descriptor length
LD      (IX+$0C),$1B       ; to $1b00 to include bitmaps and attributes.

;;;
LD      HL,$4000           ; set start to display file start.
LD      (IX+$0D),L         ; place start in
LD      (IX+$0E),H         ; the descriptor.
JR      SA_TYPE_3         ; forward to SA-TYPE-3

; ---

; the branch was here to consider CODE.

SA_CODE CP    $AF          ; is character the token 'CODE' ?
          JR    NZ,SA_LINE ; forward, if not, to SA_LINE
                          ; to consider an auto-started BASIC program.

;;;
LD      A,($5B74)          ; fetch command from T_ADDR
CP      $03                ; is it MERGE ?
JR      Z,REPORT_Ca       ; back, if so, to REPORT-Ca.

LD      A,$03              ;+ Produce an error
CALL    TST_COM            ;+ if command is 'MERGE'

RST     20H                ; NEXT-CHAR advances character address.
CALL    PR_ST_END         ; routine PR-ST-END checks if a carriage
                          ; return or ':' follows.

```

```

        JR    NZ,SA_CODE_1    ; forward, if there are parameters, to SA-CODE-1

;;;     LD    A,($5B74)      ; else fetch the command from T_ADDR.
;;;     AND   A              ; test for zero - SAVE without a specification.
;;;     JR    Z,REPORT_Ca    ; back, if so, to REPORT-Ca.

        CALL  TST_COM_0      ;+ Test that command is not zero - SAVE

;   For LOAD and VERIFY put a zero on the stack to signal use the address that
;   the code was saved from.

        CALL  USE_ZERO       ; routine USE-ZERO stacks a zero in runtime.
        JR    SA_CODE_2     ; forward to SA-CODE-2

; ---

;   if there are more characters after CODE expect start and possibly length.

SA_CODE_1 CALL  EXPT_1NUM    ; routine EXPT-1NUM checks for numeric
                          ; expression and stacks it in run-time.

        RST   18H           ; GET-CHAR was the last instruction.
        CP   $2C           ; does a comma follow ?
        JR   Z,SA_CODE_3    ; forward, if so, to SA-CODE-3

;   else allow saved code to be loaded to a specified address.

;;;     LD    A,($5B74)      ; fetch command from T_ADDR.
;;;     AND   A              ; is the command SAVE which requires length ?
;;;     JR    Z,REPORT_Ca    ; back, if so, to REPORT-Ca

        CALL  TST_COM_0      ;+ Test that command is not zero - SAVE

;   the command 'LOAD CODE' may rejoin here with zero handled as start.

SA_CODE_2 CALL  USE_ZERO     ; routine USE-ZERO stacks zero for length
                          ; if not checking syntax.
        JR    SA_CODE_4     ; forward to SA_CODE_4

; ---

;   the branch was here with SAVE CODE start,

SA_CODE_3 RST   20H         ; NEXT-CHAR advances character address.
        CALL  EXPT_1NUM     ; routine EXPT_1NUM checks for an expression
                          ; and stacks in run-time.

;   paths converge here and nothing must follow.

SA_CODE_4 CALL  CHECK_END    ; routine CHECK-END errors with extraneous
                          ; characters and quits if checking syntax.

;   in runtime there are two 16-bit parameters on the calculator stack.

        CALL  FIND_INT2     ; routine FIND-INT2 gets length.
        LD   (IX+$0B),C     ; place length
        LD   (IX+$0C),B     ; in descriptor.

        CALL  FIND_INT2     ; routine FIND-INT2 gets start.

        LD   (IX+$0D),C     ; place start
        LD   (IX+$0E),B     ; in descriptor.
        LD   H,B           ; transfer the
        LD   L,C           ; start to HL also.

```

```

SA_TYPE_3 LD      (IX+$00),$03      ; place type 3 - 'CODE' in descriptor.
RJ_SA_ALL JR      SA_ALL            ; forward to SA-ALL.

; ---
; the branch was here with BASIC to consider an optional auto-start line
; number e.g.
; SAVE "some name" LINE
; SAVE "fruitbats" LINE 200

SA_LINE  CP      $CA                ; is character the token 'LINE' ?
         JR      Z,SA_LINE_1        ; forward, if so, to SA-LINE-1

; else all possibilities have been considered and nothing must follow.

         CALL   CHECK_END           ; routine CHECK-END

; continue in run-time to save BASIC without auto-start.

;;;     LD      (IX+$0E),$80        ; place a high line number in descriptor
         LD      B,$80              ; set B to $80 as a disabling value.
         JR      SA_TYPE_0          ; forward, to save program, to SA-TYPE-0

; ---
; the branch was here to consider auto-start.
; Note. both the BASIC manual and the Pocket Book state that the line number
; may be omitted

SA_LINE_1 LD      A,($5B74)         ; fetch command from T_ADDR
         AND     A                  ; test for SAVE.
         JR      NZ,REPORT_Ca      ; jump forward, with anything else, to REPORT-C
         ; 'Nonsense in BASIC'

;

         RST     20H                ; NEXT-CHAR
;;;     CALL   EXPT_1NUM            ; routine EXPT_1NUM checks for numeric
;;;     ; expression and stacks in run-time.
         CALL   FETCH_NUM          ;+ routine FETCH_NUM checks for numeric
         ;+ expression and stacks in run-time defaulting
         ;+ to zero.
         CALL   CHECK_END           ; routine CHECK-END quits if syntax path.

         CALL   FIND_LINE          ; New routine FIND-LINE fetches a valid line
         ; number expression to BC.

         LD      (IX+$0D),C         ; place the valid auto-start

SA_TYPE_0 LD      (IX+$0E),B        ; line number in the descriptor.

; continue to save program and any variables.
; Note. label has been moved back.

sa_type_0 LD      (IX+$00),$00      ; place type zero - program in descriptor.
         LD      HL,($5B59)         ; fetch E_LINE to HL.
         LD      DE,($5B53)         ; fetch PROG to DE.
         SCF                        ; set carry flag to calculate from end of
         ; variables E_LINE -1.
         SBC     HL,DE              ; subtract to give total length.

         LD      (IX+$0B),L         ; place total length

```



```

LD      (IX+$0C),H      ; in descriptor.
LD      HL,($5B4B)      ; load HL from system variable VARS
SBC     HL,DE           ; subtract to give program length only.
LD      (IX+$0F),L      ; place length of program
LD      (IX+$10),H      ; in the descriptor.
EX      DE,HL           ; Transfer start to HL, length to DE.

SA_ALL  LD      A,($5B74) ; fetch command from system variable T_ADDR_lo
AND     A              ; test for zero - SAVE.

JP      Z,SA_CONTRL    ; jump forward, with SAVE, to SA-CONTRL  ->

; -----
; THE 'LOAD, MERGE and VERIFY' BRANCH
; -----
; continue with LOAD, MERGE and VERIFY.

        PUSH   HL        ; (*) save start.
        LD     BC,$0011   ; prepare to add seventeen
        ADD   IX,BC       ; to point IX at second descriptor.

LD_LOOK_H PUSH   IX        ; save IX
          LD     DE,$0011   ; seventeen bytes
          XOR   A          ; reset zero flag
          SCF          ; set carry flag to signal load the bytes.

          CALL  LD_BYTES2   ; routine LD-BYTES loads a header from tape
                          ; to second descriptor.
          POP   IX         ; restore IX.
          JR    NC,LD_LOOK_H ; loop back, until header found, to LD-LOOK-H

;;;     LD     A,$FE       ; select system channel 'S'
;;;     CALL  CHAN_SLCT    ; routine CHAN-OPEN opens system channel.

LD      (IY+$52),$03     ; set SCR_CT to 3 lines.

LD      C,$80           ; C has bit 7 set to indicate type mismatch as
                          ; a default startpoint.

LD      A,(IX+$00)      ; fetch loaded header type to A
CP      (IX-$11)        ; compare with expected type 0 - 3 placed in
                          ; header by this ROM.
JR      NZ,LD_TYPE      ; forward, with mismatch, to LD-TYPE

LD      C,$F6           ; set C to minus ten - will count characters
                          ; up to zero.

LD_TYPE CP      $04      ; check if type is in acceptable range 0 - 3.
JR      NC,LD_LOOK_H   ; back, with 4 and above, to LD-LOOK-H

LD_TYPE_M LD      DE,type_msgs ; address base of last 4 tape messages

;;;     PUSH  BC          ; save BC
;;;     CALL  PO_MSG      ; routine PO-MSG outputs relevant message.

          CALL  DISP_MSG    ;+ routine DISP_MSG outputs relevant message.

;;;     POP   BC          ; restore BC

          PUSH  IX          ; transfer IX,
          POP   DE          ; the 2nd descriptor, to DE.

```

```

        LD    HL,$FFF0        ; prepare minus seventeen.
        ADD   HL,DE           ; add to point HL back to 1st descriptor.

        LD    B,$0A          ; the count will be ten characters for the
                               ; filename.

; Check if user has typed something like LOAD "".

        LD    A,(HL)         ; fetch first character of filename and test
        INC   A              ; for the value $FF.
        JR    NZ,LD_NAME     ; forward, if not the $FF wildcard, to LD-NAME

; but if it is the wildcard, then add ten to C, which holds minus ten for a
; type match or -128 for a type mismatch. Although characters have to be
; counted, bit 7 of C will not alter from the state set here.

        LD    A,C           ; transfer $F6 or $80 to A
        ADD   A,B           ; add $0A
        LD    C,A           ; place result, $00 or $8A, in C.

; At this point we have either a type mismatch, a wildcard match or ten
; characters to be counted. The characters must be shown on the screen.

LD_NAME  INC    DE           ; Address the next input character.
        LD    A,(DE)        ; Fetch character
        CP    (HL)         ; Compare to expected
        INC   HL           ; Address next expected character
        JR    NZ,LD_CH_PR  ; Forward, with mismatch, to LD-CH-PR

        INC   C            ; Increment C - the matched character count.

LD_CH_PR AND    A           ;+ clear carry for 1 character.
        CALL  DISP_MSG     ;+ call directly as screen is known
;;;     RST    10H         ; PRINT-A prints the character.

        DJNZ LD_NAME       ; loop back, for ten characters, to LD-NAME

; if ten characters matched, and the types previously matched, then C will
; now hold zero.

        BIT   7,C          ; test if all characters matched
        JR    NZ,LD_LOOK_H ; back, if not, to LD-LOOK-H

; else, if name matched, print a terminal carriage return.

        LD    A,$0D        ; prepare carriage return. ?????
;;;     RST    10H         ; PRINT-A outputs it.
        CALL  DISP_MSG     ;+ Call print directly.

; The various control routines for LOAD, VERIFY and MERGE are now executed
; during the one-second gap following the header on tape.

        POP   HL           ; (*) restore START

        LD    A,(IX+$00)   ; Fetch the validated incoming type.
        CP    $03         ; compare with type for CODE.
        JR    Z,VR_CONTRL  ; forward, if it is CODE, to VR-CONTRL
                               ; to load or verify CODE data.

; type is a PROGRAM or an ARRAY.

        LD    A,($5B74)    ; fetch command from T_ADDR
        DEC   A            ; was it LOAD ?

```

```

        JR     Z,LD_CONTRL      ; JUMP forward, if so, to LD-CONTRL
                                ; to load BASIC or variables.

        CP     $02              ; was command MERGE ?

        JP     Z,ME_CONTRL     ; jump forward, if so, to ME-CONTRL

;   else continue into VERIFY control routine to verify.

; -----
; THE 'VERIFY CONTROL' ROUTINE
; -----
;   There are two branches to this routine.
;   1) From above to verify a program or array
;   2) from earlier with no carry to LOAD or verify CODE.

VR_CONTRL PUSH  HL              ; save pointer to data.

        LD     L,(IX-$06)      ; fetch length of old data
        LD     H,(IX-$05)      ; to HL.
        LD     E,(IX+$0B)      ; fetch length of new data
        LD     D,(IX+$0C)      ; to DE.

        LD     A,H              ; check length of old
        OR     L                ; for zero.

        JR     Z,VR_CONT_1     ; forward to VR-CONT-1 if length is unspecified
                                ; e.g. LOAD "x" CODE

;   as opposed to, say, LOAD 'x' CODE 32768,300.

        SBC   HL,DE            ; subtract the new length from the old length.
        JR     C,REPORT_R      ; forward to REPORT-R if the length on tape is
                                ; larger than that specified in command.
                                ; 'Loading error'

        JR     Z,VR_CONT_1     ; forward, if lengths match, to VR-CONT-1

;   a length on tape shorter than expected is only allowed for CODE XX

        LD     A,(IX+$00)      ; Fetch type from tape.
        CP     $03              ; Is it CODE ?
        JR     NZ,REPORT_R     ; forward, if not, to REPORT-R
                                ; 'Loading error'

VR_CONT_1 POP    HL              ; pop the pointer to the data
        LD     A,H              ; test for zero
        OR     L                ; e.g. LOAD 'x' CODE
        JR     NZ,VR_CONT_2    ; forward, if destination given, to VR-CONT-2

        LD     L,(IX+$0D)      ; else use the destination in the header
        LD     H,(IX+$0E)      ; and load code at address saved from.

VR_CONT_2 PUSH  HL              ; push the pointer to the start of data block.
        POP   IX                ; transfer to IX.

        LD     A,($5B74)        ; fetch the reduced command from T_ADDR

        CP     $02              ; is it VERIFY ?

;;;   SCF                      ; prepare a set carry flag
;;;   JR     NZ,VR_CONT_3      ; skip, if not, to VR-CONT-3

        JR     Z,LD_BLOCK      ;+ skip, if VERIFY, to LD_BLOCK

```

```

                                ;+ with carry clear.

;;;      AND      A              ; clear carry flag for VERIFY

; -----
; THE NEW 'LOAD BLOCK' WITH CARRY SET ROUTINE
; -----
;   This saves some bytes by consolidating the most popular conditions.

LD_BLK_C SCF                    ;+ Set carry flag so that data is loaded.

;   Continue to use, for verification, the same routine used to LOAD data.

;;; VR_CONT_3 LD      A,$FF      ; signal data block to be loaded

; -----
; THE 'LOAD DATA BLOCK' ROUTINE
; -----
;   This routine is called from 3 places other than above to load a data block.
;   In all cases the accumulator is first set to $FF so the routine could be
;   called at the previous instruction.

;;; LD_BLOCK  CALL  LD_BYTES      ; routine LD-BYTES

LD_BLOCK  LD      A,$FF          ;+ signal data block to be loaded, not header.

          CALL  LD_BYTES2        ; routine LD-BYTES2

          RET    C                ; return if successful.

REPORT_R  RST    30H            ; ERROR-1 1a
          DEFB  $1A              ; Error Report: Loading error

; -----
; THE 'LOAD CONTROL' ROUTINE
; -----
;   This branch is taken when the command is LOAD with type 0, 1 or 2.

LD_CONTRL LD      E,(IX+$0B)     ; fetch length of found data block
          LD      D,(IX+$0C)     ; from 2nd descriptor.
          PUSH   HL              ; save destination.
          LD      A,H            ; test for zero which indicates
          OR     L               ; an array - types 1 or 2.

          JR     NZ,LD_CONT_1    ; forward, if not, to LD-CONT-1

          INC    DE              ; increase array length
          INC    DE              ; for letter name
          INC    DE              ; and 16-bit length.
          EX     DE,HL           ; transfer adjusted length to HL.
          JR     LD_CONT_2      ; forward to LD-CONT-2

; ---

;   The branch was here with type PROGRAM.

LD_CONT_1 LD      L,(IX-$06)     ; fetch length from
          LD      H,(IX-$05)     ; the first header.
          EX     DE,HL           ;
          SCF                    ; set carry flag
          SBC   HL,DE            ;
          JR     C,LD_DATA       ; to LD-DATA

LD_CONT_2 LD      DE,$0005      ; allow an overhead of five bytes.

```

```

        ADD    HL,DE          ; add in the difference in data lengths.
        LD     B,H           ; transfer to
        LD     C,L           ; the BC register pair

        CALL  TEST_ROOM      ; routine TEST-ROOM fails if not enough room.

LD_DATA POP    HL           ; pop destination
        LD     A,(IX+$00)    ; fetch type 0, 1 or 2.
        AND   A             ; test for PROGRAM and variables.
        JR    Z,LD_PROG     ; forward, if so, to LD-PROG

; the type is a numeric or string array.

        LD     A,H           ; test the destination for zero which
        OR    L             ; indicates variable does not already exist.

        JR    Z,LD_DATA_1   ; forward, if so, to LD-DATA-1

; else the destination is the first dimension within the array structure

        DEC   HL            ; address high byte of total array length
        LD    B,(HL)        ; transfer to B.
        DEC   HL            ; address low byte of total array length.
        LD    C,(HL)        ; transfer to C.

        DEC   HL            ; point to letter of variable.
        INC   BC            ; adjust length to
        INC   BC            ; include these
        INC   BC            ; three bytes also.

        LD    ($5B5F),IX    ; save header pointer in X_PTR which is
                           ; updated by the POINTERS routine.

        CALL  RECLAIM_2     ; routine RECLAIM-2 reclaims the old variable
                           ; sliding workspace including the two headers
                           ; downwards.

        LD    IX,($5B5F)    ; reload IX from X_PTR which will have been
                           ; adjusted down by the POINTERS routine.

;;; LD_DATA_1 LD    HL,($5B59) ; address E_LINE
;;;                DEC   HL    ; now point to the $80 variables end-marker.

LD_DATA_1 CALL    L_EL_DHL  ; instead of prev 2 lines.

        LD    C,(IX+$0B)    ; fetch new data length
        LD    B,(IX+$0C)    ; from 2nd header.

        PUSH  BC            ; * save it.
        INC   BC            ; adjust the
        INC   BC            ; length to include the letter name
        INC   BC            ; and two total length bytes.

        LD    A,(IX-$03)    ; fetch letter name from old header.

;;;                PUSH  AF    ; preserve accumulator though not corrupted.

        CALL  MAKE_ROOM     ; routine MAKE-ROOM creates space for variable
                           ; sliding workspace up. IX no longer addresses
                           ; anywhere meaningful.

;;;                INC    HL    ; point to the first new location.

;;;                POP    AF    ; fetch back the letter name.

```

```

        LD     (HL),A           ; place in first new location.
        POP   DE               ; * pop the data length.

        INC   HL               ; address 2nd location
        LD   (HL),E           ; store low byte of length.
        INC   HL               ; address next.
        LD   (HL),D           ; store high byte.
        INC   HL               ; address start of data.

TX_BLK_C  PUSH  HL             ; transfer the address
LD_BLK_R  POP   IX            ; to IX register pair.

;;;      SCF                   ; set carry flag indicating load not verify.

;;;      LD   A,$FF           ; signal data not header.

        JR   LD_BLK_C         ;+ JUMP back to LD-BLOCK

; ---

;   The branch is here when a PROGRAM, as opposed to an ARRAY, is to be loaded.

LD_PROG   EX     DE,HL        ; transfer data destination to DE.

        CALL  L_EL_DHL        ;+ instead of next 2lines?
;;;      LD   HL,($5B59)       ; address E_LINE
;;;      DEC  HL               ; now address variables end-marker.

        LD   ($5B5F),IX       ; place the IX header pointer in X_PTR
        LD   C,(IX+$0B)       ; get new length
        LD   B,(IX+$0C)       ; from 2nd header
        PUSH BC               ; and save it.

        CALL RECLAIM_1        ; routine RECLAIM-1 reclaims program and vars.
                                ; adjusting X-PTR.

        POP  BC               ; restore the new length.
        PUSH HL               ; * save start
        PUSH BC               ; ** and length.

        CALL MAKE_ROOM        ; routine MAKE-ROOM creates the space.

        LD   IX,($5B5F)       ; reload IX from adjusted X_PTR

;;;      INC  HL               ; point to start of new area.
        LD   C,(IX+$0F)       ; fetch length of BASIC on tape
        LD   B,(IX+$10)       ; from 2nd descriptor
        ADD  HL,BC             ; add to address the start of variables.
        LD   ($5B4B),HL       ; set the system variable VARS

        LD   H,(IX+$0E)       ; fetch high byte of autostart line number.

;   Note. although the line number is checked at SAVE time, this check is
;   still relevant as by default auto-start is inhibited.

        LD   A,H               ; transfer to A
        AND  $C0               ; test if greater than $3F.
        JR   NZ,LD_PROG_1     ; forward, if so, to LD-PROG-1
                                ; with no autostart.

        LD   L,(IX+$0D)       ; fetch the low byte.
        LD   ($5B42),HL       ; set system variable NEWPPC to line number
;;;      LD   (IY+$0A),$00     ; set statement NSPPC to zero.

```

```

        LD      (IY+$0A),A      ; set statement NSPPC to zero.
LD_PROG_1 POP    DE            ; ** pop the length

;;;      POP    IX              ; * and start.
;;;      SCF      ; set carry flag
;;;      LD      A,$FF          ; signal data as opposed to a header.
;;;      JP      LD_BLK_C      ; jump back to LD-BLOCK

        JR      LD_BLK_R      ;+ NEW relative jump back to LD-BLOCK routine
        ;+ at the instruction POP IX

; -----
; THE 'MERGE CONTROL' ROUTINE
; -----
; The branch was here to merge a program and its variables or an array.
;

ME_CONTRL LD      C,(IX+$0B)    ; fetch length
          LD      B,(IX+$0C)    ; of data block on tape.
          PUSH   BC            ; save it.
          INC    BC            ; add one for the end-marker.

          CALL   BC_SPACES     ; routine BC_SPACES creates room in workspace.
          ; HL addresses last new location.

          LD      (HL),$80      ; place end-marker at end.
          EX     DE,HL         ; transfer first location to HL.
          POP    DE            ; restore length to DE.

          PUSH   HL            ; save address of first location.

;;;      PUSH   HL            ; and transfer first location
;;;      POP    IX            ; to IX register.

;;;      SCF      ; set carry flag to load data on tape.
;;;      LD      A,$FF          ; signal data not a header.

          CALL   TX_BLK_C      ;+ routine LD-BLOCK loads to workspace.

          POP    HL            ; restore first location in workspace to HL.
          LD      DE,($5B53)    ; set DE from system variable PROG.

; now enter a loop to merge the data block in workspace with the program and
; variables.

ME_NEW_LP LD      A,(HL)        ; fetch next byte from workspace.
          AND    $C0            ; compare with $3F.

          JR     NZ,ME_VAR_LP   ; forward to ME-VAR-LP if a variable or
          ; end-marker.

; Continue when HL, the WORKSPACE pointer, still addresses a BASIC line
; number.

ME_OLD_LP LD      A,(DE)        ; fetch high byte from PROGRAM area.
          INC    DE            ; increment the PROGRAM address.

          CP     (HL)          ; compare with line number in WORKSPACE.
          INC    HL            ; increment WORKSPACE address.

          JR     NZ,ME_OLD_L1  ; forward to ME-OLD-L1 if high bytes don't match

```

```

        LD    A,(DE)          ; fetch the low byte of PROGRAM line number.
        CP    (HL)           ; compare with low byte in WORKSPACE.

ME_OLD_L1 DEC  DE            ; point to start of
        DEC  HL             ; respective lines again.

        JR    NC,ME_NEW_L2   ; forward to ME-NEW-L2 if line number in
                                ; WORKSPACE is less than or equal to current
                                ; PROGRAM line as has to be added to program.

        PUSH HL              ; else save workspace pointer.

        EX   DE,HL           ; transfer prog pointer to HL

        CALL NEXT_ONE        ; routine NEXT-ONE finds next line in DE.

        POP  HL              ; restore workspace pointer

        JR   ME_OLD_LP       ; back to ME-OLD-LP until destination position
                                ; in program area found.

; ---

;   the branch was here with an insertion or replacement point.

ME_NEW_L2 CALL ME_ENTER      ; routine ME-ENTER enters the line

        JR   ME_NEW_LP       ; loop back to ME-NEW-LP.

; ---

;   the branch was here when the location in workspace held a variable.
;   New variables are easier than program lines as they are merely added at
;   the end of the VARIABLES area.

ME_VAR_LP LD    A,(HL)       ; fetch first byte of workspace variable.
        LD    C,A           ; copy to C also.
        CP    $80           ; is it the workspace VARIABLES end-marker ?
        RET   Z             ; return, if so, as MERGE is complete. >>>>

        PUSH HL              ; save workspace area pointer.
        LD    HL,($5B4B)     ; load HL with VARS - start of variables area.

ME_OLD_VP LD    A,(HL)       ; fetch first byte.
        CP    $80           ; is it the VARIABLES end-marker ?
        JR    Z,ME_VAR_L2   ; forward, if so, to ME-VAR-L2
                                ; to add variable at end of variables area.

        CP    C             ; compare with variable in workspace area.
        JR    Z,ME_OLD_V2   ; forward, with a match, to ME-OLD-V2
                                ; to replace.

;   else entire variables area has to be searched.

ME_OLD_V1 PUSH  BC           ; save character in C.

        CALL NEXT_ONE        ; routine NEXT-ONE gets following variable
                                ; address in DE.

        POP  BC              ; restore character in C
        EX   DE,HL           ; transfer next address to HL.

        JR   ME_OLD_VP       ; loop back to ME-OLD-VP

```



```

; ---

; the branch was here when first characters of name matched.
ME_OLD_V2 AND  $E0          ; keep bits 11100000
           CP   $A0          ; compare  10100000 - a long-named variable.

           JR   NZ,ME_VAR_L1 ; forward to ME-VAR-L1 if just one-character.

; but long-named variables have to be matched character by character.

           POP  DE           ; fetch workspace 1st character pointer
           PUSH DE           ; and save it on the stack again.
           PUSH HL          ; save variables area pointer on stack.

ME_OLD_V3 INC  HL           ; address next character in vars area.
           INC  DE           ; address next character in workspace area.
           LD   A,(DE)       ; fetch workspace character.
           CP   (HL)         ; compare to variables character.
           JR   NZ,ME_OLD_V4 ; forward, with a mismatch, to ME-OLD-V4

           RLA              ; test if it is the terminal inverted character.
           JR   NC,ME_OLD_V3 ; loop back, if more to test, to ME-OLD-V3

; otherwise the long name matches in its entirety.

           POP  HL           ; restore pointer to first character of variable

           JR   ME_VAR_L1    ; forward to ME-VAR-L1

; ---

; the branch is here when two characters don't match

ME_OLD_V4 POP  HL           ; restore the prog/vars pointer.
           JR   ME_OLD_V1    ; back to ME-OLD-V1 to resume search.

; ---

; branch here when variable is to replace an existing one

ME_VAR_L1 LD   A,$FF        ; indicate a replacement.

; this entry point is when A holds $80 indicating a new variable.

ME_VAR_L2 POP  DE           ; pop workspace pointer.
           EX  DE,HL        ; now make HL workspace pointer, DE vars pointer
           INC  A           ; zero flag set if replacement.
           SCF              ; set carry flag indicating a variable not a
                           ; program line.

           CALL ME_ENTER    ; routine ME-ENTER copies variable in.

           JR   ME_VAR_LP   ; loop back to ME-VAR-LP

; -----
; THE 'MERGE A LINE OR VARIABLE' SUBROUTINE
; -----
; A BASIC line or variable is inserted at the current point. If the line
; number or variable names match (zero flag set) then a replacement takes
; place.

ME_ENTER JR   NZ,ME_ENT_1   ; forward, for insertion only, to ME-ENT-1

; but the program line or variable matches so old one is reclaimed.

```

```

EX    AF,AF'           ; save carry - prog/var flag

LD    ($5B5F),HL      ; preserve workspace pointer in dynamic X_PTR

EX    DE,HL           ; transfer program dest pointer to HL.

;;;
CALL  NEXT_ONE        ; routine NEXT-ONE finds the following location
;;;                  ; in program or variables area.
;;;
CALL  RECLAIM_2       ; routine RECLAIM-2 reclaims the space between.

CALL  NXT_1_RC2       ;+ routine combines above 2 routines.

EX    DE,HL           ; transfer program dest pointer back to DE.

LD    HL,($5B5F)      ; fetch adjusted workspace pointer from X_PTR

EX    AF,AF'         ; restore carry - program/variable flag.

;   now the new line or variable is entered.

ME_ENT_1  EX    AF,AF'           ; save or re-save carry - prog/var flag.

        PUSH  DE                 ; save dest pointer in prog/vars area.
        CALL  NEXT_ONE           ; routine NEXT-ONE finds next in workspace.
                                     ; gets next in DE, difference in BC.
                                     ; prev addr in HL

        LD    ($5B5F),HL        ; store pointer in X_PTR

        LD    HL,($5B53)        ; load HL from system variable PROG
EX    (SP),HL                 ; swap with prog/vars pointer on stack.
PUSH  BC                      ; ** save length of new program line/variable.

EX    AF,AF'                 ; fetch back carry - prog/var flag.

JR    C,ME_ENT_2             ; skip, if handling a variable, to ME-ENT-2

CALL  MK_RM_DHL              ;+ MAKE_ROOM decrementing HL first

;;;
DEC   HL                     ; address location before pointer
;;;
CALL  MAKE_ROOM              ; routine MAKE-ROOM creates room for BASIC line

INC   HL                     ; address next. (keep this one)

JR    ME_ENT_3b              ; forward to ME-ENT-3

; ---

ME_ENT_2  CALL  MAKE_ROOM      ; routine MAKE-ROOM creates room for variable.

;;; me_ent_3  INC   HL         ; address next?

ME_ENT_3b POP   BC            ; ** pop length

        EX    DE,HL           ;+ DE now holds first new location

;   Note. HL is now used instead of DE

        POP   HL               ; * pop value for PROG which may have been
                                     ; altered by POINTERS if first line.

        LD    ($5B53),HL      ; set PROG back to original value.

```

```

        LD     HL, ($5B5F)      ; fetch adjusted workspace pointer from X_PTR

        PUSH  BC              ; save the length.
        PUSH  HL              ; and save the workspace pointer.
;;;     EX    DE,HL           ; make workspace pointer the source,
;;;                               ; prog/vars pointer the destination.

        LDIR                  ; copy bytes of line or variable into new area.

        POP   HL              ; restore workspace pointer.
        POP   BC              ; restore length.

        PUSH  DE              ; save new prog/vars pointer.

        CALL  RECLAIM_2       ; routine RECLAIM-2 reclaims the space used by
                               ; the line or variable in workspace block as no
                               ; longer required and space could be useful
                               ; for adding more lines.

        POP   DE              ; restore the prog/vars pointer.

        RET                    ; return.

; -----
; THE 'SAVE CONTROL' ROUTINE
; -----
; A branch from the main SAVE-ETC routine at SAVE-ALL.
; First the header data is saved. Then, after a wait of 1 second
; the data itself is saved.
; For tape,
; HL points to start of data.
; IX points to start of descriptor.
; For RS232 and network,
; HL points to the start of the data
; IX points to start of descriptor.
; If saving to tape then channel 'K' will be open for messages.

SA_CONTRL PUSH  HL           ; save start of data.

;;;     LD    A,$FD          ; select system channel 'K'
;;;     CALL  CHAN_SLCT      ; routine CHAN-OPEN

        CALL  IN_CHAN_K      ; is tape being used ?
        JR    NZ,SA_CBN      ; skip the prompt message if not.

;;;     XOR   A              ; Clear to address table directly
        LD    DE,tape_msgs   ; Address: tape-msgs
        CALL  PO_MSG_0       ; Routine PO-MSG -
                               ; 'Start tape then press any key.'

;;;     SET   5,(IY+$02)     ; Update TV_FLAG - signal lower screen requires
;;;                               ; clearing.

        SET   3,(IY+$01)     ;+ Set 'L' key mode for prompt situation.

        CALL  WAIT_KEY       ; routine WAIT_KEY

SA_CBN   PUSH  IX           ; Save pointer to descriptor.
        LD    DE,$0011      ; There are seventeen bytes to save.
        XOR   A              ; Set A to zero - to signal a header block.

        CALL  SA_BYTES2     ; routine SA-BYTES saves block

        POP   IX            ; restore descriptor pointer.

```

```

        LD     B,$32           ; wait for a second - 50 interrupts.
SA_1_SEC HALT                ; wait for an interrupt
        DJNZ  SA_1_SEC       ; back to SA-1-SEC until pause complete.

        LD     E,(IX+$0B)     ; fetch length of bytes from the
        LD     D,(IX+$0C)     ; descriptor.

;;;
        LD     A,$FF         ; signal data bytes.  ( dec a )

        DEC   A              ;+ signal data bytes.

        POP   IX             ; retrieve pointer to start

;;;
        JP    SA_BYTES      ; jump back to SA-BYTES

SA_BYTES2 BIT    7,(IY+$3B)   ;+ are extended streams being used. T_ADDR_hi
        JP    Z,SA_BYTES     ;+ back to tape routine if not

        LD    HL,SA_LD_RET   ; address: SA/LD_RET           Duplication.
        PUSH HL              ; is pushed as common exit route.

; -----
; THE NEW 'SAVE BYTES TO NETWORK/RS232' SUBROUTINE
; -----
; This can also, for amusement, be used to save a small program to the
; Screen e.g. SAVE #2, "ABC"
; DE holds the length of data.
; IX points to the start.
; Begin by transferring the start of data from IX to HL as the extended
; streams will use the IX register. RST 10 preserves the main registers.

SA_BYT_NB PUSH   IX          ; Transfer start to
        POP   HL            ; the HL register.

SA_BYT_LP LD     A,D         ; Test for zero length.
        OR   E              ;
        RET  Z              ; Return if so. >>

        LD   A,(HL)         ; Fetch a byte to the accumulator.
        INC HL              ; Increment address.
        DEC DE              ; decrement byte count.

        RST 10H            ; Restart outputs a byte to current channel.

        JR   SA_BYT_LP     ; loop back to save another byte to SA_BYT_LP

; -----
;
; -----

LD_BYTES2 BIT    7,(IY+$3B)   ; Test T_ADDR_hi
        JP    Z,LD_BYTES     ; jump to tape routines

        LD    HL,SA_LD_RET   ; Address: SA/LD-RET
        PUSH HL              ; is saved on stack as terminating routine.

        EX   AF,AF'         ; preserve carry

; -----
; THE NEW 'LOAD BYTES FROM NETWORK/RS232' SUBROUTINE

```

```

; -----
; IX points to start
; DE holds length
; The alternate CARRY is set if data is to be loaded.

LD_BYT_NB PUSH IX          ; transfer the destination start address
          POP  HL          ; to the HL register pair.

LD_BYT_LP CALL INPUT_AD    ; input a byte from the current channel

          JR    NC,LD_BYT_LP ; repeat until byte is acceptable. XXXXXXXXXXXX

          EX   AF,AF'       ; fetch the carry flag.
          JR   C,LD_BYT_1   ; forward, with carry, to LOAD byte.

          EX   AF,AF'       ; preserve carry.
;;;      XOR  (HL)          ; verify against byte in memory.
          CP   (HL)         ; compare

          RET  NZ           ; return if verification failed with NC also.

          JR   LD_BYT_2     ; skip forward for next byte.

LD_BYT_1 EX   AF,AF'       ; preserve carry flag bring back new byte.
          LD   (HL),A       ; insert byte from network or RS232.

LD_BYT_2 INC  HL           ; increment memory pointer.
          DEC  DE           ; decrement the byte count.
          LD   A,D          ; Test for zero.
          OR   E            ;
          JR   NZ,LD_BYT_LP ; back if not zero for more.

          SCF              ; signal success.

          RET              ; Return.

```

```

; -----
; THE NEW 'DISP_MSG' ROUTINE
; -----
; If, on entry, carry is set then this routine prints a message without
; disturbing the current channel. If the carry flag is reset then the
; single character in A is output.

```

```

DISP_MSG
          PUSH HL          ; Preserve Main registers.
          PUSH BC          ;
          PUSH DE          ;

          LD   HL,($5B51)  ; fetch the current channel.
          PUSH HL          ; and save it

          PUSH DE          ; preserve message pointer
          PUSH AF          ; preserve type and carry flag

          CALL CHAN_O_FE   ; select system channel for 'S'

          POP  AF          ; bring back the type
          POP  DE          ; and the message pointer

          JR   NC,DISP_1   ; forward with no carry to output a single char

          CALL PO_MSG      ; output message to upper screen

```

```

LD A, ':' ; follow the type message with ':'
RST 10H ;
LD A, ' ' ;
DISP_1 RST 10H ; else print the character

POP HL ; restore channel.
CALL CHAN_FLAG ; routine CHAN_FLAG updates CURCHL and flags.

POP DE ; Restore main registers.
POP BC ;
POP HL ;

RET ; Return.

```

```
; ---
```

```
; Arrangement of the two tape cassette headers in workspace.
; Originally IX addresses first location and only one header is required
; when saving.
;
```

OLD HEADER	NEW HEADER	PROG	DATA num	DATA chr	CODE	NOTES.
IX-\$11	IX+\$00	0	1	2	3	Type.
IX-\$10	IX+\$01	x	x	x	x	F (\$FF if filename is null).
IX-\$0F	IX+\$02	x	x	x	x	i
IX-\$0E	IX+\$03	x	x	x	x	l
IX-\$0D	IX+\$04	x	x	x	x	e
IX-\$0C	IX+\$05	x	x	x	x	n
IX-\$0B	IX+\$06	x	x	x	x	a
IX-\$0A	IX+\$07	x	x	x	x	m
IX-\$09	IX+\$08	x	x	x	x	e
IX-\$08	IX+\$09	x	x	x	x	.
IX-\$07	IX+\$0A	x	x	x	x	(terminal spaces).
IX-\$06	IX+\$0B	lo	lo	lo	lo	Total length
IX-\$05	IX+\$0C	hi	hi	hi	hi	of datablock.
IX-\$04	IX+\$0D	Auto	-	-	Start	Various
IX-\$03	IX+\$0E	Start	a-z	a-z	addr/0	(\$80 if no autostart).
IX-\$02	IX+\$0F	lo	-	-	-	Length of Program
IX-\$01	IX+\$10	hi	-	-	-	only i.e. without variables.

```
; Arrangement of 9-byte Interfacel Network/RS232 header when saving loading.
; Note. This has not been adopted by this ROM.
;
```

\$5BE6	HD_00	0	1	2	3	Type.
\$5BE7	HD_0B	lo	lo	lo	lo	Total length
\$5BE8	HD_0C	hi	hi	hi	hi	of datablock
\$5BE9	HD_0D	--	--	--	lo/00	Start
\$5BEA	HD_0E	--	--	--	hi/00	Address.
\$5BEB	HD_0F	lo	a-z	a-z	--	Length
\$5BEC	HD_10	hi	--	--	--	of program.
\$5BED	HD_11	Auto	--	--	--	Auto start line
\$5BEE	HD_12	Start	--	--	--	number. \$FFFF if none.

```
; -----
; THE 'CANNED CASSETTE' MESSAGES
; -----
```

```
; The last-character-inverted Cassette messages.
; Starts with normal initial step-over byte.
```

```
tape_msgs DEFB $80
          DEFM "Start tape, then press a key"
```

```
type_msgs DEFB '.'+$80
          DEFB $0D
          DEFM "Progra"
          DEFB 'm'+$80
          DEFB $0D
          DEFM "Number arra"
          DEFB 'y'+$80
          DEFB $0D
          DEFM "Char arra"
          DEFB 'y'+$80
          DEFB $0D
          DEFM "Byte"
          DEFB 's'+$80
```

```
;*****
; ** Part 5. SCREEN AND PRINTER HANDLING ROUTINES **
;*****
```

```
; -----
; THE 'PRINT OUTPUT' ROUTINE
; -----
```

```
; This is the routine most often used by the RST 10 restart although the
; subroutine is on two occasions called directly when it is known that
; output will definitely be to the lower screen.
```

```
PRINT_OUT CALL PO_FETCH      ; routine PO-FETCH fetches print position
                                ; to HL register pair.
          CP      $20          ; is character a space or higher ?
          JR      NC,PO_Q_ABLE ; jump forward, if so, to PO-ABLE

          CP      $06          ; is character in range 00-05 ?
          JR      C,PO_QUEST   ; forward, if so, to PO-QUEST

          CP      $18          ; is character in range 24d - 31d ?
          JR      NC,PO_QUEST   ; forward, if so, to PO-QUEST

          LD      HL,ctlchrtab-6 ; address - the base address of control
                                ; character table - where zero would be.

          LD      E,A          ; control character 06 - 23d
          LD      D,$00        ; is transferred to DE.

          ADD     HL,DE        ; index into table.

          LD      E,(HL)       ; fetch the offset to routine.
          ADD     HL,DE        ; add to make HL the address.
          PUSH    HL           ; push the address of routine.

          JP      PO_FETCH     ; Jump forward to PO-FETCH,
                                ; as the screen/printer position has been
                                ; disturbed, and then indirectly to the
                                ; routine on the stack.
```

```
; -----
; THE 'CONTROL CHARACTER' TABLE
; -----
```

```
; For control characters in the range 6 - 23d the following table
; is indexed to provide an offset to the handling routine that
; follows the table.
```

```

ctlchrtab DEFB PO_COMMA      - $ ; 06d offset to Address: PO-COMMA
          DEFB PO_QUESTION   - $ ; 07d offset to Address: PO-QUEST
          DEFB PO_BACK_1     - $ ; 08d offset to Address: PO-BACK-1
          DEFB PO_RIGHT      - $ ; 09d offset to Address: PO-RIGHT
          DEFB PO_QUESTION   - $ ; 10d offset to Address: PO-QUEST
          DEFB PO_QUESTION   - $ ; 11d offset to Address: PO-QUEST
          DEFB PO_QUESTION   - $ ; 12d offset to Address: PO-QUEST
          DEFB PO_ENTER      - $ ; 13d offset to Address: PO-ENTER
          DEFB PO_QUESTION   - $ ; 14d offset to Address: PO-QUEST
          DEFB PO_QUESTION   - $ ; 15d offset to Address: PO-QUEST
          DEFB PO_1_OPER     - $ ; 16d offset to Address: PO-1-OPER
          DEFB PO_1_OPER     - $ ; 17d offset to Address: PO-1-OPER
          DEFB PO_1_OPER     - $ ; 18d offset to Address: PO-1-OPER
          DEFB PO_1_OPER     - $ ; 19d offset to Address: PO-1-OPER
          DEFB PO_1_OPER     - $ ; 20d offset to Address: PO-1-OPER
          DEFB PO_1_OPER     - $ ; 21d offset to Address: PO-1-OPER
          DEFB PO_2_OPER     - $ ; 22d offset to Address: PO-2-OPER
          DEFB PO_2_OPER     - $ ; 23d offset to Address: PO-2-OPER

; -----
; THE 'CURSOR LEFT' ROUTINE
; -----
;   Backspace and up a line if that action is from the left of screen.
;   For the ZX printer backspace up to first column but not beyond.

PO_BACK_1 INC   C           ; Move left one column.
          LD    A,$22       ; Value $21 is leftmost column.
          CP    C           ; Have we passed ?
          JR    NZ,PO_BACK_3 ; Forward, if not, to PO-BACK-3
                               ; to store the new position.

          BIT   1,(IY+$01)  ; Test FLAGS - is printer in use ?
          JR    NZ,PO_BACK_2 ; Forward, if so, to PO-BACK-2
                               ; as it is not possible to move left.

          INC   B           ; Move up one screen line
          LD    C,$02       ; The rightmost column position.

;;;          LD    A,$18     ; Note. This should be $19 (not $18)
;;;          ; Credit: Dr. Frank O'Hara, 1982

          LD    A,$19       ;+ Test against the top line plus one.

          CP    B           ; Has position moved past top of screen ?
          JR    NZ,PO_BACK_3 ; Forward, if not, to PO-BACK-3
                               ; to store the new position.

          DEC   B           ; else back to $18.

PO_BACK_2 LD    C,$21       ; the leftmost column position.

PO_BACK_3 JR    PO_ENTEND   ;+ Forward, indirectly, to CL-SET and PO-STORE
                               ; to store new position in system variables.

;;;          JP    CL_SET    ; a 3-byte direct jump.

; -----
; THE 'CURSOR RIGHT' ROUTINE
; -----
;   This moves the print position to the right leaving a trail in the
;   current background colour.
;   "However the programmer has failed to store the new print position

```



```

; so CHR$ 9 will only work if the next print position is at a newly
; defined place.
; e.g. PRINT PAPER 2; CHR$ 9; AT 4,0;
; does work but is not very helpful"
; - Dr. Ian Logan, Understanding Your Spectrum, 1982.

;;; PO_RIGHT LD    A,($5B91)    ; fetch P_FLAG value
;;;          PUSH  AF          ; and preserve the original value on the stack.
;;;          LD    (IY+$57),$01 ; temporarily set P_FLAG 'OVER 1'.
;;;          LD    A,$20       ; prepare a space.
;;;          CALL  PO_CHAR     ; routine PO-CHAR to print it.
;;;          POP   AF          ; restore the original P_FLAG value.
;;;          LD    ($5B91),A    ; and restore system variable P_FLAG
;;;          RET                ; return without need to update column position.

PO_RIGHT LD    HL,$5B91        ;+ Address system variable P_FLAG
          LD    D,(HL)         ;+ Fetch the System Variable value and
          LD    (HL),1        ;+ Set to OVER 1

          CALL  PO_SV_SP      ;+ Routine prints a space

          LD    (HL),D        ;+ and place in P_FLAG
          RET                ;+ Return

; -----
; THE 'PRINT CARRIAGE RETURN' ROUTINE
; -----
; A carriage return is 'printed' to screen or printer buffer.

PO_ENTER BIT   1,(IY+$01)     ; test FLAGS - is printer in use ?

          JP    NZ,COPY_BUFF   ; to COPY-BUFF if so, to flush buffer and reset
                                ; the print position.

; Continue if writing to screen.

          LD    C,$21         ; the leftmost screen column position.

          CALL  PO_SCR        ; routine PO-SCR handles any scrolling required.

          DEC   B             ; adjust to next screen line.

PO_ENTEND JP    CL_SET        ; jump forward to CL-SET to store new position.

; -----
; THE 'PRINT COMMA' SUBROUTINE
; -----
; The comma control character. The 32 column screen has two 16 character
; tabstops. The routine is only reached via the control character table.
; If it was called from elsewhere then the call to PO-FETCH would be needed.

;;;          CALL  PO_FETCH    ; routine PO-FETCH - seems unnecessary.

PO_COMMA LD    A,C           ; the column position. $21-$01
          DEC   A             ; move right. $20-$00
          DEC   A             ; and again $1F-$00 or $FF if trailing
          AND   $10           ; will be $00 or $10.
          JR    PO_FILL      ; forward to PO-FILL

; -----
; THE 'PRINT QUESTION MARK' SUBROUTINE
; -----
; This routine prints a question mark which is commonly used to print an

```

```

; unassigned control character in range 0-31d. There are a surprising number
; yet to be assigned.

PO_QUEST LD A,$3F ; prepare the character '?'.

PO_Q_ABLE JR PO_ABLE ; forward to PO-ABLE.

; -----
; THE 'CONTROL CHARACTERS WITH OPERANDS' ROUTINES
; -----
; Certain control characters are followed by 1 or 2 operands.
; The entry points from control character table are PO-2-OPER and PO-1-OPER.
; The routines alter the output address of the current channel so that
; subsequent RST $10 instructions take the appropriate action
; before finally resetting the output address back to PRINT-OUT.

PO_TV_2 LD DE,PO_CONT ; address: PO-CONT will be next output routine

PO_TV_3 LD ($5B0F),A ; store first operand in TVDATA-hi
JR PO_CHANGE ; forward to PO-CHANGE >>

; ---

; -> This initial entry point deals with two operands - AT or TAB.

PO_2_OPER LD DE,PO_TV_2 ; address: PO-TV-2 will be next output routine
JR PO_TV_1 ; forward to PO-TV-1

; ---

; -> This initial entry point deals with one operand INK to OVER.

PO_1_OPER LD DE,PO_CONT ; address: PO-CONT will be next output routine

PO_TV_1 LD ($5B0E),A ; store control code in TVDATA-lo

PO_CHANGE LD HL,($5B51) ; use CURCHL to find current output channel.

PO_CH_2 LD (HL),E ; make it
INC HL ; the supplied
LD (HL),D ; address from DE.

RET ; return.

; ---

PO_NORM LD DE,PRINT_OUT ; prepare to make PRINT_OUT normal.
JR PO_CHANGE ;

; ---

PO_CONT
;;; LD DE,PRINT_OUT ; Address: PRINT-OUT
;;; CALL PO_CHANGE ; routine PO-CHANGE to restore normal channel.
CALL PO_NORM ;+ routine embodies above two instructions.

; Now that all the sequence of codes have been received they can be handled.
; The accumulator holds the final parameter and any previous codes are in
; the system variable TVDATA.

LD HL,($5B0E) ; TVDATA gives control code and possible
; subsequent character
LD D,A ; save current code.
LD A,L ; fetch the stored control code

```

```

        CP    $16                ; was it one operand - INK to OVER ?

        JP    C,CO_TEMP_5        ; jump forward, if so, to CO-TEMP-5

; Consider the two control codes with two operands.

        JR    NZ,PO_TAB          ; forward, if not 22 decimal, to PO-TAB (23)

; else must have been 22 decimal - 'AT'.

        LD    B,H                ; line to H    (0-23d)
        LD    C,D                ; column to C (0-31d)
        LD    A,$1F              ; prepare the value 31d
        SUB   C                  ; reverse the column number.
        JR    C,PO_AT_ERR        ; forward, if greater than 31, to PO-AT-ERR
        ; 'Integer out of range'

        ADD   A,$02              ; transform to system range $02-$21
        LD    C,A                ; and place in the column register.

; Now consider the line parameter.

        BIT   1,(IY+$01)         ; test FLAGS - is printer in use ?
        JR    NZ,PO_ENTEND       ; forward, if so, ignoring line to PO-AT-SET

        LD    A,$16              ; prepare 22 decimal
        SUB   B                  ; subtract line number to reverse legal values
        ; 0 - 22 becomes 22 - 0.

PO_AT_ERR JP    C,REPORT_Bb      ; jump, if higher than 22, to REPORT-B
        ; 'Integer out of range'

        INC   A                  ; adjust for the system range $01-$17
        LD    B,A                ; place in the line register

        INC   B                  ; adjust to system range $02-$18
        BIT   0,(IY+$02)         ; test TV_FLAG - Lower screen in use ?
        JP    NZ,PO_SCR          ; forward, if so, to PO-SCR
        ; to test for scrolling.

        CP    (IY+$31)           ; for upper screen, compare against DF_SZ

;;;        JP    C,REPORT_5        ; to REPORT-5 if too low
;;;        ; 'Out of screen'
;;;        JP    CL_SET            ; to CL_SET if valid.

PO_AT_SET JR    NC,PO_ENTEND     ;+ print position is valid so exit via CL-SET

REPORT_5a RST   30H              ;+ ERROR-1
        DEFB  $04                ;+ Error Report: Out of screen

; ---

; The branch was here when dealing with TAB.
; Note. In BASIC, TAB is followed by a 16-bit number and was initially
; designed to work with any output device.

PO_TAB    LD    A,H                ; transfer parameter to A losing the current
        ; contents - the high byte of the TAB parameter.

PO_FILL   CALL  PO_FETCH          ; routine PO-FETCH, HL = addr, BC = line/column.
        ; column 1 (right), $21 (left)

        ADD   A,C                ; add operand to current column

```

```

        DEC    A                ; range 0 - 31+
        AND    $1F              ; make range mod 32 that is 0 - 31.
        RET    Z                ; return if result is zero.

        LD     D,A              ; Counter to D
        SET    0,(IY+$01)       ; update FLAGS - signal suppress leading space.

PO_SPACE CALL    PO_SV_SP       ;+ call instruction before PO_SAVE - ld a,$20

;;;      LD     A,$20           ; space character.
;;;      CALL   PO_SAVE         ; routine PO-SAVE prints the character
;;;                                     ; using alternate set (normal output routine)

        DEC    D                ; decrement the spaces counter.
        JR     NZ,PO_SPACE      ; back to PO-SPACE until done.

        RET                    ; Return.

; -----
; Printable character(s)
; -----
; This routine prints printable characters and continues into
; the position store routine

PO_ABLE  CALL    PO_ANY         ; routine PO-ANY
                                     ; and continue into position store routine.

; -----
; THE 'POSITION STORE' ROUTINE
; -----
; This routine updates the system variables associated with the main screen,
; the lower screen/input buffer or the ZX printer.

PO_STORE BIT    1,(IY+$01)      ; Test FLAGS - is printer in use ?
        JR     NZ,PO_ST_PR      ; Forward, if so, to PO-ST-PR

        BIT    0,(IY+$02)      ; Test TV_FLAG - is lower screen in use ?
        JR     NZ,PO_ST_E       ; Forward, if so, to PO-ST-E

; This section deals with the upper screen.

        LD     ($5B88),BC       ; Update S_POSN - line/column upper screen
        LD     ($5B84),HL       ; Update DF_CC - upper display file address

        RET                    ; Return.

; ---

; This section deals with the lower screen.

PO_ST_E  LD     ($5B8A),BC       ; Update SPOSNL line/column lower screen
        LD     ($5B82),BC       ; Update ECHO_E line/column input buffer
        LD     ($5B86),HL       ; Update DFCC_L lower screen memory address
        RET                    ; Return.

; ---

; This section deals with the ZX Printer.
; Now just update the column number $00 - $21 within the channel.

PO_ST_PR LD     IX,($5B51)       ;+ set IX to CURCHL

        LD     (IX+$07),C       ;+ Update P_POSN column position printer

```

```

RET                                ; Return.

; -----
; THE 'POSITION FETCH' ROUTINE
; -----
; This routine fetches the line/column and display file address of the upper
; and lower screen or, if the printer is in use, the column position and
; absolute memory address.
; Note. that PR-CC is no longer used. The output address is calculated
; by this routine every time from the new channel variable P_POSN.
; The output address now alters whenever a channel is reclaimed.

PO_FETCH BIT 1,(IY+$01)           ; Test FLAGS - is printer in use ?
        JR  NZ,PO_F_PR           ; Forward, if so, to PO-F-PR

; assume upper screen in use and thus optimize for path that requires speed.

        LD  BC,($5B88)           ; Fetch line/column from S_POSN
        LD  HL,($5B84)           ; Fetch DF_CC display file address

        BIT 0,(IY+$02)           ; Test TV_FLAG - lower screen in use ?
        RET Z                     ; Return if upper screen in use.

; Overwrite registers with values for lower screen.

        LD  BC,($5B8A)           ; Fetch line/column from SPOSNL
        LD  HL,($5B86)           ; Fetch display file address from DFCL
        RET                       ; Return.

; ---

; This section deals with the ZX Printer.
; The column is obtained from the location within the channel.
; The output address HL is derived from this column number.

PO_F_PR LD HL,($5B51)             ;+ set HL to start of Channel from CURCHL
        LD  BC,$0007             ;+ offset to column number.
        ADD HL,BC                ;+ add to address P_POSN
        LD  C,(HL)              ;+ Fetch column from P_POSN.
        INC HL                   ;+ Start of 256 buffer.

        LD  B,A                 ;+ copy character to B.

        LD  A,$21                ;+ Reverse the column number
        SUB C                    ;+ Now $00 (left) $1F (right)
        ADD A,L                  ;+ add to low byte possibly setting carry flag.
        LD  L,A                 ;+ place back in low byte.

        LD  A,B                 ;+ copy character back to A

        RET NC                   ;+ return if address is correct.

        INC H                    ;+ else increase by 256 bytes.

        RET                       ;+ Return.

; -----
; THE 'PRINT ANY CHARACTER' ROUTINE
; -----
; This routine is used to print any character in range 32d - 255d
; It is only called from PO-ABLE which continues into PO-STORE
; On entry, HL contains the output address and BC the line column or just
; the column in the case of the ZX Printer.

```

```

PO_ANY    CP    $80          ; ASCII ?
          JR    C,PO_CHAR   ; to PO-CHAR if so.

          CP    $90          ; test if a block graphic character.
          JR    NC,PO_T_UDG ; to PO-T&UDG to print tokens and UDGs

;   The 16 2*2 mosaic characters 128-143 decimal are formed from
;   bits 0-3 of the character.

          LD    B,A          ; save character

          CALL  PO_GR_1      ; routine PO-GR-1 to construct top half
                              ; then bottom half.

          CALL  PO_FETCH     ; routine PO-FETCH re-fetches print position.

          LD    DE,$5B92     ; MEM-0 is location of 8 bytes of character

          JR    PR_ALL       ; forward to PR-ALL
                              ; to print to screen or printer.

; ---

PO_GR_1   LD    HL,$5B92     ; address MEM-0 - a temporary buffer in
                              ; systems variables which is normally used
                              ; by the calculator.
          CALL  PO_GR_2      ; routine PO-GR-2 to construct top half
                              ; and continue into routine to construct
                              ; bottom half.

PO_GR_2   RR    B            ; rotate bit 0/2 to carry
          SBC  A,A           ; result $00 or $FF
          AND  $0F           ; mask off right hand side
          LD   C,A           ; store part in C
          RR   B            ; rotate bit 1/3 of original chr to carry
          SBC  A,A           ; result $00 or $FF
          AND  $F0           ; mask off left hand side
          OR   C             ; combine with stored pattern
          LD   C,$04         ; four bytes for top/bottom half

PO_GR_3   LD    (HL),A       ; store bit patterns in temporary buffer
          INC  HL            ; next address
          DEC  C             ; jump back to
          JR   NZ,PO_GR_3    ; to PO-GR-3 until byte is stored 4 times

          RET                ; return

; ---

;   Tokens and User defined graphics are now separated.

PO_T_UDG  SUB  $A5           ; subtract the 'RND' character
          JR   NC,PO_T       ; forward, if a token, to PO-T

          ADD  A,$15         ; add 21d to restore to 0 - 20
          PUSH BC            ; save current print position
          LD   BC,($5B7B)    ; fetch UDG to address bit patterns
          JR   PO_CHAR_2     ; forward to common code at PO-CHAR-2
                              ; to lay down a bit patterned character

; ---

;   Tokens

```

```

PO_T      CALL  PO_TOKENS      ; routine PO-TOKENS prints tokens
;;;
          JP    PO_FETCH      ; an absolut jump to PO_FETCH

          JR    PO_FETCH      ;+ exit via a JUMP to PO-FETCH as this routine
          ;+ must continue into PO-STORE.
          ;+ A JR instruction could be used. (Done)

; ---

; This point is used to print ASCII characters 32d - 127d.

PO_CHAR   PUSH  BC            ; Preserve print position
          LD    BC,($5B36)    ; Fetch font pointer from address CHARS

; This common code is used to transfer the character bytes to memory.

PO_CHAR_2 EX  DE,HL          ; transfer destination address to DE

          LD    HL,$5B3B      ; point to FLAGS
          RES   0,(HL)        ; update FLAGS - allow for leading space

          CP    $20           ; is output character a space ?
          JR    NZ,PO_CHAR_3  ; skip forward, if not, to PO-CHAR-3

          SET   0,(HL)        ; update FLAGS - signal no leading space.

PO_CHAR_3 LD  H,$00          ; set high byte to 0
          LD  L,A            ; character to A, 0-21 UDG or 32-127 ASCII.

          ADD  HL,HL          ; multiply
          ADD  HL,HL          ; by
          ADD  HL,HL          ; eight.

          ADD  HL,BC          ; HL now points to first byte of character.

          POP  BC            ; retrieve the source address from CHARS or UDG.

          EX  DE,HL          ; transfer the character bitmap address to DE.

; -----
; THE 'PRINT ALL CHARACTERS' ROUTINE
; -----
; This entry point entered from above to print ASCII and UDGs but also from
; earlier to print the mosaic characters.
; HL = screen or printer destination
; DE = character bitmap source
; BC = line/column

PR_ALL    LD    A,C          ; transfer the column to A
          DEC  A            ; move to the right

          LD  A,$21          ; pre-load with leftmost position
          PUSH DE            ;+ Save character source before any branching.
          JR  NZ,PR_ALL_1    ; forward, if not zero, to PR-ALL-1

; If zero then move down a line, but B is of no significance if printer
; is in use

          DEC  B            ; down one line
          LD  C,A           ; load C with $21

          BIT  1,(IY+$01)    ; test FLAGS - is printer in use

```

```

;;;      JR      Z,PR_ALL_1      ; forward, if not, to PR-ALL-1

; This is the printer-only path but we can trickle through.

;;;      PUSH   DE              ; save source address

;;;      CALL   COPY_BUFF      ; Routine COPY-BUFF outputs line to printer
      CALL   NZ,COPY_BUFF      ;+ Routine COPY-BUFF conditionally outputs line
                                ;+ to printer leaving A=$00 and C=$21 and
                                ;+ the zero flag reset - NZ.

;;;      POP    DE              ; Restore the character source address
;;;      LD     A,C              ; the new column number ($21) to A from C.

; This is the screen-only path but we can trickle through as A!=C.

PR_ALL_1
      CP     C                  ; this test is really for screen - new line ?
;;;      PUSH   DE              ; save source

      CALL   Z,PO_SCR          ; routine PO-SCR considers scrolling.

      POP    DE                ; restore source address.

; The following applies to screen and printer.

PR_ALL_1a PUSH   BC              ; save line/column
          PUSH   HL              ; and destination

          LD     A,($5B91)       ; fetch P_FLAG to accumulator
          LD     B,$FF           ; prepare an OVER mask in B.
          RRA                    ; carry is set if temporary bit is OVER 1
          JR     C,PR_ALL_2      ; forward, if OVER 1, to PR-ALL-2

          INC    B                ; set OVER mask to 0

PR_ALL_2 RRA                    ; skip bit 1 of P_FLAG
          RRA                    ; bit 2 is temporary INVERSE
          SBC   A,A              ; will be FF for INVERSE 1 else zero
          LD     C,A              ; transfer the INVERSE mask to C

          LD     A,$08           ; prepare to count 8 bytes
          AND   A                ; clear carry to signal screen in use.

          BIT   1,(IY+$01)       ; test FLAGS - is screen in use ?
          JR     Z,PR_ALL_3      ; forward, if screen, to PR-ALL-3

;;;      SET   1,(IY+$30)       ; update FLAGS2 - signal printer buffer has
;;;                               ; been used.

          SCF                    ; set the carry flag to signal printer in use.

PR_ALL_3 EX     DE,HL           ; now HL=source, DE=destination

PR_ALL_4 EX     AF,AF'          ; Save the printer/screen Carry flag

          LD     A,(DE)          ; Fetch the existing destination byte
          AND   B                ; consider OVER
          XOR   (HL)             ; now XOR with source
          XOR   C                ; now with INVERSE MASK

          LD     (DE),A          ; update screen/printer location.

          EX    AF,AF'          ; restore discriminating flag

```



```

        JR      C,PR_ALL_6      ; forward, if printer, to PR-ALL-6
;   Continue with screen printing.

        INC    D                ; increment D - gives next screen pixel line
PR_ALL_5 INC    HL              ; address next character source byte
        DEC    A                ; the byte count is decremented
        JR     NZ,PR_ALL_4      ; back to PR-ALL-4 for all 8 bytes

        EX     DE,HL           ; transfer destination to HL
        DEC    H                ; bring back to last updated screen position
                                ; from the 'ninth' line.

        BIT    1,(IY+$01)      ; test FLAGS - is printer in use ?

        CALL   Z,PO_ATTR       ; if not, call routine PO-ATTR to update the
                                ; corresponding colour attribute.
                                ; (the address of which is now retained in DE)

        POP    HL              ; restore original screen/printer position
        POP    BC              ; and the line and column

        DEC    C                ; move column to right
        INC    HL              ; increase screen/printer position

        RET                               ; return and continue into PO-STORE
                                ; within PO-ABLE

;   Note. that DE has been made to retain the attribute byte.

;   ---

;   This branch is used to update the ZX printer position by 32 places
;   Note. The high byte of the address D now increments if a page boundary
;   is crossed as this ROM supports up to thirteen ZX Printer buffers.

PR_ALL_6 EX     AF,AF'         ; save the flag
        LD     A,$20           ; load A with 32 decimal
        ADD   A,E              ; add this to E
        LD     E,A             ; and store result in E
        JR     NC,PR_ALL_7     ;+ skip forward if no wrap.

        INC    D                ;+ increment the high byte of channel address.

PR_ALL_7 EX     AF,AF'         ; fetch the flag
        JR     PR_ALL_5        ; back to PR-ALL-5

;   -----
;   THE 'UPDATE ATTRIBUTE CELL' ROUTINE
;   -----
;   This routine is entered with the HL register holding the last screen
;   address to be updated by PRINT or PLOT.
;   The Spectrum screen arrangement leads to the L register holding the correct
;   value for the attribute file and it is only necessary to manipulate H to
;   form the correct colour attribute address.

;;; PO_ATTR  LD     A,H        ; fetch high byte $40 - $57
;;;          RRCA           ; shift
;;;          RRCA           ; bits 3 and 4
;;;          RRCA           ; to right.
;;;          AND    $03       ; range is now 0 - 2
;;;          OR     $58       ; form correct high byte for third of screen
;;;          LD     H,A        ; HL is now correct

```

```

PO_ATTR    CALL    CL_ATTR2          ;+ NEW subroutine with above code.

           LD      DE,($5B8F)        ; make D hold ATTR_T, E hold MASK-T
           LD      A,(HL)            ; fetch existing attribute from attribute file
           XOR     E                  ; apply masks
           AND     D                  ;
           XOR     E                  ;
           BIT     6,(IY+$57)        ; test P_FLAG - is this PAPER 9 ??
           JR      Z,PO_ATTR_1       ; skip, if not, to PO-ATTR-1

           AND     $C7                ; set paper
           BIT     2,A                ; to contrast with ink
           JR      NZ,PO_ATTR_1       ; skip to PO-ATTR-1

           XOR     $38                ;

PO_ATTR_1  BIT     4,(IY+$57)        ; test P_FLAG - is this INK 9 ??
           JR      Z,PO_ATTR_2       ; skip, if not, to PO-ATTR-2

           AND     $F8                ; make the ink colour contrast with paper.
           BIT     5,A                ; Is paper light ?

           JR      NZ,PO_ATTR_2       ; forward, if so, to PO-ATTR-2

           XOR     $07                ; toggle ink colour.

PO_ATTR_2  LD      (HL),A            ; write the new attribute to the attribute file
           EX     DE,HL              ;+ Note. NEW - return the attribute byte in DE.
           RET                       ; return.

; -----
; THE 'MESSAGE PRINTING' SUBROUTINE
; -----
; This entry point is used to print tape, boot-up, scroll? and error messages.
; On entry the DE register points to an initial step-over byte or the
; inverted end-marker of the previous entry in the table.
; Register A contains the message number, often zero to print first message.
; (HL has nothing important usually P_FLAG)

PO_MSG_0   XOR     A                  ;+ NEW entry point to print first message.
PO_MSG_1   SET     5,(IY+$02)        ;+ update TV_FLAG - signal lower screen will
                                           ;+ require clearing.

; -> Normal Entry Point.

PO_MSG     PUSH    HL                 ; put hi-byte zero on stack to suppress
           LD      H,$00              ; trailing spaces
           EX     (SP),HL             ; ld h,0; push hl would have done ?.
           JR      PO_TABLE           ; forward to PO-TABLE.

; ---

; This entry point prints the BASIC keywords, '<>' etc. from alt set

PO_TOKENS  LD      DE,TKN_TABLE      ; address: TKN-TABLE
           PUSH   AF                  ; stack the token number to control
                                           ; trailing spaces - see later *

; ->

PO_TABLE   CALL    PO_SEARCH          ; routine PO-SEARCH will set carry for

```

```

; all messages and function words.

JR    C,PO_EACH    ; forward to PO-EACH if not a command, '<>' etc.

;;;
LD    A,$20        ; prepare leading space
BIT   0,(IY+$01)   ; test FLAGS - leading space if not set

;;;
CALL  Z,PO_SAVE    ; routine PO-SAVE to print the space in A.

CALL  Z,PO_SV_SP   ; routine PO-SV_SP to print a space without
; disturbing registers.

PO_EACH LD    A,(DE)    ; Fetch character from the table.
AND    $7F          ; Cancel any inverted bit.

CALL  PO_SAVE      ; Routine PO-SAVE to print using the alternate
; set of registers.

LD    A,(DE)        ; Re-fetch character from table.
INC   DE            ; Address next character in the table.

ADD   A,A           ; Was character inverted ?
; (this also doubles character e.g. $41 -> $82)
JR    NC,PO_EACH   ; back, if not, to PO-EACH

POP   DE            ; * re-fetch trailing space byte to D

CP    $48           ; was the last character '$' ?
JR    Z,PO_TR_SP   ; forward, if so, to PO-TR-SP
; to consider a trailing space.

CP    $82           ; was it < 'A' i.e. '#','>','=' from tokens
; or ' ','.' (from tape) or '?' from scroll

RET   C             ; Return if so as no trailing space required.

PO_TR_SP LD    A,D    ; The trailing space flag (zero if an error msg)

CP    $03           ; Test against RND, INKEY$ and PI which have no
; parameters and therefore no trailing space.

RET   C             ; Return if no trailing space.

PO_SV_SP LD    A,$20 ; Prepare the space character and continue to
; print and make an indirect return.

; -----
; THE 'RECURSIVE PRINTING' SUBROUTINE
; -----
; This routine which is part of PRINT-OUT allows RST $10 to be used
; recursively to print tokens and the spaces associated with them.
; It is called on three occasions when the value of DE must be preserved.

PO_SAVE  PUSH  DE    ; Save DE value.
EXX      ; Switch in main set

RST     10H        ; PRINT-A prints using this alternate set.

EXX      ; Switch back to this alternate set.
POP     DE        ; Restore the initial DE value.

RET      ; Return.

; -----

```

```

; THE 'TABLE SEARCH' ROUTINE
; -----
; This subroutine searches a message or the token table for the
; message number held in A. DE holds the address of the table.

PO_SEARCH PUSH AF ; save the original message/token number

EX DE,HL ; transfer table address, DE to HL
INC A ; adjust for initial step-over byte

PO_STEP BIT 7,(HL) ; is character inverted ?
INC HL ; address next
JR Z,PO_STEP ; back, if not inverted, to PO-STEP

; The start of a new message token.

DEC A ; decrease message counter
JR NZ,PO_STEP ; back, if not zero, to PO-STEP

; Register HL now addresses the first character of the required message.

EX DE,HL ; transfer address to DE

POP AF ; restore original message/token number

CP $20 ; compare to thirty two
RET C ; return for all messages and function tokens.

; Note. there are thirty error messages, originally twenty eight.

LD A,(DE) ; test first character of token
SUB $41 ; against character 'A'

RET ; Return - with carry set if it is less
; i.e. '<>', '<=', '>='

; -----
; THE 'TEST FOR SCROLL' SUBROUTINE
; -----
; This test routine is called when printing carriage return, when considering
; PRINT AT and from the general PRINT ALL characters routine to test if
; scrolling is required, prompting the user if necessary.
; This is therefore using the alternate set.
; The B register holds the current line.
; The current channel could be the upper screen 'S' in which case the
; 'scroll?' prompt is printed or from the lower screen 'K' in which case
; no prompt is given.

PO_SCR
;;; BIT 1,(IY+$01) ; test FLAGS - is printer in use ?
;;; RET NZ ; return immediately if so.

; Continue if handling upper or lower screen.

LD DE,CL_SET ; set DE to address: CL-SET
PUSH DE ; and push for the return address.

LD A,B ; transfer the line to A.
BIT 0,(IY+$02) ; test TV_FLAG - lower screen in use ?
JP NZ,PO_SCR_4 ; jump forward, if so, to PO-SCR-4

CP (IY+$31) ; greater than DF_SZ display file size ?
REP_5 JR C,REPORT_5b ; forward, if less, to REPORT-5

```

```

; 'Out of screen'

RET    NZ                ; return (via CL-SET) if greater

BIT    4, (IY+$02)       ; test TV_FLAG - Automatic listing ?
JR     Z, PO_SCR_2       ; forward, if not, to PO-SCR-2

LD     E, (IY+$2D)       ; fetch BREG - the count of scroll lines to E.
DEC    E                 ; decrease
JR     Z, PO_SCR_3       ; forward, if zero to scroll, at PO-SCR-3.

;;;
;;; LD     A, $00         ; explicit - select channel zero.
;;; CALL  CHAN_SLCT      ; routine CHAN-OPEN opens it invoking TEMPS.

CALL  CHAN_ZERO         ;+ routine CHAN-OPEN opens it invoking TEMPS.

LD     SP, ($5B3F)       ; set stack pointer to LIST_SP

PO_N_AUTO RES 4, (IY+$02) ; Update TV_FLAG - signal auto listing finished.

RET                                ; return, ignoring pushed value CL-SET, to MAIN
; or EDITOR without updating print position >>

; ---

REPORT_5b RST 30H        ; ERROR-1
          DEFB $04        ; Error Report: Out of screen

; ---

; Continue here if not an automatic listing.

PO_SCR_2 DEC (IY+$52)    ; decrease the scroll count - SCR_CT
          JR  NZ, PO_SCR_3 ; forward, if not zero, to scroll at PO-SCR-3

; If scroll count is zero, produce prompt, so that user can see the scrolled
; output and BREAK if desired.

LD     A, $18           ; prepare 24 decimal.
SUB    B                ; subtract the current line.
LD     ($5B8C), A       ; update the scroll count - SCR_CT

; Although printing to lower screen will

LD     HL, ($5B8F)      ; L=ATTR_T, H=MASK_T
PUSH   HL              ; save on stack

LD     A, ($5B91)      ; P_FLAG
PUSH   AF              ; save on stack to prevent lower screen
; attributes (BORDCR etc.) being applied.

LD     A, $FD          ; select system channel 'K'

CALL  CHAN_SLCT        ; routine CHAN-OPEN opens it and invokes TEMPS.

;;;
;;; XOR    A            ; clear to address message directly
;;; LD     DE, scrl_mssg ; make DE address: scrl-mssg

CALL  PO_MSG_0         ; routine PO-MSG prints 'scroll?' to the lower
; screen.

;;;
;;; SET    5, (IY+$02)  ; set TV_FLAG - signal lower screen requires
; clearing

```

```

LD     HL,$5B3B      ; make HL address FLAGS
SET    3,(HL)        ; signal 'L' mode.
RES    5,(HL)        ; signal 'no new key'.

EXX                                ; switch to main set.
                                ; as calling chr input from alternative set.

CALL   WAIT_KEY        ; routine WAIT_KEY waits for new key

EXX                                ; switch back to alternate set.

CP     $20             ; space is considered as BREAK
JR     Z,REPORT_D      ; forward, if so, to REPORT-D
                                ; 'BREAK - CONT repeats'

CP     $E2             ; is character 'STOP' ?
JR     Z,REPORT_D      ; forward, if so, to REPORT-D
                                ; 'BREAK - CONT repeats'

OR     $20             ; convert to lower-case
CP     $6E             ; is character 'n' ?
JR     Z,REPORT_D      ; forward, if so, to REPORT-D
                                ; 'BREAK - CONT repeats'

;   Scrolling is required.

;;;   LD     A,$FE      ; select system channel 'S'
;;;   CALL   CHAN_SLCT  ;

CALL   CHAN_O_FE      ;+ Routine CHAN-OPEN opens it but applies
                                ;+ ATTR_P to ATTR_T nullifying any embedded
                                ;+ colour items in the current print statement.

POP    AF              ; Restore original P_FLAG
LD     ($5B91),A       ; and save in P_FLAG.
POP    HL              ; Restore original ATTR_T, MASK_T
LD     ($5B8F),HL     ; and reset ATTR_T, MASK-T as 'scroll?' has
                                ; been printed.

PO_SCR_3 CALL CL_SC_ALL ; routine CL-SC-ALL to scroll whole display

LD     B,(IY+$31)     ; fetch DF_SZ to B
INC    B              ; increase to address last line of display

;;;   LD     C,$21      ; set C to $21 (was $21 from above routine)

PUSH   BC              ; save the line and column in BC.

CALL   CL_ADDR        ; routine CL_ADDR finds display address.

;;;   LD     A,H        ; now find the corresponding attribute byte
;;;   RRCA              ; (this code sequence is used twice
;;;   RRCA              ; elsewhere and is a candidate for
;;;   RRCA              ; a subroutine.)
;;;   AND    $03        ;
;;;   OR     $58        ;
;;;   LD     H,A        ;

CALL   CL_ATTR2       ;+ Note. A NEW routine with the above code.

LD     DE,$5AE0      ; start of last 'line' of attribute area

LD     A,(DE)        ; get attribute for last line
LD     C,(HL)        ; get attribute for base line of upper part

```

```

        LD     B,$20           ; there are thirty two attribute bytes to copy
        EX     DE,HL          ; swap the pointers.

PO_SCR_3A LD     (DE),A        ; exchange the two
        LD     (HL),C        ; attributes.
        INC    DE             ; address next source location.
        INC    HL             ; address next destination location.
        DJNZ  PO_SCR_3A      ; loop back to PO-SCR-3A
                                ; for all adjacent attribute cells.

        POP   BC             ; restore the line/column.

        RET                  ; return via CL-SET (was pushed on stack).

; -----
; THE 'SCROLL?' PROMPT
; -----
; The message 'scroll?' appears here with last byte inverted.

scrl_mssg DEFB  $80           ; initial step-over byte.
          DEFM  "scroll"
          DEFB  '?'+$80

; ---

REPORT_D  RST    30H          ; ERROR-1
          DEFB  $0C          ; Error Report: BREAK - CONT repeats

; ---

; Continue here if using lower display - A holds line number.

PO_SCR_4  CP     $02          ; is line number less than 2 ?
          JR     C,REPORT_5b  ; back, if so, to REPORT-5
                                ; 'Out of Screen'

          ADD   A,(IY+$31)    ; add DF_SZ
          SUB   $19          ; subtract twenty five.
          RET   NC           ; return if scrolling is unnecessary

          NEG                    ; Negate to give number of scrolls required.

          PUSH  BC           ; (*) save line/column
                                ; to prevent corruption by input AT

          LD   B,A           ; transfer count to B

;;;          LD   HL,($5B8F)  ; fetch current ATTR_T, MASK_T to HL.
;;;          PUSH HL          ; and save
;;;          LD   HL,($5B91)  ; fetch P_FLAG
;;;          PUSH HL          ; and save.

;;;          CALL TEMPs      ; routine TEMPs sets to BORDCR etc.

          LD   A,B           ; transfer scroll number to A.

PO_SCR_4A PUSH  AF           ; save scroll number.

; Now increment the lower screen display file size DF_SZ.
; Retain the old value in the B register as scroll count

```

```

LD HL,$5B6B ; address DF_SZ
LD B,(HL) ; fetch old value
LD A,B ; transfer to A
INC A ; and increment
LD (HL),A ; then put back.

;;; LD HL,$5B89 ; address S_POSN_hi - line

LD L,$89 ; address S_POSN_hi - line
CP (HL) ; compare DF_SZ to the line number.
JR C,PO_SCR_4B ; forward, if less, to PO-SCR-4B
; to scroll the lower screen only.

INC (HL) ; else increment S_POSN_hi the upper line value

;;; LD B,$18 ; set count to whole display ??
;;; ; Note. should be $17 (not $18) and the top
;;; ; line will be scrolled into the ROM which
;;; ; is harmless on the standard set up.
;;; ; credit: P. Giblin 1984.
LD B,$17 ;+

PO_SCR_4B CALL CL_SCROLL ; routine CL-SCROLL scrolls bottom B lines up.

POP AF ; restore the scroll counter.

DEC A ; decrease counter.
JR NZ,PO_SCR_4A ; back to PO-SCR-4A until done

;;; POP HL ; restore original P_FLAG.
;;; LD (IY+$57),L ; and overwrite system variable P_FLAG.

;;; POP HL ; restore original ATTR_T/MASK_T.
;;; LD ($5B8F),HL ; and update system variables.

LD BC,($5B88) ; fetch upper display line/column S_POSN to BC.

RES 0,(IY+$02) ; signal to TV_FLAG - main screen in use.

CALL CL_SET ; call routine CL-SET for upper display.

POP BC ; (*) restore lower line/column

SIG_L_SCR SET 0,(IY+$02) ; signal to TV_FLAG - lower screen in use.

RET ; return via CL-SET for lower display.

; -----
; THE 'SET TEMPORARY COLOUR ATTRIBUTES' ROUTINE
; -----
; This subroutine is called several times to copy the permanent colour items
; to the temporary ones.

TEMPS XOR A ; clear the accumulator
LD HL,($5B8D) ; fetch L = ATTR_P and H = MASK_P

BIT 0,(IY+$02) ; test TV_FLAG - is lower screen in use ?
JR Z,TEMPS_1 ; skip, if not lower screen, to TEMPS-1

LD H,A ; set H (MASK_P) to 00000000. (All bits show)
LD L,(IY+$0E) ; fetch BORDCR to L which is used for lower
; screen.

TEMPS_1 LD ($5B8F),HL ; update system variables ATTR_T and MASK_T

```



```

        LD    A,($5B8D)      ; fetch permanent attribute from ATTR_P.

        DEC   B              ; decrement lower screen display file size.

        JR    CLS_3         ; forward to enter the backfill loop at CLS-3
                          ; where B is decremented again.

; ---

;   The backfill loop is entered at midpoint and ensures, if more than 2
;   lines have been cleared, that any other lines take the permanent screen
;   attributes.

CLS_1   LD    C,$20        ; set counter to 32 character cells per line

CLS_2   DEC   HL          ; decrease attribute address.
        LD    (HL),A      ; and place attributes in next line up.
        DEC   C          ; decrease the 32 counter.
        JR    NZ,CLS_2    ; loop back to CLS-2 until all 32 cells done.

CLS_3   DJNZ  CLS_1       ; decrease B counter and back to CLS-1
                          ; if not zero.

        LD    (IY+$31),$02 ; now set DF_SZ lower screen to 2

;   This entry point is also called from CL-ALL below to
;   reset the system channel input and output addresses to normal should they
;   have been left in an unstable state while outputting or inputting colour
;   control codes.

CL_CHAN LD    A,$FD       ; select system channel 'K'

        CALL  CHAN_SLCT   ; routine CHAN-OPEN opens it.

;;;    LD    HL,($5B51)   ; fetch CURCHL to HL to address current channel
;;;    LD    DE,PRINT_OUT ; set address to 'PRINT-OUT' for first pass.
;;;    AND   A            ; clear carry for first pass.

        CALL  PO_NORM     ;+ routine embodies above two instructions.

;;; CL_CHAN_A LD    (HL),E ; Insert the output address on the first
pass
;;;    INC   HL          ; or the input address on the second pass.
;;;    LD    (HL),D      ;
;;;    INC   HL          ;

        LD    DE,KEY_INPUT ; fetch address 'KEY-INPUT' for second pass

        CALL  KEY_CH2     ;+ inserts values

;;;    CCF              ; complement carry flag - will set on pass 1.
;;;    JR    C,CL_CHAN_A ; back to CL-CHAN-A if first pass else done.

        LD    BC,$1721   ; line 23 for lower screen

        JR    CL_SET     ; exit via CL-SET to set column
                          ; for lower display

; -----
; THE 'CLEAR WHOLE DISPLAY' SUBROUTINE
; -----

;   This subroutine called from CLS, AUTO-LIST and MAIN-3, clears 24 lines of
;   the display and resets the relevant system variables. This routine also

```

```

; recovers from an error situation where, for instance, an invalid colour or
; position control code has left the output routine addressing PO-TV-2
; or PO-CONT.

```

```

CL_ALL  LD   HL,$0000      ; Initialize plot coordinates.
        LD   ($5B7D),HL   ; Set system variable COORDS to 0,0.

        RES  0,(IY+$30)   ; update FLAGS2 - signal main screen is clear.

        CALL CL_CHAN      ; routine CL-CHAN makes channel 'K' 'normal'.

;;;    LD   A,$FE         ; select system channel 'S'

        CALL CHAN_O_FE    ;+ routine CHAN-OPEN opens it calling TEMPs.

;;;    CALL TEMPs        ; routine TEMPs applies permanent attributes,
                        ; in this case ATTR_P, to ATTR_T.
                        ; Note. this seems unnecessary.

        LD   B,$18       ; There are 24 text lines to clear.

        CALL CL_LINE     ; routine CL-LINE clears 24 text lines and sets
                        ; attributes from ATTR-P.
                        ; This routine preserves B and sets C to $21.

;;;    LD   HL,($5B51)   ; fetch CURCHL make HL address output routine.

;;;    LD   DE,PRINT_OUT ; address: PRINT-OUT
;;;    LD   (HL),E       ; is made
;;;    INC  HL           ; the normal
;;;    LD   (HL),D       ; output address.
        CALL PO_NORM     ;+ make PRINT_OUT normal.

        LD   (IY+$52),$01 ; set SCR_CT - scroll count - to default.

```

```

; Note. BC already contains $1821.

```

```

;;;    LD   BC,$1821     ; reset column and line to 0,0
                        ; and continue into CL-SET, below, exiting
                        ; via PO-STORE (for the upper screen).

```

```

; -----
; THE 'CL-SET' ROUTINE
; -----

```

```

; This important subroutine is used to calculate the character output
; address for screens or printer based on the line/column for screens
; or the column for printer.

```

```

CL_SET  BIT   1,(IY+$01)   ; test FLAGS - is printer in use ?
        JR   NZ,CL_SET_2  ; forward, if so, to CL-SET-2

        LD   A,B         ; transfer line to A.
        BIT  0,(IY+$02)   ; test TV_FLAG - lower screen in use ?
        JR   Z,CL_SET_1  ; skip, if handling upper part, to CL-SET-1

        ADD  A,(IY+$31)   ; add DF_SZ for lower screen
        SUB  $18         ; and adjust.

CL_SET_1 PUSH  BC         ; save the line/column.
        LD   B,A         ; transfer line to B
                        ; (adjusted if lower screen)

        CALL CL_ADDR     ; routine CL-ADDR calculates HL address at left
                        ; of screen.

```

```

        POP    BC                ; restore the line/column.

CL_SET_2 LD    A,$21            ; the column $01-$21 is reversed
        SUB    C                ; to range $00 - $20
        LD    E,A              ; now transfer to DE
        LD    D,$00            ; prepare for addition
        ADD   HL,DE            ; and add to base address

        JP    PO_STORE         ; exit via PO-STORE
                                ; to update the relevant system variables.

; -----
; THE 'SCROLLING' SUBROUTINE
; -----
; The routine CL-SC-ALL is called once from PO to scroll all the display
; and from the routine CL-SCROLL, once, to scroll part of the display.

CL_SC_ALL LD    B,$17          ; scroll 23 lines, after 'scroll?'.

CL_SCROLL CALL  CL_ADDR        ; routine CL-ADDR gets screen address in HL.
        LD    C,$08            ; there are 8 pixel lines to scroll.

CL_SCR_1 PUSH  BC              ; save counters.
        PUSH HL                ; and initial address.

        LD    A,B              ; get line count.
        AND   $07              ; will set zero if all third to be scrolled.
        LD    A,B              ; re-fetch the line count.
        JR    NZ,CL_SCR_3      ; forward, if partial scroll, to CL-SCR-3

; Register HL points to top line of the third which must be copied to bottom
; line of the previous third.
; ( so HL = $4800 or $5000 )

CL_SCR_2 EX    DE,HL           ; transfer HL to DE.
        LD    HL,$F8E0         ; subtract $08 from H and add $E0 to L -
        ADD   HL,DE            ; to make destination bottom line of previous
                                ; third.
        EX    DE,HL           ; restore the source to HL and destination to DE
        LD    BC,$0020         ; thirty-two bytes are to be copied.

        DEC   A                ; decrement the line count.

        LDIR                    ; copy a pixel line to previous third.

CL_SCR_3 EX    DE,HL           ; save source in DE.
        LD    HL,$FFE0         ; load the value -32.
        ADD   HL,DE            ; add to form destination in HL.
        EX    DE,HL           ; switch source and destination

        LD    B,A              ; save the count in B.
        AND   $07              ; mask to find count applicable to current
                                ; third and
        RRCA                    ; multiply by
        RRCA                    ; multiply by
        RRCA                    ; thirty two (same as 5 RLCAs)

        LD    C,A              ; transfer byte count to C ($E0 at most)
        LD    A,B              ; store line count to A
        LD    B,$00            ; make B zero

        LDIR                    ; copy bytes (BC=0, H incremented, L=0)

        LD    B,$07            ; set B to 7, C is zero.
        ADD   HL,BC            ; add 7 to H to address next third.

```

```

AND    $F8                ; has last third been done ?
JR     NZ,CL_SCR_2        ; back, if not, to CL-SCR-2.

POP    HL                 ; restore topmost address.
INC    H                  ; next pixel line down.
POP    BC                 ; restore counts.
DEC    C                  ; reduce pixel line count.
JR     NZ,CL_SCR_1        ; back, if all eight not done, to CL-SCR-1

CALL   CL_ATTR            ; routine CL-ATTR gets address in attributes
                        ; from current 'ninth line' and count in BC.

LD     HL,$FFE0           ; set HL to the 16-bit value -32.
ADD    HL,DE              ; and add to form destination address.
EX     DE,HL              ; swap source and destination addresses.

LDIR                       ; copy bytes scrolling the linear attributes.

LD     B,$01              ; continue to clear the bottom line.

; -----
; THE 'CLEAR TEXT LINES' ROUTINE
; -----
; This subroutine, called from CL-ALL, CLS-LOWER and AUTO-LIST and above,
; clears text lines at bottom of display.
; The B register holds on entry the number of lines to be cleared 1-24.

CL_LINE  PUSH  BC          ; save line count

        CALL   CL_ADDR     ; routine CL-ADDR gets top address

        LD     C,$08        ; there are eight pixel lines to a text line.

CL_LINE_1  PUSH  BC          ; save pixel line count
           PUSH  HL          ; and save the screen address
           LD   A,B          ; transfer the line to A (1-24).

CL_LINE_2  AND   $07        ; mask 0-7 to consider thirds at a time
           RRCA              ; multiply
           RRCA              ; by 32 (same as five RLCA instructions)
           RRCA              ; now 32 - 256(0)
           LD   C,A          ; store result in C
           LD   A,B          ; save line in A (1-24)
           LD   B,$00        ; set high byte to 0, prepare for ldir.
           DEC  C            ; decrement count 31-255.
           LD   D,H          ; copy HL
           LD   E,L          ; to DE.

;;;      LD   (HL),0        ; blank the first byte.

           LD   (HL),B       ;+ blank the first byte. [ was LD (HL),0 ]

           INC  DE           ; make DE point to next byte.

           LDIR              ; block move will clear lines.

           LD   DE,$0701     ; now address next third adjusting
           ADD  HL,DE        ; register E to address left hand side.
           DEC  A            ; decrease the line count.
           AND  $F8          ; will be 16, 8 or 0 (AND $18 will do).
           LD   B,A          ; transfer count to B.
           JR   NZ,CL_LINE_2 ; back to CL-LINE-2 if 16 or 8 to do
                        ; the next third.

```

```

        POP    HL                ; restore start address.
        INC    H                 ; address next line down.
        POP    BC                ; fetch counts.
        DEC    C                 ; decrement pixel line count
        JR     NZ,CL_LINE_1      ; back to CL-LINE-1 till all done.

        CALL   CL_ATTR           ; routine CL_ATTR gets attribute address
                                   ; in DE and HL and B * 32 in BC.

;;;     LD     H,D               ; transfer the address
;;;     LD     L,E               ; to HL.

        INC    DE                ; make DE point to next location.

        LD     A,($5B8D)         ; fetch ATTR_P - permanent attributes
        BIT    0,(IY+$02)        ; test TV_FLAG - lower screen in use ?
        JR     Z,CL_LINE_3       ; skip, if not, to CL-LINE-3

        LD     A,($5B48)         ; else lower screen uses BORDCR as attribute.

CL_LINE_3 LD     (HL),A          ; put attribute in first byte.
          DEC    BC              ; decrement the counter.

          LDIR                   ; copy bytes to set all attributes.

          POP    BC              ; restore the line $01-$24.
          LD     C,$21           ; make column $21. (No use WAS made of this)
          RET                    ; return to the calling routine.

; -----
; THE 'ATTRIBUTE ADDRESS' ROUTINE
; -----
; This subroutine is called from CL-LINE or CL-SCROLL with the HL register
; pointing to the 'ninth' line and H needs to be decremented before or after
; the division. Had it been done first then either present code or that used
; at the start of PO-ATTR could have been used.
; The Spectrum screen arrangement leads to the L register already holding
; the correct value for the attribute file and it is only necessary
; to manipulate H to form the correct colour attribute address.

;;; CL_ATTR  LD     A,H          ; fetch H to A - $48, $50, or $58.
;;;          RRCA                ; divide by
;;;          RRCA                ; eight.
;;;          RRCA                ; $09, $0A or $0B.
;;;          DEC    A            ; $08, $09 or $0A.
;;;          OR     $50          ; $58, $59 or $5A.
;;;          LD     H,A          ; save high byte of attributes.

CL_ATTR   EX     DE,HL          ; transfer attribute address to DE

          LD     H,C            ; set H to zero - from last LDIR.
          LD     L,B            ; load L with the line from B.
          ADD    HL,HL          ; multiply
          ADD    HL,HL          ; by
          ADD    HL,HL          ; thirty two
          ADD    HL,HL          ; to give count of attribute
          ADD    HL,HL          ; cells to the end of display.

          LD     B,H            ; transfer the result
          LD     C,L            ; to register BC.

          EX     DE,HL          ; restore attribute address to HL
          DEC    H              ; decrease from ninth line to eighth.

```

```

CL_ATTR2 LD    A,H          ; fetch H to A - $47, $4F, or $57.

        RRCA          ; divide by      ???
        RRCA          ; eight.
        RRCA          ; $08, $09 or $0A.
        AND    $03     ; $00, $01 or $02.
        OR     $58     ; $58, $59 or $5A.
        LD     H,A     ; save high byte of attributes.

        LD     D,H     ;
        LD     E,L     ;

        RET          ; return.

; -----
; THE 'SCREEN ADDRESS' SUBROUTINE
; -----
; This subroutine is called from four places to calculate the address
; of the start of a screen character line which is supplied in B.

CL_ADDR LD    A,$18       ; reverse the line number
        SUB    B          ; to range $00 - $17.
        LD    D,A        ; save line in D for later.

        RRCA          ; multiply
        RRCA          ; by
        RRCA          ; thirty-two.

        AND    $E0       ; mask off low bits to make
        LD    L,A        ; register L a multiple of 32.

        LD    A,D        ; bring back the line to A.

        AND    $18       ; mask to form $00, $08 or $10.

        OR     $40       ; add $40 - the base address of screen.

        LD    H,A        ; HL now has the correct address.

        RET          ; return.

; -----
; THE NEW 'CHANNEL SPECIFIER' SUBROUTINE
; -----
; 10 bytes.
; This subroutine checks for a single character ALPHA.
; It is also now used by the usr_$ function to exploit similarities in
; the functional specification.

EXPT_SPEC CALL  STK_FETCH ; routine STK-FETCH to fetch and delete the
                        ; string parameters.
                        ; DE points to the start, BC holds the length.

        LD    A,C        ;
        DEC   A          ;
        OR    B          ;

        LD    A,(DE)     ; fetch character

        RET    Z        ; return with single character.

REPORT_Ae RST    30H     ; ERROR-1
          DEFB   $09     ; 'Invalid argument'

```

```

; -----
; THE NEW 'BC POSITIVE' SUBROUTINE
; -----
;

BC_POSTVE CALL  STK_TO_BC      ;

                LD   A,D        ; fetch sign $01 or $FF (negative)
                OR   E          ; combine both signs - $FF if either negative.
                INC  A          ;

                RET   NZ        ; Return if both positive.

REPORT_By RST   30H           ; ERROR-1
          DEFB  $0A           ; Error Report: Integer out of range

;
; Text for banner of CAT command
;

CAT1
          DEFB  $14,$01       ; Control codes for INVERSE 1
          DEFB  $CF          ; The ' CAT ' token.
          DEFB  $06          ; The 'comma control'
          DEFM  "Free "      ; Text.

CAT2
          DEFB  0,0          ; ballast

; -----
; THE 'COPY' COMMAND
; -----
; This command copies the top 176 lines to the ZX Printer
; It is popular to call this from machine code at point
; LOEAF with B holding 192 (and interrupts disabled) for a full-screen
; copy. This particularly applies to 16K Spectrums as time-critical
; machine code routines cannot be written in the first 16K of RAM as
; it is shared with the ULA which has precedence over the Z80 chip.

COPY      DI                ; disable interrupts as this is time-critical.

          LD   B,$B0         ; top 176 lines.
          LD   HL,$4000      ; address start of the display file.

; now enter a loop to handle each pixel line.

COPY_1    PUSH  HL          ; save the screen address.
          PUSH  BC          ; and the line counter.

          CALL  COPY_LINE   ; routine COPY-LINE outputs one line.

          POP   BC          ; restore the line counter.
          POP   HL          ; and display address.
          INC   H           ; next line down screen within 'thirds'.
          LD   A,H         ; high byte to A.
          AND  $07         ; result will be zero if we have left third.
          JR   NZ,COPY_2   ; forward to COPY-2 if not to continue loop.

          LD   A,L         ; consider low byte first.
          ADD  A,$20       ; increase by 32 - sets carry if back to zero.
          LD   L,A         ; will be next group of 8.
          CCF              ; complement - carry set if more lines in

```



```

; the previous third.
SBC   A,A           ; will be FF, if more, else 00.
AND   $F8          ; will be F8 (-8) or 00.
ADD   A,H           ; that is subtract 8, if more to do in third.
LD    H,A           ; and reset address.

COPY_2   DJNZ  COPY_1           ; back to COPY-1 for all lines.

COPY_END LD    A,$04           ;+ output value 4 to port
        OUT   ($FB),A         ;+ to stop the slowed printer motor.
        EI                      ;+ enable interrupts.

        RET                    ;+ return

; -----
; THE 'COPY BUFFER' SUBROUTINE
; -----
; This routine is used to copy 8 text lines from the printer buffer
; to the ZX Printer. These text lines are mapped linearly so HL does
; not need to be adjusted at the end of each line.
; The routine is invoked in two situations.
; 1) From PO-ENTER when a carriage return is received.
; 2) From PR-ALL when the column count C is reduced to zero.

COPY_BUFF DI                      ; Disable Interrupts

;;; LD    HL,$5B00           ; the old way.

        LD    HL,($5B51)      ;+ Address of Current Channel.
        LD    DE,$08         ;+ The offset to the 256 byte channel buffer.
        ADD   HL,DE          ;+

;;; LD    B,$08             ; set count to 8 lines of 32 bytes.

        LD    B,E            ; set count to 8 lines of 32 bytes.

COPY_3   PUSH  BC              ; save counter.

        CALL  COPY_LINE      ; routine COPY-LINE outputs 32 bytes

        POP   BC              ; restore counter.
        DJNZ  COPY_3         ; loop back to COPY-3 for all 8 lines.
; then stop motor and clear buffer.

;;; COPY_4 LD    A,$04       ; output value 4 to port
;;;          OUT   ($FB),A   ; to stop the slowed printer motor.
;;;          EI                      ; enable interrupts.

COPY_4   CALL  COPY_END       ;+

; -----
; THE 'CLEAR PRINTER BUFFER' SUBROUTINE
; -----
; This routine clears an arbitrary 256 bytes of memory.
; Note. The routine seems designed to clear a buffer that follows the
; system variables.
; The routine should check a flag or HL address and simply return if COPY
; is in use.
; As a consequence of this omission the buffer was needlessly
; cleared when COPY was used and the screen/printer position was set to
; the start of the buffer and the line number to 0 (B)
; giving an 'Out of Screen' error.

CLEAR_PRB LD    HL,($5B51)      ;+ address of Current Channel.

```

```

        LD     DE,$08          ;+ the offset to buffer.
        ADD    HL,DE          ;+ now points to start of 256 byte buffer.

;;;     LD     HL,$5B00       ; The old way.
;;;     LD     (IY+$46),L    ; update PR_CC_lo - set to zero - superfluous.

;;;     XOR    A              ; clear the accumulator.
        LD     B,D           ; set count to 256 bytes.

PRB_BYTES LD     (HL),D       ; set addressed location to zero.
        INC    HL            ; address next byte - Note. not INC L.
        DJNZ  PRB_BYTES     ; back to PRB-BYTES. repeat for 256 bytes.

;;;     RES    1,(IY+$30)    ; set FLAGS2 - signal printer buffer is clear.

        LD     C,$21        ; set the column position.

;;;     JP     CL_SET        ;

        DEC    H             ;+ Set pointer to start of buffer.
        JP     PO_STORE     ;+ exit to PO-STORE to store C only.

; Note. The correct value of HL is required for when COPY_BUFF is called at
; the start of PR_ALL.

; -----
; THE 'COPY LINE' SUBROUTINE
; -----
; This routine is called from COPY and COPY-BUFF to output a line of 32
; bytes to the ZX Printer.
; Output to port $FB -
; bit 7 set - activate stylus.
; bit 7 low - deactivate stylus.
; bit 2 set - stops printer.
; bit 2 reset - starts printer
; bit 1 set - slows printer.
; bit 1 reset - normal speed.
;
; The slowing of the printer ensures that the two stylies, attached to the
; motor-driven rubber belt, come to rest off the paper.

COPY_LINE LD     A,B         ; Fetch the counter 1-8 or 1-176
        CP     $03          ; Is it 01 or 02 ?.
        SBC    A,A         ; Result is $FF if so else $00.
        AND    $02         ; Result is 02 now else 00.
                                ; Bit 1 set slows the printer.
        OUT    ($FB),A     ; Slow the printer for the last two lines.

        LD     D,A         ; Save the mask to control the printer later.

COPY_L_1  CALL   BREAK_KEY  ; Call BREAK-KEY to read keyboard immediately.

        JR     C,COPY_L_2  ; Forward, if 'break' not pressed, to COPY-L-2

;;;     LD     A,$04        ; Stop the
;;;     OUT    ($FB),A     ; printer motor.
;;;     EI              ; Enable interrupts.

        CALL  COPY_END     ;+ Routine stops the motor and performs EI.

;;;     CALL  CLEAR_PRB    ; Call routine CLEAR-PRB.

; Now see if it is part of the fixed screen that is being copied.

```

```

        LD    A,H          ;+ Fetch high byte of address being copied.
        CP    $58         ;+ Is address less than attribute file ?

        CALL  NC,CLEAR_PRB ;+ If not call routine CLEAR-PRB.
                          ;+ Note. should not be cleared if COPY in use.

REPORT_Dc RST    30H      ; ERROR-1
          DEFB   $0C      ; Error Report: BREAK - CONT repeats

; ---

COPY_L_2  IN    A,($FB)   ; Test now to see if
          ADD   A,A       ; a printer is attached.
          RET   M         ; return if not - but continue with parent
                          ; command.

          JR    NC,COPY_L_1 ; back, if stylus not in position, to COPY-L-1

          LD    C,$20     ; set count to 32 bytes.

COPY_L_3  LD    E,(HL)    ; fetch a byte from line.
          INC  HL         ; address next location. Note. not INC L.
          LD    B,$08     ; count the bits.

COPY_L_4  RL    D         ; prepare mask to receive bit.
          RL    E         ; rotate leftmost print bit to carry
          RR    D         ; and back to bit 7 of D restoring bit 1

COPY_L_5  IN    A,($FB)   ; read the port.
          RRA          ; bit 0 to carry.
          JR    NC,COPY_L_5 ; back, if stylus not in position, to COPY-L-5

TAG5     LD    A,D        ; transfer command bits to A.
LOF24:   OUT   ($FB),A    ; and output to port.
          DJNZ  COPY_L_4  ; loop back, for all 8 bits, to COPY-L-4

          DEC  C          ; decrease the byte count.
          JR   NZ,COPY_L_3 ; back, until 256 bits done, to COPY-L-3

          RET           ; return to calling routine COPY/COPY-BUFF.

; -----
; THE 'EDITOR' ROUTINE
; -----
; The editor is called to prepare or edit a BASIC line.
; It is also called from INPUT to input a numeric or string expression or
; to input characters sent by a network station or serial device.
; The behaviour and options are quite different in the various modes
; and distinguished by bit 5 of FLAGX.
;
; This is a compact and highly versatile routine.

EDITOR   LD    HL,($5B3D) ; fetch ERR_SP
          PUSH HL        ; save on stack

ED_AGAIN LD    HL,ED_ERROR ; address: ED-ERROR
          PUSH HL        ; save address on stack and
          LD    ($5B3D),SP ; make ERR_SP point to it.

; Note. While in editing/input mode should an error occur then RST 08 will
; update X_PTR to the location reached by CH_ADD and jump to ED-ERROR
; where the error will be cancelled and the loop begin again from ED-AGAIN

```

```

; above. The position of the error will be apparent when the lower screen is
; reprinted. If no error then the re-iteration is to ED-LOOP below when
; input is arriving from the keyboard.

```

```

ED_LOOP  CALL  WAIT_KEY      ; routine WAIT-KEY gets key possibly changing
; the mode.
        PUSH  AF           ; save the key.

```

```

; Do we need to always click?

```

```

; ; ;
        LD   HL,$00C8      ; Give a short click.
        LD   D,$00        ;
        LD   D,H          ;+
        LD   E,(IY-$01)   ; Use PIP value for duration.
        CALL BEEPER       ; routine BEEPER gives click - effective
; with rubber keyboard.

```

```

        POP  AF           ; get saved key value.

```

```

        LD   HL,ED_LOOP   ; address: ED-LOOP is loaded to HL.
        PUSH HL           ; and pushed onto stack.

```

```

; At this point there is a looping return address on the stack, an error
; handler and an input stream set up to supply characters.
; The character that has been received can now be processed.

```

```

        CP   $18          ; range 24 to 255 ?
        JR   NC,ADD_CHAR  ; forward, if so, to ADD-CHAR.

```

```

; ; ;
        CP   $07          ; lower than 7 ?

```

```

        CP   $06          ;+ lower than 6 ?

```

```

        JR   C,ADD_CHAR   ; forward to ADD-CHAR also.
; Note. This is a 'bug' and chr$ 6, the comma
; control character, should have had an
; entry in the ED-KEYS table.
; Steven Vickers, 1984, Pitman.

```

```

        LD   BC,$0002     ; Prepare early for ink/paper etc.

```

```

        CP   $10          ; less than 16 decimal ?
        JR   C,ED_KEYS    ; forward to ED-KEYS ,if editing control in the
; range 6 to 15, as dealt with by a table.

```

```

; ; ;
        LD   BC,$0002     ; prepare for ink/paper etc.

```

```

        LD   D,A          ; save character in D
        CP   $16          ; is it ink/paper/bright etc. ?
        JR   C,ED_CONTR   ; forward, if so, to ED-CONTR

```

```

; leaves 22d AT and 23d TAB
; which can't be entered via KEY-INPUT.
; so this code is never normally executed
; when the keyboard is used for input.

```

```

        INC  BC           ; if it was AT/TAB - 3 locations required
        BIT  7,(IY+$37)   ; test FLAGX - Is this INPUT LINE ?
        JP   Z,ED_IGNORE  ; jump to ED-IGNORE if not, else

```

```

        CALL WAIT_KEY     ; routine WAIT-KEY - input address is KEY-NEXT
; but is reset to KEY-INPUT

```

```

        LD   E,A          ; save first in E

```

```

ED_CONTR CALL  WAIT_KEY   ; routine WAIT-KEY for control.

```

```

; input address will be key-next.

PUSH DE ; saved code/parameters
LD HL, ($5B5B) ; fetch address of keyboard cursor from K_CUR

RES 0, (IY+$07) ; allow MODE 'L' or 'G' cancelling 'E'

CALL MAKE_ROOM ; routine MAKE-ROOM makes 2/3 spaces at cursor

POP BC ; restore code/parameters
; ; ;
INC HL ; Address the first location
LD (HL), B ; place code (ink etc.)
INC HL ; address next
LD (HL), C ; place possible parameter. If only one
; then DE points to this location also.
JR ADD_CH_1 ; forward to ADD-CH-1

; -----
; THE 'ADD CHAR' SUBROUTINE
; -----
; This is the branch used to add normal non-control characters
; with ED-LOOP as the stacked return address.
;
; It is also the OUTPUT service routine for system channel 'R'.

ADD_CHAR RES 0, (IY+$07) ; allow MODE 'L' or 'G' cancelling 'E'

LD HL, ($5B5B) ; fetch address of keyboard cursor from K_CUR

LD BC, $0001 ; one space required
CALL MAKE_ROOM ; create space at K_CUR.

; ; ; CALL ONE_SPACE ; routine ONE_SPACE creates one space.

; Either a continuation of above or from ED-CONTR with ED-LOOP on stack.

ADD_CH_1 LD (DE), A ; load current character to last new location.
INC DE ; address next
LD ($5B5B), DE ; and update K_CUR system variable.

RET ; return - either a simple return
; from ADD-CHAR or to ED-LOOP on stack.

; -----
; THE 'ED KEYS' SECTION
; -----
; A branch of the editing loop to deal with control characters using a
; look-up table. On entry BC now holds $0002.

ED_KEYS LD E, A ; character to E.
; ; ; LD D, $00 ; prepare to add.
LD D, B ; prepare to add.

; ; ; LD HL, ED_KEYS_T -7 ; base address of editing keys table.

LD HL, ED_KEYS_T -6 ;+ NEW base address of editing keys table.

ADD HL, DE ; add E
LD E, (HL) ; fetch one-byte offset to E.
ADD HL, DE ; add offset for address of handling routine.
PUSH HL ; push the routine address on the machine stack.

LD HL, ($5B5B) ; load address of the cursor from K_CUR.

```

```

; New. carry results of next test into the routine to save performing
; the tests separately within the routines.

TST_INP_M BIT    5,(IY+$37)      ;+ Test FLAGX - INPUT mode ?

        RET                ; Make an indirect jump forward to routine.

; Note Zero flag determines mode, BC holds $0002.

; -----
; THE 'EDITING KEYS' TABLE
; -----
; For each code in the range $07 to $0F this table contains a single offset
; byte to the routine that services that code.
; Note. for the correct handling of comma-separated items, over the network,
; there should be an entry for CHR$6 with offset to ED-SYMBOL. Done.

ED_KEYS_T DEFB  ED_SYMBOL-$      ;+ 06d offset to Address: ED-SYMBOL
          DEFB  ED_EDIT -$       ; 07d offset to Address: ED-EDIT
          DEFB  ED_LEFT -$       ; 08d offset to Address: ED-LEFT
          DEFB  ED_RIGHT -$      ; 09d offset to Address: ED-RIGHT
          DEFB  ED_DOWN -$       ; 10d offset to Address: ED-DOWN
          DEFB  ED_UP -$        ; 11d offset to Address: ED-UP
          DEFB  ED_DELETE-$     ; 12d offset to Address: ED-DELETE
          DEFB  ED_ENTER -$      ; 13d offset to Address: ED-ENTER
          DEFB  ED_SYMBOL-$     ; 14d offset to Address: ED-SYMBOL
          DEFB  ED_GRAPH -$     ; 15d offset to Address: ED-GRAPH

; -----
; THE 'EDIT KEY' SUBROUTINE
; -----
; The user has pressed SHIFT 1 to bring edit line down to bottom of screen.
; Alternatively the user wishes to clear the input buffer and start again.
; Alternatively ...

ED_EDIT  LD      HL,($5B49)      ; fetch E_PPC the last line number entered.
          ; Note. may not exist and may follow program.

;;;

          BIT    5,(IY+$37)      ; test FLAGX - INPUT mode ?

          JR     NZ,CLEAR_SP     ; jump forward, if INPUT mode, to CLEAR-SP

          CALL  LINE_ADDR       ; routine LINE-ADDR to find address of line
          ; or following line if it doesn't exist.
          ; in DE.

          CALL  LINE_NO        ; routine LINE-NO will get line number from
          ; address or number of previous line if at the
          ; end-marker.

          LD    A,D             ; If there is no program then DE will
          OR    E               ; contain zero so test for this.

          JR     Z,CLEAR_SP     ; jump forward, if so, to CLEAR-SP

; Note. at this point we have a validated line number, not just an
; approximation and it would be best to update E_PPC with the true
; cursor line value which would enable the line cursor to be suppressed
; in all situations - see shortly.

          LD    ($5B49),DE      ;+ make E_PPC number the true line number.

          PUSH HL               ; save address of line.
          INC  HL               ; address low byte of length.
          LD   C,(HL)           ; transfer to C
          INC  HL               ; next to high byte

```

```

LD     B,(HL)           ; transfer to B.
LD     HL,$000A        ; an overhead of ten bytes
ADD    HL,BC           ; is added to length.
LD     B,H             ; transfer adjusted value
LD     C,L             ; to BC register.

CALL   TEST_ROOM      ; routine TEST-ROOM checks free memory.

CALL   CLEAR_SP       ; routine CLEAR-SP clears editing area.

LD     HL,($5B51)      ; address CURCHL
EX     (SP),HL        ; swap with line address on stack
PUSH   HL             ; save line address underneath

LD     A,$FF          ; select system channel 'R'
CALL   CHAN_SLCT     ; routine CHAN-OPEN opens it

POP    HL             ; drop line address
DEC    HL             ; make it point to first byte of line num.
DEC    (IY+$0F)       ; decrease E_PPC_lo to suppress line cursor.
; Note. ineffective when E_PPC is one
; greater than last line of program perhaps
; as a result of a delete.
; credit: Paul Harrison 1982.
; fixed above

CALL   OUT_LINE      ; routine OUT-LINE outputs the BASIC line
; to the editing area.
INC    (IY+$0F)       ; restore E_PPC_lo to the previous value.

LD     HL,($5B59)     ; address E_LINE in editing area.

INC    HL             ; advance
INC    HL             ; past space
INC    HL             ; and digit characters
INC    HL             ; of line number.

LD     ($5B5B),HL     ; update K_CUR to address start of BASIC.
REST_CHAN POP    HL   ; restore the address of CURCHL.

JP     CHAN_FLAG      ;+ routine CHAN-FLAG sets flags for it.

;;;      CALL   CHAN_FLAG      ; routine CHAN-FLAG sets flags for it.
;;;      RET     ; RETURN to ED-LOOP.

; -----
; THE 'CLEAR SPACE' SUBROUTINE
; -----
; The editing area or workspace is cleared depending on context.
; This is called from ED-EDIT to clear workspace if edit key is
; used during input, to clear editing area if no program exists
; and to clear editing area prior to copying the edit line to it.
; It is also used by the error routine to clear the respective
; area depending on FLAGX.

CLEAR_SP PUSH   HL    ; preserve HL throughout.

CALL   SET_HL        ; routine SET-HL
; if in edit  HL = WORKSP-1, DE = E_LINE
; if in input HL = STKBOT,  DE = WORKSP

DEC    HL            ; adjust

CALL   RECLAIM_1     ; routine RECLAIM-1 reclaims space setting BC

```

```

; to zero.

LD      ($5B5B),HL      ; set K_CUR to start of empty area.
;;;
LD      (IY+$07),$00    ; set MODE to 'KLC'

LD      (IY+$07),B      ;+ set MODE to 'KLC'

POP     HL               ; restore HL.
RET                                           ; return.

; -----
; THE 'CURSOR DOWN EDITING' SUBROUTINE
; -----
; The BASIC lines are displayed at the top of the screen and the user
; wishes to move the cursor down one line in edit mode.
; With INPUT LINE, this key must be used instead of entering STOP.

;;; ED_DOWN BIT 5, (IY+$37) ; test FLAGX - Input Mode ?

ED_DOWN JR    NZ,ED_STOP ; skip, if INPUT mode, to ED-STOP

LD      HL,$5B49        ; address E_PPC - 'current line'
CALL    LN_FETCH        ; routine LN-FETCH fetches number of next
                        ; line or same if at end of program.
JR      ED_LIST         ; forward to ED-LIST to produce an
                        ; automatic listing.

; ---

ED_STOP LD      (IY+$00),$10 ; set ERR_NR to 'STOP in INPUT' code
JR      ED_ENTER ; forward to ED-ENTER to produce error.

; -----
; THE 'CURSOR LEFT EDITING' SUBROUTINE
; -----
; This acts on the cursor in the lower section of the screen in both
; editing and input mode.

ED_LEFT CALL    ED_EDGE ; routine ED-EDGE moves left if possible
JR      ED_CUR ; forward to ED-CUR to update K-CUR
                        ; and return to ED-LOOP.

; -----
; THE 'CURSOR RIGHT EDITING' SUBROUTINE
; -----
; This acts on the cursor in the lower screen in both editing and input
; mode and moves it to the right.
; Note. The new code, suggested by Andrew Owen, avoids placing the cursor
; between a control code and its parameter.

ED_RIGHT LD      A,(HL) ; fetch addressed character.

CP      $0D ; is it carriage return ?
RET     Z ; return if so to ED-LOOP

INC     HL ; address next character

CP      $15 ;+ OVER or higher
JR      NC,ED_CUR ;+

CP      $0F ;+
JR      C,ED_CUR ;+

```



```

        INC    HL            ;+ Step over a control code parameter.
ED_CUR  LD     ($5B5B),HL   ; update K_CUR system variable
        RET                    ; return to ED-LOOP

; -----
; THE 'EDITING DELETE' SUBROUTINE
; -----
; This acts on the lower screen and deletes the character to left of
; cursor. If control characters are present these are deleted first
; leaving the naked parameter (0-7) which appears as a '?' except in the
; case of chr$ 6 which is the comma control character. It is not mandatory
; to delete these second characters.
; Note. the second method would delete both controls and their parameters.

ED_DELETE CALL ED_EDGE      ; routine ED-EDGE moves cursor to left
        LD    BC,$0001      ; of character to be deleted.
        JP    RECLAIM_2     ; to RECLAIM-2 reclaim the one character.

;;;     EX    DE,HL         ;
;;;     JP    RECLAIM_1     ;

; -----
; THE 'EDITING IGNORE' SUBROUTINE
; -----
; Since AT and TAB cannot be entered this point is never reached
; from the keyboard. If inputting from a tape device or network then
; the control and two following characters are ignored and processing
; continues as if a carriage return had been received.
; Here, perhaps, another Spectrum has said print #15; AT 0,0; "This is yellow"
; and this one is interpreting input #7; a$.

ED_IGNORE CALL WAIT_KEY     ; routine WAIT-KEY to ignore code.
        CALL WAIT_KEY       ; routine WAIT-KEY to ignore next code.

; -----
; THE 'EDITING ENTER KEY' SUBROUTINE
; -----
; The ENTER key has been pressed to have BASIC line or INPUT accepted.

ED_ENTER POP    HL          ; discard address ED-LOOP
        POP    HL          ; drop address ED-ERROR

ED_END  POP    HL          ; the previous value of ERR_SP
        LD    ($5B3D),HL   ; is restored to ERR_SP system variable
        BIT   7,(IY+$00)   ; is ERR_NR $FF ?
        RET   NZ           ; return if 'OK'

        LD    SP,HL        ; else put error routine on stack
        RET                    ; and make an indirect jump to it.

; -----
; THE 'ED-EDGE' SUBROUTINE
; -----
; This routine moves the cursor left. The complication is that it must
; not position the cursor between control codes and their parameters.
; It is further complicated in that it deals with TAB and AT characters
; which are never present from the keyboard.
; The method is to advance from the beginning of the line each time,
; jumping one, two, or three characters as necessary saving the original
; position at each jump in DE. Once it arrives at the cursor then the next

```

```

; legitimate leftmost position is in DE.

ED_EDGE   SCF           ; carry flag must be set to call the nested
          CALL  SET_DE  ; subroutine SET-DE.
          ; if input then DE=WORKSP
          ; if editing then DE=E_LINE
          SBC   HL,DE    ; subtract address from start of line
          ADD   HL,DE    ; and add back.
          INC   HL       ; adjust for carry.
          POP   BC       ; drop return address
          RET   C        ; return to ED-LOOP if already at left
          ; of line.

          PUSH  BC       ; resave return address - ED-LOOP.
          LD   B,H       ; transfer HL - cursor address
          LD   C,L       ; to BC register pair.
          ; at this point DE addresses start of line.

ED_EDGE_1 LD   H,D       ; transfer DE - leftmost pointer
          LD   L,E       ; to HL
          INC  HL        ; address next leftmost character to
          ; advance position each time.
          LD   A,(DE)    ; pick up previous in A
          AND  $F0       ; lose the low bits
          CP   $10       ; is it INK to TAB $10-$1F ?
          ; that is, is it followed by a parameter ?
          JR   NZ,ED_EDGE_2 ; forward, if not, to ED-EDGE-2
          ; HL has been incremented once

          INC  HL        ; address next as at least one parameter.

; In fact since 'tab' and 'at' cannot be entered the next section seems
; superfluous.
; The test will always fail and the jump to ED-EDGE-2 will be taken.
;
; However, as Vickers later revealed these can be encountered with the
; RS232 and Network.

          LD   A,(DE)    ; reload leftmost character
          SUB  $17       ; decimal 23 ('tab')
          ADC  A,$00     ; will be 0 for 'tab' and 'at'.
          JR   NZ,ED_EDGE_2 ; forward, if not, to ED-EDGE-2
          ; HL has been incremented twice

          INC  HL        ; increment a third time for 'at'/'tab'

ED_EDGE_2 AND  A        ; prepare for true subtraction
          SBC  HL,BC     ; subtract cursor address from pointer
          ADD  HL,BC     ; and add back
          ; Note when HL matches the cursor position BC,
          ; there is no carry and the previous
          ; position is in DE.
          EX  DE,HL     ; transfer result to DE if looping again.
          ; transfer DE to HL to be used as K-CUR
          ; if exiting loop.
          JR   C,ED_EDGE_1 ; back to ED-EDGE-1 if cursor not matched.

          RET           ; return.

; -----
; THE 'CURSOR UP EDITING' SUBROUTINE
; -----
; The main screen displays part of the BASIC program and the user wishes
; to move up one line scrolling if necessary.

```

```

; This has no alternative use in INPUT mode.

;;; ED_UP BIT 5,(IY+$37) ; test FLAGX - INPUT mode ?
ED_UP RET NZ ; return if in INPUT mode - to ED-LOOP.
LD HL,($5B49) ; get current line from E_PPC
CALL LINE_ADDR ; routine LINE-ADDR gets address
EX DE,HL ; and previous in DE
CALL LINE_NO ; routine LINE-NO gets prev line number
LD HL,$5B4A ; set HL to E_PPC_hi as next routine stores
; top first.
CALL LN_STORE ; routine LN-STORE loads DE value to HL
; high byte first - E_PPC_lo takes E

; this branch is also taken from ED_DOWN.

ED_LIST CALL AUTO_LIST ; routine AUTO-LIST lists to upper screen
; including adjusted current line.
;;; LD A,$00 ;- explicit - select lower screen again

CHAN_ZERO XOR A ;+ select lower screen again.
JP CHAN_SLCT ; exit via CHAN-OPEN to ED-LOOP

; -----
; THE 'symbol and graphics' CODES
; -----
; These will not be encountered with the keyboard but would be handled
; otherwise as follows.
; As noted earlier, Vickers says there should have been an entry in
; the KEYS table for chr$ 6 which also pointed here.
; If, for simplicity, two Spectrums were both using #15 as a directional
; channel connected to each other:-
; then, when the other Spectrum has said PRINT #15; 24, 7
; INPUT #15; x ; y would then treat the comma control as a newline and the
; control would skip to INPUT y.
; On the standard Spectrum, it was possible to get round the missing chr$ 6
; handler by sending multiple print items separated by a newline '.
; Otherwise the expression "24,7" would be assigned to the first variable x
; raising 'Nonsense in BASIC'.

; chr$14 would have the same functionality.

; This is chr$ 14.
ED_SYMBOL BIT 7,(IY+$37) ; test FLAGX - is this INPUT LINE ?
JR Z,ED_ENTER ; back, if not, to ED-ENTER
; to treat as if enter had been pressed
; else continue and add code to buffer.

; Next is chr$ 15
; Note that ADD-CHAR precedes the table so we can't offset to it directly.

ED_GRAPH JP ADD_CHAR ; jump back to ADD-CHAR

; -----
; THE 'ED_ERROR' ROUTINE
; -----
; If an error occurs while editing, or inputting, then ERR_SP
; points to the stack location holding address ED_ERROR.
; Note. this is specifically designed to deal with a BREAK into network input.

```

```

ED_ERROR BIT 4, (IY+$30) ; test FLAGS2 - is K channel in use ?
JR Z, ED_END ; back, if not, to ED-END

; but as long as we're editing lines or inputting from the keyboard, then
; we've run out of memory so give a short rasp.

;;; LD (IY+$00), $FF ; reset ERR_NR to 'OK'.
;;; LD D, $00 ; prepare for beeper.
;;; LD E, (IY-$02) ; use RASP value.
;;; LD HL, $1A90 ; set a duration.
;;; CALL BEEPER ; routine BEEPER emits a warning rasp.

CALL ED_RASP ;+ call the above code in new subroutine.

JP ED_AGAIN ; to ED-AGAIN to re-stack the address of
; this routine and make ERR_SP point to it.

; -----
; THE 'KEYBOARD INPUT' ROUTINE
; -----
; This is the service routine for the input stream of the keyboard channel
'K'.

KEY_INPUT BIT 3, (IY+$02) ; test TV_FLAG - has a key been pressed in
; editor ?

CALL NZ, ED_COPY ; routine ED-COPY, if so, to reprint the lower
; screen at every keystroke/mode change.

AND A ; clear carry flag - required exit condition.

;;; BIT 5, (IY+$01) ; test FLAGS - has a new key been pressed ?

LD HL, $5B3B ;+ Address system variable FLAGS
BIT 5, (HL) ;+ test FLAGS - has a new key been pressed ?

RET Z ; return if no key has been pressed. >>

; Continue if the interrupt routine has supplied a key.

LD A, ($5B08) ; system variable LASTK will hold last key -
; from the interrupt routine.

;;; RES 5, (IY+$01) ; update FLAGS - reset the new key flag.
RES 5, (HL) ; +update FLAGS - reset the new key flag.

;;; PUSH AF ; Save the input character.

; Now test if screen is to be cleared. after scroll?, Start tape, the
; copyright message or an error message.

BIT 5, (IY+$02) ; test TV_FLAG - clear lower screen ?

JR Z, KEY_CMP ;+ forward if not

BIT 3, (HL) ;+ is FLAGS set - L mode

PUSH AF ;+ Now save the input character.

;;; CALL NZ, CLS_LOWER ;
CALL CLS_LOWER ;+ routine CLS-LOWER.

```



```

SIG_KSTAT SET    3, (IY+$02)      ; update TV_FLAG - show key state has changed
              RET                    ; make the return.

; ---

;   now deal with colour controls - 16-23 ink, 24-31 paper

KEY_CONTR LD     B,A              ; make a copy of character.
          AND    $07              ; mask to leave bits 0-7
          LD     C,A              ; and store in C.
          LD     A,$10            ; initialize to 16d - INK.
          BIT   3,B              ; was it paper ?
          JR    NZ,KEY_DATA       ; forward to KEY-DATA with INK 16d and
                                ; colour in C.

          INC   A                ; else change from INK to PAPER (17d)

KEY_DATA LD     (IY-$2D),C        ; put the colour (0-7)/state(0/1) in KDATA
          LD     DE,KEY_NEXT      ; address: KEY-NEXT will be next input stream
          JR    KEY_CHAN         ; forward to KEY-CHAN to change it ...

; ---

; ... so that INPUT_AD directs control to here at next call to WAIT-KEY

KEY_NEXT LD     A, ($5B0D)        ; pick up the parameter stored in KDATA.
          LD     DE,KEY_INPUT     ; address: KEY-INPUT will be next input stream
                                ; continue to restore default channel and
                                ; make a return with the control code.

KEY_CHAN LD     HL, ($5B4F)       ; address start of CHANNELS area using CHANS
                                ; system variable.
          INC   HL                ; step over the
KEY_CH2  INC   HL                ; output address
          LD     (HL),E           ; and update the input
          INC   HL                ; routine address for
          LD     (HL),D           ; the next call to WAIT-KEY.

KEY_DONE2 SCF                    ; set carry flag to show a key has been found
          RET                    ; Return.

; -----
; THE 'LOWER SCREEN COPYING' ROUTINE
; -----
;   This subroutine is called whenever the line in the editing area or
;   input workspace is required to be printed to the lower screen.
;   It is by calling this routine after any change that the cursor, for
;   instance, appears to move to the left.
;   Remember the edit line will contain characters and tokens
;   e.g. "1000 LET a=1" is 8 characters.
;   It may also contain embedded colour control codes.

ED_COPY  CALL   TEMPS            ;.routine TEMPS sets temporary attributes.

          RES   3, (IY+$02)       ; update TV_FLAG - signal no change in mode
          RES   5, (IY+$02)       ; update TV_FLAG - signal don't clear lower
                                ; screen.
          LD   HL, ($5B8A)        ; fetch SPOSNL
          PUSH HL                 ; and save on stack.

          LD   HL, ($5B3D)        ; fetch ERR_SP
          PUSH HL                 ; and save also

```

```

LD    HL,ED_FULLL      ; address: ED-FULL
PUSH  HL               ; is pushed as the error routine

LD    ($5B3D),SP       ; and ERR_SP made to point to it.

LD    HL,($5B82)       ; fetch ECHO_E
PUSH  HL               ; and push also

SCF                    ; set carry flag to control SET-DE
CALL  SET_DE           ; call routine SET-DE
                        ; if in input DE = WORKSP
                        ; if in edit  DE = E_LINE
EX    DE,HL            ; start address to HL

CALL  OUT_LINE2        ; routine OUT-LINE2 outputs entire line up to
                        ; carriage return including initial
                        ; characterized line number when present.
EX    DE,HL            ; transfer new address to DE
CALL  OUT_CURS         ; routine OUT-CURS considers a
                        ; terminating cursor.

LD    HL,($5B8A)       ; fetch updated SPOSNL
EX    (SP),HL          ; exchange with ECHO_E on stack
EX    DE,HL            ; transfer ECHO_E to DE

CALL  TEMPS            ;.routine TEMPS to re-set attributes if altered.

;   the lower screen was not cleared, at the outset, so if deleting then old
;   text from a previous print may follow this line and requires blanking.

ED_BLANK LD    A,($5B8B) ; fetch SPOSNL_hi is current line
SUB      D             ; compare with old
JR      C,ED_C_DONE   ; forward to ED-C-DONE if no blanking

JR      NZ,ED_SPACES  ; forward to ED-SPACES if line has changed

LD      A,E            ; old column to A
SUB     (IY+$50)       ; subtract new in SPOSNL_lo
JR      NC,ED_C_DONE  ; forward to ED-C-DONE if no backfilling.

ED_SPACES LD    A,$20  ; prepare a space.
PUSH    DE             ; save old line/column.

CALL    PRINT_OUT     ; routine PRINT-OUT prints a space over
                        ; any text from previous print.
                        ; Note. Since the blanking only occurs when
                        ; using PRINT_OUT to print to the lower screen,
                        ; there is no need to vector via a RST 10
                        ; and we can use this alternate set.

POP     DE             ; restore the old line column.
JR      ED_BLANK      ; back to ED-BLANK until all old text blanked.

; -----
; THE 'EDITOR-FULL' ERROR ROUTINE
; -----
;   This is the error routine addressed by ERR_SP.  This is not for the out of
;   memory situation as we're just printing.  The pitch and duration are exactly
;   the same as used by ED-ERROR from which this has been augmented.  The
;   situation is that the lower screen is full and a rasp is given to suggest
;   that to continue would perhaps not be the best idea you've had that day.

;;; ED_FULL  LD    D,$00      ; prepare to moan.
;;;         LD    E,(IY-$02)  ; fetch RASP value.

```

```

;;;      LD      HL,$1A90      ; set duration.

;;;      CALL    BEEPER        ; routine BEEPER.

;;;      LD      (IY+$00),$FF  ; clear ERR_NR.

ED_FULLL  CALL    ED_RASP      ;+ call the above code in new subroutine.

          LD      DE,($5B8A)    ; fetch SPOSNL.
          JR      ED_C_END      ; forward to ED-C-END

; -----
; THE NEW 'ED_RASP' SUBROUTINE
; -----

ED_RASP   LD      D,$00        ;+ prepare to moan.
          LD      E,(IY-$02)    ;+ fetch RASP value.

          LD      HL,$1A90      ;+ set duration.

          CALL    BEEPER        ;+ routine BEEPER.

SET_ER_FF LD      (IY+$00),$FF ;+ clear ERR_NR.

          RET                    ;+

; -----

; the exit point from line printing continues here.

ED_C_DONE POP     DE           ; fetch new line/column.
          POP     HL           ; fetch the error address.

; the error path rejoins here.

ED_C_END  POP     HL           ; restore the old value of ERR_SP.
          LD      ($5B3D),HL    ; update the system variable ERR_SP

          POP     BC           ; old value of SPOSN_L
          PUSH    DE           ; save new value

          CALL    CL_SET       ; routine CL-SET and PO-STORE update ECHO_E
                                ; and SPOSN_L from BC ( and sets D to zero)

          POP     HL           ; restore new value
          LD      ($5B82),HL    ; and overwrite ECHO_E

;;;      LD      (IY+$26),$00   ; make error pointer X_PTR_hi out of bounds

          LD      (IY+$26),D    ;+ make error pointer X_PTR_hi out of bounds

          RET                    ; return

; -----
; Point to first and last locations of work space
; -----
; These two nested routines ensure that the appropriate pointers are
; selected for the editing area or workspace. The routines that call
; these routines are designed to work on either area.

; this routine is called once

```



```

SET_HL   LD    HL,($5B61)      ; fetch WORKSP to HL.
        DEC   HL              ; point to last location of editing area.
        AND   A               ; clear carry to limit exit points to first
        ; or last.

```

```

; this routine is called with carry set and exits at a conditional return.

```

```

SET_DE   LD    DE,($5B59)      ; fetch E_LINE to DE
;;      BIT    5,(IY+$37)      ; test FLAGX - Input Mode ?
        CALL  TST_INP_M       ;+ bit 5,(iy+$37) as a 3-byte call.
        RET    Z              ; return now if in editing mode

        LD    DE,($5B61)      ; fetch WORKSP to DE
        RET    C              ; return if carry set ( entry = set-de)

        LD    HL,($5B63)      ; fetch STKBOT to HL as well
        RET                    ; and return (entry = set-hl (in input))

```

```

; -----
; THE 'REMOVE FLOATING POINT' ROUTINE
; -----

```

```

; When a BASIC LINE or the INPUT BUFFER is parsed any numbers will have
; an invisible chr 14d inserted after them and the 5-byte integer or
; floating point form inserted after that. Similar invisible value holders
; are also created after the numeric and string variables in a DEF FN list.
; This routine removes these 'compiled' numbers starting at a point in the
; edit line or input workspace.

```

```

REMOVE_FP LD    A,(HL)        ; fetch character
        CP    $0E             ; is it the CHR$ 14 number marker ?
        LD    BC,$0006        ; prepare to strip six bytes

        CALL  Z,RECLAIM_2     ; routine RECLAIM-2 reclaims bytes if CHR$ 14.

        LD    A,(HL)         ; reload next (or same) character
        INC   HL              ; and advance address
        CP    $0D             ; end of the line or the input buffer ?
        JR    NZ,REMOVE_FP    ; back to REMOVE-FP until entire line done.

        RET                    ; return.

```

```

; *****
; ** Part 6. EXECUTIVE ROUTINES **
; *****

```

```

; The memory.

```

```

;
; +-----+-----+-----+-----+-----+
; | BASIC   | Display | Attributes | System   |
; | ROM     | File    | File      | Variables |
; +-----+-----+-----+-----+
; | ^       | ^       | ^         | ^         |
; | $0000  | $4000  | $5800     | $5B00     | $5BC8 = CHANS
;
;
; -+-----+-----+-----+-----+-----+
; | Channel |$80| BASIC | Variables |$80| Edit Line |NL|$80|
; | Info   | | Program | Area   | | or Command | | |
; -+-----+-----+-----+-----+-----+
; | ^       | ^       | ^         | ^         | ^         |
; | CHANS   | PROG    | VARS      | E_LINE    | WORKSP
;

```

```

;
;
;          ---5-->          <---2--- <---3---
;  +-----+-----+-----+-----+-----+-----+-----+-----+
;  | INPUT |NL| Temporary | Calc. | Spare | Machine | GO SUB |?|$3E| UDGs |
;  | data  |  | Work Space | Stack |      | Stack  | Stack  |  |  |      |
;  +-----+-----+-----+-----+-----+-----+-----+-----+
;  ^                ^         ^         ^                ^     ^     ^
; WORKSP                STKBOT STKEND  sp                RAMTOP UDG  P_RAMT
;

```

```

; -----
; THE 'NEW' COMMAND
; -----

```

```

; The NEW command is about to set all RAM below RAMTOP to zero and then
; re-initialize the system. All RAM above RAMTOP should, and will be,
; preserved.
; There is nowhere to store values in RAM or on the stack which becomes
; inoperable. Similarly PUSH and CALL instructions cannot be used to store
; values or section common code. The alternate register set is the only place
; available to store 3 persistent 16-bit system variables.

```

```

NEW      DI                ; Disable Interrupts - machine stack will be
; cleared.
        LD    A,$FF        ; Flag coming from NEW.
        LD    DE,($5BB2)   ; Fetch RAMTOP as top value.
        EXX                ; Switch in alternate set.
        LD    BC,($5BB4)   ; Fetch P-RAMT differs on 16K/48K machines.
        LD    DE,($5B38)   ; Fetch RASP/PIP.
        LD    HL,($5B7B)   ; Fetch UDG differs on 16K/48K machines.
        EXX                ; Switch back to main set and continue into...

```

```

; -----
; THE 'START-NEW' BRANCH
; -----

```

```

; This branch is taken from above and from RST 00h.
; The common code tests RAM and sets it to zero re-initializing all the
; non-zero system variables and channel information. The A register flags
; if coming from START or NEW.

```

```

START_NEW LD    B,A        ; Save the flag to control later branching.
        LD    A,$07        ; Select a white border
        OUT   ($FE),A      ; and set it now by writing to a port.
        LD    A,$3F        ; Load the accumulator with last page in ROM.
        LD    I,A          ; Set the I register - this remains constant
; and can't be in the range $40 - $7F as 'snow'
; appears on the screen.

```

```

;;;     NOP                ; These seem unnecessary.
;;;     NOP                ;
;;;     NOP                ; Ho Ho Hum.
;;;     NOP                ;
;;;     NOP                ; Reset the network probably.
;;;     NOP                ;

```

```

; -----
; THE 'RAM CHECK' SECTION
; -----

```

```

; Typically, a Spectrum will have 16K or 48K of RAM and this code will test
; it all until it finds an unpopulated location or, less likely, a faulty
; location. Usually it stops when it reaches the top $FFFF, or in the case
; of NEW the supplied top value. The entire screen turns black with
; sometimes red stripes on black paper just visible.

```

```

ram_check LD    H,D          ; Transfer the top value to the HL register
          LD    L,E          ; pair.

RAM_FILL LD    (HL), $02     ; Load memory with $02 - red ink on black paper.
          DEC   HL           ; Decrement memory address.
          CP    H            ; Have we reached ROM - $3F ?
          JR    NZ, RAM_FILL ; Back, if not, to RAM-FILL

RAM_READ AND    A           ; Clear carry - prepare to subtract.
          SBC   HL, DE       ; subtract and add back setting
          ADD   HL, DE       ; carry when back at start.
          INC   HL           ; and increment for next iteration.
          JR    NC, RAM_DONE ; forward to RAM-DONE if we've got back to
                              ; starting point with no errors.

          DEC   (HL)         ; decrement to 1.
          JR    Z, RAM_DONE  ; forward to RAM-DONE if faulty.

          DEC   (HL)         ; decrement to zero.
          JR    Z, RAM_READ  ; back to RAM-READ if zero flag was set.

RAM_DONE DEC   HL           ; step back to last valid location.
          EXX                    ; regardless of state, set up possibly
                              ; stored system variables in case from NEW.
          LD    ($5BB4), BC   ; insert P-RAMT.
          LD    ($5B38), DE   ; insert RASP/PIP.
          LD    ($5B7B), HL   ; insert UDG.
          EXX                    ; switch in main set.
          INC   B             ; now test if we arrived here from NEW.
          JR    Z, RAM_SET    ; forward to RAM-SET if we did.

; this section applies to START only.

          LD    ($5BB4), HL   ; set P-RAMT to the highest working RAM
                              ; address.
          LD    DE, $3EAF     ; address of last byte of 'U' bitmap in ROM.
          LD    BC, $00A8     ; there are 21 user defined graphics.
          EX    DE, HL        ; switch pointers and make the UDGs a
          LDDR                    ; copy of the standard characters A - U.
          EX    DE, HL        ; switch the pointer to HL.
          INC   HL           ; update to start of 'A' in RAM.
          LD    ($5B7B), HL   ; make UDG system variable address the first
                              ; bitmap.
          DEC   HL           ; point at RAMTOP again.

;;;          LD    BC, $0040   ; without disturbing HL, set the values of
;;;          LD    ($5B38), BC ; the PIP and RASP system variables.
;;;          ; Note. PIP is already zero.

          INC   A             ;+ increment from $3F to $40.
          LD    ($5B38), A    ;+ set RASP only to sixty four.

; the NEW command path rejoins here.

RAM_SET LD    ($5BB2), HL    ; set system variable RAMTOP to HL.

; the NMI_ADD system variable points here by default to provide a Warm Reset.

NMI_PTR LD    HL, $3C00     ; "A seemingly strange place to set CHARS"
          LD    ($5B36), HL  ; Note. but it all makes sense now - see L0066.

          LD    HL, ($5BB2)  ; fetch RAMTOP to HL.

```

```

LD      (HL), $3E      ; top of user ram holds GO SUB end marker
                        ; an impossible line number - see RETURN.
                        ; no significance in the number $3E. On the
                        ; ZX80 and ZX81 $3F was used.

DEC     HL             ; followed by empty byte (not important).
LD      SP, HL        ; set up the machine stack pointer.
DEC     HL             ;
DEC     HL             ;
LD      ($5B3D), HL   ; ERR_SP is where the error pointer is
                        ; at moment empty - will take address MAIN-4
                        ; at the call preceding that address,
                        ; although interrupts and calls will make use
                        ; of this location in meantime.

IM      1             ; select interrupt mode 1.
LD      IY, $5B3A    ; set IY to ERR_NR. IY can reach all standard
                        ; system variables but shadow ROM system
                        ; variables will be mostly out of range.

EI                                     ; enable interrupts now that we have a stack.

;   At this point check to see if the NMI has been activated.

LD      A, ($5B50)    ;+ fetch high byte of CHANS_hi
AND     A             ;+ is it uninitialized?
JR      Z, SET_CHANS  ;+ forward if so as from NEW/START

;   else the NMI was activated and we don't want to lose the program.

LD      A, $03        ;+ prepare to reset streams 2,1 and 0.

CALL    NMI_STRMS    ;+ reset the streams - reclaiming any dynamic
                        ;+ buffers without incurring memory leaks.

LD      A, $1D        ;+ prepare the NMI error code.
JP      MAIN_G       ;+ forward to report NMI.

; ---

SET_CHANS

;;;   LD      HL, $5BB6      ; the old address of the channels

LD      HL, $5BC9      ;+ the address of the channels - now following
                        ;+ the system variables NTHCS.

LD      ($5B4F), HL   ; set the CHANS system variable.

LD      DE, INIT_CHAN ; address: init-chan in ROM.

;;;   LD      BC, $0015     ; there were 21 bytes of initial data.

LD      C, $10        ;+ there are [16] bytes of initial data in ROM.

EX      DE, HL        ; swap the pointers.
LDIR                                ; copy the bytes to RAM.

EX      DE, HL        ; swap pointers. HL points to program area.
DEC     HL            ; decrement address.
LD      ($5B57), HL   ; set DATADD to location before program area.
INC     HL            ; increment again.

LD      ($5B53), HL   ; set PROG the location where BASIC starts.

```



```

;;;      SET    1,(IY+$01)      ; update FLAGS - signal printer in use.
;;;      CALL   CLEAR_PRB      ; call routine CLEAR-PRB to initialize system
;;;                                     ; variables associated with printer.
;;;                                     ; The buffer is clear.

      LD      (IY+$31),$02      ; set DF_SZ the lower screen display size to
                                     ; two lines

      CALL   CLS                ; call routine CLS to set up system
                                     ; variables associated with screen and clear
                                     ; the screen and set attributes.

;;;      XOR    A                ; clear accumulator so that we can address

      LD      DE,COPYRIGHT-1    ; the message table directly.
      CALL   PO_MSG_0          ; routine PO-MSG puts
                                     ; '(c) 1982 Sinclair Research Ltd'
                                     ; at bottom of display.
;;;      SET    5,(IY+$02)      ; update TV_FLAG - signal lower screen will
;;;                                     ; require clearing.

      JR     MAIN_1            ; forward to MAIN-1

; -----
; THE 'MAIN EXECUTION' LOOP
; -----
; This is the Main Execution Loop within which control remains after
; initialization. It is entered for the first time at MAIN-1 and thereafter
; each iteration begins with an Automatic Listing. An 'automatic Listing' is
; one that appears without involving the LIST command, for example, when the
; user presses [ENTER] after an Error Report.

MAIN_EXEC LD      (IY+$31),$02    ; set DF_SZ lower screen display file size to
                                     ; two lines.
      CALL   AUTO_LIST          ; routine AUTO-LIST

; The Initial Entry Point.

MAIN_1  CALL   SET_MIN          ; routine SET-MIN clears work areas.

;;; MAIN_2 LD      A,$00          ;- explicit - select stream zero.

MAIN_2  CALL   CHAN_ZERO        ;+ routine CHAN_ZERO opens channel zero

MAIN_2b res     3,(iy+$02)        ;+ Gotcha! Signal no change in Mode.

      CALL   EDITOR            ; routine EDITOR is called.
                                     ; Note the above routine is where the Spectrum
                                     ; waits for user-interaction. Perhaps the
                                     ; most common input at this stage is LOAD "".

      CALL   LINE_SCAN         ; routine LINE-SCAN scans the User's input.

      BIT    7,(IY+$00)        ; test ERR_NR - will be $FF if syntax is OK.
      JR     NZ,MAIN_3         ; forward, if correct, to MAIN-3.

; Note. Now test if channel 'K' is in use

      BIT    4,(IY+$30)        ; test FLAGS2 - K channel in use ?
      JR     Z,MAIN_4         ; forward, if not, to MAIN-4

```

```

; Channel 'K' was in use so X_PTR will have been set.

    LD    HL,($5B59)      ; an editing error so address E_LINE.

    CALL  REMOVE_FP      ; routine REMOVE-FP removes the hidden
                        ; floating-point forms.

;;;    LD    (IY+$00),$FF  ; system variable ERR_NR is reset to 'OK'.

    CALL  SET_ER_FF      ;+ NEW 3-byte call

    JR    MAIN_2b        ; back to MAIN-2 to allow user to correct.

; ---

; The branch was here if syntax has passed test.

;;; MAIN_3    LD    HL,($5B59)      ; fetch the edit line address from E_LINE.
;;;          LD    ($5B5D),HL      ; system variable CH_ADD is set to first
;;;          ; character of edit line.
;;;          ; Note. the above two instructions are a
;;;          ; little inadequate.
;;;          ; They are repeated with a subtle difference
;;;          ; at the start of the next subroutine and
are
;;;          ; therefore not required above.

MAIN_3    CALL  E_LINE_NO      ; routine E-LINE-NO will fetch any line
                        ; number to BC if this is a program line.

    LD    A,B            ; test if the number of
    OR    C              ; the line is non-zero.
    JP    NZ,MAIN_ADD     ; jump forward to MAIN-ADD if so to add the
                        ; line to the BASIC program.

; Has the user just pressed the ENTER key ?

    RST   18H           ; GET-CHAR gets character addressed by CH_ADD.
    CP    $0D           ; is it a carriage return ?
    JR    Z,MAIN_EXEC   ; back, if so, to MAIN-EXEC
                        ; for an automatic listing.

; This must be a direct command.

    BIT   0,(IY+$30)     ; test FLAGS2 - clear the main screen ?

    CALL  NZ,CL_ALL      ; routine CL-ALL, if so, e.g. after listing.

    CALL  CLS_LOWER      ; routine CLS-LOWER anyway.

    LD    A,$19         ; compute scroll count as twenty five
    SUB   (IY+$4F)      ; minus the value of S_POSN_hi.
    LD    ($5B8C),A     ; update SCR_CT system variable.

    SET   7,(IY+$01)    ; update FLAGS - signal running program.

;;;    LD    (IY+$00),$FF  ; set ERR_NR to 'OK'.
    CALL  SET_ER_FF      ;+ NEW 3-byte call

    LD    (IY+$0A),$01  ; set NSPPC to one for first statement.

    CALL  LINE_RUN      ; call routine LINE-RUN to run the line.
                        ; sysvar ERR_SP therefore addresses MAIN-4

```

```

; Examples of direct commands are RUN, CLS, LOAD "", PRINT USR 40000,
; LPRINT "A"; etc.
; Also, OPEN #0,"n";2 which allows another Spectrum to take control of this
; one.
; If a user written machine-code program disables interrupts then it
; must enable them to pass the next step. We also jumped to here if the
; keyboard was not being used.

```

```

MAIN_4   HALT                ; wait for interrupt the only routine that can
        RES    5,(IY+$01)    ; set bit 5 of FLAGS.
        ; reset bit 5 of FLAGS - signal no new key.

;;;     BIT    1,(IY+$30)    ; test FLAGS2 - is printer buffer clear ?
;;;     CALL   NZ,COPY_BUFF  ; call routine COPY-BUFF if not empty.
;;;     ; Note. the programmer has neglected
;;;     ; to set bit 1 of FLAGS first.

        LD    A,($5B3A)     ; fetch ERR_NR
        INC   A             ; increment to give true code.

```

```

; Now deal with a runtime error as opposed to an editing error.
; However if the error code is now zero then the OK message will be printed.

```

```

MAIN_G   PUSH   AF          ; save the error number.

;;;     LD    HL,$0000      ; prepare to clear some system variables.
;;;     LD    (IY+$37),H    ; clear all the bits of FLAGX.
;;;     LD    (IY+$26),H    ; blank X_PTR_hi to suppress error marker.
;;;     LD    ($5B0B),HL    ; blank DEFADD to signal that no defined
;;;     ; function is currently being evaluated.

        XOR   A            ; Set accumulator to zero
        LD    (IY+$37),A    ; clear all the bits of FLAGX.
        LD    (IY+$26),A    ; blank X_PTR_hi to suppress error marker.
        LD    (IY+$2E),A    ; blank DEFADD_hi to signal inactive.

;;;     LD    HL,$0001      ; prepare stream data.

;;;     LD    ($5B16),HL    ; ensure STRMS-00 is the keyboard.
;;;     ; and not the network as would have been set
;;;     ; by OPEN #0, "n" ; 2

        CALL  SET_MIN      ; routine SET-MIN clears workspace etc.

;;;     RES    5,(IY+$37)    ; update FLAGX - signal in EDIT not INPUT mode.
;;;     ; Note. all the bits were reset earlier.

        CALL  CLS_LOWER    ; call routine CLS-LOWER.

;;;     SET    5,(IY+$02)    ; update TV_FLAG - signal lower screen
;;;     ; requires clearing.

        POP   AF           ; bring back the true error number

        LD    B,A          ; and make a copy in B.
        CP    $0A         ; is it a print-ready digit ?

        JR    C,MAIN_5     ; forward, if so, to MAIN-5

        ADD   A,$07        ; add ASCII offset to letters.

MAIN_5   CALL  OUT_CODE    ; call routine OUT-CODE to print the code.

        LD    A,$20        ; followed by a space.

```



```

RST 10H ; PRINT-A

LD A,B ; fetch stored report code.
LD DE,rpt_mesgs ; address: rpt-mesgs.

CALL PO_MSG_1 ; call routine PO-MSG to print the message.

;;;
XOR A ; clear accumulator to directly
;;; LD DE,comma_sp -1 ; address the comma and space message.
;;; CALL PO_MSG_0 ; routine PO-MSG prints ', ' although it would
;;; ; be more succinct to use RST $10.

LD A,', ' ;+ comma
RST 10H ;+ print
LD A,' ' ;+ space
RST 10H ;+ print

LD BC,($5B45) ; fetch PPC the current line number.
CALL OUT_NUM_1 ; routine OUT-NUM-1 will print that

LD A,$3A ; then a ':' character.
RST 10H ; PRINT-A

LD C,(IY+$0D) ; then SUBPPC for statement

;;; LD B,$00 ; limited to 127
CALL OUT_NUM_0 ; routine OUT-NUM-0 prints C.

CALL CLEAR_SP ; routine CLEAR-SP clears editing area which
; probably contained 'RUN'. (B = 0)

LD A,($5B3A) ; fetch ERR_NR again
INC A ; test for no error originally $FF.
JR Z,MAIN_9 ; forward, if no error, to MAIN-9

CP $09 ; is code Report 9 STOP ?
JR Z,MAIN_6 ; forward, if so, to MAIN-6

CP $15 ; is code Report L BREAK ?
JR NZ,MAIN_7 ; forward, if so, to MAIN-7

; Stop or Break was encountered so consider CONTINUE.

MAIN_6 INC (IY+$0D) ; increment SUBPPC to next statement.

;;; MAIN_7 LD BC,$0003 ; prepare to copy 3 system variables to
MAIN_7 LD C,$03 ;+ prepare to copy 3 system variables to
LD DE,$5B70 ; ...address OSPPC - statement for CONTINUE.
; also updating OLDPPC line number below.

LD HL,$5B44 ; set source top to NSPPC next statement.
BIT 7,(HL) ; did BREAK occur before the jump ?
; e.g. between GO TO and next statement.
JR Z,MAIN_8 ; skip forward to MAIN-8, if not, as set-up
; is correct.

ADD HL,BC ; set source to SUBPPC number of current
; statement/line which will be repeated.

MAIN_8 LDDR ; copy PPC to OLDPPC and SUBPPC to OSPCC
; or NSPPC to OLDPPC and NEWPPC to OSPCC

```

```

MAIN_9  LD      (IY+$0A), $FF      ; update NSPPC - signal 'no jump'.

RES     3, (IY+$01)              ; update FLAGS - signal use 'K' mode for
                                ; the first character in the editor and

JP      MAIN_2                   ; jump back to MAIN-2.

; -----
; THE 'CANNED REPORT MESSAGES'
; -----
; The 30 Error reports with the last byte inverted.
; The first entry is a dummy entry. The last, which begins with $7F, the
; Spectrum character for copyright symbol, is placed here for convenience
; as is the preceding comma and space.
; The report line must accommodate a 4-digit line number and a 3-digit
; statement number which limits the length of the message text to twenty
; characters.
; e.g. "B RETURN without GOSUB, 1000:127" [ 32 characters ]

rpt_mesgs  DEFB  $80
            DEFB  'O','K'+$80          ; 0
            DEFM  'NEXT without FO"
            DEFB  'R'+$80              ; 1
            DEFM  "Variable not foun"
            DEFB  'd'+$80              ; 2
            DEFM  "Subscript wron"
            DEFB  'g'+$80              ; 3
            DEFM  "Out of memor"
            DEFB  'y'+$80              ; 4
            DEFM  "Out of scree"
            DEFB  'n'+$80              ; 5
            DEFM  "Number too bi"
            DEFB  'g'+$80              ; 6
            DEFM  "RETURN without GOSU"
            DEFB  'B'+$80              ; 7
            DEFM  "End of fil"
            DEFB  'e'+$80              ; 8
            DEFM  "STOP statemen"
            DEFB  't'+$80              ; 9
            DEFM  "Invalid argumen"
            DEFB  't'+$80              ; A
            DEFM  "Integer out of rang"
            DEFB  'e'+$80              ; B
            DEFM  "Nonsense in BASI"
            DEFB  'C'+$80              ; C
            DEFM  "BREAK - CONT repeat"
            DEFB  's'+$80              ; D
            DEFM  "Out of DAT"
            DEFB  'A'+$80              ; E
            DEFM  "Invalid file nam"
            DEFB  'e'+$80              ; F
            DEFM  "No room for lin"
            DEFB  'e'+$80              ; G
            DEFM  "STOP in INPU"
            DEFB  'T'+$80              ; H
            DEFM  "FOR without NEX"
            DEFB  'T'+$80              ; I
            DEFM  "Invalid I/O devic"
            DEFB  'e'+$80              ; J
            DEFM  "Invalid colou"
            DEFB  'r'+$80              ; K
            DEFM  "BREAK into progra"
            DEFB  'm'+$80              ; L

```

```

DEFM "RAMTOP no goo"
DEFB 'd'+$80 ; M
DEFM "Statement los"
DEFB 't'+$80 ; N
DEFM "Invalid strea"
DEFB 'm'+$80 ; O
DEFM "FN without DE"
DEFB 'F'+$80 ; P
DEFM "Parameter erro"
DEFB 'r'+$80 ; Q
DEFM "Loading erro"
DEFB 'r'+$80 ; R

DEFM "Stream close" ;+
DEFB 'd'+$80 ;+ S
DEFM "NM" ;+
DEFB 'I'+$80 ;+ T
DEFM "Net R/W erro" ;+
DEFB 'r'+$80 ;+ U

;;; comma_sp DEFB ',',' '+$80 ; used in report line.

COPYRIGHT DEFB $7F ; copyright
DEFM " 1982 Sinclair Research Ltd"
DEFB '.'+$80 ;+ just differentiate

; -----
; THE 'REPORT_G' ROUTINE
; -----
; Note ERR_SP points here during line entry which allows the normal
; 'Out of Memory' report to be augmented to the more precise 'No room for
; line' report. Since this can only occur as a result of a direct command,
; there is no need to record the X-PTR via the error restart.

; No room for line
REPORT_G LD A,$10 ; i.e. 'G' -$30 -$07

;;; LD BC,$0000 ; this seems unnecessary.

JP MAIN_G ; jump back to MAIN-G

; -----
; THE 'MAIN_ADD' SECTION
; -----
; Note this is not a subroutine but a branch of the main execution loop.
; System variable ERR_SP still points to editing error handler.
; A new line is added to the BASIC program at the appropriate place.
; An existing line with same number is deleted first.
; Entering an existing line number deletes that line.
; Entering a non-existent line allows the subsequent line to be edited next.

MAIN_ADD LD ($5B49),BC ; set E_PPC to extracted line number.
RST 18H ;;;;
;;; LD HL,($5B5D) ; fetch CH_ADD - points to location after the
; initial digits (set in E_LINE_NO).
EX DE,HL ; save start of BASIC in DE.

LD HL,REPORT_G ; Address: REPORT-G
PUSH HL ; is pushed on stack and addressed by ERR_SP.
; the only error that can occur is
; 'Out of memory'.

LD HL,($5B61) ; fetch WORKSP - end of line.

```

```

SCF                ; prepare for true subtraction.
SBC    HL,DE       ; find length of BASIC and
PUSH   HL          ; save it on stack.
LD     H,B         ; transfer line number
LD     L,C         ; to HL register.
CALL   LINE_ADDR  ; routine LINE-ADDR will see if
                ; a line with the same number exists.
JR     NZ,MAIN_ADD1 ; forward if no existing line to MAIN-ADD1.

;;;
CALL   NEXT_ONE   ; routine NEXT-ONE finds the existing line.
CALL   RECLAIM_2  ; routine RECLAIM-2 reclaims it.

CALL   NXT_1_RC2  ;+ routine combines above 2 routines.

MAIN_ADD1 POP      BC          ; retrieve the length of the new line.
LD      A,C       ; and test if a carriage return only
DEC     A         ; i.e. one byte long.
OR      B         ; result would be zero.
JR      Z,MAIN_ADD2 ; forward, if so, to MAIN-ADD2

PUSH   BC         ; save the length again.
INC    BC         ; adjust for inclusion
INC    BC         ; of line number (two bytes)
INC    BC         ; and line length
INC    BC         ; (two bytes).
;;;
DEC    HL         ; HL points to location before the destination

LD     DE,($5B53) ; fetch the address of PROG
PUSH   DE         ; and save it on the stack

CALL   MK_RM_DHL  ;+ MAKE_ROOM decrementing HL first

;;;
CALL   MAKE_ROOM  ; routine MAKE-ROOM creates BC spaces in
                ; program area and updates pointers.
POP    HL         ; restore old program pointer.
LD     ($5B53),HL ; and put back in PROG as it may have been
                ; altered by the POINTERS routine.

POP    BC         ; retrieve BASIC length
PUSH   BC         ; and save again.

INC    DE         ; points to end of new area.
LD     HL,($5B61) ; set HL to WORKSP - location after edit line.
DEC    HL         ; decrement to address end marker.
DEC    HL         ; decrement to address the carriage return.

LDDR                   ; copy the BASIC line back to initial command.

LD     HL,($5B49)    ; fetch E_PPC - line number.
EX     DE,HL        ; swap it to DE, HL points to last of
                ; four locations.

POP    BC           ; retrieve length of line.
LD     (HL),B       ; high byte last.
DEC    HL           ;
LD     (HL),C       ; then low byte of length.
DEC    HL           ;
LD     (HL),E       ; then low byte of line number.
DEC    HL           ;
LD     (HL),D       ; then high byte range $0 - $27 (1-9999).

MAIN_ADD2 POP      AF          ; drop the address of Report G

JP     MAIN_EXEC    ; and back to MAIN-EXEC producing a listing
                ; and to reset ERR_SP in EDITOR.

```

```

; -----
; THE 'INITIAL CHANNEL' INFORMATION
; -----
; This initial channel information is copied from ROM to RAM, during
; initialization. It's new location is after the system variables and is
; addressed by the system variable CHANS which means that it can slide up and
; down in memory. The table is never searched, by this ROM, and the last
; character, which could be anything other than a comma, provides a
; convenient resting place for DATADD.

```

```

INIT_CHAN DEFW PRINT_OUT      ; PRINT-OUT
          DEFW KEY_INPUT      ; KEY-INPUT
          DEFB $4B            ; 'K'
          DEFW PRINT_OUT      ; PRINT-OUT
          DEFW REPORT_J       ; REPORT-J
          DEFB $53            ; 'S'
          DEFW ADD_CHAR       ; ADD-CHAR
          DEFW REPORT_J       ; RAW_INPUT
          DEFB $52            ; 'R'

```

```

;;;      DEFW PRINT_OUT      ; PRINT-OUT
;;;      DEFW REPORT_J       ; REPORT-J
;;;      DEFB $50            ; 'P'

```

```

          DEFB $80            ; End Marker

```

```

REPORT_J  RST   30H           ; ERROR-1
          DEFB  $12           ; Error Report: Invalid I/O device

```

```

; -----
; THE 'INITIAL STREAM' DATA
; -----
; This is the initial stream data for the seven streams $FD - $03 that is
; copied from ROM to the STRMS system variables area during initialization.
; There are reserved locations there for another 12 streams. Each location
; contains an offset to the second byte of a channel. The first byte of a
; channel can't be used as that would result in an offset of zero for some
; and zero is used to denote that a stream is closed.

```

```

INIT_STRM DEFB $01, $00      ; stream $FD offset to channel 'K'
          DEFB $06, $00      ; stream $FE offset to channel 'S'
          DEFB $0B, $00      ; stream $FF offset to channel 'R'

```

```

          DEFB $01, $00      ; stream $00 offset to channel 'K'
          DEFB $01, $00      ; stream $01 offset to channel 'K'
          DEFB $06, $00      ; stream $02 offset to channel 'S'

```

```

;;;      DEFB $10, $00      ; stream $03 offset to channel 'P'

```

```

; -----
; THE 'INPUT CONTROL' SUBROUTINE
; -----
;

```

```

WAIT_KEY  BIT   5, (IY+$02)   ; test TV_FLAG - clear lower screen ?
          JR    NZ, WAIT_KEY1  ; forward, if so, to WAIT-KEY1

          SET   3, (IY+$02)   ; update TV_FLAG - signal reprint the edit
          ; line to the lower screen. SIG_KSTAT.

```

```

WAIT_KEY1 CALL INPUT_AD      ; routine INPUT-AD is called.

```

```

        RET    C                ; return with acceptable keys.

        JR     Z,WAIT_KEY1     ; back to WAIT-KEY1 if no key is pressed
                                ; or it has been handled within INPUT-AD.

; Note. When inputting from the keyboard all characters are returned with
; above conditions so this path is never normally taken.
; It is taken when 'Iris' closes her channel.

REPORT_8  RST    30H          ; ERROR-1
          DEFB   $07          ; Error Report: End of file

; -----
; THE 'INPUT ADDRESS' ROUTINE
; -----
; This routine fetches the address of the input stream from the current
; channel area using the system variable CURCHL.

INPUT_AD  EXX                ; switch in alternate set.
          PUSH   HL           ; save HL register

          LD     HL,($5B51)    ; fetch address of CURCHL - current channel.
          INC   HL            ; step over output routine
          INC   HL            ; to point to low byte of input routine.
          JR    CALL_SUB      ; forward to CALL-SUB.

; -----
; THE 'OUT CODE' ROUTINE
; -----
; This routine is called on five occasions to print the ASCII equivalent of
; a value 0-9.

OUT_CODE  LD     E,$30        ; add 48 decimal to give the ASCII character
          ADD   A,E           ; '0' to '9' and continue into the main output
                                ; routine.

; -----
; THE 'MAIN OUTPUT' ROUTINE
; -----
; The PRINT-A-2 is a continuation of the RST 10 restart that outputs any
; character. The routine prints to the current channel and the printing of
; control codes may alter that channel to divert subsequent RST 10
; instructions to temporary routines. The normal channel is PRINT_OUT.

PRINT_A_2 EXX                ; switch in alternate set
          PUSH   HL           ; save HL register
          LD     HL,($5B51)    ; fetch CURCHL the current channel.

; input-ad rejoins here also.

CALL_SUB  LD     E,(HL)       ; put the low byte in E.
          INC   HL            ; advance address.
          LD     D,(HL)       ; put the high byte to D.
          EX    DE,HL         ; transfer the stream to HL.

          CALL  CALL_JUMP     ; use routine CALL-JUMP in effect CALL (HL).

          POP   HL            ; restore saved HL register.
          EXX                ; switch back to the main set and
          RET                 ; return.

; ---

```

```

; Note. the most popular channel number could be placed here e.g. LD A,$FE

; -----
; THE 'OPEN CHANNEL 0xFE' ROUTINE
; -----

CHAN_O_FE LD    A,$FE          ;
          JR    CHAN_SLCT      ;

; -----
; THE 'OPEN CHANNEL SYNTAX' ROUTINE
; -----

CHN_O_SYN CALL UNSTACK_Z      ;+ Return if Checking Syntax.

; -----
; THE 'CHANNEL SELECT' ROUTINE
; -----
; This subroutine is used by the ROM to select a channel 'K', 'S', 'R' or 'P'.
; This is either for its own use or in response to a user's request, for
; example, when '#' is encountered with output - PRINT, LIST etc.
; or with input - INPUT, INKEY$ etc.
; It is entered with a system stream $FD - $FF, or a user stream $00 - $0F
; in the accumulator.

CHAN_SLCT ADD    A,A           ; double the stream ($FF will become $FE etc.)
          ADD    A,$16         ; add the offset to stream 0 from $5B00
          LD    L,A           ; result to L
          LD    H,$5B         ; now form the address in STRMS area.
          LD    E,(HL)        ; fetch low byte of CHANS offset
          INC   HL            ; address next
          LD    D,(HL)        ; fetch high byte of offset
          LD    A,D           ; test that the stream is open.
          OR    E             ; zero if closed.
          JP    Z,REPORT_O     ; forward if closed to report
                              ; 'Invalid stream'

;;;      JR    NZ,CHAN_OP_1    ; forward to CHAN-OP-1 if open.
;;; REPORT_Oa RST    30H       ; ERROR-1
;;;      DEFB $17             ; Error Report: Invalid stream

; continue here if stream was open. Note that the offset is from CHANS
; to the second byte of the channel.

CHAN_OP_1 DEC    DE           ; reduce offset so it points to the channel.
          LD    HL,($5B4F)    ; fetch CHANS the location of the base of
                              ; the channel information area
          ADD   HL,DE         ; and add the offset to address the channel.
                              ; and continue to set flags.

; -----
; THE 'CHANNEL FLAGS' SUBROUTINE
; -----
; This subroutine is used from ED-EDIT, str$ and read-in to reset the
; current channel when it has been temporarily altered.

CHAN_FLAG RES    4,(IY+$30)   ; update FLAGS2 - signal K channel not in use.
                              ; Note. provide a default for
                              ; channel 'R','S' and 'P'.
          LD    ($5B51),HL    ; set CURCHL system variable to the
                              ; address in HL
;;;      INC   HL            ; advance past
;;;      INC   HL            ; output routine.
;;;      INC   HL            ; advance past

```

```

;;;      INC    HL          ; input routine.
;;;      LD     C,(HL)      ; pick up the letter.

      CALL   IN_CHAN_K    ;+ routine gets channel letter in A.

      LD     HL,CHN_CD_LU-1 ; address: chn-cd-lu

      CALL   INDEXER_0    ; routine INDEXER finds offset to a
                          ; flag-setting routine.

      RET    NC           ; but if the letter wasn't found in the
                          ; table just return now. - channel 'R'.

;;;      LD     D,$00      ; prepare to add.
;;;      LD     E,(HL)     ; offset to E
;;;      ADD    HL,DE      ; add offset to location of offset to form
;;;                          ; address of routine

CALL_JUMP JP      (HL)    ; jump to the routine

; Footnote. calling any location that holds JP (HL) is the equivalent to
; a pseudo Z80 instruction CALL (HL). The ROM uses the instruction above.

; -----
; THE 'CHANNEL CODE LOOK-UP' TABLE
; -----
; This table is used by the routine above to find one of the three
; flag setting routines below it.
; A zero end-marker is required as channel 'R' is not present.

CHN_CD_LU DEFB 'K', CHAN_K-$-1 ; offset $06 to CHAN-K
          DEFB 'S', CHAN_S-$-1 ; offset $12 to CHAN-S
          DEFB 'P', CHAN_P-$-1 ; offset $1B to CHAN-P

          DEFB $00             ; end marker.

; -----
; THE 'CHANNEL K FLAG' ROUTINE
; -----
; routine to set flags for lower screen/keyboard channel.

CHAN_K
;;;      SET    0,(IY+$02)  ; update TV_FLAG - signal lower screen in use

      CALL   SIG_L_SCR    ;+ set 0,(iy+$02) as a 3-byte call.

      RES    5,(IY+$01)   ; update FLAGS - signal no new key ??

      SET    4,(IY+$30)   ; update FLAGS2 - signal K channel in use

      JR     CHAN_S_1     ; forward to CHAN-S-1 for indirect exit

; -----
; THE 'CHANNEL S FLAG' ROUTINE
; -----
; routine to set flags for upper screen channel.

CHAN_S   RES    0,(IY+$02) ; TV_FLAG - signal main screen in use

CHAN_S_1 RES    1,(IY+$01) ; update FLAGS - signal printer not in use

      JP     TEMPS        ; jump back to TEMPS and exit via that
                          ; routine after setting temporary attributes.

```



```

; -----
; THE 'CHANNEL P FLAG' ROUTINE
; -----
; This routine sets a flag so that subsequent print related commands
; print to printer or update the relevant system variables.
; This status remains in force until reset by the routine above.

CHAN_P   SET    1, (IY+$01)      ; update FLAGS - signal printer in use

        RET                                ; return

; -----
; THE 'ONE SPACE' SUBROUTINE
; -----
; This routine WAS called once only to create a single space
;;; ONE_SPACE LD    BC,$0001      ; create space for a single character.

MK_RM_EL LD    HL, ($5B59)      ; fetch E_LINE to HL.

MK_RM_DHL DEC   HL              ; point to location before.

; -----
; THE 'MAKE ROOM' ROUTINE
; -----
; This entry point is used to create BC spaces in various areas such as
; program area, variables area, workspace etc..
; The entire free RAM is available to each BASIC statement.
; On entry, HL addresses where the first location is to be created.
; Afterwards, HL will address this location.
; Note. It used to point to the location before this.

MAKE_ROOM PUSH  HL              ; save the address pointer.

        CALL TEST_ROOM          ; routine TEST-ROOM checks if room
                                ; exists and generates an error if not.
        POP   HL                ; restore the address pointer.

        CALL POINTERS           ; routine POINTERS updates the
                                ; dynamic memory location pointers.
                                ; DE now holds the old value of STKEND.

        LD    HL, ($5B65)       ; fetch new STKEND the top destination.

        EX   DE, HL             ; HL now addresses the top of the area to
                                ; be moved up - old STKEND.
        LDDR                                ; the program, variables, etc are moved up.

        INC  HL                 ;+ New - as suggested by James Smith.

        RET                                ; return with new area ready to be populated.

; Note. HL now points to first location of new area, and DE to last of new
; locations.

; -----
; THE 'POINTERS' SUBROUTINE
; -----
; This routine is called by MAKE-ROOM to adjust upwards and by RECLAIM to
; adjust downwards the pointers within dynamic memory.
; The fourteen pointers to dynamic memory, starting with VARS and ending
; with STKEND, are updated adding BC if they are higher than the position
; in HL.

```

```
; The system variables are in no particular order except that STKEND, the
; first free location after dynamic memory must be the last encountered.
```

```
POINTERS  PUSH  AF          ; preserve accumulator.
          PUSH  HL          ; put pos pointer on stack.

          LD   HL,$5B4B     ; address VARS the first of the
          LD   A,$0E       ; fourteen variables to consider.

PTR_NEXT  LD   E,(HL)      ; fetch the low byte of the system variable.
          INC  HL          ; advance address.
          LD   D,(HL)      ; fetch high byte of the system variable.
          EX   (SP),HL     ; swap pointer on stack with the variable
          ; pointer.
          AND  A          ; prepare to subtract.
          SBC  HL,DE       ; subtract variable address
          ADD  HL,DE       ; and add back
          EX   (SP),HL     ; swap pos with system variable pointer
          JR   NC,PTR_DONE ; forward, if var before pos, to PTR-DONE

          PUSH DE          ; save system variable address.
          EX   DE,HL       ; transfer to HL
          ADD  HL,BC       ; add the offset
          EX   DE,HL       ; back to DE
          LD   (HL),D      ; load high byte
          DEC  HL          ; move back
          LD   (HL),E      ; load low byte
          INC  HL          ; advance to high byte
          POP  DE          ; restore old system variable address.

PTR_DONE  INC  HL          ; address next system variable.
          DEC  A           ; decrease counter.
          JR   NZ,PTR_NEXT ; back, if more, to PTR-NEXT

          EX   DE,HL       ; transfer old value of STKEND to HL.
          ; Note. this has always been updated.
          POP  DE          ; pop the address of the position.

          POP  AF          ; pop preserved accumulator.
          AND  A           ; clear carry flag preparing to subtract.

          SBC  HL,DE       ; subtract position from old STKEND
          LD   B,H         ; to give number of data bytes
          LD   C,L         ; to be moved.
          INC  BC         ; increment as we also copy byte at old STKEND.
          ADD  HL,DE       ; recompute old STKEND.
          EX   DE,HL       ; transfer to DE.

          RET              ; return.
```

```
; -----
; THE 'COLLECT LINE NUMBER' SUBROUTINE
; -----
```

```
; This routine extracts a line number, at an address that has previously
; been found using LINE-ADDR, and it is entered at LINE-NO. If it encounters
; the program 'end-marker' then the previous line is used and if that
; should also be unacceptable then zero is used as it must be a direct
; command. The program end-marker is the variables end-marker $80, or
; if variables exist, then the first character of any variable name.
; Note. any two zero bytes in ROM will do for a line zero.
```

```
;;; LINE_ZERO DEFDB $00, $00 ; dummy line number used for direct commands
;;; ; Note. space character is now used instead.
```

```

LINE_NO_A EX    DE,HL          ; fetch the previous line to HL and set
              LD    DE,LINE_ZERO ; set DE to word zero pointer should HL also
                                      ; fail.

;   -> The Entry Point.

LINE_NO  LD    A,(HL)          ; fetch the high byte - max $2F
          AND   $C0             ; mask off the invalid bits.
          JR    NZ,LINE_NO_A   ; to LINE-NO-A if an end-marker.

          LD    D,(HL)          ; reload the high byte.
          INC   HL              ; advance address.
          LD    E,(HL)          ; pick up the low byte.
          RET                    ; return from here.

; -----
; THE 'CREATE BC SPACES' SUBROUTINES
; -----
;+ This was formerly a restart but is now called as a subroutine
;+ to free up the RST 30 for error handling.

BC_SPACE1 LD    C,1            ;+ Creates one space - the most popular option.

BC_SPACE0 LD    B,0            ;+ Only C need be specified.

BC_SPACES PUSH  BC             ; save number of spaces.
          LD    HL,($5B61)      ; fetch WORKSP.
          PUSH HL              ; save address of workspace.

RESERVE   LD    HL,($5B63)      ; STKBOT first location of calculator stack

          CALL  MK_RM_DHL       ;+ routine MAKE_ROOM adjusting HL

;;;      DEC    HL              ; make one less than new location
;;;      CALL  MAKE_ROOM        ; routine MAKE-ROOM creates the room.
;;;      INC    HL              ; address the first new location

          INC   HL              ; advance to second
          POP   BC              ; restore old WORKSP
          LD    ($5B61),BC      ; system variable WORKSP was perhaps
                                      ; changed by POINTERS routine.
          POP   BC              ; restore count for return value.
          EX   DE,HL           ; switch. DE = location after first new space
          INC   HL              ; HL now location after new space

          RET                    ; Return.

; -----
; THE 'SET MINIMUM' SUBROUTINE
; -----
; This routine sets the editing area, workspace and calculator stack
; to their minimum configurations as at initialization and indeed this
; routine could have been relied on to perform that task.
; This routine uses HL only and returns with that register holding
; WORKSP/STKBOT/STKEND though no use is made of this. The routines also
; resets MEM to its usual place in the systems variable area should it
; have been relocated to a FOR-NEXT variable. The main entry point
; SET-MIN is called at the start of the MAIN-EXEC loop and prior to
; displaying an error.
; Although not intended as such, this routine used to clear up any imbalance
; in the calculator stack.

SET_MIN   LD    HL,($5B59)      ; fetch E_LINE

```

```

        LD      (HL), $0D          ; insert carriage return
        LD      ($5B5B), HL       ; make K_CUR keyboard cursor point there.
        INC     HL                ; next location
        LD      (HL), $80        ; holds end-marker $80
        INC     HL                ; next location becomes
        LD      ($5B61), HL      ; start of WORKSP

; This entry point is used prior to input and prior to the execution,
; or parsing, of each statement.

SET_WORK LD      HL, ($5B61)      ; fetch WORKSP value
        LD      ($5B63), HL      ; and place in STKBOT

; This entry point is used to move the stack back to its normal place
; after temporary relocation during line entry and also from ERROR-3

SET_STK  LD      HL, ($5B63)      ; fetch STKBOT value
        LD      ($5B65), HL      ; and place in STKEND.

;;;     PUSH   HL                ; perhaps an obsolete entry point.

        LD      HL, $5B92        ; normal location of MEM-0
        LD      ($5B68), HL      ; is restored to system variable MEM.

;;;     POP    HL                ; saved value not required.

        RET                       ; return.

; -----
; THE 'REC-EDIT' ROUTINE
; -----
; This is legacy code from the ZX80/ZX81 and it is not used in this ROM.
; That task, in fact, is performed here by the dual-area routine CLEAR-SP.

;;; REC-EDIT
;;; L16D4:  LD      DE, ($5B59)    ; fetch start of edit line from E_LINE.
;;;        JP      RECLAIM_1      ; jump forward to RECLAIM-1.

; -----
; THE 'TABLE INDEXING' SUBROUTINE
; -----
; This routine is used to search two-byte hash tables for a character held
; in C, returning the address of the following offset byte.  If it is known
; that the character is in the table e.g. for priorities, then the table
; requires no zero end-marker.  If this is not known at the outset then a
; zero end-marker is required and carry is set to signal success.

; -> The Entry Point.

INDEXER_0 LD      C, A            ;+ Replaces 4 similar instructions
        LD      B, $00          ;+ A useful return value.

INDEXER_1 INC     HL            ; Address the next pair of values.

INDEXER  LD      A, (HL)        ; Fetch the first byte of pair
        AND     A              ; Is it the end-marker ?
;;;     RET     Z                ; Return, if so, with carry reset.
        JR     NZ, INDEXER_2    ;
        LD      A, C            ;
        RET                       ;

INDEXER_2 CP      C            ; Is it the required character ?
        INC     HL            ; Address next location.

```

```

        JR     NZ,INDEXER_1      ; Back, if no match, to INDEXER-1

        LD     C,(HL)           ;
        ADD   HL,BC             ;

        SCF                     ; Set the carry flag.

        RET                    ; Return with carry set.

; -----
; The Channel and Streams Routines
; -----
; A channel is an input/output route to a hardware device
; and is identified to the system by a single letter e.g. 'K' for
; the keyboard. A channel can have an input and output route
; associated with it in which case it is bi-directional like
; the keyboard. Others like the upper screen 'S' are output
; only and the input routine usually points to a report message.
; Channels 'K' and 'S' are system channels and it would be inappropriate
; to close the associated streams so a mechanism is provided to
; re-attach them. When the re-attachment is no longer required, then
; closing these streams resets them as at initialization.

; -----
; THE 'CLOSE STREAM' COMMAND
; -----
; This command allows streams to be closed after use.
; Any temporary memory areas used by the stream would be reclaimed and
; finally flags set or reset if necessary.
; Any attempt to CLOSE streams $00 to $04, without first opening the stream,
; will lead to either a system restart or the production of a strange report.
; credit: Martin Wren-Hilton 1982.

CLOSE    CALL  STR_DATA        ; routine STR-DATA fetches parameter
; from calculator stack and gets the
; existing STRMS data pointer address in HL
; and stream offset from CHANS in BC.

; Note. this offset could be zero if the stream is already closed. A check
; for this should occur now and an error should be generated, for example,
; Report S 'Stream is closed'.

        JR     NZ,CLOSE_OK      ;+ Continue if stream is open.

REPORT_S RST   30H             ;+ ERROR-1
        DEFB  $1B             ;+ 'Stream is closed'

CLOSE_OK CALL  CLOSE_2        ; routine CLOSE-2 will perform any actions
; peculiar to that stream without disturbing
; data pointer to STRMS entry in HL.

        LD     BC,$0000        ; the stream is to be blanked.

;;;

        LD     DE,$A3E2        ;

        LD     DE,$A4E4        ;+ the number of bytes from stream 4 to $10000

        EX    DE,HL           ; transfer the offset to HL and the STRMS data
; pointer to the DE register.

        ADD   HL,DE           ; add the offset to the data pointer.

        JR     C,CLOSE_1      ; forward, if a non-system stream, to CLOSE_1

; proceed with a negative result offset now 12 (was 14).

```

```

;;; LD BC,INIT_STRM +14; prepare the address of the byte after streams.

LD BC,INIT_STRM +12;+ prepare the address of the byte after the
;+ initial stream data in ROM.

ADD HL,BC ; index into the ROM data table with negative
; value.
LD C,(HL) ; Read low-order byte from ROM to C
INC HL ; address next ROM location.
LD B,(HL) ; Read high-order byte from ROM to B.

; For streams 0 - 2 just enter the initial data back into the STRMS entry
; Streams 0 - 2 can't be closed as they are shared by the operating system.
; For streams 3 - 15, the BC register holds zero, and the entry is blanked.

CLOSE_1 EX DE,HL ; Transfer address of stream to HL.
LD (HL),C ; place zero (or low byte).
INC HL ; next address.
LD (HL),B ; place zero (or high byte).
RET ; return.

; -----
; THE 'CLOSE-2' SUBROUTINE
; -----
; This routine finds the offset to a special closing routine,
; in this ROM and within 256 bytes of the close stream look up table that
; reclaims any buffers associated with a stream.
; IN: HL=address in STRMS BC=offset from CHANS to 2nd byte of channel

CLOSE_2 PUSH HL ; * save address of stream data pointer
; in STRMS on the machine stack.
LD HL,($5B4F) ; fetch CHANS address to HL
ADD HL,BC ; add the offset to address the second byte

DEC HL ; point to first byte.

LD ($5B51),HL ;+ Update system variable CURCHL
;+ While we have the channel in the register,
;+ make it 'current; as we may have to flush.

PUSH HL ;+ copy to IX register.
POP IX ;+

LD D,B ;+ Save offset in DE.
LD E,C ;+

LD A,(IX+$04) ;+ pick up the channel letter in A.

LD HL,CL_STR_LU-1 ; address: cl-str-lu in ROM.

CALL INDEXER_0 ; routine INDEXER uses the code to get
; the 8-bit offset from the current point to
; the address of the Closing Routine in ROM.

;;; LD C,(HL) ; transfer the offset to C.
;;; LD B,$00 ; prepare to add.
;;; ADD HL,BC ; add offset to point to the address of the
;;; ; routine that closes the stream.

JP (HL) ; jump to that routine.

; ---

```

```

TAG6:      DEFB  0,0,0,0      ;+ ballast
           DEFB  0,0,0,0      ;+ ballast

```

```

; -----
; THE 'CLOSE STREAM LOOK UP' TABLE
; -----
; This table contains an entry for a letter found in the CHANS area
; followed by an 8-bit displacement, from that byte's address in the
; table to the routine that performs any ancillary actions associated
; with closing the stream of that channel.
; The table doesn't require a zero end-marker as the letter has been
; picked up from a channel that has an open stream.

```

```

CL_STR_LU DEFB  'K', CLOSE_E-$-1; offset to CLOSE_E
           DEFB  'S', CLOSE_E-$-1; offset to CLOSE_E
           DEFB  'P', CLOSE_P-$-1;+ offset to CLOSE_P
           DEFB  'B', CLOSE_A-$-1;+ offset to CLOSE_A
           DEFB  'T', CLOSE_A-$-1;+ offset to CLOSE_A
           DEFB  'N', CLOSE_N-$-1;+ offset to CLOSE_N

```

```

; -----
; THE 'CLOSE PRINTER STREAM' SUBROUTINE
; -----
; The last data block must be sent as an EOF record.

```

```

CLOSE_P   CALL  COPY_BUFF      ; send EOF record.
           JR    CLOSE_A       ; skip forward to generic CLOSE_A routine.

```

```

; -----
; THE 'CLOSE NETWORK' SUBROUTINE
; -----
; The last data block must be sent as an EOF record except when T_ADDR_hi
; indicates that 'CLEAR #' has been used. In this case the network buffer
; is simply closed losing its contents.

```

```

CLOSE_N   BIT    6, (IY+$3B)    ; Test T_ADDR_hi
           CALL  Z, SEND_NEOF    ; send EOF record.

```

```

; -----
; THE 'CLOSE ALL' SUBROUTINE
; -----
;+ Initially, removed the 264 byte "P" channel and the ZX printer buffer.
;+ In fact this routine is generic and will remove any channel.

```

```

CLOSE_A   PUSH  DE              ; Save CHANS offset.
           PUSH  IX              ;
           POP   HL              ; HL addresses the start of the channel.

           LD    C, (IX+$05)     ;
           LD    B, (IX+$06)     ; BC contains length.

           PUSH  BC              ; Preserve bytes to reclaim.

           CALL  RECLAIM_2       ; Routine RECLAIM-2

           POP   BC              ; Restore reclaimed byte count.

```

```

; Any open streams that point to channels beyond that deleted (offset =DE)
; will have to have offsets reduced by the amount reclaimed (length = BC)
; This is similar to REST-STRM in Interface 1

```

```

        LD    A,$10            ; 16 user streams

        LD    HL,$5B16        ; Start of user streams in sysvars.
NEXT_STRM LD    ($5B5F),HL    ; Save current pointer in X_PTR

        LD    E,(HL)          ; Fetch displacement for current stream.
        INC  HL                ;
        LD    D,(HL)          ;

        POP  HL                ; restore chans offset
        PUSH HL               ; push the value again.

        AND  A                 ; clear carry

        SBC  HL,DE            ; compare by subtraction.

        JR   NC,UPD_POINT     ; forward if before deleted channel to do a
                                ; dummy update as provides easier pathing.

        EX  DE,HL             ; transfer current displacement to HL.
        AND  A                 ; clear carry.

        SBC  HL,BC            ; reduce displacement by amount deleted.

        EX  DE,HL             ; transfer new displacement to DE.
UPD_POINT LD    HL,($5B5F)    ; Fetch STRMS pointer from X_PTR

        LD    (HL),E           ;
        INC  HL                ;
        LD    (HL),D           ;
        INC  HL                ;

        DEC  A                 ; Decrement stream counter.
        JR   NZ,NEXT_STRM     ; loop back till all sixteen tested.

        POP  HL                ; balance stack

; Note. as long as X_PTR points to somewhere harmless it need not be set to
; a zero value. Interface 1 mistakenly sets the low byte anyway.

; -----
; THE 'CLOSE END' SUBROUTINE
; -----
; The close stream routines have no ancillary actions to perform with regard
; to 'K' and 'S'.

CLOSE_E  POP  HL                ; * now just restore the stream data pointer

        RET                    ; in STRMS and return.

; -----
; THE 'STREAM DATA' SUBROUTINE
; -----
; This routine finds the data entry in the STRMS area for the specified
; stream which is passed on the calculator stack. It returns with HL
; pointing to this system variable and BC holding a displacement from
; the CHANS area to the second byte of the stream's channel. If BC holds
; zero, then that signifies that the stream is closed.

```



```

STR_DATA CALL FIND_INT1      ; Routine FIND-INT1 fetches parameter to A
                                ; setting B to zero.

CP      $10                    ; Is it less than 16d ?
JR      C,STR_DATA1          ; Skip forward, if so, to STR-DATA1

; Note. the unimplemented ERASE and MOVE commands also now point here.

REPORT_O RST 30H              ; ERROR-1
        DEFB $17              ; Error Report: Invalid stream

; ---

STR_DATA1 ADD A,$03           ; add the offset for the three system streams.
                                ; range 00 - 15d becomes 3 - 18d.
        RLCA                  ; double the offset as there are two bytes per
                                ; stream - now 06 - 36d
        LD HL,$5B10          ; address STRMS - the start of the streams
                                ; data area in the system variables.
        LD C,A                ; transfer the low byte to C.

        LD B,$00              ; prepare to add offset.

        ADD HL,BC             ; add to address the data entry in STRMS.

; the data entry itself contains an offset from CHANS to the address of the
; stream

        LD C,(HL)             ; Fetch low byte of displacement to C.
        INC HL                 ; Address next.
        LD B,(HL)             ; Fetch high byte of displacement to B.
        DEC HL                 ; Step back to leave HL pointing to STRMS
                                ; data entry.

        LD A,B                 ;+ Test for zero now
        OR C                   ;+ as a common return condition.

        RET                    ; Return with CHANS displacement in BC
                                ; and address of stream data entry in HL.

; -----
; THE 'OPEN #' COMMAND
; -----
; This command has been changed from CLASS_03 to CLASS_05
; Command syntax example: OPEN #6,"p" and OPEN #7,"n";64

OPEN    LD A,$FF              ; set all bits of A as station indicator.
        EX AF,AF'            ; preserve as an invalid network station.

        CALL EXPT_SEP         ; is next character a separator ?
        JR NZ,CHK_O_END      ; forward if not to check end - no station.

; If there was a separator then the network station comes next.

;;;     RST 20H                ; NEXT_CHAR
;;;     CALL EXPT_1NUM         ; routine EXPT-1NUM checks for number
;;;     CALL CHECK_END        ; as in OPEN #9,"n",64

        CALL CHK_END_1        ;+ above three routines combined.

; It is runtime so the network station is on the stack.

        CALL FIND_INT1        ;+ routine FIND-INT1 fetches parameter to A.

```

```

        EX    AF,AF'          ;+ preserve in alternate register

;   It is simpler to pass through check than jump over it.

CHK_O_END CALL  CHECK_END      ; finish if checking syntax.

;   In runtime, the channel code entry is on the calculator stack with the next
;   value containing the stream identifier.  They have to be swapped.

        RST   28H             ;; FP-CALC      ;s,c.
        DEFB  $01             ;;exchange    ;c,s.
        DEFB  $38             ;;end-calc

        CALL  STR_DATA        ; routine STR-DATA fetches the stream off
                                ; the stack and returns with the CHANS
                                ; displacement in BC and HL addressing
                                ; the STRMS data entry.  The zero flag will be
                                ; set if the stream is closed.

;;;      LD    A,B            ; test for zero which
;;;      OR    C              ; indicates the stream is closed.

        JR    Z,OPEN_1        ; skip forward, if closed, to OPEN-1

;   If it is an open system channel, then it can be re-attached.

        EX    DE,HL           ; save STRMS address in DE.
        LD    HL,($5B4F)      ; fetch CHANS.
        ADD   HL,BC           ; add the offset to address the second
                                ; byte of the channel.

;;;      INC   HL             ;
;;;      INC   HL             ;
;;;      INC   HL             ;
;;;      LD    A,(HL)         ;

        CALL  NUMBER_3        ;+ add 3 to hl and fetch A comparing to 'K'.

;   A new channel can replace an existing one only if the existing channel
;   is not associated with a dynamic buffer.  Otherwise the buffer would be
;   left hanging.  The channel to be replaced is checked against a list of
;   those that are not dynamic.
;   Note.  If the channel is dynamic then it must be closed and then opened.
;   This manual closure may involve re-instating an initial channel.

        EX    DE,HL           ; bring back the STRMS pointer.

;;;      CP    $4B           ; is it 'K' ?
;;;      JR    Z,OPEN_1      ; forward, if so, to OPEN-1

;;;      CP    $53           ; is it 'S' ?
;;;      JR    Z,OPEN_1      ; forward, if so, to OPEN-1

        CP    $53             ; is it 'S' ? (was 'P')
        JR    NZ,REPORT_O     ; back, if not, to REPORT-O
                                ; 'Invalid stream'.

;   Continue if one of the upper-case letters was found and rejoin here from
;   above if the stream was already closed.

OPEN_1  CALL  OPEN_2          ; routine OPEN-2 opens the stream.

```

```

; It now remains to update the STRMS variable.

        JP    PO_CH_2            ;+ jump to similar code to that below. (JS)

;;;     LD    (HL),E            ; insert or overwrite the low byte.
;;;     INC   HL                ; address high byte in STRMS.
;;;     LD    (HL),D            ; insert or overwrite the high byte.
;;;     RET                      ; return.

; -----
; THE 'OPEN_2' SUBROUTINE
; -----
; As well as creating buffers, this routine also sets flags.
; Note. that on the original Spectrum the network station was passed in
; after the "N" channel identifier. This made syntax checking easy but if
; the station identifier was numeric it is a departure from the rule that
; any number can be replaced by a numeric expression. The station identifier
; could have been a character.

OPEN_2   PUSH  HL                ; * save the STRMS data entry pointer throughout

        CALL  EXPT_SPEC          ;+ NEW routine fetches a one character specifier
        ;+ to A

;;;     CALL  STK_FETCH          ; routine STK-FETCH now fetches the paremeters.
;;;     LD    A,B                ; test that it is not
;;;     OR    C                  ; the null string.
;;;     JR    NZ,OPEN_3          ; skip forward to OPEN-3 with 1 character or
;;;                               ; more!!!!
;;; REPORT_F RST 30H            ; ERROR-1
;;;     DEFB  $0E                ; Error Report: Invalid file name
;;; OPEN_3   PUSH  BC            ; Save the length of the string.
;;;     LD    A,(DE)             ; Pick up the first character.

        AND   $DF                ; Make it upper-case.

;;;     LD    C,A                ; Place channel specifier in C.
        LD    HL,OP_STR_LU-1     ; Address: op-str-lu is addressed.

        CALL  INDEXER_0          ; Routine INDEXER will search for the letter.

        JR    NC,REPORT_F        ; Forward, if not found, to REPORT-F
        ; 'Invalid filename'

;;;     LD    C,(HL)             ; Fetch the displacement to opening routine.
;;;     LD    B,$00              ; prepare to add.
;;;     ADD   HL,BC              ; Now form address of the opening routine.
;;;     POP   BC                 ; Restore the length of the string.

        JP    (HL)               ; Jump forward to the relevant routine.

; -----
; THE 'OPEN STREAM LOOK-UP' TABLE
; -----
; The open stream look-up table consists of matched pairs.
; The channel letter is followed by an 8-bit displacement to the
; associated stream-opening routine in this ROM.
; The table requires a zero end-marker as the letter has been
; provided by the user and not the operating system.
; Note. The table has been re-arranged so that those without buffers
; come last providing two look-up tables in one.

OP_STR_LU
        DEFB  'P', OPEN_P-$-1 ; offset to OPEN-P

```

```

        DEFB 'N', OPEN_N-$-1 ;+   offset to OPEN_N
        DEFB 'B', OPEN_B-$-1 ;+   offset to OPEN-B
        DEFB 'T', OPEN_T-$-1 ;+   offset to OPEN-T

NOBUF_LU DEFB 'K', OPEN_K-$-1 ;   offset to OPEN-K
        DEFB 'S', OPEN_S-$-1 ;   offset to OPEN-S

        DEFB $00                ;   end-marker.

; -----
; THE 'STREAM OPENING' SUBROUTINES
; -----
; Note. That was then, this is now.
; These routines would have opened any buffers associated with the stream
; before jumping forward to OPEN-END with the displacement value in E
; and perhaps a modified value in BC. The strange pathing does seem to
; provide for flexibility in this respect.

; -----
; THE 'OPEN-K' SUBROUTINE
; -----
; Open Keyboard channel.
; Note. the full 16-bit offset is now supplied in DE.

;;; OPEN_K LD    E,$01            ; offset to channel 'K'.

OPEN_K    LD    DE,$0001         ;+ 01 is offset to 2nd byte of channel 'K'.
          JR    OPEN_END        ; forward to OPEN-END

; -----
; THE 'OPEN-S' SUBROUTINE
; -----
; Open Screen channel.
; Note. the full 16-bit offset is now supplied in DE.

;;; OPEN_S LD    E,$06            ; offset to channel 'K'.

OPEN_S    LD    DE,$0006         ;+ 06 is offset to 2nd byte of channel 'S'
          JR    OPEN_END        ; forward to OPEN-END

; -----
; THE 'OPEN-P' SUBROUTINE
; -----
; Open Printer channel.

OPEN_P    LD    IX,PCHAN_DAT     ;+ point to the channel data.
          JR    OPEN_ALL        ;+ forward to generic opening routine.

; -----
; THE 'OPEN-B' SUBROUTINE
; -----
; Open B RS232 channel

OPEN_B    LD    IX,BCHAN_DAT     ;+ point to the channel data.
          JR    OPEN_ALL        ;+ forward to generic opening routine.

; -----
; THE 'OPEN-T' SUBROUTINE
; -----
; Open T RS232 channel

OPEN_T    LD    IX,TCHAN_DAT     ;+ point to the channel data.

```

```

JR      OPEN_ALL      ;+ forward to generic opening routine.

; -----
; THE 'OPEN PERMANENT "N" CHANNEL' ROUTINE
; -----
;   e.g. OPEN #9,"N";2

OPEN_N   LD      IX,NCHAN_DAT      ;+

; -----
; THE 'OPEN_ALL' ROUTINE
; -----
;+ Generic Channel Opening Routine.
;+ DE still points to string

OPEN_ALL LD      HL,($5B53)        ; Set pointer from PROG
        LD      C,(IX+$05)        ; length lo.
        LD      B,(IX+$06)        ; length hi.

        CALL    MK_RM_DHL        ;+ routine MAKE_ROOM decrementing HL first.

; HL points to the 1st location, DE to last new location, BC is zero
;;;      INC      HL              ; HL points to start of new channel

        PUSH    HL              ; (*) Save channel pointer.

        EX      DE,HL          ; Transfer HL to DE.

        PUSH    IX              ; Transfer ROM data pointer
        POP     HL              ; to HL.

        LD      C,(IX-$01)      ; Find number of bytes in ROM

        LDIR                     ; Block copy the channel data.

; Note. a call to clear the ZX Printer buffer is required here.
; but can be done directly.

        LD      A,(IX+$04)      ;

        CP      'P'            ;
        JR      Z,P_BLANK      ; Forward, if printer, to P_BLANK

        CP      'N'            ; is it network ?
        JR      NZ,OFFSET      ;

        EX      AF,AF'        ; save device letter, bring back station.

        CP      $41            ; compare to 64
        JP      NC,REPORT_B    ; forward, if over, to report
                                ; 'Integer out of range'

        LD      (DE),A          ; set channel variable NCIRIS
        INC     DE              ; address own station number.

        LD      A,($5BBC)      ; fetch global station number from sysvar NTSTAT
        LD      (DE),A          ; update channel variable NCSELF
        EX      AF,AF'        ; save again.

```

```

        INC     DE                ; point to next location

; Note. the network buffer does not have to be cleared. As long as we set
; the other channel variables to zero that is sufficient so use the same
; routine as is used for the ZX Printer buffer which does all but 4.

P_BLANK  LD     H,D                ;
        LD     L,E                ;
        INC     DE                ;

        LD     (HL),B            ; Blank first location
        DEC     C                ; set count to 255 decimal or whatever.

        LDIR                    ;

; now calculate offset from CHANS

OFFSET   LD     HL,($5B4F)        ; Address CHANS

        POP     DE                ; (*) Restore the channel pointer

        EX     DE,HL            ;
        INC     HL              ; the second byte is used.
        AND     A                ; prepare to subtract
        SBC     HL,DE           ; result is in HL
        EX     DE,HL            ; transfer offset to DE

;;;     POP     BC                ; Restore length of string.

        CP     'N'              ;
        JR     Z,OPEN_END2      ; skip the length test

; -----
; THE 'OPEN END' ROUTINE
; -----

;;; OPEN_END  DEC     BC                ; the stored length of 'K','S','P' or whatever
;;;                                     ; is now tested.
;;;         LD     A,B                ; test now if initial or residual length
;;;         OR     C                  ; is one character.
; OPEN_IFN   JP     NZ,REPORT_F        ; back, if not, to REPORT-Fb
;;;         LD     D,A                ; 'Invalid file name'
;;;                                     ; load D with zero to form the displacement.

; It used to go like that and now it goes like this...

OPEN_END  EX     AF,AF'            ; station number - should be $FF
        INC     A                  ; test for $FF

OPEN_END2 POP     HL                ; * restore the saved STRMS pointer.

        RET     Z                  ; return to update STRMS entry thereby
        ; signaling stream is open.

; A parameter has been supplied for a channel that does not require one
; e.g. OPEN #6,"t",78

REPORT_F  RST     30H              ; ERROR-1
        DEFB   $0E                ; Error Report: Invalid file name

; -----

```

```

; THE "P" CHANNEL DATA'
; -----
; The eight bytes "P" channel descriptor.

        DEFB  $08                ;+ length of channel data

PCHAN_DAT DEFW  PRINT_OUT        ;+ PRINT-OUT
          DEFW  REPORT_J         ;+ REPORT-J
          DEFB  'P'              ;+ Letter as in standard ROM
          DEFW  $0108            ;+ Length of channel including printer buffer.
          DEFB  $21              ;+ P_POSN (IX+$07)

; -----
; THE "B" CHANNEL DATA'
; -----
; The seven bytes "B" channel descriptor. Maybe stick the 2-byte buffer here.

        DEFB  $07                ;+ length of channel data

BCHAN_DAT DEFW  BCHAN_OUT        ;+ BCHAN_OUT
          DEFW  BCHAN_IN         ;+ BCHAN_IN
          DEFB  'B'              ;+ Letter
          DEFW  $0007            ;+ Length of channel

; -----
; THE "T" CHANNEL DATA'
; -----
; The seven bytes "T" channel descriptor.

        DEFB  $07                ;+ length of channel data

TCHAN_DAT DEFW  TCHAN_OUT        ;+ TCHAN_OUT
          DEFW  TCHAN_IN         ;+ TCHAN_IN
          DEFB  'T'              ;+ Letter
          DEFW  $0007            ;+ Length of channel

; -----
; THE "N" CHANNEL DATA'
; -----
; The seven bytes "N" channel descriptor.

        DEFB  $07                ;+ length of data

NCHAN_DAT DEFW  NCHAN_OUT        ;+ NCHAN-OUT
          DEFW  NCHAN_IN         ;+ NCHAN_IN
          DEFB  $4E              ;+ character "N"
          DEFW  $0110            ;+ length

; The other channel variables for network are defaulted to zero. They are -
;
; 1 NCIRIS IX+$07 ; The destination station number.
; 1 NCSELF IX+$08 ; This SPECTRUM's station number.
; 2 NCNUMB IX+$09 ; The block number.
; 1 NCTYPE IX+$0B ; The packet type code ... 0 data, 1 EOF.
; 1 NCOBL IX+$0C ; The number of bytes in the data block.
; 1 NCDCS IX+$0D ; The data checksum.
; 1 NCHCS IX+$0E ; The header checksum.
; 1 NCCUR IX+$0F ; The position of the last character taken from
; ; the buffer.
; 1 NCIBL IX+$10 ; The number of bytes in the input buffer.
; 255 NCB IX+$11 ; A 255 byte data buffer.

```

```

; *****
; ** THE RS232 ROUTINES **
; *****
;
; -----
; THE "'T" CHANNEL INPUT SERVICE' ROUTINE
; -----
; The text channel input is limited to 7 bits so use the binary channel input
; and reset the most significant bit.

TCHAN_IN CALL BCHAN_IN ; routine BCHAN-IN

RES 7,A ; reset the MSB.

RET ; Return.

; -----
; THE "'B" CHANNEL INPUT SERVICE' ROUTINE
; -----
; For serial input a two-byte buffer SER_FL is used.
; Sometimes 16 bits are received at a time so the second byte is stored
; here.

BCHAN_IN LD HL,$5BBE ; Point to the SER_FL system variable.
LD A,(HL) ; Fetch a byte.
AND A ; Test for zero which signals no stored byte.

JR Z,REC_BYTE ; Forward, if so, to REC-BYTE.

LD (HL),$00 ; else signal taking the stored byte.
INC HL ; Point to the stored byte.
LD A,(HL) ; Load it to the accumulator.
SCF ; Signal success by setting carry.

RET ; Return.

; ---

REC_BYTE CALL TEST_BRK ; Routine TEST-BRK tests the BREAK keys.

DI ; Disable Interrupts

LD A,($5BBD) ; Fetch I/O colour from IOBOARD system variable.
OUT ($FE),A ; Change the border to show activity.

; The value for

LD DE,($5BBA) ; fetch value from BAUD system variable.
LD HL,$0320 ; set counter to 800 decimal.

LD B,D ; copy BAUD value
LD C,E ; to BC register.

SRL B ; 0 -> 76543210 -> C Halve the value
RR C ; C -> 76543210 -> C

LD A,$FE ; Make CTS (Clear To Send) high.
OUT ($EF),A ;

; The other device, VTX modem, BBC computer, PC, Spectrum etc. will now send
; the data.

READ_RS IN A,($F7) ; bit 7 is TXdata serial data

```



```

        RLCA                ; rotate into carry.
        JR    NC,TST_AGAIN  ; forward to TST-AGAIN if TXdata low

        IN    A,($F7)       ; repeat the test 3 times
        RLCA                ;
        JR    NC,TST_AGAIN  ; forward to TST-AGAIN

        IN    A,($F7)       ;
        RLCA                ;
        JR    NC,TST_AGAIN  ; forward to TST-AGAIN

        IN    A,($F7)       ;
        RLCA                ;
        JR    C,START_BIT   ; forward, if high for four tests, to START-BIT

TST_AGAIN DEC    HL        ; decrement the 800 counter.
          LD    A,H        ; test for
          OR    L          ; zero.
          JR    NZ,READ_RS ; back, if not, to READ-RS

          PUSH AF         ; (*) Save the zero failure flag

          LD    A,$EE      ; make CTS (Clear To Send) line low.
          OUT  ($EF),A    ;

          JR    WAIT_1    ; forward to WAIT-1

; ---

; The branch was here when TXdata was high for 4 tests.

START_BIT LD    H,B        ; Load HL with halved BAUD value.
          LD    L,C        ;

          LD    B,$80      ; Load B with start bit.

          DEC   HL        ; reduce counter by the time for the 4 tests.
          DEC   HL        ;
          DEC   HL        ;

SERIAL_IN ADD   HL,DE      ; Add the BAUD value.
          NOP                ; (4) timing value.

BD_DELAY  DEC   HL        ; ( 6) Delay for 26 * BAUD
          LD    A,H        ; ( 4)
          OR    L          ; ( 4)
          JR    NZ,BD_DELAY ; (12) back to BD-DELAY

          ADD   A,$00      ; (7) wait
          IN   A,($F7)     ; Read a bit
          RLCA                ; rotate bit 7 to carry.
          RR    B          ; pick up carry in B.
          JR    NC,SERIAL_IN ; loop back, if no start bit, to SERIAL-IN

; After looping eight times, the start bit will pass through and B will
; contain a received byte.

          LD    A,$EE      ; Send CTS line low.
          OUT  ($EF),A    ;

          LD    A,B        ; transfer received byte to A.
          CPL                ; complement.
          SCF                ; signal success.

```

```

        PUSH AF                ; (*) push success flag

;   The success and failure (time out) paths converge here with HL holding zero.

WAIT_1  ADD   HL,DE            ; transfer DE (BAUD) to HL.

WAIT_2  DEC   HL                ; ( 6) Delay for stop bit.
        LD   A,L                ; ( 4)
        OR   H                    ; ( 4)
        JR   NZ,WAIT_2          ; (12/7) back to WAIT-2

;   Register HL is now zero.

        ADD  HL,DE              ; HL = 0 + BAUD
        ADD  HL,DE              ; HL = 2 * BAUD
        ADD  HL,DE              ; HL = 3 * BAUD

;   The device at the other end of the cable may send a second byte even though
;   CTS is low.

T_FURTHER DEC  HL              ; decrement counter.
        LD   A,L                ; Test for
        OR   H                    ; zero.
        JR   Z,END_RS_IN        ; forward, if no 2nd byte, to END-RS-IN

        IN   A,($F7)            ; Read TXdata.
        RLCA                      ; test bit.
        JR   NC,T_FURTHER       ; back, if none, to T-FURTHER

;   As with first byte, TXdata must be high for four tests

        IN   A,($F7)            ;
        RLCA                      ;
        JR   NC,T_FURTHER       ; back to T-FURTHER

        IN   A,($F7)            ;
        RLCA                      ;
        JR   NC,T_FURTHER       ; back to T-FURTHER

        IN   A,($F7)            ;
        RLCA                      ;
        JR   NC,T_FURTHER       ; back to T-FURTHER

;   A second byte is on its way and is received exactly as before.

        LD   H,D                ;
        LD   L,E                ;
        SRL  H                    ;
        RR   L                    ;
        LD   B,$80              ;
        DEC  HL                ;
        DEC  HL                ;
        DEC  HL                ;

SER_IN_2 ADD  HL,DE            ;
        NOP                      ; timing

BD_DELAY2 DEC  HL              ;
        LD   A,H                ;
        OR   L                    ;
        JR   NZ,BD_DELAY2       ; back to BD-DELAY2

        ADD  A,$00              ;

```

```

        IN    A, ($F7)          ;
        RLCA                          ;
        RR    B                  ;
        JR    NC, SER_IN_2      ; back to SER-IN-2

; The start bit has been pushed out and B contains the second received byte.

        LD    HL, $5BBE         ; Address the SER_FL system variable.
        LD    (HL), $01        ; signal there is a byte in next location
        INC   HL                ; address that location
        LD    A, B              ; transfer byte to A.
        CPL                          ; complement.
        LD    (HL), A          ; and insert in second byte of serial flag.

END_RS_IN CALL BORD_REST      ; routine BORD-REST restores the normal border.

        POP   AF                ; restore byte and flags
                                ; (either 0 and NC or received byte and carry).

;;;      EI                    ; Enable Interrupts

        RET                     ; Return.

; -----
; THE "'T" CHANNEL OUTPUT' ROUTINE
; -----
; The text channel output routine is able to list programs and, when printing,
; takes correct action with TAB values etc. I think.
; Note. The "t" channel can be tested on the RealSpec emulator as follows -
; 1) Assemble this file and note down addresses of BCHAN_IN and BCHAN_OUT
; 2) Select this ROM [F3] and serial interface [ALT F3]
; 3) Select output to a file.
; 3) Arrow down to bottom and supply IO addresses e.g. I 184E 19B0
; 4) Session "t" channel output will appear in file SERIAL.BIN

TCHAN_OUT CP    $A5            ; Compare to 'RND' - first token
          JR    C, NOT_TOKEN   ; Forward, if less, to NOT-TOKEN

          SUB   $A5            ; Reduce token to range $00-$5A

          JP    PO_TOKENS      ; Routine PO_TOKENS recursively prints tokens

;;;      RET                    ; Return.

; ---

NOT_TOKEN LD    HL, $5B3B      ; Address the FLAGS system variable.
          RES   0, (HL)        ; update FLAGS - allow for leading space.
          CP    $20            ; compare character to space
          JR    NZ, NOT_LEAD   ; forward, if not, to NOT-LEAD

          SET   0, (HL)        ; update FLAGS - signal suppress leading space.

; The mosaic graphics and UDGs are output as '?' as also is (c) copyright.

NOT_LEAD CP    $7F            ; compare to copyright symbol. (DEL in ASCII)
          JR    C, NOT_GRAPH   ; forward, if less, to NOT-GRAPH

          LD    A, $3F         ; Output CHR$(127) and graphics as '?'

NOT_GRAPH CP    $20            ; compare against space.
          JR    C, CTRL_CODE   ; forward, if less, to CTRL_CODE

```

```

        PUSH  AF                ; preserve character.

        INC   (IY+$7D)          ; increment width  WIDTH_lo
        LD    A, ($5BB8)        ; load A with limit WIDTH_hi
        CP    (IY+$7D)          ; compare to width  WIDTH_lo
        JR    NC, EMIT_CH       ; forward, if width less or equal, to EMIT-CH

        CALL  TAB_SETZ          ; routine TAB-SETZ sets iy+$7D to zero and
                                ; emits CR/LF.

;;;
        LD    (IY+$7D), $01     ; set WIDTH_lo to one - for current character.
        INC   (IY+$7D)          ; + set WIDTH_lo to one - for current character.

EMIT_CH  POP    AF              ; restore the unprinted character.
        JR    BCH_OUT          ; jump, indirectly, to BCHAN-OUT

; ---

;   The branch was here with control codes.

CTRL_CODE CP    $0D            ; is character a carriage return ?
        JR    NZ, NOT_CR       ; forward, if not, to NOT-CR

TAB_SETZ  LD    (IY+$7D), $00   ; set width WIDTH_lo to zero.

        LD    A, $0D            ; output a CR carriage return.
        CALL  BCHAN_OUT        ; routine BCHAN-OUT

        LD    A, $0A            ; output a LF line feed.
BCH_OUT  JR    BCHAN_OUT        ; jump to BCHAN-OUT

; ---

NOT_CR   CP    $06             ; is character a comma control ?
        JR    NZ, NOT_COMMA    ; forward, if not, to NOT_COMMA

        LD    BC, ($5BB7)       ; load BC with width and limit from WIDTH
        LD    E, $00            ; set the space counter to zero.

SPC_COUNT INC  E                ; increment space counter.
        INC  C                  ; increment width.
        LD   A, C                ; load A with width.
        CP   B                  ; and compare to limit.
        JR   Z, CMM_LP2         ; forward, if at limit, to CMM-LP2

CMM_LOOP SUB  $08               ; subtract 8 - the tab stop.
        JR  Z, CMM_LP2          ; forward, when zero, to CMM-LP2

        JR  NC, CMM_LOOP        ; back, if higher than 8, to CMM-LOOP

;   The result is less than zero so back to space count.

        JR  SPC_COUNT           ; back to SPC-COUNT

;   The count in E is the spaces to advance to next multiple of eight.

CMM_LP2  CALL  PO_SV_SP         ; +

;;;
        PUSH  DE                ; save counter.
;;;
        LD    A, $20             ; prepare a space.
;;;
        CALL  TCHAN_OUT          ; routine TCHAN-OUT outputs recursively.
;;;
        POP   DE                ; restore counter.

```

```

        DEC    E           ; decrement
        RET    Z           ; return when zero.

        JR     CMM_LP2     ; loop back, if not, to CMM-LP2

; ---

NOT_COMMA CP    $16       ; compare to twenty two ('AT')
          JR    Z,TAB_PROC ; forward, if so, to TAB-PROC

          CP    $17       ; compare to twenty three ('TAB')
          JR    Z,TAB_PROC ; forward, also, to TAB-PROC

          CP    $10       ; compare to sixteen (INK)
          RET    C        ; return if less.

; Now store code in TVDATA and alter the current channel to TAB_SERV2

          LD    DE,TAB_SERV2 ; Service routine for ink, paper etc.

          JR    STORE_COD    ; forward to STORE-COD

; ---

TAB_PROC  LD    DE,TAB_SERV ; addr: TAB-SERV

STORE_COD JP    PO_TV_1     ; jump to similar code for tv output.

;;; STORE_COD LD    ($5B0E),A ; store control code in TVDATA_lo
;;; ALTER_OUT LD    HL,($5B51) ; Fetch current channel from CURCHL
;;;          LD    (HL),E     ; Update the low byte of output address.
;;;          INC   HL         ;
;;;          LD    (HL),D     ; Now update the high byte.
;;;          RET                ; Return.

; -----
; THE 'TAB SERVICE ROUTINE'
; -----
; This deals with TAB and AT control codes.

TAB_SERV LD    DE,TAB_SERV2 ; addr: TAB-SERV2

          JP    PO_TV_3     ;+ use existing PO routine

;;;          LD    ($5B0F),A   ; store second byte in TVDATA_hi
;;;          JR    ALTER_OUT   ; back to ALTER-OUT

; -----
; THE 'TAB SERVICE 2' ROUTINE
; -----
; Once all the control sequence has been received this routine sorts them.

TAB_SERV2 LD    DE,TCHAN_OUT ; prepare normal address TCHAN-OUT

          CALL  PO_CHANGE    ;+ routine PO_CHANGE restores it.

          LD    D,A         ; save final character in D.

          LD    A,($5B0E)   ; fetch first character from TVDATA_lo

          CP    $16         ; is it the AT control code ?
          JR    Z,TST_WIDTH ; forward, with AT, to TST-WIDTH ????
```

```

        CP    $17          ; is it the TAB control code ?
        CCF          ; if less, e.g. INK the carry is set so reset
                    ; the carry for return condition.
        RET    NZ          ; return if INK - INVERSE and ignore.

; Continue with TAB.

        LD    A,($5B0F)    ; fetch low byte 0 - 255 from TVDATA_hi
        LD    D,A          ; and store in D, ignoring high byte.

; The TAB parameter, which is 16 bit is therefore taken mod 256 as only the
; low byte is used. For AT the column value is used and the line is ignored.

TST_WIDTH LD    A,($5BB8)    ; fetch limit (max width, default 80) to A.
          CP    D            ; compare to column/tab value.

          JR    Z,TAB_MOD    ; forward, if a match, to TAB-MOD ???

          JR    NC,TABZERO   ; forward if column less than limit to TABZERO

; The column/tab value is higher than the maximum width so calculate

TAB_MOD  LD    B,A          ; Transfer maximum width to B.
          LD    A,D          ; Transfer column/tab value to A.
          SUB   B            ; subtract a full line of characters.
          LD    D,A          ; and load result back to column/tab.
          JR    TST_WIDTH    ; loop back to TST-WIDTH

; ---

; The branch was here when the column/tab value was less than the width.

TABZERO LD    A,D          ; Transfer column/tab to A.
          OR    A            ; Test for zero.
          JR    Z,TAB_SETZ   ; Back, if so, to TAB-SETZ
                    ; to output a carriage return and linefeed.

TABLOOP LD    A,($5BB7)    ; Fetch current print position from WIDTH_lo
          CP    D            ; Compare to column/tab value.

          RET    Z          ; Return when positions equal.

>>

        CALL  PO_SV_SP      ;+

;;;      PUSH  DE            ; Preserve the column/tab value.
;;;      LD    A,$20         ; Prepare a space.
;;;      CALL  TCHAN_OUT     ; Routine TCHAN-OUT outputs a space.
;;;      POP   DE            ; Restore the column/tab value.

          JR    TABLOOP     ; Back to TABLOOP

; -----
; THE '"B" CHANNEL OUTPUT' ROUTINE
; -----
; The bits of a byte are sent inverted. They are fixed in length and heralded
; by a start bit and followed by two stop bits.

BCHAN_OUT LD    B,$0B      ; Set bit count to eleven - 1 + 8 + 2.
          CPL          ; Invert the bits in the character.

```

```

LD      C,A          ; Copy character to C.

LD      A,($5BBD)    ; select I/O border colour from IOBORD
OUT     ($FE),A      ; change the border colour.

LD      A,$EF        ;          11101111
OUT     ($EF),A      ; Make CTS (Clear To Send) low.

CPL                                ; reset bit 0,    00010000

OUT     ($F7),A      ; Make RXdata low

LD      HL,($5BBA)   ; fetch value from BAUD system variable
LD      D,H          ; Copy to DE.
LD      E,L          ;

BD_DEL_1 DEC DE      ; ( 6) Wait 26 * BAUD cycles.
LD      A,D          ; ( 4)
OR      E            ; ( 4)
JR      NZ,BD_DEL_1 ; (12) back to BD-DEL-1

TEST_DTR CALL TEST_BRK ; routine TEST-BRK allows user to stop.

IN      A,($EF)      ; Read the communication port.
AND     $08          ; isolate DTR (Data Terminal Ready) bit.
JR      Z,TEST_DTR  ; back, until DTR found high, to TEST-DTR

SCF                                ; Set carry flag as start bit.

DI                                ; Disable Interrupts.

; The bit sending loop.

SER_OUT_L ADC A,$00   ; 76543210 <- C
OUT     ($F7),A      ; Send rxdata, start bit

LD      D,H          ; transfer BAUD to DE.
LD      E,L          ;

BD_DEL_2 DEC DE      ; ( 6) Wait for 26 * BAUD
LD      A,D          ; ( 4)
OR      E            ; ( 4)
JR      NZ,BD_DEL_2 ; (12) back to BD-DEL-2

DEC     DE           ; (6)
XOR     A            ; clear rxdata bit
SRL     C            ; shift a bit of output byte to carry.
DJNZ   SER_OUT_L    ; back for 11 bits to SER-OUT-L

; Note. the last two bits will have been sent reset as C is exhausted.

;;; EI              ; Enable Interrupts.
;;; LD      A,$01   ; set rxdata bit (inc a)

INC     A            ; set rxdata bit.

LD      C,$EF       ; prepare port address.
LD      B,$EE       ; prepare mask %11101110

OUT     ($F7),A     ; Send rxdata high.
OUT     (C),B       ; Send CTS and comms data low - switch off
RS232.

```

```

BD_DEL_3  DEC   HL           ; ( 6) The final 26 * BAUD delay.
          LD    A,L         ; ( 4)
          OR    H           ; ( 4)
          JR    NZ,BD_DEL_3 ; (12) back to BD-DEL-3

; -----
; THE 'BORDER RESTORE' SUBROUTINE
; -----
; This routine could also be used by the tape routines
; It restores the border colour to normal after it has been altered to show
; communication activity. Since interrupts are usually enabled at the same
; time, that instruction has been incorporated here to conserve ROM space.

BORD_REST PUSH  AF           ; Preserve accumulator throughout.

          LD    A,($5B48)    ; Fetch border colour from BORDCR.
          AND   $38         ; Mask off paper bits.
          RRCA                ; Rotate
          RRCA                ; to the
          RRCA                ; range 0-7.

          OUT   ($FE),A     ; Change the border colour.

          POP   AF          ; Restore flags.

          EI                ;+ Enable Interrupts.

          RET                ; Return.

; -----
; THE 'TEST BREAK' SUBROUTINE
; -----
; Note. this could also be called at statement return STMT_RET.

TEST_BRK  CALL  BREAK_KEY   ; Call the standard ROM routine.
          RET   C           ; return if BREAK not pressed.

          CALL  BORD_REST    ; else restore the border colour to normal.

REPORT_Lb RST    30H        ; ERROR-1
          DEFB  $14         ; Error Report: BREAK into program

; *****
; ** THE NETWORK ROUTINES **
; *****

; "Spectrum" is the Latin word for a rainbow.
; "Iris" is the Greek word for a rainbow.
; By convention, "Spectrum" refers to this computer and "Iris" refers to the
; other computer which could be a ZX Spectrum or Sinclair QL.

; While Sinclair Research were secretive about the microdrive internals,
; there were no such restrictions on the Sinclair Network which remains an
; open standard. It was also adopted by the Disciple Disk Interface.

; "Indeed the linking of one microcomputer to another should be encouraged
; and the establishment of a Sinclair Network Standard may prove an
; important step forward"
; - Dr. Ian Logan, Interface 1 ROM co-author, 1983.

; -----
; THE '"N" CHANNEL INPUT SERVICE' ROUTINE
; -----

```



```

; The address of this network input service routine is contained in the
; channel information area and accessed by the INPUT_AD routine when the
; current channel has been made the "N" channel.
; The routine inputs a single byte from the network and if the 255-byte
; network buffer is empty, this may involve receiving a packet from the
; network.

```

```

NCHAN_IN  LD    IX,($5B51)      ; Set index register from system variable CURCHL
          LD    A,(IX+$0C)      ; Fetch number of output buffer bytes from NCOBL
          ; This should be zero when reading.
          AND   A               ; Test for zero.
          JR    Z,TEST_BUFF     ; Forward, if so, to TEST-BUFF.
          RST   30H             ; ERROR-1
          DEFB  $1D             ; 'Net R/W error'
          ; Should be -
          ; 'Reading a 'write' file' 22 chars

```

```

; ---

```

```

TEST_BUFF LD    A,(IX+$10)      ; Fetch number of input buffer bytes from NCIBL
          AND   A               ; test for zero.
          JR    Z,TST_N_EOF     ; forward, if so, to TST-N-EOF
          LD    E,(IX+$0F)      ; Fetch position of last character taken NCCUR
          DEC   A               ; Decrement the total count.
          SUB   E               ; Subtract the taken count - will set the carry
          ; flag if at end.
          JR    C,TST_N_EOF     ; Forward, if so, to TST-N-EOF
          LD    D,$00           ; Prepare to index.
          INC   E               ; Increment the position
          LD    (IX+$0F),E      ; and update the channel variable NCCUR.
          ADD   IX,DE           ; Index into the buffer at that position.
          LD    A,(IX+$10)      ; Read the byte from the buffer.
          SCF                    ; Signal success.
          RET                    ; Return.

```

```

; ---

```

```

TST_N_EOF LD    A,(IX+$0B)      ; Fetch packet type from NCTYPE - 0 data, 1 EOF.
          AND   A               ; Test for data.
          JR    Z,GET_N_BUF     ; Forward, if so, to GET-N-BUF  ->

```

```

; Note. Iris has closed her channel.

```

```

          RET                    ; Return (NC and NZ)
          ; Note. causes error 'End of file'

```

```

; ---

```

```

; ->

```

```

GET_N_BUF LD    A,($5BBD)      ; fetch I/O border colour from IOBORD
          OUT   ($FE),A        ; and change the colour to show activity.
          DI                    ; Disable Interrupts.

```

```

TRY_AGAIN CALL  WT_SCOUT      ; routine WT-SCOUT waits for the scout leader.
              JR    NC,TIME_OUT ; forward, if none, to TIME-OUT
              CALL  GET_NBLK   ; routine GET-NBLK gets the header and data.
              JR    NZ,TIME_OUT ; forward, if error, to TIME-OUT
;;;          EI                ; Enable Interrupts
              CALL  BORD_REST  ; routine BORD-REST restores the border.
              LD    (IX+$0F),$00 ; Set cursor position NCCUR to zero.
              LD    A,($5BC5)  ; Fetch header type code from NTTYE - data/EOF.
              LD    (IX+$0B),A  ; update the channel variable NCTYPE
              JR    TEST_BUFF   ; back to TEST-BUFF to read the first byte.

; ---

;;; TIME_OUT LD  A,(IX+$07)    ; Fetch the destination station number NCIRIS
;;;          AND  A            ; test for zero - a broadcast.
TIME_OUT CALL  TST_BR         ;+ New routine to test for a broadcast.
              JR    Z,TRY_AGAIN ; back, if a broadcast, to TRY-AGAIN
              ; Note. a broadcast will not time out.
              JR    BORD_REST  ; back to exit via BORD_REST restoring border.

;;;          EI                ; enable interrupts
;;;          CALL  BORD_REST  ; routine BORD-REST restores border preserving
;;;          ; the AF registers and enabling interrupts.
;;;          AND  $00         ; signal failure. (NZ NC already set)
;;;          RET              ; Return.

; -----
; THE '"N" CHANNEL OUTPUT' ROUTINE
; -----
; The address of this network output service routine is contained in the
; channel information area and accessed by the RST 10H output restart
; routine when the current channel has been made the "N" channel.
; The routine outputs a single byte to the network and if the 255-byte
; network buffer is full, this may involve sending a packet to the
; network.

NCHAN_OUT LD    IX,($5B51)    ; Set index register from system variable CURCHL
              LD    B,A        ; Copy the character to B.
              LD    A,(IX+$10) ; Fetch number of input buffer bytes from NCIBL
              ; should be zero if channel is used for writing.
              AND  A            ; test for zero bytes.
              LD    A,B        ; bring the character back.
              JR    Z,TEST_OUT ; forward, if zero bytes, to TEST-OUT
              RST  30H         ; ERROR-1
              DEFB $1D         ; 'Net R/W error'

```

```

; Should be -
; 'Writing to a 'read' file' 24 chars

; ---
TEST_OUT LD    E, (IX+$0C)    ; fetch number of output buffer bytes from NCOBL
        INC    E              ; increment the count. 1-255
        JR     NZ, ST_BF_LEN  ; forward, if not full, to ST-BF-LEN

; The buffer is full and must be sent to the network.

        PUSH  AF              ; preserve character yet to be output

        XOR   A               ; Set A to 0 to signal data and not EOF.

        CALL  S_PACK_1        ; routine S-PACK-1 sends the 255-byte buffer.

; The character can now be placed in the empty buffer at position 1.

        POP   AF              ; restore the output character.

        LD    E, $01          ; set buffer position to 1.

ST_BF_LEN LD    (IX+$0C), E    ; Update the byte count channel variable NCOBL
        LD    D, $00          ; Prepare to index.
        ADD   IX, DE          ; Index into the network buffer.
        LD    (IX+$10), A     ; and store the byte at the offset.

        RET                    ; Return.

; -----
; THE NEW 'NETWORK CR' ROUTINE
; -----
; This routine is an extra check after outputting a carriage return.

CR_END   CALL  IN_CHAN_K      ;+ routine fetches the current channel letter.

        CP    'N'            ;+ Is it the network.

        RET   NZ              ;+ Return if not.

; -----
; THE 'SEND CR BLOCK TO NETWORK' ROUTINE
; -----
; This should be sent as part of PRINT_CR to flush.

SEND_NCR LD    C, $00        ; a data block signal.

        JR    SEND_END       ; forward to send the packet.

; -----
; THE 'SEND EOF BLOCK TO NETWORK' ROUTINE
; -----
; This should be sent as part of CLOSE to flush.

SEND_NEOF LD   C, $01        ;+ An EOF signal

SEND_END LD    IX, ($5B51)    ; Set IX to current channel from CURCHL
        LD    A, (IX+$0C)    ; Load A from NCOBL the number of characters in
                                ; the output buffer.
        AND   A              ; Test for zero.
        RET   Z              ; Return with zero.

```

```

        LD      A,C          ; Signal an EOF packet if 1.

; -----
; THE 'S-PACK-1' ROUTINE
; -----
;

S_PACK_1  CALL   SEND_PACK    ; routine SEND-PACK sends a packet

        RET     NZ           ; Return if not a broadcast.

; -----
; THE 'BROADCAST DELAY' ROUTINE
; -----
; This routine ensures that there is a gap between packets when broadcasting.

BR_DELAY  LD     DE,$1500     ; Set a delay counter.

DL_LOOP   DEC    DE          ; decrement.
          LD     A,E         ; Test for zero.
          OR    D            ;
          JR    NZ,DL_LOOP   ; back, if not, to DL-LOOP

          RET                ; Return.

; -----
; THE 'SEND-PACK' ROUTINE
; -----
; This routine checksums, and then outputs to the network, an 8-byte
; header and a corresponding data block.

SEND_PACK LD     (IX+$0B),A   ; Update the channel variable NCTYPE with the
          ; packet type - 0 data, 1 EOF.

          LD     B,(IX+$0C)   ; Load counter with number of output characters
          ; from NCOBL channel variable.

          LD     A,($5BBD)    ; Fetch I/O border colour from IOBORD
          OUT    ($FE),A     ; Change border to show communication activity.

          PUSH  IX           ; Transfer the channel base address
          POP   DE           ; to the DE register pair.

          LD     HL,$0011    ; prepare the offset seventeen.
          ADD   HL,DE        ; and add to point to the first data byte.

;;;      XOR    A           ; Initialize the data checksum to zero.
;;; CHKS1 ADD   A,(HL)      ; add a data byte.
;;;      INC   HL           ; increment buffer pointer.
;;;      DJNZ  CHKS1       ; back, for count of characters, to CHKS1

          CALL  CHKS0       ;+ New general purpose checksum routine.

          LD     (IX+$0D),A   ; insert the checksum in NDCDS channel variable.

          LD     HL,$0007    ; prepare the offset seven

          ADD   HL,DE        ; and add to address NCIRIS first header byte.

          PUSH  HL           ; (*)save the header pointer.

;;;      LD     B,$07       ; Set byte counter to seven.
;;;      XOR    A           ; Initialize the header checksum to zero.
;;; CHKS2 ADD   A,(HL)     ; add the addressed byte.

```

```

;;;      INC      HL          ; increment the pointer.
;;;      DJNZ    CHKS2       ; loop back to CHKS2

      CALL    CHKS7         ; routine checksums seven bytes

      LD      (HL),A        ; insert the checksum into NCHCS channel var.

      DI          ; Disable Interrupts

SENDSCOUT CALL    SEND_SC    ; routine SEND-SC

      POP     HL          ; (*) restore the header pointer - NCIRIS.
      PUSH    HL          ; (*) and preserve again.

      LD      E,$08        ; There are eight bytes in a network header.

      CALL    OUT_BLK_N     ; routine OUT-BLK-N sends HEADER and receives
                          ; the response code.

      JR     NZ,SENDSCOUT  ; back, with no response, to SENDSCOUT

      PUSH   IX          ; transfer base address of channel
      POP    HL          ; to the HL register.

      LD     DE,$0011     ; prepare an offset of seventeen.
      ADD    HL,DE       ; add to address the first byte of buffer data.

      LD     E,(IX+$0C)   ; Fetch count of output characters from NCOBL
      LD     A,E         ; copy value to A.
      AND    A          ; test for zero.
      JR     Z,INC_BLK_N  ; forward, if zero, to INC-BLKN

      LD     B,$20        ; Set a delay value for a gap between the
                          ; physical 8-byte header and data.

SP_DL_1  DJNZ    SP_DL_1  ; self loop to SP-DL-1

      CALL    OUT_BLK_N     ; routine OUT-BLK-N sends the DATA and receives
                          ; the response byte.

      JR     NZ,SENDSCOUT  ; back, with no response, to SENDSCOUT

;;; INC_BLK_N  INC     (IX+$09) ; increment the channel variable NCNUMB_lo
;;;           JR     NZ,SP_N_END ; forward, if not '256' to SP-N-END
;;;           INC     (IX+$0A)   ; increment the channel variable NCNUMB_hi

INC_BLK_N  CALL    SUBINC    ;+ an existing subroutine that does above.

SP_N_END  POP     HL          ; (*) restore the pointer to NCIRIS

      CALL    BORD_REST     ; routine BORD-REST restores border.

;;;      EI          ; enable interrupts.

      LD     (IX+$0C),0     ;+++ SET the number of output bytes to zero.

TST_BR   LD     A,(IX+$07)  ; fetch station of other machine from NCIRIS
      AND    A          ; test for zero - a broadcast.

      RET          ; Return - with zero flag set for broadcast.

; -----
; THE 'OUT-BLK-N' ROUTINE

```

```

; -----
; This routine sends a single block of data, which could be a header or
; buffer block, and validates the response from IRIS.

OUT_BLK_N CALL  OUTPAK          ; routine OUTPAK sends the data block returning
; with DE holding zero.

;;;          LD    A, (IX+$07)    ; fetch the other station number from NCIRIS
;;;          AND   A              ; test for zero.

          CALL  TST_BR          ;+ New routine to test for a broadcast.

          RET   Z              ; Return if a broadcast, no response required.

          LD    HL,$5BC0        ; Make HL address system variable NTRESP

;;;          LD    (HL),$00        ; and insert a zero.
;;;          LD    E,$01          ; set byte count to 1.

          LD    (HL),E          ;+ and insert a zero.
          INC   E              ;+ set byte count to 1.

          CALL  INPAK          ; routine INPAK reads one byte from network.

          RET   NZ            ; return, signaling failure, if no activity.

          LD    A, ($5BC0)      ; Fetch updated value of NTRESP.
          DEC   A              ; test for $01.
          RET                   ; Return, with zero flag set for success.

; -----
; THE 'HEADER AND DATA BLOCK RECEIVING' ROUTINE
; -----
; This subroutine is called once from NCHAN_IN to read in the next header
; and data block from the network, when the buffer is empty.
; An eight byte header is sent from the network channel of the sending
; computer but received into eight system variables.

GET_NBLK LD    HL,$5BC1        ; Address system variable NTDEST
          LD    E,$08          ; Set byte count to eight.

          CALL  INPAK          ; Routine INPAK reads in a header.

          RET   NZ            ; Return, signaling failure, if inactive.

;;;          LD    HL,$5BC1        ; Address system variable NTDEST again.

          LD    L,$C1          ;+ Address system variable NTDEST again

;;;          XOR   A              ; Initialize checksum to zero.
;;;          LD    B,$07          ; Set byte count to seven.
;;; CHKS3 ADD   A, (HL)          ; Add the addressed byte.
;;;          INC   HL            ; Point to next header byte.
;;;          DJNZ  CHKS3        ; Back, for all seven bytes, to CHKS3
;;;          CP    (HL)          ; Compare with eighth byte.

          CALL  CHKS7          ; routine to checksum seven bytes.

          RET   NZ            ; Return if checksum disagrees.

; The header has been successfully received and it can be examined to see
; what type of data this is.

```

```

;;; LD A, ($5BC1) ; Fetch the value of NTDEST the received sysvar

LD L, $C1 ;+ Set HL to NTDEST the received system variable
LD A, (HL) ;+ Fetch value to A.

INC L ;+ Set HL to $5BC2 NTSRCE before branching.

AND A ; test for zero.
JR Z, BRCAST ; forward, if so, to BRCAST

CP (IX+$08) ; Compare the destination with NCSELF - this
; station's number.
RET NZ ; Return if data not intended for this Spectrum.

```

; The header indicates the data is for SELF.

```

;;; LD A, ($5BC2) ; Fetch value of received system variable NTSRCE
;;; ; the sending station.

LD A, (HL) ;+ Fetch the sender from $5BCF NTSRC.

CP (IX+$07) ; Compare to channel variable NCIRIS.
RET NZ ; Return if not the expected sender.

```

; The header indicates that both the sender and recipient (SELF) are correct.

```

JR TEST_BLKX ; Forward to TEST-BLKN

```

; ---

; The branch was here when the header indicated a broadcast.

BRCAST

```

;;; LD A, (IX+$07) ; Check the station number of NCIRIS.
;;; OR A ; Test for zero - a broadcast.

CALL TST_BR ;+ New routine to test for a broadcast.

RET NZ ; Return, with failure, if not.

```

; The two paths converge here.

```

TEST_BLKX LD HL, ($5BC3) ; Fetch, from received system variable NTNUMB,
; the number of the block.

LD E, (IX+$09) ; Fetch bytes of expected block NCNUMB_lo and
LD D, (IX+$0A) ; NCNUMB_hi, to DE, from channel variables.

AND A ; prepare for true subtraction.
SBC HL, DE ; subtract the two block numbers.
JR Z, GET_NBUFF ; forward, if they match, to GET-NBUFF

DEC HL ; Decrement HL in case the previously received
LD A, H ; block is being resent because the sender
OR L ; missed our response byte.
RET NZ ; Return if this is not the previous block.

CALL GET_NBUFF ; Routine GET-NBUFF gets the buffer data and
; resends the response byte also incrementing
; the block count.

```

; Note. the next check is new.

```

RET    NZ                ;+ Return if, say, the checksum disagrees the
                        ;+ second time around.

; Cancel the increment and return failure so that we try for the expected
; data again.
; Note. The DEC instruction does not affect the carry flag!

LD     A,(IX+$09)        ;+ Fetch copy of NCNUMB_lo to accumulator.
DEC    (IX+$09)          ; decrement actual NCNUMB_lo
AND    A                 ;+ Was it originally zero?
;;;   JR    NC,GETNB_END ; Forward, if not 255, to GETNB-END
JR     NZ,GETNB_END      ;+ Forward, if not now 255, to GETNB-END
DEC    (IX+$0A)          ; Decrement NCNUMB_hi
GETNB_END OR    $01      ; Reset the zero flag signaling failure to
                        ; the calling routine.
RET                                         ; Return.

; ---

; The branch was here to read the data into the network buffer.
; First send a response byte for the header if this is not a broadcast.
GET_NBUFF CALL  SEND_RESP ; routine sends response byte if not a broadcast

LD     A,($5BC6)         ; Fetch received system variable NTLEN
AND    A                 ; test for zero.
JR     Z,STORE_LEN      ; forward, if empty, to STORE-LEN

PUSH   IX                ; transfer channel base address to
POP    HL                 ; the HL register.

LD     DE,$0011          ; prepare an offset of seventeen.
ADD    HL,DE             ; and add to address start of the data buffer.
PUSH   HL                 ; (*) Preserve the start of network buffer.
LD     E,A               ; Transfer block length to E, value 1-255.

CALL   INPAK             ; routine INPAK reads in the data.

LD     HL,($5BC6)        ;+ load two system variables NTLEN/NTDCS at
once.
LD     B,L               ;+ count of bytes NTLEN to B.
LD     E,H               ;+ checksum NTDCS to E.

POP    HL                 ; (*) Restore start of buffer.
RET    NZ                 ; Return failure if network was inactive.

;;;   LD     A,($5BC6)    ; Fetch count of data bytes from sysvar NTLEN
;;;   LD     B,A          ; transfer to B. (Beyond reach of IY)
;;;   LD     A,($5BC7)    ; Fetch network data checksum from NTDCS
;;; The checksum is verified in the opposite way in which it was derived.
;;; CHKS4 SUB    (HL)     ; Subtract the addressed value.
;;;   INC    HL          ; Increment data pointer.
;;;   DJNZ  CHKS4        ; Back, for all bytes, to CHKS4

CALL   CHKS0             ;+ general purpose checksum adding routine.
CP     E                 ;+ compare with expected.

```



```

        RET    NZ                ; Return failure if result does not agree.

;;;    LD     A,($5BC1)          ; Fetch station from system variable NTDEST
;;;    AND    A                    ; Check for zero - a broadcast

        CALL   SEND_RESP        ; routine SEND-RESP sends response for data
                                   ; if not a broadcast.

STORE_LEN LD     A,($5BC6)      ; Fetch the verified length from sysvar NTLEN
        LD     (IX+$10),A      ; and insert value in channel variable NCIBL.

; Note the next could be a once-called subroutine to increment NCNUMB.

SUBINC   INC    (IX+$09)        ; Increment NCNUMB_lo

        JR    NZ,GETBF_END     ; Forward, if no wraparound, to GETBF-END

        INC    (IX+$0A)        ; Increment the high byte NCNUMB_hi

GETBF_END CP    A                ; Set the zero flag.

        RET                    ; Return with zero flag set indicating success.

```

```

; -----
; THE NEW 'CHECKSUM' ROUTINES
; -----

```

```

; This routine saves just a few bytes by making a subroutine of repetitive
; code. It checksums the header or buffer data. The header data is always
; seven bytes in length. The second entry point is used for the variable
; length buffer data.

```

```

CHKS7    LD     B,$07           ; 7 header bytes to check.

CHKS0    XOR    A                ; Initialize checksum.

CHKSL    ADD    A,(HL)          ; Add a byte.
        INC    HL                ; Address next.
        DJNZ  CHKSL            ; loop back for B bytes.

        CP    (HL)              ; compare with final value which could be sum

        RET                    ; return.

```

```

; -----
; THE 'NETWORK STATE' ROUTINE
; -----

```

```

; This routine waits for the network to become inactive so that it may be
; claimed by this SPECTRUM. So that two waiting Spectrums do not claim the
; network at the same time a random count is used.

```

```

NET_STATE LD    A,R            ; Fetch a random 7-bit value from the Refresh
                                   ; register

        OR    $C0                ; OR with %11000000 giving range 192 - 255.
        LD    B,A                ; transfer to B for count.

        CALL  CHK_REST          ; routine CHK-REST

        JR    C,NET_STATE      ; back to NET-STATE if network is busy.

        RET                    ; return.

```

```

; -----
; THE 'CHECK-RESTING' ROUTINE
; -----
; This subroutine checks that the network is inactive for a period
; determined by the B register which will $80 if called from below or a
; random value if called from the above routine.

CHK_REST  CALL  TEST_BRK          ; routine TEST-BRK will return here if BREAK is
; not pressed.

MAKESURE  PUSH  BC                ; timing
          POP   BC                ; timing

          IN    A,($F7)           ; Read the network port
          RRCA                    ; Test bit 0.
          RET   C                 ; Return if network is claimed by other
; machines.

          DJNZ  MAKESURE          ; back to MAKESURE for a random count.

          RET                      ; Return.

; -----
; THE 'WAIT SCOUT' ROUTINE
; -----
; This routine is called once from NCHAN_IN to identify a SCOUT when this
; station is expecting to receive a network packet.

WT_SCOUT  CALL  TEST_BRK          ; routine TEST-BRK allows user to abort.

          LD    HL,$01C2          ; An even timing value.

CLAIMED   LD    B,$80            ; The non-random count for CHK REST

          CALL  CHK_REST          ; routine CHK-REST

          JR    NC,WT_SYNC        ; forward, if network resting, to WT-SYNC

          DEC  HL                 ; decrement counter
          DEC  HL                 ; decrement counter
          LD   A,H                ; Test for
          OR   L                  ; zero.
          JR   NZ,CLAIMED         ; back, if not, to CLAIMED

; If operation has timed out, then return failure unless expecting a
; broadcast in which case the subroutine waits indefinitely.

;;;      LD    A,(IX+$07)         ; fetch value of channel variable NCIRIS
;;;      AND   A                  ; test for broadcast.

          CALL  TST_BR            ;+ test for a broadcast

          JR   Z,CLAIMED          ; back, if so, to CLAIMED

          RET                      ; Return signaling failure.

; ---

; The branch was here when the network was found to be at rest.

WT_SYNC   IN    A,($F7)           ; read the port.
          RRCA                    ; rotate 'net input' to carry.

```

```

        JR    C,SCOUT_END    ; forward, if scout found, to SCOUT-END  ->
; This is a clever twist.

        LD    A,$7F          ; Read port $7FFE the row with SPACE
        IN    A,($FE)        ;
        OR    $FE            ; Now read port $FEFE the row with SHIFT
        IN    A,($FE)        ;
        RRA                    ; If both SHIFT and SPACE then carry is reset.

        CALL  NC,TEST_BRK    ; routine TEST-BRK errors if BREAK was pressed.

        DEC   HL              ; decrement the counter.
        LD    A,H             ; Test for
        OR    L                ; zero.
        JR    NZ,WT_SYNC     ; back, if not, to WT-SYNC

;;;      LD    A,(IX+$07)     ; load station number from NCIRIS
;;;      AND   A              ; test for a broadcast.

        CALL  TST_BR         ;+ New routine to test for a broadcast.

        JR    Z,WT_SYNC     ; back, if zero, to WT-SYNC

        RET                    ; Return failure - NZ

```

```

; -----
; THE 'SCOUT END' BRANCH
; -----
; The scout is only read by the machine that sent it and as long as it can
; be read back then the sending machine is happy. This receiving machine
; uses the scout leader to synchronize its timing.

```

```

SCOUT_END LD    L,$09        ; set outer counter for 9 bits.

LP_SCOUT  DEC   L            ; ( 4) decrement counter.
          SCF                    ; ( 4) set success condition


          RET   Z            ; ( ) RETURN after nine bits have been timed.

          LD    B,$0E        ; An inner delay counter.

DELAY_SC  DJNZ  DELAY_SC    ; self loop to DELAY-SC

          JR    LP_SCOUT     ; loop back to LP-SCOUT

```



```

;          send      send 8 bits of the      |
;          SCOUT     global station number  Network claimed.
;          leader
;
; -----
; THE 'SEND SCOUT' ROUTINE
; -----
;   In order to claim the network for writing, the SPECTRUM sends out a leader
;   followed by the eight inverted bits of the global station number which
;   should be unique to each machine.

SEND_SC   CALL   NET_STATE      ; routine NET-STATE repeatedly examines the
;                               ; network until it is satisfied that the
;                               ; network is at rest.

          LD     C,$F7          ; The comms port number.
          LD     HL,$0009       ; H is the leader value, L is the count of
;                               ; the SCOUT bits.

          LD     A,($5BBC)      ; Fetch the global station number from NTSTAT
          LD     E,A            ; Transfer to E.

          IN     A,($F7)        ; Test that the network is still inactive.
          RRCA                   ; rotate 'net input' to carry.
          JR     C,SEND_SC      ; back, if network has become active, to SEND-SC

;   Now output the nine values starting with the zero leader in H.

ALL_BITS  OUT     (C),H         ; output bit 0 'net output'

          LD     D,H            ; ( 4) copy state to D for later.
          LD     H,$00          ; set output byte to zero.
          RLC     E              ; rotate a bit from 'global station' to carry.
          RL     H              ; pick it up in bit 0.

          LD     B,$08          ; set timing counter

S_SC_DEL  DJNZ   S_SC_DEL      ; self loop back to S-SC-DEL

          IN     A,($F7)        ; read the network.
          AND    $01            ; isolate the 'net input' bit.
;                               ; Note. network is activated with a zero bit.
;                               ; Received bit is therefore opposite state.
          CP     D              ; compare with expected state.
          JR     Z,SEND_SC      ; back, if not inverted, to SEND-SC
;                               ; to start process again.

          DEC    L              ; decrement the bit counter.
          JR     NZ,ALL_BITS    ; back, if SCOUT not complete, to ALL-BITS

          LD     A,$01          ;; set the output bit.
          OUT    ($F7),A        ;; Make the network inactive.

          LD     B,$0E          ; Wait for a delay

END_S_DEL DJNZ   END_S_DEL      ; self loop to END-S-DEL

          RET                    ; Return.

; -----

```

```

; THE 'INPAK' ROUTINE
; -----
; This routine reads into the network buffer at address HL a pack of bytes
; the count of which is in E.
; The value of E will be -
; a) 1 when reading the Network Response byte.
; b) 8 when reading an eight-byte header into the system variables.
; c) The value of NTLEN, from within the above header, when reading data.

INPAK      LD      B,$FF          ; Set a time-out counter.

N_ACTIVE   IN      A,($F7)        ; Read the network port.
           RRA                    ; rotate 'net input' bit to carry.

           JR      C,INPAK_2      ; forward, if set, to INPAK-2

           DJNZ   N_ACTIVE        ; loop back, 255 times, to N-ACTIVE

           INC    B                ; Indicate network inactive by resetting zero.

           RET                    ; Return. (NZ)

; ---

INPAK_2    LD      B,E            ; Set B to count the number of bytes.

; The byte reading loop.

INPAK_L    LD      E,$80          ; prepare a receiving byte with a marker bit.

           LD      A,$CE          ; Make A %11001110 (wait,cts and comms data low)
           OUT    ($EF),A        ; Enable the network.

           NOP                    ; ( 4) Wait 48 clock cycles.
           NOP                    ; ( 4)
           INC    IX              ; (10)
           DEC    IX              ; (10)
           INC    IX              ; (10)
           DEC    IX              ; (10)

UNTIL_MK   LD      A,$00          ; ( 7) Timing.
           IN      A,($F7)        ; (10) Read net input to bit 0.
           RRA                    ; ( 4) rotate to carry.
           RR      E              ; ( 8) and pick up in E.
           JP     NC,UNTIL_MK     ; (10) JUMP, back if no marker bit, to UNTIL-MK

           LD      (HL),E         ; store the received byte.
           INC    HL              ; Address next location.
           DJNZ   INPAK_L        ; back to INPAK-L

           CP     A                ; Set zero flag to signal success.
           RET                    ; Return.

; -----
; THE 'SEND RESPONSE BYTE' ROUTINE
; -----
; When a header or a data block is successfully received then this routine is
; used to send a response byte to acknowledge the successful receipt of the
; data over the network.

SEND_RESP  LD      HL,$5BC1       ; Address station number NTDEST
           XOR    A                ; set accumulator to zero
           CP     (HL)            ; compare with NTDEST

```

```

        RET    Z                ; return if a broadcast.

        DEC    HL                ; Address $5BC0 NTRESP
        LD     E,$01            ; Load 1 to the byte count.
        LD     (HL),E           ; Insert the value 1

; -----
; THE 'OUTPAK' ROUTINE
; -----
; This routine sends a packet of bytes, up to 255 in length, over the network.
; The start of the data is in HL and the number of bytes is held in E.

OUTPAK  XOR    A                ; clear bit 0
        OUT    ($F7),A          ; send leader to port.
        LD     B,$04            ; ( 4) set timing value.

DEL_0_1 DJNZ   DEL_0_1          ; (12/7) back to DEL-0-1 for leader of

; Now enter a loop to send E bytes each with a set start bit and a reset
; stop bit.

OUTPAK_L LD    A,(HL)           ; ( 6) Fetch a byte to be sent.
        CPL                    ; ( 4) complement.
        SCF                    ; ( 4) Set an initial start bit
        RLA                    ; ( 4) C <- 76543210 <- C
        LD    B,$0A            ; ( 6) Set count to ten bits

UNT_MARK OUT   ($F7),A          ; Output bit 0, to net.
        RRA                    ; C -> 76543210 -> C ; Rotate next bit to
        ; bit 0.
        AND    A                ; clear carry flag to feed in final stop bit.
        DEC    B                ; decrement bit counter.
        LD     D,$00            ; ( 7) timing
        JP     NZ,UNT_MARK      ; JUMP back for 10 bits to UNT-MARK

; The last bit sent will be a reset stop bit.

        INC    HL                ; increment buffer address
        DEC    E                ; decrement the byte count.
        PUSH  HL                ; (11) timing.
        POP   HL                ; (11) timing.
        JP   NZ,OUTPAK_L        ; JUMP, if E not zero, to OUTPAK-L

        LD     A,$01            ; switch off network.
        OUT    ($F7),A          ;
        RET                    ; Return.

; -----
; THE 'FORMAT' COMMAND
; -----
; by James Smith.
; This sets the local network station number which defaulted to 1 at
; switch-on. It can also be used to set the baud rate and printer width.
; FORMAT "n",2 set this station to station 2 ( acceptable range 1 - 64 ).
; FORMAT "b",1200 set baud rate for "b" and "t" RS232 transfers.
; FORMAT "t",80 set printer width of the "t" channel.
;
; This is a CLASS-00 command so it is only executed in runtime when the two
; parameters will be on the calculator stack.

FORMAT  CALL   FIND_INT2        ; routine FIND-INT2 gets number to BC

```

```

        PUSH BC                ; save on machine stack.

        CALL EXPT_SPEC        ; gets channel specifier in A

        AND $DF              ; Make it upper-case.

        POP BC               ; retrieve numeric parameter.

        CP 'B'               ; channel "B" BAUD rate ?
        JR Z,FORMAT_B        ; forward, if so, to FORMAT_B

; After the 16 bit BAUD rate, only 8-bit values are allowed for width/station.

        INC B                ; Test the high-order
        DEC B                ; byte for zero.

        JP NZ,REPORT_B       ; ERROR
                                ; 'Integer out of range'

        CP 'T'               ; Text width ?
        JP Z,FORMAT_T        ; jump back, if so, to FORMAT_T

        CP 'N'               ; Network ?
        JP NZ,REPORT_C       ; back, if unknown letter, to report XXXXX
                                ; 'Nonsense in BASIC'

FORMAT_N LD A,C              ; number should be 1-64
        DEC A                ;

        CP $40               ; compare to 64
        JP NC,REPORT_Q       ;

        INC A                ; correct for earlier DEC

        LD ($5BBC),A         ; set NTSTAT

        RET                  ; Return.

; ---

; Note. these 5 bytes have been moved to space between restarts. (JS)

; FORMAT_T LD A,C            ; get TAB width
;          LD ($5BB8),A      ; set it
;          RET              ; Return.

; -----
; THE 'SET BAUD RATE' ROUTINE
; -----
; by James Smith.
; The BAUD rate is calculated as follows:
; BAUD = (3500000/(26*baud rate)) - 2
;

FORMAT_B CALL STACK_BC        ; put value on calculator stack.

        RST 28H              ; FP-CALC
        DEFB $34             ; ;stk-data
        DEFB $35             ; ;Exponent $85, Bytes:1 constant = 26
        DEFB $50             ; ;$50 ($00,$00,$00)
        DEFB $04             ; ;multiply
        DEFB $34             ; ;stk-data
        DEFB $80             ; ;Exponent $96, Bytes: 3 constant = 3500000

```

```

DEFB $46,$55,$9F,$80 ;; ($55,$9F,$80,$00)
DEFB $01                ;;exchange
DEFB $05                ;;divide
DEFB $38                ;;end-calc

CALL FP_TO_BC           ; get delay into BC

DEC BC                  ; subtract value
DEC BC                  ; two.

LD ($5BBA),BC          ; set BAUD system variable

RET                     ; Return.

```

```

; -----
; THE 'CAT' COMMAND
; -----

```

```

; This CAT command lists the streams to the screen and really grows on you.
; It was inspired by Andrew Pennell's "Stream Lister" which appears in the
; book "master your zx microdrive" published by Melbourne House.

```

CAT

```

CALL CL_ALL             ; clear 24 lines and leave upper screen open.

LD DE,CAT1              ; Point to start of banner text.
LD BC,CAT2-CAT1         ; Set the length.
CALL PR_STRING          ; routine PR_STRING outputs counted string.

LD BC,45                ; decimal adjustment to equate to command line.

CALL TEST_ROOM          ; routine TEST_ROOM returns free RAM in HL.

LD A,H                  ; The value is negated and must be transferred
CPL                     ; to BC registers.
LD B,A                  ;

LD A,L                  ;
CPL                     ;
LD C,A                  ;

CALL STACK_BC           ; stack the 16 bit value.
CALL PRINT_FP           ; print the free memory.

LD DE,CAT3              ; address the remaining text setting inverse 0
LD BC,CAT4-CAT3         ; set the length of the string.

CALL PR_STRING          ; print the rest of the banner.

LD A,$FD                ; The starting stream. (decimal 253).
LD HL,$5B10             ; The relevant system variables location.

```

LOOP

```

AND A                   ; test for zero
PUSH AF                 ; save the stream
PUSH HL                 ; save the address in STRMS area
JR NZ,NO_BLANK         ; skip forward if not stream zero.

```

```

LD A,$0D                ; print a carriage return as a separator
RST 10H                 ; if it is zero

```

NO_BLANK

```

CALL STACK_A           ;
LD A,$0D               ;
RST 10H                 ;

```



```

CALL PRINT_FP      ;
LD A,6             ;
RST 10H           ;
POP HL            ;

LD C,(HL)         ;
INC L             ;
LD B,(HL)         ;
INC L             ;
LD A,B           ;
OR C              ;
JR Z,PR_CR       ;
LD IX,($5B4F)    ; CHANS
ADD IX,BC        ;
LD A,(IX+$03)   ;
RST 10H         ;
PR_CR POP AF     ;
INC A           ;
CP $10         ;
JR NZ,LOOP     ;

RET              ; Return.

CAT3
DEFB $06        ; The 'comma control'
DEFB $14,$00    ; The control codes for INVERSE 0
DEFB $0D        ; The carriage return character.

CAT4

; -----
; THE 'AUTO-LIST' SUBROUTINE
; -----
; This produces an automatic listing in the upper screen.

AUTO_LIST LD ($5B3F),SP ; save stack pointer in LIST_SP
LD (IY+$02),$10 ; update TV_FLAG set bit 3

CALL CL_ALL ; routine CL-ALL clears 24 lines.

;;; SET 0,(IY+$02) ; update TV_FLAG - signal lower screen in use
CALL SIG_L_SCR ; set 0,(iy+$02) as a call.

LD B,(IY+$31) ; fetch lower screen DF_SZ to B.

CALL CL_LINE ; routine CL-LINE clears lower display
; preserving B.

RES 0,(IY+$02) ; update TV_FLAG - signal main screen in use
SET 0,(IY+$30) ; update FLAGS2 - signal it will be necessary
; to clear the main screen.

LD HL,($5B49) ; fetch E_PPC current edit line to HL.
LD DE,($5B6C) ; fetch S_TOP to DE, the current top line
; (initially zero)
AND A ; prepare for true subtraction.
SBC HL,DE ; subtract and
ADD HL,DE ; Add back.
JR C,AUTO_L_2 ; to AUTO-L-2 if S_TOP is higher than E_PPC
; to set S_TOP to E_PPC

PUSH DE ; save the top line number.

CALL LINE_ADDR ; routine LINE-ADDR gets address of E_PPC.

LD DE,$02C0 ; prepare known number of characters in

```

```

; the default upper screen.

EX    DE,HL      ; transfer offset to HL, program address to DE.
SBC   HL,DE      ; subtract high value from low to obtain the
                ; negated result used in addition.
EX    (SP),HL    ; swap result with top line number on stack.

CALL  LINE_ADDR  ; routine LINE-ADDR gets address of that
                ; top line in HL and next line in DE.

POP   BC         ; restore the result to balance the stack.
AUTO_L_1  PUSH  BC      ; save the result.

CALL  NEXT_ONE   ; routine NEXT-ONE gets address in HL of the
                ; line after auto-line (in DE).

POP   BC         ; restore result.
ADD   HL,BC      ; compute back.
JR    C,AUTO_L_3 ; forward, if line 'should' appear, to AUTO-L-3

EX    DE,HL      ; transfer the address of next line to HL.
LD    D,(HL)     ; get line
INC   HL         ; number
LD    E,(HL)     ; in DE.
DEC   HL         ; Adjust back to start.
LD    ($5B6C),DE ; update system variable S_TOP.

JR    AUTO_L_1   ; back, until estimate reached, to AUTO-L-1

; ---

; the jump was to here if S_TOP was greater than E_PPC
AUTO_L_2  LD     ($5B6C),HL      ; make S_TOP the same as E_PPC.

; continue here with valid starting point from above or good estimate
; from computation

AUTO_L_3  LD     HL,($5B6C)      ; fetch S_TOP line number to HL.

CALL  LINE_ADDR  ; routine LINE-ADDR gets address in HL.
                ; Address of next in DE.

JR    Z,AUTO_L_4 ; forward, if line exists, to AUTO-L-4

EX    DE,HL      ; else use address of next line.

AUTO_L_4  CALL  LIST_ALL      ; routine LIST-ALL quits when screen full >>>

; The return will be to here if no scrolling occurred

JP    PO_N_AUTO  ;+ to code similar to below.

;;;      RES    4,(IY+$02)      ; update TV_FLAG - signal no auto listing.
;;;      RET                      ; return.

; -----
; THE 'LLIST' COMMAND
; -----
; List Program to any stream.
; As the manual points out, this is not standard BASIC.
; A short form of LIST #3. The listing goes to stream 3 - default printer.
; This always was a nonsense for compatibility with the ZX81 but now one is

```

```

;   unable to assume that stream 3 will be used for a printer.
;   This will be replaced with an extra UDG.

LLIST      LD      A,$03          ; the usual stream for a Printer

           JR      LIST_1        ; forward to LIST-1

; -----
; THE 'LIST' COMMAND
; -----
; List Program to any stream.
; Note. While a starting line can be specified it is not possible to specify
; an end line. Just listing a line makes it the current edit line.

LIST       LD      A,$02          ; default is stream 2 - the upper screen.

LIST_1     LD      (IY+$02),$00    ; the TV_FLAG is initialized with bit 0 reset
           ; indicating upper screen in use.
;;;       CALL    SYNTAX_Z        ; routine SYNTAX-Z - checking syntax ?
;;;       CALL    NZ,CHAN_SLCT    ; routine CHAN-OPEN if in run-time.

           CALL    CHN_O_SYN      ;+ Routine opens channel in runtime.

;;;       RST     18H            ; GET-CHAR

           CALL    STR_ALTER      ; routine STR-ALTER will alter if '#'.

           JR      C,LIST_4       ; forward, if not a hash, to LIST-4

;;;       RST     18H            ; GET-CHAR
;;;       CP     $3B            ; is character a ';' ?
;;;       JR      Z,LIST_2       ; skip, if so, to LIST-2
;;;       CP     $2C            ; is character a ',' ?

           CALL    EXPT_SEP      ;+ NEW routine to check for ';' or ','.

           JR      NZ,LIST_3      ; forward, if neither separator, to LIST-3

; we have, say, LIST #15, and a number must follow the separator.

LIST_2     RST     20H            ; NEXT-CHAR

           CALL    EXPT_1NUM      ; routine EXPT-1NUM checks for numeric
           ; expression and stacks it in run-time.

           JR      LIST_5        ; forward to LIST-5

; ---

; the branch was here with just LIST #3 etc.

LIST_3     CALL    USE_ZERO      ; routine USE-ZERO defaults first line.

           JR      LIST_5        ; forward to LIST-5

; ---

; the branch was here with LIST

LIST_4     CALL    FETCH_NUM      ; routine FETCH-NUM checks if a number
           ; follows else uses zero.

LIST_5     CALL    CHECK_END      ; routine CHECK-END quits if syntax OK      >>

```

```

; Continue in runtime.

        CALL  FIND_LINE      ;+ routine FIND-LINE fetches the number from the
                                ;+ calculator stack and validates in run-time.

;;;     LD     A,B           ; fetch high byte of line number and
;;;     AND    $3F          ; make less than $40 so that NEXT-ONE
;;;                               ; (from LINE-ADDR) doesn't lose context.
;;;                               ; Note. this is not satisfactory and the typo
;;;                               ; LIST 20000 will list an entirely different
;;;                               ; section than LIST 2000. Such typos are not
;;;                               ; available for checking if they are direct
;;;                               ; commands.

;;;     LD     H,B           ; transfer the modified
;;;     LD     L,C           ; line number to HL.

        LD     ($5B49),HL    ; update E_PPC to the new line number.

        CALL  LINE_ADDR     ; routine LINE-ADDR gets the address of the
                                ; line.

; This routine is called from AUTO-LIST

LIST_ALL LD     E,$01       ; signal current line not yet printed

LIST_ALL2 CALL  OUT_LINE    ; routine OUT-LINE outputs a BASIC line
                                ; using PRINT-OUT and makes an early return
                                ; when no more lines to print. >>>

        RST   10H          ; PRINT-A prints the carriage return (in A)

        BIT   4,(IY+$02)    ; test TV_FLAG - automatic listing ?
        JR    Z,LIST_ALL2   ; back, if not, to LIST-ALL-2
                                ; (loop exit is via OUT-LINE)

; Continue here if an automatic listing required.

        LD     A,($5B6B)    ; fetch DF_SZ lower display file size.
        SUB   (IY+$4F)      ; subtract S_POSN_hi the current line number.
        JR    NZ,LIST_ALL2  ; back to LIST-ALL-2 if upper screen not full.

        XOR   E             ; A contains zero, E contains one if the
                                ; current edit line has not been printed
                                ; or zero if it has (from OUT-LINE).

        RET   Z             ; return if the screen is full and the line
                                ; has been printed.

; Continue with automatic listings if the screen is full and the current
; edit line is missing. OUT-LINE will scroll automatically.

        PUSH  HL            ; save the pointer address.
        PUSH  DE            ; save the E flag.
        LD    HL,$5B6C      ; fetch S_TOP the rough estimate.

        CALL  LN_FETCH      ; routine LN-FETCH updates S_TOP with
                                ; the number of the next line.

        POP   DE            ; restore the E flag.
        POP   HL            ; restore the address of the next line.
        JR    LIST_ALL2    ; back to LIST-ALL-2.

; -----

```

```

; THE 'PRINT A WHOLE BASIC LINE' SUBROUTINE
; -----
; This routine prints a whole BASIC line and it is called from LIST-ALL to
; output the line to current channel and from ED-EDIT to 'sprint' the line
; to the edit buffer.

OUT_LINE LD BC,($5B49) ; fetch E_PPC the current line which may be
; unchecked and not exist.

CALL CP_LINES ; routine CP-LINES finds match or line after.

LD D,$3E ; prepare cursor '>' in D.
JR Z,OUT_LINE1 ; to OUT-LINE1 if matched or line after.

LD DE,$0000 ; put zero in D, to suppress line cursor.
RL E ; pick up carry in E if line before current
; leave E zero if same or after.

OUT_LINE1 LD (IY+$2D),E ; save flag in BREG which is spare.
LD A,(HL) ; get high byte of line number.
CP $40 ; is it too high ($2F is maximum possible) ?
POP BC ; drop the return address and
RET NC ; make an early return if so >>>

PUSH BC ; save return address

CALL OUT_NUM_2 ; routine OUT-NUM-2 to print addressed number
; with leading space.

INC HL ; skip low number byte.
INC HL ; and the two
INC HL ; length bytes.
RES 0,(IY+$01) ; update FLAGS - signal leading space required.
LD A,D ; fetch the cursor.
AND A ; test for zero.
JR Z,OUT_LINE3 ; forward, if zero, to OUT-LINE3

RST 10H ; PRINT-A prints '>' the current line cursor.

; this entry point is called from ED-COPY

OUT_LINE2 SET 0,(IY+$01) ; update FLAGS - suppress leading space.

OUT_LINE3 PUSH DE ; save flag E for a return value.
EX DE,HL ; save HL address in DE.
RES 2,(IY+$30) ; update FLAGS2 - signal NOT in QUOTES.

LD HL,$5B3B ; point to FLAGS.
RES 2,(HL) ; signal 'K' mode. (starts before keyword)

;;; BIT 5,(IY+$37) ; test FLAGX - input mode ?
CALL TST_INP_M ;+ bit 5,(iy+$37) as a 3-byte call.
JR Z,OUT_LINE4 ; forward, if not, to OUT-LINE4

SET 2,(HL) ; signal 'L' mode. (used for input)

OUT_LINE4 LD HL,($5B5F) ; fetch X_PTR - possibly the error pointer
; Address.
AND A ; clear the carry flag.
SBC HL,DE ; test if an error address has been reached.
JR NZ,OUT_LINE5 ; forward, if not, to OUT-LINE5

LD A,$3F ; load A with '?' the error marker.
CALL OUT_FLASH ; routine OUT-FLASH to print flashing marker.

```

```

OUT_LINE5 CALL OUT_CURS      ; routine OUT-CURS will print the cursor if
                                ; this is the right position.
        EX  DE,HL            ; restore address pointer to HL.
        LD  A,(HL)          ; fetch the addressed character.

        CALL NUMBER         ; routine NUMBER skips a hidden floating
                                ; point number if present.

        INC HL              ; now increment the pointer.
        CP  $0D             ; is character end-of-line ?

        JR  Z,OUT_LINE6    ; forward, if so, to OUT-LINE6
                                ; as line is complete

        EX  DE,HL            ; save the pointer in DE.
        CALL OUT_CHAR       ; routine OUT-CHAR to output character/token.

        JR  OUT_LINE4      ; back to OUT-LINE4 until entire line is done.

```

```
; ---
```

```

OUT_LINE6 POP DE             ; bring back the flag E, zero if current line
                                ; printed else value one if still to print.

        RET                ; return - with A holding $0D

```

```
; -----
; THE 'CHANNEL LETTER' SUBROUTINE
; -----
;
```

```

IN_CHAN_K LD HL,($5B51)     ; fetch address of current channel CURCHL
        JR  NUMBER_4       ; forward to pick up channel letter.

```

```
; -----
; THE 'NUMBER' SUBROUTINE
; -----
;
```

```
; This subroutine is called from two processes. while outputting BASIC lines
; and while searching statements within a BASIC line. During both, this
; routine will pass over an invisible number indicator and the five bytes
; floating-point number that follows it. Note that this causes floating
; point numbers to be stripped from the BASIC line when it is fetched to the
; edit buffer by OUT_LINE. The number marker also appears after the
; arguments of a DEF FN statement and may mask old 5-byte string parameters.

```

```

NUMBER  CP  $0E             ; character fourteen ?
        RET  NZ             ; return if not.

        INC HL              ; skip the character
NUMBER_5 INC HL            ; and five bytes
NUMBER_4 INC HL            ; following.
NUMBER_3 INC HL            ;
        INC HL              ;
        INC HL              ;
        LD  A,(HL)         ; fetch the following character
        CP  $4B            ;+ default comparison - is it letter 'K' ?
        RET                ; for return value.

```

```
; -----
; THE 'PRINT A FLASHING CHARACTER' SUBROUTINE
; -----
;
```

```
; This subroutine is called from OUT-LINE to print a flashing error
; marker '?' or from the next routine to print a flashing cursor e.g. 'L'.

```

```

;   However, this only gets called from OUT-LINE when printing the edit line
;   or the input buffer to the lower screen, so a direct call to PRINT_OUT
;   can be used, even though out-line outputs to other streams.
;   In fact the alternate set is used for the whole routine.

```

```

OUT_FLASH EXX                ; Switch in alternate set

;;;      LD      HL,($5B8F)    ; fetch L = ATTR_T, H = MASK-T
;;;      PUSH   HL            ; preserve original value and masks.

;;;      RES    7,H           ; reset flash mask bit so active.
;;;      SET    7,L           ; make attribute FLASH.
;;;      LD      ($5B8F),HL    ; update system variables ATTR_T and MASK-T

;;;      LD      HL,$5B91     ; Address P_FLAG
;;;      LD      D,(HL)       ; fetch value to D
;;;      PUSH   DE            ; and preserve original value.
;;;      LD      (HL),$00     ; clear inverse, over, ink/paper 9

      CALL  PRINT_OUT        ; Routine PRINT-OUT outputs character without
                          ; the need to vector via RST 10.

      EX     DE,HL          ;+ Note. NEW transfer attribute byte to HL.

      SET    7,(HL)         ;+ Make it flash.

;;;      POP    HL           ; pop the original P_FLAG to H.
;;;      LD      (IY+$57),H   ; and restore system variable P_FLAG.

;;;      POP    HL           ; restore original attribute and mask
;;;      LD      ($5B8F),HL   ; and restore system variables ATTR_T/MASK_T

      EXX                    ; Switch back to main set

      RET                    ; Return

```

```

; -----
; THE 'PRINT THE CURSOR' SUBROUTINE
; -----

```

```

;   This routine is called before any character is output while outputting
;   a BASIC line or the input buffer. This includes listing to a printer or
;   the screen, copying a BASIC line to the edit buffer and printing the
;   input buffer or edit buffer to the lower screen. It is only in the
;   latter two cases that it has any relevance and in the last case it
;   performs another very important function also.

```

```

OUT_CURS  LD      HL,($5B5B)  ; fetch K_CUR the current cursor address
          AND     A           ; prepare for true subtraction.
          SBC    HL,DE       ; test against pointer address in DE and
          RET     NZ         ; return if not at exact position.

```

```

;   the value of MODE, maintained by KEY-INPUT, is tested and if non-zero
;   then this value 'E' or 'G' will take precedence.

```

```

      LD      A,($5B41)      ; fetch MODE 0='KLC', 1='E', 2='G'.
      RLC     A              ; double the value and set flags.
      JR     Z,OUT_C_1      ; forward, if still zero, to OUT-C-1 ('KLC').

      ADD    A,$43          ; Add 'C' - will become 'E' if originally 1
                          ; or 'G' if originally 2.

      JR     OUT_C_2        ; forward to OUT-C-2 to print.

```

```

; ---

```

```

; If mode was zero then, while printing a BASIC line, bit 2 of flags has been
; set if 'THEN' or ':' was encountered as a main character and reset
; otherwise. This is now used to determine if the 'K' cursor is to be printed
; but this transient state is also now transferred permanently to bit 3
; of FLAGS to let the interrupt routine know how to decode the next key.

```

```

OUT_C_1  LD    HL,$5B3B      ; Address FLAGS
        RES   3,(HL)       ; signal 'K' mode initially.
        LD    A,$4B        ; prepare letter 'K'.

        BIT   2,(HL)       ; test FLAGS - was the
                           ; previous main character ':' or 'THEN' ?

        JR    Z,OUT_C_2    ; forward, if so to print, at OUT-C-2

        SET   3,(HL)       ; signal 'L' mode to the interrupt routine.
                           ; Note. transient bit has been made permanent.

        INC   A            ; Augment character from 'K' to 'L'.

        BIT   3,(IY+$30)   ; test FLAGS2 - consider caps lock ?
                           ; which is maintained by KEY-INPUT.

        JR    Z,OUT_C_2    ; forward, if not set to print, at OUT-C-2

        LD    A,$43        ; alter character 'L' to 'C'.

```

```

;;;     PUSH  DE           ; save address pointer but OK as OUT-FLASH
;;;     ; uses alternate set without RST 10.

```

```

OUT_C_2  JR    OUT_FLASH   ;+ routine OUT-FLASH to print.

```

```

;;;     POP   DE           ; restore and

```

```

;;;     RET                ; return. (replace CALL,RET with a JR)

```

```

; -----
; THE 'LN_FETCH' SUBROUTINE
; -----

```

```

; These two subroutines are called while editing.
; The first entry point is from ED-DOWN with HL addressing E_PPC to fetch the
; next line number.
; Also from AUTO-LIST with HL addressing S_TOP just to update S_TOP with the
; value of the next line number. It gets fetched but is discarded.
;

```

```

; These routines never get called while the editor is being used for input.

```

```

LN_FETCH LD    E,(HL)      ; fetch low byte
        INC   HL          ; address next
        LD    D,(HL)      ; fetch high byte.
        PUSH HL          ; save system variable hi pointer.
        EX   DE,HL       ; line number to HL,
        INC   HL          ; increment as a starting point.

        CALL  LINE_ADDR   ; routine LINE-ADDR gets address in HL.

        CALL  LINE_NO    ; routine LINE-NO gets line number in DE.

        POP   HL         ; restore system variable hi pointer.

```

```

; This entry point is from the ED-UP with HL addressing E_PPC_hi

```

```

;;; L191C:  BIT   5,(IY+$37) ; test FLAGX - input mode ?

```



```

;;;          RET    NZ          ; return if not edit mode.
;;;          ; Note. above already checked by ED-UP/ED-DOWN.

LN_STORE LD    (HL),D          ; save high byte of line number.
          DEC   HL             ; address lower
          LD    (HL),E          ; save low byte of line number.

          RET                  ; return.

; -----
; THE 'OUTPUT NUMBERS IN BASIC LINE' ROUTINE
; -----
; This routine entered at OUT-SP-NO is used to compute then output the first
; three digits of a 4-digit BASIC line printing a space if necessary.
; The line number, or residual part, is held in HL and the BC register
; holds a subtraction value -1000, -100 or -10.
; Note. for example line number 200 is output by
; space(out_char), 2(out_code), 0(out_char) final number always out-code.

OUT_SP_2 LD    A,E             ; will be space if OUT-CODE not yet called.
          ; or $FF if spaces are suppressed.
          ; else $30 ('0').
          ; (from the first instruction at OUT-CODE)
          AND   A               ; test bit 7 of A.
          RET   M               ; return if $FF, as leading spaces not
          ; required. This is set when printing line
          ; number and statement in MAIN-5.

          JR    OUT_CHAR        ; forward to exit via OUT-CHAR.

; ---
; -> the single entry point.

OUT_SP_NO XOR   A              ; initialize digit to 0

OUT_SP_1 ADD   HL,BC           ; add negative number to HL.
          INC   A               ; increment digit
          JR    C,OUT_SP_1      ; back to OUT-SP-1 until no carry from
          ; the addition.

          SBC   HL,BC           ; cancel the last addition
          DEC   A               ; and decrement the digit.
          JR    Z,OUT_SP_2      ; back to OUT-SP-2 if it is zero.

          JP   OUT_CODE         ; jump back to exit via OUT-CODE.    ->

; -----
; THE 'OUTPUT CHARACTERS IN A BASIC LINE' SUBROUTINE
; -----
; This subroutine ...

OUT_CHAR CALL  NUMERIC          ; routine NUMERIC tests if it is a digit ?

          JR    NC,OUT_CH_3     ; to OUT-CH-3 to print digit without
          ; changing mode. Will be 'K' mode if digits
          ; are at beginning of edit line.

          CP   $21              ; less than quote character ?
          JR    C,OUT_CH_3      ; to OUT-CH-3 to output controls and space.

          RES  2,(IY+$01)       ; initialize FLAGS to 'K' mode and leave
          ; unchanged if this character would precede

```

```

; a keyword.

CP    $CB          ; is character 'THEN' token ?
JR    Z,OUT_CH_3   ; forward, if so, to OUT-CH-3

CP    $3A          ; is character ':' ?
JR    NZ,OUT_CH_1  ; forward, if not, to OUT-CH-1
                    ; to change mode back to 'L'.

;;;
BIT    5,(IY+$37)  ; FLAGX - Input Mode ??
CALL   TST_INP_M   ;+ bit 5,(iy+$37) as a 3-byte call.
JR    NZ,OUT_CH_2  ; forward, if in INPUT, to OUT-CH-2
                    ; Note. this check should seemingly be at
                    ; the start. Commands seem inappropriate in
                    ; INPUT mode and are rejected by the syntax
                    ; checker anyway.
                    ; unless INPUT LINE is being used.

BIT    2,(IY+$30)  ; test FLAGS2 - is the ':' within quotes ?
JR    Z,OUT_CH_3   ; forward, if not, to OUT-CH-3

JR    OUT_CH_2     ; forward to OUT-CH-2 as ':' is within quotes

; ---
OUT_CH_1 CP    $22          ; is it the quote character '"' ?
          JR    NZ,OUT_CH_2 ; forward, with others, to OUT-CH-2
                    ; to set 'L' mode.

          PUSH   AF          ; save character.
          LD    A,($5B6A)     ; fetch FLAGS2.
          XOR   $04          ; toggle the quotes flag - BIT 2, FLAGS2
          LD    ($5B6A),A     ; update FLAGS2
          POP   AF          ; and restore character.

OUT_CH_2 SET   2,(IY+$01)    ; update FLAGS - signal L mode if the cursor
                    ; is next.

OUT_CH_3 RST   10H          ; PRINT-A vectors the character to
                    ; channel 'S', 'K', 'R' or 'P'.
          RET                ; return.

; -----
; THE 'LINE ADDRESS' SUBROUTINE
; -----
; This routine is used often to get the address, in HL, of a BASIC line
; number supplied in HL, or failing that the address of the following line
; and the address of the previous line in DE.

LINE_ADDR PUSH   HL          ; save line number in HL register
          LD    HL,($5B53)    ; fetch start of program from PROG
          LD    D,H          ; transfer address to
          LD    E,L          ; the DE register pair.

LINE_AD_1 POP    BC          ; restore the line number to BC

          CALL  CP_LINES      ; routine CP-LINES compares with that
                    ; addressed by HL

          RET    NC          ; return if line has been passed or matched.
                    ; if NZ, address of previous is in DE

          PUSH  BC          ; save the current line number

```

```

        CALL  NEXT_ONE          ; routine NEXT-ONE finds address of next
                                ; line number in DE, previous in HL.

        EX    DE,HL            ; switch so next in HL
        JR    LINE_AD_1        ; back, for another comparison, to LINE-AD-1

; -----
; THE 'COMPARE LINE NUMBERS' SUBROUTINE
; -----
; This routine compares a line number supplied in BC with an addressed
; line number pointed to by HL.

CP_LINES LD    A,(HL)          ; Load the high byte of line number and
        CP    B                ; compare with that of supplied line number.
        RET   NZ                ; return if yet to match (carry will be set).

        INC   HL                ; address low byte of
        LD    A,(HL)            ; number and pick up in A.
        DEC   HL                ; step back to first position.
        CP    C                ; now compare.
        RET   Z                ; zero set if exact match.
                                ; carry set if yet to match.
                                ; no carry indicates a match or
                                ; next available BASIC line or
                                ; program end marker.

; -----
; THE 'FIND EACH STATEMENT' SUBROUTINE
; -----
; The single entry point EACH-STMT is used to
; 1) To find the D'th statement in a line.
; 2) To find a token in held E.

;;; L1988:  INC    HL            ; not used
;;;        INC    HL            ; not used
;;;        INC    HL            ; not used

; -> entry point.

EACH_STMT LD    ($5B5D),HL      ; Save HL in CH_ADD
        LD    C,$00            ; Initialize the quotes flag

EACH_S_1  DEC    D              ; Decrease the statement count
        RET   Z                ; Return if zero

        RST   20H              ; NEXT-CHAR
        CP    E                ; Is it the search token ?
        JR    NZ,EACH_S_3      ; Forward, if not, to EACH-S-3

        AND   A                ; clear carry

        RET                    ; return signaling success.

; ---

EACH_S_2  INC    HL            ; next address
        LD    A,(HL)          ; next character

EACH_S_3  CALL   NUMBER         ; routine NUMBER skips if number marker

        LD    ($5B5D),HL      ; save character address in CH_ADD
        CP    $22             ; is it quotes character '"' ?

```

```

        JR    NZ,EACH_S_4      ; forward, if not, to EACH-S-4
        DEC   C                ; toggle bit 0 of C
EACH_S_4 CP    $3A            ; is character ':'
        JR    Z,EACH_S_5      ; forward, if so, to EACH-S-5
        CP    $CB            ; is character 'THEN'
        JR    NZ,EACH_S_6     ; forward, if not, to EACH-S-6
EACH_S_5 BIT   0,C           ; is it within quotes ?
        JR    Z,EACH_S_1      ; back, if not, to EACH-S-1
EACH_S_6 CP    $0D           ; end of line ?
        JR    NZ,EACH_S_2     ; back, if not, to EACH-S-2
        DEC   D                ; decrease the statement counter
                                ; which should be zero else
                                ; 'Statement Lost'.
        SCF                    ; set carry flag - signal not found
        RET                    ; return
; -----
; Storage of variables. For full details - see chapter 24.
; ZX Spectrum BASIC Programming by Steven Vickers 1982.
;
; It is bits 7-5 of the first character of a variable that allow
; the six types to be distinguished. Bits 4-0 are the reduced letter.
; So any variable name is higher than $3F and can be distinguished
; also from the variables area end-marker $80.
;
; 76543210 meaning                brief outline of format.
; -----
; 010    string variable.          2 byte length + contents.
; 110    string array.            2 byte length + contents.
; 100    array of numbers.        2 byte length + contents.
; 011    simple numeric variable. 5 bytes.
; 101    variable length named numeric. 5 bytes.
; 111    for-next loop variable.  18 bytes.
; 10000000 the variables area end-marker.
;
; Note. any of the above seven will serve as a program end-marker.
; -----
; -----
; THE 'NEXT ONE' SUBROUTINE
; -----
; This versatile routine is used to find the address of the next line
; in the program area or the next variable in the variables area.
; The reason one routine is made to handle two apparently unrelated tasks
; is that it can be called indiscriminately when merging a line or a
; variable.
NEXT_ONE  PUSH  HL            ; save the pointer address.
         LD    A,(HL)        ; get first byte.
         CP    $40           ; compare with upper limit for line numbers.
         JR    C,NEXT_O_3    ; forward to NEXT-O-3 if within BASIC area.
; The continuation here is for the next variable.
         BIT   5,A           ; is it a string or an array variable ?
         JR    Z,NEXT_O_4    ; forward to NEXT-O-4 to compute length.

```



```

LD      ($5B5D),HL      ; store in the system variable CH_ADD.

RST    20H              ; NEXT-CHAR skips any noise and white-space
                        ; to point exactly at the first digit.

LD      HL,$5B92        ; use MEM-0 as a temporary calculator stack
                        ; an overhead of three locations are needed.
LD      ($5B65),HL      ; set new STKEND.

CALL    INT_TO_FP       ; routine INT-TO-FP will read digits till
                        ; a non-digit found.
CALL    FP_TO_BC        ; routine FP-TO-BC will retrieve number
                        ; from stack at MEMBOT.
JR      C,REPORT_Ce     ; forward to E-L-1 if overflow i.e. > 65535.
                        ; 'Nonsense in BASIC'

LD      HL,$D8F0        ; load HL with the value -9999
ADD     HL,BC           ; add to line number in BC

;   a line in the range 0 - 9999 has been entered.

JP      NC,SET_STK      ; jump back to SET-STK to set the calculator
                        ; stack back to its normal place and exit
                        ; from there.

;;; E_L_1 JP      C,REPORT_C      ; to REPORT-C 'Nonsense in BASIC' if over.

REPORT_Ce RST    30H      ; ERROR-1
DEFB    $0B           ; 'Nonsense in BASIC'

;;;      JP      SET_STK          ; jump back to SET-STK

; -----
; THE 'REPORT AND LINE NUMBER PRINTING' SUBROUTINE
; -----
;   Entry point OUT-NUM-1 is used by the Error Reporting code to print
;   the line number and later the statement number held in BC.
;   If the statement was part of a direct command then -2 is used as a
;   dummy line number so that zero will be printed in the report.
;   This routine is also used to print the exponent of E-format numbers.
;
;   Entry point OUT-NUM-2 is used from OUT-LINE to output the line number
;   addressed by HL with leading spaces if necessary.

OUT_NUM_0 LD      B,$00      ;+ New entry point to print C

OUT_NUM_1 PUSH    DE          ; save the
PUSH    HL                ; registers.

XOR     A                ; set A to zero.
BIT     7,B              ; is the line number minus two ?
JR      NZ,OUT_NUM_4      ; forward, if so, to OUT-NUM-4
                        ; to print zero for a direct command.

LD      H,B              ; transfer the
LD      L,C              ; number to HL.

LD      E,$FF            ; signal 'no leading zeros'.
JR      OUT_NUM_3        ; forward to continue at OUT-NUM-3

; ---

;   Entry point from OUT-LINE - HL addresses line number.

```

```

OUT_NUM_2 PUSH DE ; save flags
          LD D,(HL) ; high byte to D
          INC HL ; address next
          LD E,(HL) ; low byte to E
          PUSH HL ; save pointer
          EX DE,HL ; transfer number to HL
          LD E,$20 ; signal 'output leading spaces'

OUT_NUM_3 LD BC,$FC18 ; value -1000
          CALL OUT_SP_NO ; routine OUT-SP-NO outputs space or number

          LD BC,$FF9C ; value -100
          CALL OUT_SP_NO ; routine OUT-SP-NO

          LD C,$F6 ; value -10 ( B is still $FF )
          CALL OUT_SP_NO ; routine OUT-SP-NO

          LD A,L ; remainder to A.

OUT_NUM_4 CALL OUT_CODE ; routine OUT-CODE for final digit.
          ; else report code zero wouldn't get printed.

          POP HL ; Restore the
          POP DE ; registers.

          RET ; return.

```

```

;*****
;** Part 7. BASIC LINE AND COMMAND INTERPRETATION **
;*****

```

```

; -----
; THE 'OFFSET' TABLE
; -----

```

```

; The BASIC interpreter has found a command code $CE - $FF
; which is then reduced to range $00 - $31 and added to the base address
; of this table to give the address of an offset which, when added to
; the offset therein, gives the location in the following parameter table
; where a list of class codes, separators and addresses relevant to the
; command exists.

```

```

offst_tbl DEFB P_DEF_FN - $ ; B1 offset to Address: P-DEF-FN
          DEFB P_CAT - $ ; CB offset to Address: P-CAT
          DEFB P_FORMAT - $ ; BC offset to Address: P-FORMAT
          DEFB P_MOVE - $ ; BF offset to Address: P-MOVE
          DEFB P_ERASE - $ ; C4 offset to Address: P-ERASE
          DEFB P_OPEN - $ ; AF offset to Address: P-OPEN
          DEFB P_CLOSE - $ ; B4 offset to Address: P-CLOSE
          DEFB P_MERGE - $ ; 93 offset to Address: P-MERGE
          DEFB P_VERIFY - $ ; 91 offset to Address: P-VERIFY
          DEFB P_BEEP - $ ; 92 offset to Address: P-BEEP
          DEFB P_CIRCLE - $ ; 95 offset to Address: P-CIRCLE
          DEFB P_INK - $ ; 98 offset to Address: P-INK
          DEFB P_PAPER - $ ; 98 offset to Address: P-PAPER
          DEFB P_FLASH - $ ; 98 offset to Address: P-FLASH
          DEFB P_BRIGHT - $ ; 98 offset to Address: P-BRIGHT
          DEFB P_INVERSE - $ ; 98 offset to Address: P-INVERSE
          DEFB P_OVER - $ ; 98 offset to Address: P-OVER
          DEFB P_OUT - $ ; 98 offset to Address: P-OUT
          DEFB P_LPRINT - $ ; 7F offset to Address: P-LPRINT
          DEFB P_LLIST - $ ; 81 offset to Address: P-LLIST
          DEFB P_STOP - $ ; 2E offset to Address: P-STOP

```



```

DEFB P_READ      - $ ; 6C offset to Address: P-READ
DEFB P_DATA      - $ ; 6E offset to Address: P-DATA
DEFB P_RESTORE   - $ ; 70 offset to Address: P-RESTORE
DEFB P_NEW       - $ ; 48 offset to Address: P-NEW
DEFB P_BORDER    - $ ; 94 offset to Address: P-BORDER
DEFB P_CONT      - $ ; 56 offset to Address: P-CONT
DEFB P_DIM       - $ ; 3F offset to Address: P-DIM
DEFB P_REM       - $ ; 41 offset to Address: P-REM
DEFB P_FOR       - $ ; 2B offset to Address: P-FOR
DEFB P_GO_TO     - $ ; 17 offset to Address: P-GO-TO
DEFB P_GO_SUB    - $ ; 1F offset to Address: P-GO-SUB
DEFB P_INPUT     - $ ; 37 offset to Address: P-INPUT
DEFB P_LOAD      - $ ; 77 offset to Address: P-LOAD
DEFB P_LIST      - $ ; 44 offset to Address: P-LIST
DEFB P_LET       - $ ; 0F offset to Address: P-LET
DEFB P_PAUSE     - $ ; 59 offset to Address: P-PAUSE
DEFB P_NEXT      - $ ; 2B offset to Address: P-NEXT
DEFB P_POKE      - $ ; 43 offset to Address: P-POKE
DEFB P_PRINT     - $ ; 2D offset to Address: P-PRINT
DEFB P_PLOT      - $ ; 51 offset to Address: P-PLOT
DEFB P_RUN       - $ ; 3A offset to Address: P-RUN
DEFB P_SAVE      - $ ; 6D offset to Address: P-SAVE
DEFB P_RANDOM    - $ ; 42 offset to Address: P-RANDOM
DEFB P_IF        - $ ; 0D offset to Address: P-IF
DEFB P_CLS       - $ ; 49 offset to Address: P-CLS
DEFB P_DRAW      - $ ; 5C offset to Address: P-DRAW
DEFB P_CLEAR     - $ ; 44 offset to Address: P-CLEAR
DEFB P_RETURN    - $ ; 15 offset to Address: P-RETURN
DEFB P_COPY      - $ ; 5D offset to Address: P-COPY

```

```

; -----
; THE 'PARAMETER OR SYNTAX' TABLE
; -----

```

```

; For each command there exists a variable list of parameters.
; If the character is greater than a space it is a required separator.
; If less, then it is a command class in the range 00 - 0B.
; Note that classes 00, 03 and 05 will fetch the addresses from this table.
; Some classes e.g. 07 and 0B have the same address in all invocations
; and the command is re-computed from the low-byte of the parameter address.
; Some e.g. 02 are only called once so a call to the command is made from
; within the class routine rather than holding the address within the table.
; Some class routines check syntax entirely and some leave this task for the
; command itself.
; Others for example CIRCLE (x,y,z) check the first part (x,y) using the
; class routine and the final part (,z) within the command.
; The last few commands appear to have been added in a rush but their syntax
; is rather simple e.g. MOVE "M1","M2"

```

```

P_LET      DEFB $01      ; Class-01 - A variable is required.
           DEFB $3D      ; Separator: '='
           DEFB $02      ; Class-02 - An expression, numeric or string,
                        ; must follow.

P_GO_TO    DEFB $06      ; Class-06 - A numeric expression must follow.
           DEFB $00      ; Class-00 - No further operands.
           DEFW GO_TO    ; Address: GO-TO

P_IF       DEFB $06      ; Class-06 - A numeric expression must follow.
           DEFB $CB      ; Separator: 'THEN'
           DEFB $05      ; Class-05 - Variable syntax checked
                        ; by routine.
           DEFW IF       ; Address: IF

```

```

P_GO_SUB  DEFB  $06          ; Class-06 - A numeric expression must follow.
          DEFB  $00          ; Class-00 - No further operands.
          DEFW  GO_SUB       ; Address: GO-SUB

P_STOP    DEFB  $00          ; Class-00 - No further operands.
          DEFW  STOP        ; Address: STOP

P_RETURN  DEFB  $00          ; Class-00 - No further operands.
          DEFW  RETURN      ; Address: RETURN

P_FOR     DEFB  $04          ; Class-04 - A single character variable must
          DEFB  $3D          ; follow.
          DEFB  $06          ; Separator: '='
          DEFB  $CC          ; Class-06 - A numeric expression must follow.
          DEFB  $06          ; Separator: 'TO'
          DEFB  $06          ; Class-06 - A numeric expression must follow.
          DEFB  $05          ; Class-05 - Variable syntax checked
          DEFW  FOR          ; by routine.
          DEFW  FOR          ; Address: FOR

P_NEXT    DEFB  $04          ; Class-04 - A single character variable must
          DEFB  $00          ; follow.
          DEFW  NEXT        ; Class-00 - No further operands.
          DEFW  NEXT        ; Address: NEXT

P_PRINT   DEFB  $05          ; Class-05 - Variable syntax checked entirely
          DEFW  PRINT       ; by routine.
          DEFW  PRINT       ; Address: PRINT

P_INPUT   DEFB  $05          ; Class-05 - Variable syntax checked entirely
          DEFW  INPUT       ; by routine.
          DEFW  INPUT       ; Address: INPUT

P_DIM     DEFB  $05          ; Class-05 - Variable syntax checked entirely
          DEFW  DIM         ; by routine.
          DEFW  DIM         ; Address: DIM

P_REM     DEFB  $05          ; Class-05 - Variable syntax checked entirely
          DEFW  REM         ; by routine.
          DEFW  REM         ; Address: REM

P_NEW     DEFB  $00          ; Class-00 - No further operands.
          DEFW  NEW        ; Address: NEW

P_RUN     DEFB  $03          ; Class-03 - A numeric expression may follow
          DEFW  RUN         ; else default to zero.
          DEFW  RUN         ; Address: RUN

P_LIST    DEFB  $05          ; Class-05 - Variable syntax checked entirely
          DEFW  LIST       ; by routine.
          DEFW  LIST       ; Address: LIST

P_POKE    DEFB  $08          ; Class-08 - Two comma-separated numeric
          DEFB  $00          ; expressions required.
          DEFW  POKE       ; Class-00 - No further operands.
          DEFW  POKE       ; Address: POKE

P_RANDOM  DEFB  $03          ; Class-03 - A numeric expression may follow
          DEFW  RANDOMIZE  ; else default to zero.
          DEFW  RANDOMIZE  ; Address: RANDOMIZE

P_CONT    DEFB  $00          ; Class-00 - No further operands.
          DEFW  CONTINUE   ; Address: CONTINUE

```

```

P_CLEAR      DEFB  $03      ; Class-03 - A numeric expression may follow
; ; ;                                     ; else default to zero.
; ; ;                                     ;+ Variable syntax checked by routine.
      DEFB  $05      ; Address: CLEAR
      DEFW  CLEAR

P_CLS        DEFB  $00      ; Class-00 - No further operands.
      DEFW  CLS      ; Address: CLS

P_PLOT       DEFB  $09      ; Class-09 - Two comma-separated numeric
      ; expressions required with optional colour
      ; items.
      DEFB  $00      ; Class-00 - No further operands.
      DEFW  PLOT     ; Address: PLOT

P_PAUSE      DEFB  $06      ; Class-06 - A numeric expression must follow.
      DEFB  $00      ; Class-00 - No further operands.
      DEFW  PAUSE    ; Address: PAUSE

P_READ       DEFB  $05      ; Class-05 - Variable syntax checked entirely
      ; by routine.
      DEFW  READ     ; Address: READ

P_DATA       DEFB  $05      ; Class-05 - Variable syntax checked entirely
      ; by routine.
      DEFW  DATA    ; Address: DATA

P_RESTORE    DEFB  $03      ; Class-03 - A numeric expression may follow
      ; else default to zero.
      DEFW  RESTORE  ; Address: RESTORE

P_DRAW       DEFB  $09      ; Class-09 - Two comma-separated numeric
      ; expressions required with optional colour
      ; items.
      DEFB  $05      ; Class-05 - Variable syntax checked
      ; by routine.
      DEFW  DRAW     ; Address: DRAW

P_COPY       DEFB  $00      ; Class-00 - No further operands.
      DEFW  COPY     ; Address: COPY

P_LPRINT     DEFB  $05      ; Class-05 - Variable syntax checked entirely
      ; by routine.
      DEFW  LPRINT   ; Address: LPRINT

P_LLIST      DEFB  $05      ; Class-05 - Variable syntax checked entirely
      ; by routine.
      DEFW  LLIST    ; Address: LLIST

P_SAVE       DEFB  $0B      ; Class-0B - Offset address converted to tape
      ; command.

P_LOAD       DEFB  $0B      ; Class-0B - Offset address converted to tape
      ; command.

P_VERIFY     DEFB  $0B      ; Class-0B - Offset address converted to tape
      ; command.

P_MERGE      DEFB  $0B      ; Class-0B - Offset address converted to tape
      ; command.

P_BEEP       DEFB  $08      ; Class-08 - Two comma-separated numeric
      ; expressions required.
      DEFB  $00      ; Class-00 - No further operands.

```

```

        DEFW BEEP                ; Address: BEEP

P_CIRCLE DEFB $09                ; Class-09 - Two comma-separated numeric
        ; expressions required with optional colour
        ; items.
        DEFB $05                ; Class-05 - Variable syntax checked
        ; by routine.
        DEFW CIRCLE            ; Address: CIRCLE

P_INK    DEFB $07                ; Class-07 - Offset address is converted to
        ; colour code.

P_PAPER  DEFB $07                ; Class-07 - Offset address is converted to
        ; colour code.

P_FLASH  DEFB $07                ; Class-07 - Offset address is converted to
        ; colour code.

P_BRIGHT DEFB $07                ; Class-07 - Offset address is converted to
        ; colour code.

P_INVERSE DEFB $07                ; Class-07 - Offset address is converted to
        ; colour code.

P_OVER   DEFB $07                ; Class-07 - Offset address is converted to
        ; colour code.

P_OUT    DEFB $08                ; Class-08 - Two comma-separated numeric
        ; expressions required.
        DEFB $00                ; Class-00 - No further operands.
        DEFW OUT                ; Address: OUT

P_BORDER DEFB $06                ; Class-06 - A numeric expression must follow.
        DEFB $00                ; Class-00 - No further operands.
        DEFW BORDER            ; Address: BORDER

P_DEF_FN DEFB $05                ; Class-05 - Variable syntax checked entirely
        ; by routine.
        DEFW DEF_FN            ; Address: DEF-FN

P_OPEN   DEFB $06                ; Class-06 - A numeric expression must follow.
;;;     DEFB $2C                ; Separator: ', '
        DEFB $0C                ;+ Class-0C - NEW either ';' or ', '
        DEFB $0A                ; Class-0A - A string expression must follow.
;;;     DEFB $00                ; Class-00 - Was No further operands.
        DEFB $05                ;+ Class-05 - New Variable syntax.
        DEFW OPEN                ; Address: OPEN

P_CLOSE  DEFB $06                ; Class-06 - A numeric expression must follow.
        DEFB $00                ; Class-00 - No further operands.
        DEFW CLOSE            ; Address: CLOSE

P_FORMAT DEFB $0A                ; Class-0A - A string expression must follow.
        DEFB $0C                ; Class-0C - NEW either ';' or ', '
        DEFB $06                ; Class-06 - A numeric expression must follow.
        DEFB $00                ; Class-00 - No further operands.
        DEFW FORMAT            ; Address: FORMAT

; Since the commands MOVE ERASE and CAT will not be used then the syntax
; can be removed and they can all use the CAT error-generating routine.

P_MOVE   DEFB $0A                ; Class-0A - A string expression must follow.
;;;     DEFB $2C                ; Separator: ', '

```



```

        LD    C,A                ; transfer the current character to C.
;  advance CH_ADD to a position after command and test if it is a command.

        RST   20H                ; NEXT-CHAR to advance pointer
        LD    A,C                ; restore current character
        SUB   $CE                ; subtract 'DEF FN' - first command
        JR    C,SEP_RPT_C        ; jump, if less than a command, to REPORT-C
                                   ; 'Nonsense in BASIC'

        LD    C,A                ; put the valid command code back in C.
                                   ; register B is zero.
        LD    HL,offst_tbl        ; address: offst-tbl
        ADD   HL,BC                ; index into table with one of 50 commands.
        LD    C,(HL)              ; pick up displacement to syntax table entry.
        ADD   HL,BC                ; add to address the relevant entry.

        JR    GET_PARAM          ; forward to continue at GET-PARAM

; -----
; THE 'MAIN SCAN' LOOP
; -----
;

SCAN_LOOP LD    HL,($5B74)        ; Fetch Table Address from T_ADDR during
                                   ; subsequent loops.

;  -> the initial entry point with HL addressing start of syntax table entry.

GET_PARAM LD    A,(HL)            ; Pick up the parameter.
        INC   HL                ; Address next one.
        LD    ($5B74),HL          ; Save pointer in system variable T_ADDR

;;;
;;; LD    BC,SCAN_LOOP            ; Address: SCAN-LOOP
;;; PUSH  BC                    ; is now pushed on stack as looping address.

        LD    HL,SCAN_LOOP        ;+ address: SCAN-LOOP
        PUSH HL                  ;+ is now pushed on stack as looping address.

        LD    C,A                ; store parameter in C.
        CP    $20                ; is it greater than ' ' ?
        JR    NC,SEPARATOR        ; forward, if so, to SEPARATOR

        LD    HL,CLASS_TBL        ; address: class-tbl.

        LD    B,$00                ; prepare to index into the class table.   ;;;

        ADD   HL,BC                ; index to find displacement to routine.
        LD    C,(HL)              ; displacement to BC
        ADD   HL,BC                ; add to address the CLASS routine.
        PUSH  HL                  ; push the address on the stack.

        RST   18H                ; GET-CHAR - HL points to place in statement.

        DEC   B                    ; reset the zero flag - the initial state
                                   ; for all class routines.

        RET                       ; Make an indirect jump to routine
                                   ; and then to SCAN-LOOP (also on stack).

;  Note. one of the class routines will eventually drop the return address
;  off the stack breaking out of the above seemingly endless loop.

```

```

; -----
; THE 'SEPARATOR' ROUTINE
; -----
; This routine is called once to verify that the mandatory separator
; present in the parameter table is also present in the correct
; location following the command. For example, the 'THEN' token after
; the 'IF' token and expression.

SEPARATOR RST 18H ; GET-CHAR
          CP C ; does it match the character in C ?

SEP_RPT_C JP NZ,REPORT_C ; jump forward, if not, to REPORT-C
          ; 'Nonsense in BASIC'.

          RST 20H ; NEXT-CHAR advance to next character
          RET ; return.

; -----
; THE 'STATEMENT RETURN' POINT
; -----
; Control returns to this point after every statement by virtue of the
; address pushed on the machine stack.

STMT_RET CALL TEST_BRK ;+ the BREAK KEY is tested after every
statement.

;;; JR C,STMT_R_1 ; step forward to STMT-R-1 if not pressed.
;;; REPORT_L RST 30H ; ERROR-1
;;; DEFB $14 ; Error Report: BREAK into program

; ---

STMT_R_1 BIT 7,(IY+$0A) ; test a bit of NSPPC - will be set if $FF -
; no jump to be made.
JR NZ,STMT_NEXT ; forward, if no jump, to STMT-NEXT

LD HL,($5B42) ; fetch BASIC line number from NEWPPC

BIT 7,H ; test the high order byte.
; bit 7 is set if minus two - direct command(s)

JR Z,LINE_NEW ; forward, if a jump is to be made, to LINE-NEW

; -----
; THE 'RUN A DIRECT COMMAND' ROUTINE
; -----
; A direct command is to be run or, if continuing from above, the next
; statement in a sequence of direct commands is to be considered.

LINE_RUN LD HL,$FFFE ; The dummy value minus two
          LD ($5B45),HL ; is set/reset as line number in PPC.

          LD HL,($5B61) ; point to the start of workspace WORKSP.
          DEC HL ; now point to $80 Edit Line end-marker.
          LD DE,($5B59) ; address the start of line using E_LINE.

          DEC DE ; now location before - for GET-CHAR.

          LD A,($5B44) ; load statement to A from NSPPC.

          JR NEXT_LINE ; forward to NEXT-LINE.

; -----
; THE 'LINE NEW' ROUTINE

```

```

; -----
; This routine finds the start address of new line.
; The branch was to here if a jump is to made to a new line number and
; statement.
; That is, the previous statement was a GO TO, GO SUB, RUN, RETURN, NEXT
etc..

LINE_NEW CALL LINE_ADDR ; routine LINE-ADDR gets address of line
; returning zero flag set if line found.
LD A,($5B44) ; fetch new statement from NSPPC
JR Z,LINE_USE ; forward to LINE-USE if line matched.

; continue as must be a direct command.

AND A ; test statement which should be zero
JR NZ,REPORT_N ; forward, if not, to REPORT-N
; 'Statement lost'

;

;;; LD B,A ; save statement in B. ??
LD A,(HL) ; fetch high byte of line number.
AND $C0 ; test if using direct command
; a program line is less than $3F
;;; LD A,B ; retrieve statement.
;;; ; (we can assume it is zero).
JR Z,LIN_USE_0 ; forward to LINE-USE if was a program line

; Alternatively, a direct statement has finished correctly.

REPORT_0 RST 30H ; ERROR-1
DEFB $FF ; Error Report: OK

; -----
; THE 'REM' COMMAND
; -----
; The REM command routine.
; The return address STMT-RET is dropped and the rest of line ignored.

REM POP BC ; drop return address STMT-RET and
; continue ignoring rest of line.

; -----
; End of line?
; -----
;
;

;;; LINE_END CALL SYNTAX_Z ; routine SYNTAX_Z (UNSTACK_Z?)
;;; RET Z ; return if checking syntax.

LINE_END CALL UNSTACK_Z ;+ return early if checking syntax.

LD HL,($5B55) ; fetch NXTLIN to HL.
LD A,$C0 ; test against the
AND (HL) ; system limit $3F.
RET NZ ; return if higher as must be end of program.
; (or direct command)

LIN_USE_0 XOR A ; set statement to zero.

; and continue to set up the next following line and then consider this new
one.

```



```

; -----
; THE 'LINE USE' BRANCH
; -----
;   The branch was here from LINE-NEW if BASIC is branching.
;   or a continuation from above if dealing with a new sequential line.
;   First make statement zero number one leaving others unaffected.

LINE_USE  CP    $01                ; will set carry if zero.
          ADC   A,$00              ; add in any carry.

          LD    D,(HL)             ; high byte of line number to D.
          INC   HL                 ; advance pointer.
          LD    E,(HL)             ; low byte of line number to E.
          LD    ($5B45),DE        ; set system variable PPC.

          INC   HL                 ; advance pointer.
          LD    E,(HL)             ; low byte of line length to E.
          INC   HL                 ; advance pointer.
          LD    D,(HL)             ; high byte of line length to D.

          EX    DE,HL              ; swap pointer to DE before adding
          ADD   HL,DE              ; to address the end of the line.
          INC   HL                 ; advance to start of next line.

; -----
; THE 'NEXT LINE' SUBROUTINE
; -----
;   The pointer will be the next line if continuing from above or to edit line
;   end-marker ($80) if from LINE-RUN.

NEXT_LINE LD    ($5B55),HL        ; store pointer in system variable NXTLIN

          EX    DE,HL              ; bring back pointer to previous or edit line
          LD    ($5B5D),HL        ; and update CH_ADD with character address.

          LD    D,A                ; store statement in D.
          LD    E,$00              ; set E to zero to suppress token searching
                                   ; if EACH-STMT is to be called.
          LD    (IY+$0A),$FF      ; set statement NSPPC to $FF signaling
                                   ; no jump to be made.
          DEC   D                  ; decrement and test statement
          LD    (IY+$0D),D        ; set SUBPPC to decremented statement number.
          JP    Z,STMT_LOOP       ; to STMT-LOOP if result zero as statement is
                                   ; at start of line and address is known.

          INC   D                  ; else restore statement.
          CALL  EACH_STMT         ; routine EACH-STMT finds the D'th statement
                                   ; address as E does not contain a token.
          JR    Z,STMT_NEXT       ; forward to STMT-NEXT if address found.

REPORT_N  RST   30H                ; ERROR-1
          DEFB  $16                ; 'Statement lost'

; -----
; THE NEW 'CHECK FOR NUMBER AND SYNTAX' ROUTINE
; -----
;   Combines two or three routines into one call.

CHK_END_1 RST   20H                ;+ NEXT_CHAR

CHK_END_2 CALL  EXPT_1NUM         ;+ Check for 1 number and stack in runtime

; -----
; THE 'CHECK END' SUBROUTINE

```

```

; -----
; This combination of routines is called from 20 places when
; the end of a statement should have been reached and all preceding
; syntax is in order.

CHECK_END CALL SYNTAX_Z      ; routine SYNTAX-Z
          RET  NZ              ; return immediately in runtime

          POP  BC              ; drop address of calling routine.
          POP  BC              ; drop address STMT-RET.
                                ; and continue to find next statement.

; -----
; THE 'STATEMENT NEXT' ROUTINE
; -----
; Acceptable characters at this point are carriage return and ':'.
; If so, go to next statement which in the first case will be on next line.

STMT_NEXT RST  18H           ; GET-CHAR - ignoring white space etc.

          CP   $0D            ; is character carriage return ?
          JR   Z,LINE_END     ; back, if so, to LINE-END

          CP   $3A            ; is character a ':' ?
          JP   Z,STMT_LOOP    ; jump back, if so, to STMT-LOOP

          JR   VAL_RPT_C      ; forward, with any other, to VAL_RPT_C
                                ; 'Nonsense in BASIC'

; -----
; THE 'COMMAND CLASS' TABLE
; -----
;

CLASS_TBL DEFB CLASS_00 - $ ; offset to Address: CLASS-00
          DEFB CLASS_01 - $ ; offset to Address: CLASS-01
          DEFB CLASS_02 - $ ; offset to Address: CLASS-02
          DEFB CLASS_03 - $ ; offset to Address: CLASS-03
          DEFB CLASS_04 - $ ; offset to Address: CLASS-04
          DEFB CLASS_05 - $ ; offset to Address: CLASS-05
          DEFB CLASS_06 - $ ; offset to Address: CLASS-06
          DEFB CLASS_07 - $ ; offset to Address: CLASS-07
          DEFB CLASS_08 - $ ; offset to Address: CLASS-08
          DEFB CLASS_09 - $ ; offset to Address: CLASS-09
          DEFB CLASS_0A - $ ; offset to Address: CLASS-0A
          DEFB CLASS_0B - $ ; offset to Address: CLASS-0B

          DEFB CLASS_0C - $ ; offset to Address: CLASS_0C

; -----
; THE 'COMMAND CLASSES 00, 03 and 05' ROUTINES
; -----
; class-03 e.g. RUN or RUN 20 ; optional operand.
; class-00 e.g. CONTINUE      ; no operand.
; class-05 e.g. PRINT         ; variable syntax checked by routine.

CLASS_03 CALL  FETCH_NUM      ; routine FETCH-NUM

CLASS_00 CP    A              ; set zero flag.

; if entering here then all class routines are entered with zero reset.

```

```

CLASS_05 POP BC ; drop address SCAN-LOOP.
CALL Z,CHECK_END ; if zero set then call routine CHECK-END >>>
; as should be no further characters.

; If checking syntax then classes 00 and 03 terminate at the above step.

EX DE,HL ; save HL to DE.
LD HL,($5B74) ; fetch T_ADDR
LD C,(HL) ; fetch low byte of routine
INC HL ; address next.
LD B,(HL) ; fetch high byte of routine.
EX DE,HL ; restore HL from DE
PUSH BC ; push the address

RET ; and make an indirect jump to the command.

; -----
; THE 'COMMAND CLASS 01' ROUTINE
; -----
; e.g. LET A = 2*3 ; A variable is required.

; This class routine is also called from INPUT and READ to find the
; destination variable for an assignment.

CLASS_01 CALL LOOK_VARS ; routine LOOK-VARS returns carry set if the
; variable is not found in runtime.

VAR_A_1 LD (IY+$37),$00 ; Set FLAGX to zero
JR NC,VAR_A_2 ; Forward, if found or syntax path, to VAR-A-2

; The variable was not found in runtime.

SET 1,(IY+$37) ; Update FLAGX - signal a new variable.

JR NZ,VAR_A_3 ; Forward, if not array subscript, to VAR-A-3
; e.g. LET a$(3,3) = "X"

REPORT_2 RST 30H ; ERROR-1
DEFB $01 ; Error Report: Variable not found.

; ---

; The branch was here when the variable was found or if checking syntax.

VAR_A_2 CALL Z,STK_VAR ; routine STK-VAR considers a subscript/slice.
BIT 6,(IY+$01) ; test FLAGS - numeric or string result ?
JR NZ,VAR_A_3 ; forward, if numeric, to VAR-A-3.

XOR A ; Default A to array/slice - to be retained.

CALL SYNTAX_Z ; Routine SYNTAX-Z
CALL NZ,STK_FETCH ; Routine STK-FETCH is called in runtime
; may overwrite A with 1.

LD HL,$5B71 ; Address the FLAGX system variable.
OR (HL) ; sets bit 0 if simple variable to be reclaimed.
LD (HL),A ; update bit 0 of FLAGX
EX DE,HL ; bring start of string/subscript to HL

VAR_A_3 LD ($5B72),BC ; update STRLEN system variable.
LD ($5B4D),HL ; update DEST of assigned string.
RET ; Return.

```

```

; -----
; THE 'COMMAND CLASS 02' ROUTINE
; -----
; This is only used in the LET command.
;
; e.g. LET A = 2*3 ; an expression must follow the separator.

CLASS_02 POP BC ; drop the return address SCAN-LOOP

CALL VAL_FET_1 ; routine VAL-FET-1 is called to check
; expression and assign result in runtime.

CALL CHECK_END ; routine CHECK-END checks nothing else
; is present in statement.

RET ; Return in runtime also.

; -----
; THE 'FETCH A VALUE' SUBROUTINE
; -----
;
;
VAL_FET_1 LD A, ($5B3B) ; fetch initial FLAGS system variable to A.
VAL_FET_2 PUSH AF ; Save initial flags A briefly

CALL SCANNING ; routine SCANNING evaluates expression.

POP AF ; Restore the initial flags - A.

LD D, (IY+$01) ; Fetch post-scanning FLAGS value to D
XOR D ; XOR the before and after flags.
AND $40 ; isolate bit 6 of result.

VAL_RPT_C JR NZ,REPORT_C ; Forward, if not zero, to REPORT-C
; 'Nonsense in BASIC'

BIT 7,D ; Test FLAGS - is syntax being checked ?

JP NZ,LET ; Jump forward, in runtime, to LET
; to make the assignment.

RET ; Return from here when checking syntax.

; -----
; THE 'COMMAND CLASS 04' ROUTINE
; -----
; e.g. FOR i ; a single character variable must follow

CLASS_04 CALL LOOK_VARS ; routine LOOK-VARS

PUSH AF ; preserve flags.

LD A,C ; fetch type - should be 011xxxxx
OR $9F ; combine with 10011111.
INC A ; test if result is now $FF by incrementing.

JR NZ,REPORT_C ; forward, if result not zero, to REPORT-C
; 'Nonsense in BASIC'

POP AF ; else restore flags.

```

```

JR    VAR_A_1          ; back to VAR-A-1

; -----
; Expect numeric/string expression
; -----
; This routine is used to get the two coordinates of STRING$, ATTR and POINT.
; It is also called from PRINT-ITEM to get the two numeric expressions that
; follow the AT ( in PRINT AT, INPUT AT ).

NEXT_2NUM RST    20H          ; NEXT-CHAR advance past 'AT' or '('.

CLASS_08                                ; e.g. POKE 65535,2
                                         ; two numeric expressions separated by comma

EXPT_2NUM CALL   EXPT_1NUM          ; routine EXPT-1NUM is called for first
                                         ; numeric expression
      CP    $2C                    ; is character ',' ?
      JR    NZ,REPORT_C             ; to REPORT-C if not the required separator.
                                         ; 'Nonsense in BASIC'.

      RST    20H                    ; NEXT-CHAR

;    ->

CLASS_06                                ; e.g. GO TO a*1000
                                         ; a numeric expression must follow

EXPT_1NUM CALL   SCANNING           ; routine SCANNING
      BIT    6,(IY+$01)             ; test FLAGS - Numeric or string result ?
      RET    NZ                      ; return if result is numeric.

REPORT_C RST    30H                ; ERROR-1
      DEFB  $0B                      ; Error Report: Nonsense in BASIC

; -----
; THE 'COMMAND CLASS 0A' ROUTINE
; -----
;
; A string expression must follow. These classes only occur in unimplemented
; commands although the routine EXPT_EXP is called from SAVE_ETC.
; It is used in the FORMAT and OPEN syntax tables.

CLASS_0A

EXPT_EXP CALL   SCANNING           ; routine SCANNING
      BIT    6,(IY+$01)             ; test FLAGS - Numeric or string result ?
      RET    Z                       ; return if string result.
      JR    REPORT_C                 ; back, if numeric, to REPORT-C.

; -----
; THE 'COMMAND CLASS 07' ROUTINE
; -----
; Set permanent colours
; e.g. PAPER 6
; a single class for a collection of similar commands. Clever.

```

```

;
; Note. these commands should ensure that current channel is 'S'

;;; CLASS_07 BIT 7, (IY+$01) ; test FLAGS - checking syntax only ?
;;; RES 0, (IY+$02) ; update TV_FLAG - signal main screen in use
;;; CALL NZ, TEMPs ; routine TEMPs is called in runtime.

CLASS_07 LD A, $FE ;
CALL CHN_O_SYN ;+ ensure control codes go to screen and not a
;+ microdrive file in runtime.
;+ Returns if checking syntax.

POP AF ; drop return address SCAN-LOOP

LD A, ($5B74) ; Fetch T_ADDR_lo to accumulator.
; points to '$07' entry + 1
; e.g. for INK points to $EC now

; Note if you move alter the syntax table next line may have to be altered.

SUB P_INK-$D8 % 256 ; convert $EB to $D8 ('INK') etc.
; ( was SUB $13 in standard ROM )

CALL CO_TEMP_4 ; routine CO-TEMP-4

CALL CHECK_END ; routine CHECK-END check that nothing else
; appears in the statement and quits if
; checking syntax. >>

; Return to here in runtime. The temporary attributes set up by CO_TEMP_4
; are now copied to the permanent attributes to make the change premanent.

LD HL, ($5B8F) ; pick up ATTR_T and MASK_T

LD ($5B8D), HL ; and transfer to ATTR_P and MASK_P

LD HL, $5B91 ; point to P_FLAG.
LD A, (HL) ; pick up in A
RLCA ; rotate to left
XOR (HL) ; combine with HL
AND $AA ; AND with %10101010
XOR (HL) ; only only the permanent bits affected

LD (HL), A ; reload into system variable P_FLAG.

RET ; Return.

; -----
; THE 'COMMAND CLASS 09' ROUTINE
; -----
; e.g. PLOT PAPER 0; 128,88 ; two coordinates preceded by optional
; ; embedded colour items.
;
; Note. this command should ensure that current channel is actually 'S'.

CLASS_09 CALL SYNTAX_Z ; routine SYNTAX_Z
JR Z, CL_09_1 ; forward to CL_09_1 if checking syntax.

;;; RES 0, (IY+$02) ; update TV_FLAG - signal main screen in use
;;; CALL TEMPs ; routine TEMPs is called in runtime.

CALL CHAN_O_FE ;+ ensure control codes go to screen and not
;+ to the network in runtime.

```

```

        LD    HL,$5B90      ; point to MASK_T
        LD    A,(HL)       ; fetch mask to accumulator.
        OR    $F8          ; or with 11111000 paper/bright/flash 8
        LD    (HL),A      ; put mask back to MASK_T system variable.
        RES   6,(IY+$57)   ; reset P_FLAG - signal NOT PAPER 9 ?

        RST   18H         ; GET-CHAR

CL_09_1  CALL  CO_TEMP_2   ; routine CO-TEMP-2 deals with any embedded
                          ; colour items.

        JR    EXPT_2NUM    ; exit via EXPT-2NUM to check for x,y.

; Note. if either of the numeric expressions contain STR$ then the flag
; setting above will be undone when the channel flags are reset during STR$.
; e.g.
; 10 BORDER 3 : PLOT VAL STR$ 128, VAL STR$ 100
; credit: John Elliott.

; -----
; THE 'COMMAND CLASS 0B' ROUTINE
; -----
; Again a single class for four commands.
; This command just jumps back to SAVE-ETC to handle the four tape commands.
; The routine itself works out which command has called it by examining the
; address in T_ADDR_lo. Note therefore that the syntax table has to be
; located where these and other sequential command addresses are not split
; over a page boundary.

CLASS_0B  JP    SAVE_ETC   ; jump way back to SAVE-ETC

; -----
; THE NEW 'EXPECT SEPARATOR' ROUTINE
; -----
; Seven bytes
; Returns with zero flag set if character is a separator.

EXPT_SEP  RST   18H       ; GET_CHAR

        CP    $2C        ; is it a comma
        RET   Z          ;
        CP    $3B        ; is it a semicolon
        RET

; -----
; THE NEW 'CLASS 0C' SUBROUTINE
; -----

CLASS_0C  CALL  EXPT_SEP   ; check for a valid separator ';' or ','.

        JR    NZ,REPORT_C ; jump forward, if not, to REPORT-C
                          ; 'Nonsense in BASIC'.

NXT_CH   RST   20H       ; NEXT-CHAR advance to next character
        RET

; -----
; THE 'FETCH A NUMBER' SUBROUTINE
; -----
; This routine is called from CLASS-03 when a command may be followed by
; an optional numeric expression e.g. RUN. If the end of statement has
; been reached then zero is used as the default.
; Also called from LIST-4.

```

```

; Note. called from SAVE "program" LINE

FETCH_NUM CP    $0D                ; is character a carriage return ?
           JR    Z,USE_ZERO         ; forward, if so, to USE-ZERO

           CP    $3A                ; is it ':' ?
           JR    NZ,EXPT_1NUM      ; back, if not, to EXPT-1NUM
                                           ; else continue and use zero.

; -----
; THE 'USE ZERO' ROUTINE
; -----
; This routine is called four times to place the value zero on the
; calculator stack as a default value in runtime.

;;; USE_ZERO CALL SYNTAX_Z         ; routine SYNTAX_Z (UNSTACK_Z?)
;;;           RET  Z                ;

USE_ZERO CALL UNSTACK_Z           ;+ return early if checking syntax.

           RST  28H                ;; FP-CALC          .
           DEFB $A0                ;;stk-zero      0.
           DEFB $38                ;;end-calc      0.

           RET                    ; Return.

; -----
; THE 'STOP' COMMAND
; -----
; Command Syntax: STOP
; One of the shortest and least used commands. As with 'OK' not an error.
; Note. moved to fill a couple of bytes at $0064.

; -----
; THE 'IF' COMMAND
; -----
; e.g. IF Warp Factor > 8 THEN PRINT "Och! she'll blow Captain."
; The parser has already checked the expression the result of which is on
; the calculator stack. The presence of the 'THEN' separator has also been
; checked and CH-ADD points to the command after THEN.

IF        POP  BC                  ; drop return address - STMT-RET
           CALL SYNTAX_Z          ; routine SYNTAX-Z
           JR   Z,IF_1            ; forward, if checking syntax, to IF-1
                                           ; to check syntax of PRINT "Och! She'll blow..."

           RST  28H                ;; FP-CALC          Warp Factor > 8 (1=TRUE 0=FALSE)
           DEFB $02                ;;delete          .
           DEFB $38                ;;end-calc

           EX  DE,HL              ; make HL point to deleted value

           CALL TEST_ZERO         ; routine TEST-ZERO

           JP  C,LINE_END         ; jump to LINE-END if FALSE (0)

IF_1      JP  STMT_L_1           ; to STMT-L-1, if true (1) to execute command
                                           ; after 'THEN' token.

; -----
; THE 'FOR' COMMAND

```



```

; -----
; e.g. FOR i = 0 TO 1 STEP 0.1
; Using the syntax tables, the parser has already checked for a start and
; limit value and also for the intervening separators. The two values v,l
; are on the calculator stack. The CLASS-04 routine has also checked the
; variable and the name is in STRLEN_lo.
; The routine begins by checking for an optional STEP.

FOR      CP      $CD          ; is there a 'STEP' ?
        JR      NZ,F_USE_1    ; Forward, if not, to F-USE-1

;;;     RST      20H          ; NEXT-CHAR
;;;     CALL     EXPT_1NUM     ; routine EXPT-1NUM checks for number
;;;     CALL     CHECK_END     ; routine CHECK-END

        CALL    CHK_END_1     ;+ above three routines

        JR      F_REORDER     ; forward to F-REORDER

; ---

F_USE_1  CALL    CHECK_END     ; routine CHECK-END

        RST      28H          ;; FP-CALC      v,l.
        DEFB    $A1          ;;stk-one      v,l,1=s.
        DEFB    $38          ;;end-calc

F_REORDER RST      28H          ;; FP-CALC      v,l,s.
        DEFB    $C0          ;;st-mem-0     v,l,s.
        DEFB    $02          ;;delete      v,l.
        DEFB    $01          ;;exchange   l,v.
        DEFB    $E0          ;;get-mem-0   l,v,s.
        DEFB    $01          ;;exchange   l,s,v.
        DEFB    $38          ;;end-calc

        CALL    LET          ; routine LET assigns the initial value v to
        ; the variable.

        LD      ($5B68),HL    ; The system variable MEM is made to point to
        ; the variable instead of its normal location
        ; at MEMBOT.
        DEC     HL           ; point to the single-character name.
        LD      A,(HL)       ; fetch character.
        SET     7,(HL)       ; set bit 7 at variable location.

        LD      BC,$0006     ; add six to HL to skip the value and
        ADD     HL,BC        ; address where limit should be.

        RLCA                ; test bit 7 of original variable name.

        JR      C,F_L_S     ; forward, if already correct type, to F-L-S

        LD      C,$0D        ; otherwise an additional 13 bytes are needed.
        ; 5 for each value, two for line number and
        ; 1 byte for looping statement.

        CALL    MAKE_ROOM    ; routine MAKE-ROOM creates them.

;;;     INC      HL          ; make HL address the limit.

F_L_S    PUSH    HL          ; save the limit position.

        RST      28H          ;; FP-CALC      l,s.

```

```

DEFB $02          ;;delete          1.
DEFB $02          ;;delete          .
DEFB $38          ;;end-calc        .

;   At this point, DE points to STKEND the start of the two deleted numbers.

POP   HL          ; restore variable limit position
EX    DE,HL      ; swap pointers
LD    C,$0A      ; ten bytes to move

LDIR                     ; Copy 'deleted' values to limit and step.

LD    HL,($5B45)  ; Load with current line number from PPC
EX    DE,HL      ; exchange pointers.

LD    (HL),E     ; save the looping line in
INC   HL         ; in the next
LD    (HL),D     ; two variable locations.

LD    D,(IY+$0D) ; fetch statement from SUBPPC system variable.
INC   D         ; increment the statement.
INC   HL        ; increment the variable pointer
LD    (HL),D    ; and store the looping statement.

CALL  NEXT_LOOP  ; routine NEXT-LOOP considers an initial
                ; iteration.

RET   NC         ; Return to STMT-RET, if a loop is possible, to
                ; execute the next statement.

;   No loop is possible, so execution continues after the matching 'NEXT'

LD    B,(IY+$38) ; get the single-character name from STRLEN_lo
LD    HL,($5B45) ; get the current line from PPC
LD    ($5B42),HL ; and store it in NEWPPC
LD    A,($5B47) ; fetch current statement from SUBPPC
NEG                     ; Negate as counter decrements from zero
                ; initially and we are in the middle of a line.
LD    D,A         ; Store result in D.

RST   18H         ;;;;
;;; LD    HL,($5B5D) ; get current character address from CH_ADD
LD    E,$F3      ; The search will be for the token 'NEXT'

F_LOOP PUSH BC    ; save the variable name in B.

LD    BC,($5B55) ; fetch NXTLIN

CALL  LOOK_PROG  ; routine LOOK-PROG searches for 'NEXT' token
                ; setting carry flag if end of program reached
                ; and updating NEWPPC with line number, BC.

LD    ($5B55),BC ; update NXTLIN

POP   BC         ; retrieve the variable name in B.

JR    C,REPORT_I ; forward, if at program end, to REPORT-I
                ; 'FOR without NEXT'

RST   20H         ; NEXT-CHAR fetches character after NEXT
OR    $20        ; ensure it is upper-case.
CP    B         ; compare with FOR variable name
JR    Z,F_FOUND  ; forward, if it matches, to F-FOUND

```

```

; but if no match i.e. nested FOR/NEXT loops then continue search.

        RST    20H            ; NEXT-CHAR
        JR     F_LOOP        ; back to F-LOOP

; ----

F_FOUND  RST    20H            ; NEXT-CHAR
        LD     A,$01         ; subtract the negated counter from 1
        SUB    D             ; to give the statement after the NEXT
        LD     ($5B44),A     ; set system variable NSPPC
        RET                    ; return to STMT-RET to branch to new
                                ; line and statement. ->

; ----

REPORT_I  RST    30H            ; ERROR-1
        DEFB   $11          ; Error Report: FOR without NEXT

; -----
; THE 'LOOK PROGRAM' SUBROUTINE
; -----
; Used to find tokens DATA, DEF FN or NEXT.
; This routine searches the program area for one of the above three keywords.
; On entry, HL points to start of search area.
; The token is in E, and D holds a statement count, decremented from zero.

LOOK_PROG LD     A, (HL)      ; fetch current character
        CP     $3A          ; is it ':' a statement separator ?
        JR     Z,LOOK_P_2    ; forward, if so, to LOOK-P-2

; The starting point was PROG-1 or is now the end of a line.

LOOK_P_1  INC    HL          ; increment pointer to address
        LD     A, (HL)      ; the high byte of line number
        AND   $C0          ; test for program end marker $80 or a
                                ; variable
        SCF                    ; Set Carry Flag
        RET    NZ          ; return with carry set if at end of program. ->

        LD     B, (HL)      ; high byte of line number to B
        INC   HL           ;
        LD     C, (HL)      ; low byte to C.

        LD     ($5B42),BC    ; set system variable NEWPPC.

        INC   HL           ;
        LD     C, (HL)      ; low byte of line length to C.
        INC   HL           ;
        LD     B, (HL)      ; high byte to B.

        PUSH  HL           ; save current address - pointing to BASIC.

        ADD   HL,BC        ; add length to current address.
        LD   B,H           ; and transfer the result - the next line -
        LD   C,L           ; to the BC register.

        POP   HL           ; retrieve the current address.

        LD   D,$00         ; initialize statement counter to zero.

LOOK_P_2  PUSH  BC         ; preserve address of next line
        CALL  EACH_STMT    ; routine EACH-STMT searches current line.

```

```

        POP    BC                ; retrieve address of next line.

        RET    NC                ; return if match was found. ->

        JR     LOOK_P_1          ; back, for next line, to LOOK-P-1

; -----
; THE 'NEXT' COMMAND
; -----
; e.g. NEXT i
; The parameter tables have already evaluated the presence of a variable

NEXT    BIT    1,(IY+$37)        ; test FLAGX - handling a new variable ?

        JP     NZ,REPORT_2        ;.jump back, if so, to REPORT-2
        ; 'Variable not found'

; now test if the found variable is a simple variable uninitialized by a FOR.

        LD     HL,($5B4D)         ; load address of variable from DEST
        BIT    7,(HL)            ; is it correct type ?
        JR     Z,REPORT_1         ; forward, if not, to REPORT-1
        ; 'NEXT without FOR'

        INC    HL                ; step past variable name
        LD     ($5B68),HL         ; and set system variable MEM to point to the
        ; three 5-byte numbers - value, limit, step.

; Now add the step and put result in the value (mem-0).

        RST    28H                ;; FP-CALC      .
        DEFB   $E0                ;;get-mem-0    v.
        DEFB   $E2                ;;get-mem-2    v,s.
        DEFB   $0F                ;;addition    v+s.
        DEFB   $C0                ;;st-mem-0    v+s.
        DEFB   $02                ;;delete     .
        DEFB   $38                ;;end-calc   .

        CALL   NEXT_LOOP          ; routine NEXT-LOOP tests against limit.

        RET    C                  ; return if no more iterations possible.

        LD     HL,($5B68)         ; find start of variable contents from MEM.

        LD     DE,$000F           ; add 3*5 to
        ADD    HL,DE              ; address the looping line number

        LD     E,(HL)             ; low byte to E
        INC    HL                 ;
        LD     D,(HL)             ; high byte to D

        INC    HL                 ; address looping statement
        LD     H,(HL)             ; and store in H

        EX     DE,HL              ; exchange - HL = line number, D = statement.

        JP     GO_TO_2            ; exit via GO-TO-2 to execute another loop.

; ---

REPORT_1 RST    30H                ; ERROR-1
        DEFB   $00                ; Error Report: NEXT without FOR

```

```

; -----
; THE 'NEXT LOOP' SUBROUTINE
; -----
; This routine is called from the FOR command to test for an initial
; iteration and from the NEXT command to test for all subsequent iterations.
; the system variable MEM addresses the variable's contents which, in the
; latter case, have had the step, possibly negative, added to the value.

NEXT_LOOP RST 28H ; FP-CALC
          DEFB $E1 ;get-mem-1 l.
          DEFB $E0 ;get-mem-0 l,v.
          DEFB $E2 ;get-mem-2 l,v,s.
          DEFB $36 ;less-0 l,v,(1/0) negative step ?
          DEFB $00 ;jump-true l,v,(1/0)

          DEFB NEXT_1 - $ ;to NEXT-1 if step negative

          DEFB $01 ;exchange v,l.

NEXT_1 DEFB $03 ;subtract l-v OR v-l.
       DEFB $37 ;greater-0 (1/0)
       DEFB $00 ;jump-true .

       DEFB NEXT_2 - $ ;to NEXT-2 if no more iterations.

       DEFB $38 ;end-calc .

       AND A ; clear carry flag signaling another loop.

       RET ; return

; ---

NEXT_2 DEFB $38 ;end-calc .

       SCF ; set carry flag signaling looping exhausted.

       RET ; return

; -----
; THE 'READ' COMMAND
; -----
; e.g. READ a, b$, c$(1000 TO 3000)
; A list of comma-separated variables is assigned from a list of
; comma-separated expressions.
; As it moves along the first list, the character address CH_ADD is stored
; in X_PTR while CH_ADD is then used to read the second list.

READ_3 RST 20H ; NEXT-CHAR

; -> Entry point.

READ CALL CLASS_01 ; routine CLASS-01 checks variable.

      CALL SYNTAX_Z ; routine SYNTAX-Z

      JR Z,READ_2 ; forward, if checking syntax, to READ-2

; The runtime path continues.

      RST 18H ; GET-CHAR fetches character address of variable
              ; within BASIC to HL.

```

```

LD      ($5B5F),HL      ; save character position in X_PTR.

LD      HL,($5B57)      ; load HL with Data Address DATADD, which is
                        ; the start of the program or the address
                        ; after the last expression that was read or
                        ; the address preceding the line number of the
                        ; last RESTORE command.

LD      A,(HL)          ; fetch character
CP      $2C             ; is it a comma ?
JR      Z,READ_1        ; forward, if so, to READ-1

;   else all data in this statement has been read so look for next DATA token.

LD      E,$E4           ; prepare token 'DATA'

CALL    LOOK_PROG      ; routine LOOK-PROG finds the token

JR      NC,READ_1      ; forward, if 'DATA' found, to READ-1

;   else report the error.

REPORT_E  RST    30H      ; ERROR-1
          DEFB   $0D      ; Error Report: Out of DATA

; ---

READ_1    CALL    TEMP_PTR1      ; routine TEMP-PTR1 advances updating CH_ADD
                        ; with new DATADD position.

          CALL    VAL_FET_1      ; routine VAL-FET-1 assigns value to variable
                        ; checking types match and advancing CH_ADD.

          RST    18H            ; GET-CHAR fetches adjusted character position

          LD      ($5B57),HL      ; store back in DATADD

          LD      HL,($5B5F)      ; fetch original READ statement pointer from
X_PTR

          LD      (IY+$26),$00    ; nullify X_PTR_hi as redundant.

          CALL    TEMP_PTR2      ; routine TEMP-PTR2 restores the READ character
                        ; address to CH_ADD.

READ_2    RST    18H            ; GET-CHAR
          CP      $2C             ; is it ',' indicating more variables to read ?
          JR      Z,READ_3        ; back, if so, to READ-3

          CALL    CHECK_END      ; routine CHECK-END checks that nothing
                        ; follows and returns if checking syntax >>

          RET                    ; return from here in runtime to STMT-RET.

; -----
; THE 'DATA' COMMAND
; -----
;   e.g. DATA 1, 2, "text", score-1, a$(location, room, object), FN r(49),
;   wages - tax, TRUE, The meaning of life
;   In runtime this 'command' is passed by but the syntax is checked when such
;   a statement is found while parsing a line.

DATA      CALL    SYNTAX_Z      ; routine SYNTAX-Z to check status
          JR      NZ,DATA_2      ; forward, if in runtime, to DATA-2

```

```

; The syntax path continues.

DATA_1  CALL  SCANNING      ; routine SCANNING to check syntax of expression
        CP    $2C          ; is following character a comma ?
        CALL  NZ,CHECK_END ; if not, routine CHECK-END checks that
                          ; statement is complete. Will make an early
                          ; exit if it is. >>>
        RST   20H          ; NEXT-CHAR advances past comma.
        JR    DATA_1      ; loop back to DATA-1

; ---

DATA_2  LD    A,$E4        ; in runtime, set token to 'DATA' and continue
                          ; into the PASS-BY routine.

; -----
; THE 'PASS BY' SUBROUTINE
; -----
; This routine is used to backtrack to a command token and then forward to
; the next statement in runtime.
; The A register contains the required token - either $E4 (DATA) from above,
; or $CE (DEF FN) when called.

PASS_BY LD    B,A          ; Give BC enough space to find the token.
        CPDR                    ; Compare decrement and repeat. (Only use).
                          ; Work backwards until keyword is found which
                          ; is the start of statement before any quotes.
                          ; HL points to location before keyword.

        LD    DE,$0200      ; count 1+1 statements, dummy value in E to
                          ; inhibit searching for a token.

        JP    EACH_STMT     ; to EACH-STMT to find next statement

; -----
; THE 'RESTORE' COMMAND
; -----
; The RESTORE command sets the system variable for the data address to
; point to the location before the supplied line number or first line
; thereafter.
; This alters the position where subsequent READ commands look for data.
; Note. If supplied with inappropriate high numbers the system may crash
; in the LINE-ADDR routine as it will pass the program/variables end-marker
; and then lose control of what it is looking for - variable or line number.
; - observation, Steven Vickers, 1984, Pitman.

RESTORE CALL  FIND_LINE     ;+ routine FIND-INT2 puts integer in BC.
                          ;+ Note. B is now checked against limit $3F
                          ;+ and an error generated if higher.

; this entry point is used from RUN command with BC holding zero

REST_RUN LD    H,B          ; transfer the line
        LD    L,C          ; number to the HL register.

        CALL  LINE_ADDR     ; routine LINE-ADDR to fetch the address.

```

```

        DEC    HL                ; point to the location before the line.
        LD     ($5B57),HL        ; update the dynamic system variable DATADD.

        RET                     ; return to STMT-RET (or RUN)

; -----
; THE 'RANDOMIZE' COMMAND
; -----
; This command sets the SEED for the RND function to a fixed value.
; With the parameter zero, a random start point is used depending on
; how long the computer has been switched on.

RANDOMIZE CALL  FIND_INT2        ; routine FIND-INT2 puts parameter in BC.

        LD     A,B              ; test this
        OR     C                ; for zero.
        JR     NZ,RAND_1        ; forward to RAND-1 if not zero.

        LD     BC,($5B78)       ; use the lower two bytes at FRAMES1.

RAND_1  LD     ($5B76),BC        ; place in SEED system variable.

        RET                     ; return to STMT-RET

; -----
; THE 'CONTINUE' COMMAND
; -----
; The CONTINUE command transfers the OLD (but incremented) values of
; line number and statement to the equivalent "NEW VALUE" system variables
; by using the last part of GO TO and exits indirectly to STMT-RET.

CONTINUE LD     HL,($5B6E)       ; fetch OLDPPC line number.
        LD     D,(IY+$36)       ; fetch OSPPC statement.

        JR     GO_TO_2         ; forward to GO-TO-2

; -----
; THE 'GO TO' COMMAND
; -----
; The GO TO command routine is also called by GO SUB and RUN routines
; to evaluate the parameters of both commands.
; It updates the system variables used to fetch the next line/statement.
; It is at STMT-RET that the actual change in control takes place.
; Unlike some BASICs the line number need not exist.
; Note. the high byte of the line number is incorrectly compared with $F0
; instead of $3F. This leads to commands with operands greater than 32767
; being considered as having been run from the editing area and the
; error report 'Statement Lost' is given instead of 'OK'.
; - Steven Vickers, 1984.

GO_TO   CALL  FIND_LINE        ;+ routine FIND-INT2 puts operand in BC

;;;    LD     H,B              ; transfer line
;;;    LD     L,C              ; number to HL.
;;;    LD     D,$00            ; set statement to 0 - first.

;;;    LD     A,H              ; compare high byte only
;;;    CP     $F0              ; to $F0 i.e. 61439 in full.
;;;    JR     NC,REPORT_Bb     ; forward, if higher, to REPORT-B

; This call entry point is used to update the system variables e.g. by RETURN.

GO_TO_2 LD     ($5B42),HL       ; save line number in NEWPPC
        LD     (IY+$0A),D       ; and statement in NSPPC

```



```

RET                                ; to STMT-RET (or GO-SUB command)

; -----
; THE 'OUT' COMMAND
; -----
; Syntax has been entirely checked and the two comma-separated values are on
; the calculator stack.

OUT      CALL  TWO_PARAM           ; routine TWO-PARAM fetches values to BC and A.

        OUT   (C),A               ; perform the operation.

        RET                                ; return to STMT-RET.

; -----
; THE 'POKE' COMMAND
; -----
; This routine alters a single byte in the 64K address space.
; Happily no check is made as to whether ROM or RAM is addressed.
; Sinclair BASIC requires no poking of the system variables.

POKE     CALL  TWO_PARAM           ; routine TWO-PARAM fetches values to BC and A.

        LD   (BC),A               ; load memory location with A.

        RET                                ; return to STMT-RET.

; -----
; THE 'FETCH TWO PARAMETERS' SUBROUTINE
; -----
; This routine fetches a byte and word from the calculator stack producing an
; error if either is out of range.

TWO_PARAM CALL  FP_TO_A           ; routine FP-TO-A
        JR   C,REPORT_Bb         ; forward, with 8-bit overflow, to REPORT-B
        ; 'Integer out of range'

        JR   Z,TWO_P_1           ; skip forward, if positive, to TWO-P-1

        NEG                                ; negative numbers are made positive.

TWO_P_1  PUSH  AF                 ; save the byte value

        CALL FIND_INT2           ; routine FIND-INT2 gets 16-bit integer to BC

        POP  AF                 ; restore the byte value

        RET                                ; return

; -----
; THE 'FIND INTEGERS' ROUTINES
; -----
; The first of these routines fetches a 8-bit integer (range 0-255) from the
; calculator stack to the accumulator and is used for colours, streams,
; durations and coordinates.
; The second routine fetches 16-bit integers to the BC register pair and is
; used to fetch command and function arguments involving line numbers or
; memory addresses and also array subscripts and tab arguments.

; ->

FIND_INT1 CALL  FP_TO_A           ; routine FP-TO-A

```

```

        JR     FIND_I_1          ; forward to common exit routine at FIND-I-1
; ---
;   ->
FIND_INT2 CALL  FP_TO_BC          ; routine FP-TO-BC
;   The common exit routine checks that numbers are positive and do not overflow
FIND_I_1  JR     C,REPORT_Bb      ; skip forward, with overflow, to REPORT-Bb
        RET     Z                 ; return if BC (or A) is positive.

REPORT_Bb RST    30H              ; ERROR-1
        DEFB   $0A              ; Error Report: Integer out of range

; -----
; THE NEW 'FIND LINE' SUBROUTINE
; -----
;+ This new routine is used in place of FIND_INT2 to validate the line numbers
;+ that it fetches.

FIND_LINE CALL  FIND_INT2        ;+ Routine gets 16 bit integer in BC.
        LD     H,B                ;
        LD     L,C                ;

        LD     A,B                ;+ Fetch high byte.

        CP     $40                ;+ Compare with the system limit.

        JR     NC,REPORT_Bb       ;+ Back, if higher, than 16383 to ERROR_Bb
        ;+ 'Integer out of range'

        LD     D,$00              ;+ Useful return value.

        RET                       ;+ Return.

; -----
; THE NEW 'CLEAR HASH' ROUTINE
; -----
;   This routine responds to the command 'CLEAR #' by closing the sixteen
;   streams in turn. Any pending printer output is flushed but network output
;   is discarded. A hash has been found and it remains to check that nothing
;   follows.

CLR_HASH  RST    20H              ;+ NEXT_CHAR
        CALL  CHECK_END           ;+ CHECK_END quits if checking syntax >>

;   The runtime path.

        LD     A,16                ;+ Set stream to sixteen

NMI_STRMS SET    6,(IY+$3B)       ;+ Set T_ADDR_hi to indicate no Network EOF.

ALL_STRMS DEC    A                ;+ pre-decrement
        PUSH  AF                  ;+ save stream and result flag.

        CALL  STR_DATA1           ;+ get the offset

        CALL  NZ,CLOSE_OK         ;+ CLOSE the stream if it's open.

```

```

        POP    AF                ;+

        JR     NZ,ALL_STRMS     ;+ do all sixteen

        RET                    ;+ Return.

; -----
; THE 'RUN' COMMAND
; -----
; This command runs a program starting at an optional line.
; It performs a 'RESTORE 0' then CLEAR

RUN      CALL  GO_TO           ; routine GO-TO puts line number in
                                ; system variables.

;;;     LD     BC,$0000        ; prepare to set DATADD to first line.
        LD     B,D             ;+
        LD     C,D             ;+

        CALL  REST_RUN        ; routine REST-RUN does the 'restore'.
                                ; Note. BC still holds zero.

        JR     CLEAR_RUN      ; forward to CLEAR-RUN to clear variables
                                ; without disturbing RAMTOP and
                                ; exit indirectly to STMT-RET

; -----
; THE 'CLEAR' COMMAND
; -----
; This command reclaims the space used by the variables.
; It also clears the screen and the GO SUB stack.
; With an integer expression, it sets the uppermost memory
; address within the BASIC system.
; "Contrary to the manual, CLEAR doesn't execute a RESTORE" -
; Steven Vickers, Pitman Pocket Guide to the Spectrum, 1984.
; Notice also that if an error occurs then the GOSUB stack is not cleared.

CLEAR    RST    18H            ; GET_CHAR
        CP     $23            ; is character a '#' ?
        JR     Z,CLR_HASH     ; back if so.

        CALL  FETCH_NUM       ;+ routine FETCH_NUM checks for numeric
                                ;+ expression and stacks in run-time defaulting
                                ;+ to zero.

        CALL  CHECK_END       ; routine CHECK-END quits if syntax path.

        CALL  FIND_INT2      ; routine FIND-INT2 fetches address to BC.

CLEAR_RUN LD     A,B           ; test for
        OR     C              ; zero.
        JR     NZ,CLEAR_1     ; skip, if not zero, to CLEAR-1

        LD     BC,($5BB2)     ; use the existing value of RAMTOP if zero.

CLEAR_1  PUSH  BC             ; save RAMTOP value.

        LD     DE,($5B4B)     ; fetch VARS

;;;     LD     HL,($5B59)     ; fetch E_LINE
;;;     DEC    HL             ; adjust to point at variables end-marker.

        CALL  L_EL_DHL       ;+ NEW routine with above code.

```

```

        CALL RECLAIM_1      ; routine RECLAIM-1 reclaims the space used by
                           ; the variables, setting BC to zero.

; Note. A call to REST_RUN here would execute a RESTORE as per BASIC manual
; but it is difficult to decide if CLEAR should execute a RESTORE. Vickers
; merely points out that the ROM doesn't.

        CALL CLS           ; routine CLS to clear screen.

        LD HL,($5B65)      ; fetch STKEND the start of free memory.
; ; ; LD DE,$0032          ; allow for another 50 bytes.
        LD E,$32           ; allow for another 50 bytes.
        ADD HL,DE          ; add the overhead to HL.

        POP DE             ; restore the RAMTOP value.
        SBC HL,DE         ; if HL is greater than the value then jump
        JR NC,REPORT_M    ; forward to REPORT-M
                           ; 'RAMTOP no good'

        LD HL,($5BB4)     ; now P-RAMT ($7FFF on 16K RAM machine)
        AND A             ; exact this time.
        SBC HL,DE         ; new RAMTOP must be lower or the same.
        JR NC,CLEAR_2     ; skipa, if in actual RAM, to CLEAR-2

REPORT_M RST 30H          ; ERROR-1
        DEFB $15          ; Error Report: RAMTOP no good

; Now, even if RAMTOP has not moved, the GOSUB stack is cleared and
; initialized.

CLEAR_2 EX DE,HL          ; transfer RAMTOP value to HL.
        LD ($5BB2),HL     ; update system variable RAMTOP.
        POP DE            ; pop the return address STMT-RET.
        POP BC            ; pop the Error Address.
        LD (HL),$3E       ; now put the GO SUB end-marker at RAMTOP.
        DEC HL            ; leave a location beneath it.
        LD SP,HL          ; initialize the machine stack pointer.

        PUSH BC           ; push the error address.

        LD ($5B3D),SP     ; make ERR_SP point to location.
        EX DE,HL          ; put STMT-RET in HL.

        JP (HL)           ; and go there directly.

; -----
; THE 'GO SUB' COMMAND
; -----
; The GO SUB command diverts BASIC control to a new line number in a very
; similar manner to GO TO but the current line number and current statement
; plus 1 are placed on the GO SUB stack as a RETURN point.

GO_SUB POP DE             ; drop the address STMT-RET
        LD H,(IY+$0D)     ; fetch statement from SUBPPC and
        INC H             ; increment it
        EX (SP),HL        ; swap - error address to HL,
                           ; H (statement) at top of stack,
                           ; L (unimportant) beneath.
        INC SP            ; adjust to overwrite unimportant byte
        LD BC,($5B45)     ; fetch the current line number from PPC
        PUSH BC           ; and PUSH onto GO SUB stack.
                           ; the empty machine-stack can be rebuilt
        PUSH HL           ; push the error address.

```

```

        LD      ($5B3D),SP      ; make system variable ERR_SP point to it.
        PUSH   DE              ; push the address STMT-RET.

        CALL   GO_TO          ; call routine GO-TO to update the system
                               ; variables NEWPPC and NSPPC.
                               ; then make an indirect exit to STMT-RET via
        LD      BC,$0014      ; a 20-byte overhead memory check.

; -----
; THE 'TEST ROOM' SUBROUTINE
; -----
; This routine is used on many occasions when extending a dynamic area
; upwards or the GO SUB stack downwards.

TEST_ROOM LD      HL,($5B65)   ; fetch STKEND
          ADD     HL,BC        ; add the supplied test value
          JR      C,REPORT_4   ; forward, if over $FFFF, to REPORT-4
                               ; 'Out of memory'

          EX     DE,HL        ; The result was less so transfer to DE
          LD     HL,$0050     ; test against another 80 bytes
          ADD     HL,DE        ; anyway
          JR      C,REPORT_4   ; forward, if this passes $FFFF, to REPORT-4
                               ; 'Out of memory'

          SBC    HL,SP        ; if less than the machine stack pointer
          RET     C           ; then return - OK.
                               ; Register HL contains the negated number of
                               ; free bytes.

REPORT_4 LD      L,$03        ; prepare 'Out of memory'

          JP     ERROR_3      ; jump back to ERROR-3
                               ; Note. this error can't be trapped at $0008

; -----
; THE 'FREE MEMORY' USER ROUTINE
; -----
; This routine is not used by the ROM but allows users to evaluate
; approximate free memory with PRINT 65536 - USR address.
; Note. It has been moved, for stability, to location ninety three decimal.

; -----
; THE 'RETURN' COMMAND
; -----
; As with any command, there are two values on the machine stack at the time
; it is invoked. The machine stack is below the GO SUB stack. Both grow
; downwards, the machine stack by two bytes, the GO SUB stack by 3 bytes.
; The highest location is a statement byte followed by a two-byte line number.

RETURN   POP     BC           ; drop the address STMT-RET.
          POP     HL           ; now the error address.
          POP     DE           ; now a possible BASIC return line.
          LD     A,D           ; the high byte $00 - $27 is
          CP     $3E          ; compared with the traditional end-marker $3E.
          JR     Z,REPORT_7   ; forward, with a match, to REPORT-7
                               ; 'RETURN without GO SUB'

; It was not the end-marker so a single statement byte remains at the base of
; the calculator stack. It can't be popped off.

          DEC     SP           ; adjust stack pointer to create room for two
                               ; bytes.

```

```

EX      (SP),HL          ; statement to H, error address to base of
                        ; new machine stack.
EX      DE,HL           ; statement to D, BASIC line number to HL.
LD      ($5B3D),SP      ; adjust ERR_SP to point to new stack pointer

PUSH   BC               ; now re-stack the address STMT-RET

JP      GO_TO_2         ; back to GO-TO-2
                        ; to update statement and line system variables
                        ; and exit indirectly to the address just pushed
                        ; on the stack.

; ---

REPORT_7  PUSH   DE      ; replace the end-marker.
          PUSH   HL      ; now restore the error address
                        ; as will be required in a few clock cycles.

          RST    30H     ; ERROR-1
          DEFB  $06     ; Error Report: RETURN without GOSUB

; Note. 'GO SUB' won't fit in message.

; -----
; THE 'PAUSE' COMMAND
; -----
; The PAUSE command takes as its parameter the number of interrupts
; for which to wait. PAUSE 50 pauses for about a second in the UK.
; PAUSE 60 waits for the same time in the USA.
; PAUSE 0 pauses indefinitely.
; Both forms can be finished early by pressing a key.

PAUSE     CALL   FIND_INT2      ; routine FIND-INT2 puts value in BC

PAUSE_1   HALT                ; wait for an interrupt.
          DEC    BC            ; decrease the counter.
          LD     A,B           ; test if the
          OR     C             ; result is zero.
          JR     Z,PAUSE_END    ; forward, if so, to PAUSE-END

          LD     A,B           ; test if
          AND    C             ; now $FFFF
          INC    A             ; that is, initially zero.
          JR     NZ,PAUSE_2     ; skip forward, if not, to PAUSE-2

          INC    BC            ; restore counter to zero.

PAUSE_2   BIT     5,(IY+$01)    ; test FLAGS - has a new key been pressed ?
          JR     Z,PAUSE_1     ; back, if not, to PAUSE-1

PAUSE_END RES  5,(IY+$01)      ; update FLAGS - signal no new key

          RET                  ; Return.

; -----
; THE 'CHECK FOR BREAK' SUBROUTINE
; -----
; This routine is called from COPY-LINE, when interrupts are disabled, to
; test if BREAK (SHIFT - SPACE) is being pressed.
; It is also called at STMT-RET after every statement.

BREAK_KEY LD     A,$7F         ; Input address: $7FFE
          IN     A,($FE)       ; read lower right keys
          RRA                  ; rotate bit 0 - SPACE

```

```

RET    C                ; return if not reset

LD     A,$FE           ; Input address: $FEFE
IN     A,($FE)         ; read lower left keys
RRA                    ; rotate bit 0 - SHIFT

RET                    ; carry will be set if not pressed.
                    ; return with no carry if both keys
                    ; pressed.

; -----
; THE 'DEF FN' COMMAND
; -----
; e.g. DEF FN r$(a$,a) = a$(a TO )
; this 'command' is ignored in runtime but has its syntax checked during
; line-entry.

DEF_FN CALL SYNTAX_Z    ; routine SYNTAX-Z

JR     Z,DEF_FN_1      ; forward, if parsing, to DEF-FN-1

LD     A,$CE           ; else in runtime load A with 'DEF FN' and
JP     PASS_BY         ; jump back to PASS-BY

; ---

; The syntax path continues here.

DEF_FN_1 SET 6,(IY+$01) ; set FLAGS - assume numeric result

CALL  ALPHA           ; call routine ALPHA

JR     NC,REPORT_Cd   ; forward, if not, to DEF-FN-4
                    ; 'Nonsense in BASIC'

RST   20H             ; NEXT-CHAR
CP    $24             ; is character '$' ?
JR     NZ,DEF_FN_2    ; forward, if not type string, to DEF-FN-2

;;; RES 6,(IY+$01)    ; set FLAGS - signal string result.
CALL  STR_RSLT       ;+

RST   20H             ; get NEXT-CHAR

DEF_FN_2 CP $28       ; is character '(' ?
JR     NZ,REPORT_Cd  ; forward, if not, to DEF-FN-7
                    ; 'Nonsense in BASIC'

RST   20H             ; NEXT-CHAR
CP    $29             ; is character ')' ?
JR     Z,DEF_FN_6    ; forward, if null arguments, to DEF-FN-6

DEF_FN_3 CALL ALPHA   ; routine ALPHA checks that it is the expected
                    ; alphabetic character.

DEF_FN_4 JR NC,REPORT_Cd ; jump, if not, to REPORT-C
                    ; 'Nonsense in BASIC'.

EX    DE,HL           ; save pointer in DE

RST   20H             ; NEXT-CHAR re-initializes HL from CH_ADD
                    ; and advances.

```

```

CP      $24          ; is character a '$' ?
JR      NZ,DEF_FN_5  ; forward, if not string argument, to DEF-FN-5

EX      DE,HL        ; save pointer to '$' in DE

RST     20H          ; NEXT-CHAR re-initializes HL and advances

DEF_FN_5 EX      DE,HL        ; bring back pointer.

LD      BC,$0006     ; the function requires six hidden bytes for
                    ; each parameter passed.
                    ; The first byte will be $0E
                    ; then 5-byte numeric value
                    ; or 5-byte string pointer.

CALL    MAKE_ROOM    ; routine MAKE-ROOM creates space in program
                    ; area.
;;;      INC      HL        ; adjust HL (set by LDDR)
          INC      HL        ; to point to first location.
          LD      (HL),$0E    ; insert the 'hidden' marker.

; Note. these invisible storage locations hold nothing meaningful for the
; moment. They will be used every time the corresponding function is
; evaluated in runtime.
; Now consider the following character fetched earlier.

CP      $2C          ; is it ',' ? (more than one parameter)
JR      NZ,DEF_FN_6  ; forward, if not, to DEF-FN-6

RST     20H          ; else NEXT-CHAR
JR      DEF_FN_3     ; and back to DEF-FN-3

; ---

DEF_FN_6
;;;      CP      $29          ; is character the closing ')' ?
;;;      JR      NZ,REPORT_Cd ; forward, if not, to DEF-FN-7
;;;      RST     20H          ; get NEXT-CHAR

CALL    RBRKT_NXT    ;+ check for right-hand bracket and advances.

CP      $3D          ; is it '=' ?
JR      NZ,REPORT_Cd ; to DEF-FN-7
                    ; 'Nonsense in BASIC'

RST     20H          ; address NEXT-CHAR
LD      A,($5B3B)    ; get FLAGS which has been set above

PUSH    AF           ; and preserve

CALL    SCANNING     ; routine SCANNING checks syntax of expression
                    ; and also sets flags.

POP     AF           ; restore previous flags

XOR     (IY+$01)     ; XOR with FLAGS - bit 6 should be same
                    ; therefore will be reset.
AND     $40          ; isolate bit 6.

;;; DEF_FN_7 JP    NZ,REPORT_C ; jump back to REPORT-C if the expected result
                    ; is not the same type.

```



```

; 'Nonsense in BASIC'

;;; CALL CHECK_END ; routine CHECK-END will return early

CALL Z,CHECK_END ; routine CHECK-END will return early if
; at end of statement and move onto next
; else produce error report. >>>

; There will be no return to here.

REPORT_Cd RST 30H ;+ ERROR-1
DEFB $0B ;+ Error Report: Nonsense in BASIC

; -----
; THE 'UNSTACK-Z' SUBROUTINE (6)
; -----
; All routines are capable of being run in two modes - syntax checking mode
; and runtime mode. This routine is called often to allow a routine to
; return early if checking syntax.

UNSTACK_Z CALL SYNTAX_Z ; routine SYNTAX-Z sets zero flag if syntax
; is being checked.

POP HL ; drop the return address.
RET Z ; return to previous call in chain if checking
; syntax.

JP (HL) ; jump to return address as BASIC program is
; actually running.

; -----
; THE 'LPRINT' COMMAND
; -----
; A simple form of 'PRINT #3' although it can output to 16 streams.
; Probably for compatibility with other BASICS particularly ZX81 BASIC.
; An extra UDG might have been better.

LPRINT LD A,$03 ; the printer channel
JR PRINT_1 ; forward to PRINT-1

; -----
; THE 'PRINT' COMMAND
; -----
; The Spectrum's main stream output command.
; The default stream is stream 2 which is normally the upper screen
; of the computer. However the stream can be altered in range 0 - 15.

PRINT LD A,$02 ; the stream for the upper screen.

; The LPRINT command joins here.

PRINT_1 CALL CHN_O_SYN ;+ routine opens channel in runtime.

;;; CALL SYNTAX_Z ; routine SYNTAX-Z checks if program running
;;; CALL NZ,CHAN_SLCT ; routine CHAN-OPEN if so (calls TEMPs)
;;; CALL TEMPs ; routine TEMPs sets temporary colours.

CALL PRINT_2 ; routine PRINT-2 - the actual item

CALL CHECK_END ; routine CHECK-END gives error if not at end
; of statement

```



```

        CALL UNSTACK_Z          ; routine UNSTACK_Z quits if checking syntax.

        CALL STK_TO_BC         ; routine STK-TO-BC get the numbers in B and C.
        LD   A,$16             ; prepare the 'at' control.
        JR   PR_AT_TAB        ; forward to PR-AT-TAB to print the sequence.

; ---

PR_ITEM_2 CP   $AD             ; is character 'TAB' ?
          JR   NZ,PR_ITEM_3    ; forward, if not, to PR-ITEM-3

          RST  20H             ; NEXT-CHAR to address next character
          CALL EXPT_1NUM       ; routine EXPT-1NUM checks for numeric
                                ; expression and stacks it in run-time.

          CALL UNSTACK_Z      ; routine UNSTACK_Z quits if checking syntax.

          CALL FIND_INT2      ; routine FIND-INT2 puts integer in BC.
          LD   A,$17          ; prepare the 'tab' control.

PR_AT_TAB RST  10H            ; PRINT-A outputs the control

          LD   A,C             ; first value to A
          RST  10H            ; PRINT-A outputs it.

          LD   A,B             ; second value
          RST  10H            ; PRINT-A

          RET                  ; return - item finished >>>

; ---

;   Now consider paper 2; #2; a$

PR_ITEM_3 CALL CO_TEMP_3      ; routine CO-TEMP-3 will print any colour
          RET   NC             ; items - return if success.

;   Now consider a change in the output stream.
;   Note. as this is called from IN_ITEM it can also effect a change in the
;   stream used for INPUT.

          CALL STR_ALTER      ; routine STR-ALTER considers new stream
          RET   NC             ; return if altered.

          CALL SCANNING      ; routine SCANNING now to evaluate expression

          CALL UNSTACK_Z     ; routine UNSTACK_Z quits if not runtime.

          BIT   6,(IY+$01)    ; test FLAGS - Numeric or string result ?

;   Note. the next two instructions have been switched so that STK_FETCH
;   can return zero if BC is zero (used elsewhere).

          JP   NZ,PRINT_FP    ; to PRINT-FP to print if numeric >>>

          CALL STK_FETCH      ; routine STK-FETCH if string.
                                ; note flags now affected.

;   It was a string expression - start in DE, length in BC
;   Now enter a loop to print it

```

```

PR_STRING LD    A,B          ; this tests if the
          OR    C            ; length is zero and sets flag accordingly.
          DEC   BC          ; this doesn't but decrements counter.
          RET   Z            ; return if zero.

          LD    A,(DE)       ; fetch character.
          INC   DE           ; address next location.

          RST   10H         ; PRINT-A.

          JR    PR_STRING   ; loop back to PR-STRING.

; -----
; THE 'END OF PRINTING' SUBROUTINE
; -----
; This subroutine returns zero if no further printing is required
; in the current statement.
; The first terminator is found in escaped input items only,
; the others in print_items.

PR_END_Z  CP    $29         ; is character a ')' ?
          RET   Z            ; return if so - e.g. INPUT (p$); a$

PR_ST_END CP    $0D         ; is it a carriage return ?
          RET   Z            ; return also - e.g. PRINT a

          CP    $3A         ; is character a ':' ?
          RET   Z            ; return - zero flag will be set with match.
                          ; e.g. PRINT a :

; -----
; THE 'PRINT POSITION' ROUTINE
; -----
; This routine considers a single positional character ';', ',', ''

PR_POSN_1 RST   18H         ; GET-CHAR
          CP    $3B         ; is it ';' ?
                          ; i.e. print from last position.
          JR    Z,PR_POSN_3 ; forward, if so, to PR-POSN-3
                          ; i.e. do nothing.

          CP    $2C         ; is it ',' ?
                          ; i.e. print at next tabstop.
          JR    NZ,PR_POSN_2 ; forward to PR-POSN-2 if anything else.

          CALL  SYNTAX_Z    ; routine SYNTAX-Z

          JR    Z,PR_POSN_3 ; forward to PR-POSN-3 if checking syntax.

          LD    A,$06       ; prepare the 'comma' control character.

          RST   10H         ; PRINT-A outputs to current channel in
                          ; run-time.

          JR    PR_POSN_3   ; skip to PR-POSN-3.

; ---

; check for newline.

PR_POSN_2 CP    $27         ; is character a '"' ? (newline)
          RET   NZ          ; return if no match >>>

          CALL  PRINT_CR    ; routine PRINT-CR outputs a carriage return

```

```

; in runtime only.

PR_POSN_3 RST 20H ; NEXT-CHAR to A.
          CALL PR_END_Z ; routine PR-END-Z checks if at end.
          JR NZ,PR_POSN_4 ; skip forward, if not, to PR-POSN-4

          POP BC ; drop return address if at end.

PR_POSN_4 CP A ; reset the zero flag.
          RET ; and return to loop or quit.

; -----
; THE 'ALTER STREAM' SUBROUTINE
; -----
; This routine is called from PRINT ITEMS above, and also LIST as in LIST #15

STR_ALTER RST 18H ;+ GET_CHAR
          CP $23 ; is character '#' ?
          SCF ; set carry flag.
          RET NZ ; return if no match.

          RST 20H ; NEXT-CHAR
          CALL EXPT_1NUM ; routine EXPT-1NUM gets stream number
          AND A ; prepare to exit early with carry reset

          CALL UNSTACK_Z ; routine UNSTACK_Z exits early if parsing

CHAN_CHK CALL FIND_INT1 ; routine FIND-INT1 gets number off stack

          CP $10 ; stream must be range 0 - 15 decimal.
          JP NC,REPORT_O ; jump back, if not, to REPORT-0
          ; 'Invalid stream'.

          CALL CHAN_SLCT ; Routine CHAN-OPEN

          AND A ; Clear carry - signal item dealt with.

          RET ; Return.

; -----
; THE 'INPUT' COMMAND
; -----
; This command inputs by default from the stream 1. On the standard
; Spectrum this is selected before CLS-LOWER so the channel that is
; in force is the system 'K' channel and can only be overridden by the user
; using INPUT #1.

INPUT CALL SYNTAX_Z ; routine SYNTAX-Z to check if in runtime.
      JR Z,INPUT_1 ; forward, if checking syntax, to INPUT-1

      LD A,$01 ; select stream 1 which is reserved for INPUT.
      CALL CHAN_SLCT ; routine CHAN-OPEN opens the channel.

      CALL IN_CHAN_K ;+ routine IN-CHAN-K tests if keyboard in use.

;;; CALL CLS_LOWER ; routine CLS-LOWER wrongly clears lower screen.

      CALL Z,CLS_LOWER ;+ routine CLS-LOWER clears the lower screen
      ;+ and sets DF_SZ to two and TV_FLAG to $01
      ;+ but only if channel 1 is the keyboard.

INPUT_1 LD (IY+$02),$01 ; update TV_FLAG - signal lower screen in use
        ; ensuring that the correct set of system

```

```

; variables are updated and that the border
; colour is used.

; Note. The Complete Spectrum ROM Disassembly incorrectly names DF-SZ as the
; system variable that is updated above and if, you make this unnecessary
; alteration then there will be two blank lines between the lower screen and
; the upper screen areas which will also scroll wrongly.

        CALL  IN_ITEM_1      ; routine IN-ITEM-1 to handle the input.

        CALL  CHECK_END     ; routine CHECK-END will make an early exit
; if checking syntax. >>>

; keyboard input has been made and it remains to adjust the upper
; screen in case the lower two lines have been extended upwards.

        LD    BC,($5B88)    ; fetch S_POSN current line/column of
; the upper screen.
        LD    A,($5B6B)    ; fetch DF_SZ the display file size of
; the lower screen.
        CP    B            ; test that lower screen does not overlap.
        JR    C,INPUT_2    ; forward, if not, to INPUT-2

; the two screens overlap so adjust upper screen.

        LD    C,$21        ; set column of upper screen to leftmost.
        LD    B,A          ; and line to one above lower screen.
; continue forward to update upper screen
; print position.

INPUT_2 LD    ($5B88),BC    ; set S_POSN update upper screen line/column.
        LD    A,$19        ; subtract from twenty five
        SUB   B            ; the new line number.
        LD    ($5B8C),A    ; and place result in SCR_CT - scroll count.
        RES  0,(IY+$02)    ; update TV_FLAG - signal main screen in use.
        CALL  CL_SET      ; routine CL-SET sets the print position
; system variables for the upper screen.
        JP    CLS_LOWER   ; jump back to CLS-LOWER and make
; an indirect exit >>.

; -----
; THE 'INPUT ITEM' SUBROUTINE
; -----
; This subroutine deals with the input items and print items from the current
; input channel which was defaulted to 'K' above.

IN_ITEM_1 CALL PR_POSN_1   ; routine PR-POSN-1 deals with a single
; position item at each call.
        JR    Z,IN_ITEM_1 ; back to IN-ITEM-1 until no more in a
; sequence.

        CP    $28        ; is character '(' ?
        JR    NZ,IN_ITEM_2 ; forward, if not, to IN-ITEM-2

; any variables within brackets will be treated as part, or all, of the
; prompt instead of being used as destination variables.

        RST  20H        ; NEXT-CHAR
        CALL PRINT_2    ; routine PRINT-2 to output the dynamic
; prompt.

        RST  18H        ; GET-CHAR

;;; CP    $29        ; is character a matching ')' ?

```

```

;;;      JR      NZ,REPORT_Cy      ; forward, if not, to REPORT-Cy
;;;      RST     20H                ; NEXT-CHAR

      CALL    RBRKT_NXT            ;+ check for right-hand bracket and advance.

      JP      IN_NEXT_2            ; jump forward to IN-NEXT-2

; ---

;   Consider INPUT LINE

IN_ITEM_2 CP      $CA              ; is the character the token 'LINE' ?
          JR      NZ,IN_ITEM_3     ; forward, if not, to IN-ITEM-3

          RST     20H              ; NEXT-CHAR - variable must come next.
          CALL    CLASS_01         ; routine CLASS-01 returns destination
                                ; address of variable to be assigned.
                                ; or generates an error if no variable
                                ; at this position.

          SET     7,(IY+$37)       ; update FLAGX - signal handling INPUT LINE

          BIT     6,(IY+$01)       ; test FLAGS - numeric or string result ?

;;;      JP      NZ,REPORT_C       ; jump back to REPORT-C if not string
;;;                                ; 'Nonsense in BASIC'.

          JR      Z,IN_PROMPT      ; forward, if string, to IN-PROMPT
                                ; to set up workspace.

REPORT_Cy RST     30H              ;+ ERROR-1
          DEFB   $0B              ;+ Error Report: Nonsense in BASIC

; ---

;   the jump was here for other variables.
;   Note. the character '#' will cause a jump to IN_NEXT_1

IN_ITEM_3 CALL    ALPHA            ; routine ALPHA checks if character is
                                ; a suitable variable name.

          JP      NC,IN_NEXT_1     ; jump forward, if not, to IN-NEXT-1

          CALL    CLASS_01         ; routine CLASS-01 returns destination
                                ; address of variable to be assigned.
          RES     7,(IY+$37)       ; update FLAGX - signal not INPUT LINE.

;   The two paths converge here.

IN_PROMPT CALL    SYNTAX_Z         ; routine SYNTAX-Z

          JP      Z,IN_NEXT_2     ; forward to IN-NEXT-2 if checking syntax.

;   Continue in runtime.

          CALL    SET_WORK         ; routine SET-WORK clears workspace.

          LD     HL,$5B71          ; point to system variable FLAGX
          RES   6,(HL)            ; signal string result.
          SET   5,(HL)            ; signal in Input Mode for editor.

;;;      LD     BC,$0001          ; initialize space required to one for the CR.

          LD     C,$01            ;+ initialize space required to one for the CR.

```

```

        BIT    7,(HL)           ; test FLAGX - INPUT LINE in use ?

        JR     NZ,IN_PR_2      ; forward, if so, to IN-PR-2
                                ; as that is all the space that is required.

;   If not INPUT LINE then the result can be numeric or string.

        LD     A,($5B3B)       ; load accumulator from FLAGS
        AND    $40             ; mask to test BIT 6 of FLAGS and clear
                                ; the other bits in A.
                                ; numeric result expected ?
        JR     NZ,IN_PR_1      ; forward, if so, to IN-PR-1

        LD     C,$03          ; increase space to three bytes for the
                                ; pair of surrounding quotes.

IN_PR_1  OR     (HL)           ; if numeric result, set bit 6 of FLAGX.
        LD     (HL),A         ; and update system variable

IN_PR_2  CALL   BC_SPACE0     ; BC_SPACES opens 1 or 3 bytes in workspace
        LD     (HL),$0D       ; insert carriage return at last new location.

;;;     LD     A,C           ; fetch the length, one or three.
;;;     RRCA          ; lose bit 0.
;;;     RRCA          ; test if quotes required.
;;;     JR     NC,IN_PR_3    ; forward, if not, to IN-PR-3

        BIT    1,C           ;+ test if quotes required.
        JR     Z,IN_PR_3     ;+ skip forward, if not, to IN_PR_3

        LD     A,$22         ; load the '"' character
        LD     (DE),A        ; place quote in first new location at DE.
        DEC   HL             ; decrease HL - from carriage return.
        LD     (HL),A        ; and place a quote in second location.

IN_PR_3  LD     ($5B5B),HL    ; set keyboard cursor K_CUR to HL

        BIT    7,(IY+$37)     ; test FLAGX - is this INPUT LINE ?
        JR     NZ,IN_VAR_3    ; forward, if so, to IN-VAR-3 as input will
                                ; be accepted without checking its syntax.

;   prepare to parse the numeric or string input if not INPUT LINE.

;;;     RST    18H           ;+
        LD     HL,($5B5D)     ; fetch CH_ADD
        PUSH  HL             ; and save on stack.
        LD     HL,($5B3D)     ; fetch ERR_SP
        PUSH  HL             ; and save on stack

IN_VAR_1 LD     HL,IN_VAR_1   ; address: IN-VAR-1 - this address
        PUSH  HL             ; is saved on stack to handle errors.

        BIT    4,(IY+$30)     ; test FLAGS2 - is K channel in use ?
        JR     Z,IN_VAR_2     ; forward, if not keyboard, to IN-VAR-2

;   Now update the error pointer so that user is able to alter until correct.

        LD     ($5B3D),SP     ; set ERR_SP to point to IN-VAR-1 on stack.

IN_VAR_2 LD     HL,($5B61)    ; set HL to WORKSP - start of workspace.

        CALL  REMOVE_FP      ; routine REMOVE-FP removes floating point
                                ; forms when looping in the error condition.

```



```

;;;      LD      (IY+$00), $FF      ; set ERR_NR to 'OK' cancelling the error.
;;;      ; but X_PTR causes flashing error marker
;;;      ; to be displayed at each call to the editor.

      CALL  SET_ER_FF      ;+ NEW 3-byte call.

      CALL  EDITOR      ; routine EDITOR allows input to be entered
                        ; or corrected if this is second time around.

;   If we pass to next then there are no system errors

      RES   7, (IY+$01)      ; update FLAGS - signal checking syntax
      CALL  IN_ASSIGN      ; routine IN-ASSIGN checks syntax using
                        ; the VAL-FET-2 and powerful SCANNING routines.
                        ; any syntax error and its back to IN-VAR-1.
                        ; but with the flashing error marker showing
                        ; where the error is.
                        ; Note. the syntax of string input has to be
                        ; checked as the user may have removed the
                        ; bounding quotes or escaped them as with
                        ; "hat" + "stand" for example.

;   Proceed if syntax passed.

      JR    IN_VAR_4      ; jump forward to IN-VAR-4

; ---

;   The jump was to here when using INPUT LINE.

IN_VAR_3  CALL  EDITOR      ; routine EDITOR is called for input

;   When ENTER received rejoin other route but with no syntax check.

;   Paths for INPUT and INPUT LINE converge here.

IN_VAR_4
;;;      LD      (IY+$22), $00      ; set K_CUR_hi to a low value
;;;      LD      (IY+$22), A        ;+ set K_CUR_hi to a low value so that cursor
;;;      ;+ no longer appears in the input line. (A=13)

      CALL  IN_CHAN_K      ; routine IN-CHAN-K tests if keyboard in use.

      JR    NZ, IN_VAR_5    ; forward to IN-VAR-5 if using another input
                        ; channel.

;   continue here if using the keyboard.

      CALL  ED_COPY      ; routine ED-COPY overprints the edit line
                        ; to the lower screen. The only visible
                        ; affect is that the cursor disappears.
                        ; if you're inputting more than one item in
                        ; a statement then that becomes apparent.

      LD    BC, ($5B82)    ; fetch line and column from ECHO_E

      CALL  CL_SET      ; routine CL-SET sets S-POSNL to those
                        ; values.

;   if using another input channel rejoin here.

IN_VAR_5  LD      HL, $5B71    ; point HL to FLAGX
          RES     5, (HL)      ; signal not in input mode

```

```

        BIT    7,(HL)           ; is this INPUT LINE ?
        RES    7,(HL)           ; cancel the bit anyway.
        JR     NZ,IN_VAR_6      ; forward to IN-VAR-6 if INPUT LINE.

        POP    HL               ; drop the looping address
        POP    HL               ; drop the address of previous
                                ; error handler.

        LD     ($5B3D),HL       ; set ERR_SP to point to it.
        POP    HL               ; drop original CH_ADD which points to
                                ; INPUT command in BASIC line.

        LD     ($5B5F),HL       ; save in X_PTR while input is assigned.
        SET    7,(IY+$01)       ; update FL_AGS - Signal running program
        CALL   IN_ASSIGN        ; routine IN-ASSIGN is called again
                                ; this time the variable will be assigned
                                ; the input value without error.
                                ; Note. the previous example now
                                ; becomes "hatstand"

        LD     HL,($5B5F)       ; fetch stored CH_ADD value from X_PTR.
; ; ; LD     (IY+$26),$00       ; set X_PTR_hi so that it is no longer relevant.
        LD     (IY+$26),A       ;+ set X_PTR_hi so that it is irrelevant. (A=13)
        LD     ($5B5D),HL       ; put restored value back in CH_ADD
        JR     IN_NEXT_2        ; forward to IN-NEXT-2 to see if anything
                                ; more in the INPUT list.

; ---

; the jump was to here with INPUT LINE only

IN_VAR_6 LD     HL,($5B63)       ; STKBOT points to the end of the input.
        LD     DE,($5B61)       ; WORKSP points to the beginning.
        SCF                               ; prepare for true subtraction.
        SBC    HL,DE             ; subtract to get length
        LD     B,H               ; transfer it to
        LD     C,L               ; the BC register pair.
        CALL   STK_STO_s         ; routine STK-STO-$ stores parameters on
                                ; the calculator stack.

        CALL   LET               ; routine LET assigns it to destination.

        JR     IN_NEXT_2        ; forward to IN-NEXT-2 as print items
                                ; not allowed with INPUT LINE.
                                ; Note. that "hat" + "stand" will, for
                                ; example, be unchanged.

; ---

; The jump was to here when ALPHA found more items while looking for
; a variable name. The routine PR_ITEM_1 is called for the first time
; which allows the stream to be altered if the character is '#'.

IN_NEXT_1 CALL   PR_ITEM_1       ; routine PR-ITEM-1 considers further items.
IN_NEXT_2 CALL   PR_POSN_1       ; routine PR-POSN-1 handles a position item.

        JP     Z,IN_ITEM_1       ; jump back to IN-ITEM-1 if the zero flag
                                ; indicates more items are present.

        RET                       ; Return.

; -----
; INPUT ASSIGNMENT Subroutine
; -----
; This subroutine is called twice from the INPUT command when normal

```

```

; keyboard input is assigned. On the first occasion syntax is checked
; using SCANNING. The final call with the syntax flag reset is to make
; the assignment.

IN_ASSIGN LD    HL,($5B61)      ; fetch WORKSP start of input
          LD    ($5B5D),HL     ; set CH_ADD to first character

          RST   18H            ; GET-CHAR ignoring any leading white-space.
          CP    $E2            ; is it 'STOP'
          JR    Z,IN_STOP      ; forward, if so, to IN-STOP

          LD    A,($5B71)      ; load accumulator from FLAGX

          CALL  VAL_FET_2      ; routine VAL-FET-2 makes assignment
                               ; or goes through the motions if checking
                               ; syntax. SCANNING is used.

          RST   18H            ; GET-CHAR
          CP    $0D            ; is character a carriage return ?
          RET   Z              ; return with a match.
                               ; either syntax is OK
                               ; or assignment has been made.

; if another character was found then raise an error.
; User doesn't see report but the flashing error marker
; appears in the lower screen.

REPORT_Cb RST   30H            ; ERROR-1
          DEFB  $0B            ; Error Report: Nonsense in BASIC
; ---

;;; IN_STOP  CALL  SYNTAX_Z      ; routine SYNTAX-Z (UNSTACK_Z?)
;;;          RET   Z              ; return if checking syntax

IN_STOP   CALL  UNSTACK_Z      ;+ return if checking syntax.
                               ;+ as user wouldn't see error report.
                               ;+ but generate visible error report
                               ;+ on second invocation.

REPORT_H  RST   30H            ; ERROR-1
          DEFB  $10            ; Error Report: STOP in INPUT

; -----
; THE 'TEST FOR CHANNEL K' SUBROUTINE
; -----
; This subroutine is called once from the INPUT command to check if
; the input routine in use is the one for the keyboard.
; It returns with the zero flag set for the keyboard and reset for the
; network and RS232.
; Note. this routine, essentially the same as set out here, has been moved
; to a position before the NUMBER routine with which it is now combined.

;;; IN_CHAN_K LD    HL,($5B51)      ; fetch address of current channel CURCHL
;;;          INC   HL              ;
;;;          INC   HL              ; advance past
;;;          INC   HL              ; input and
;;;          INC   HL              ; output streams
;;;          LD    A,(HL)          ; fetch the channel identifier.
;;;          CP    $4B            ; test for 'K'
;;;          RET                    ; return with zero set if keyboard is use.

; -----
; THE 'COLOUR ITEM' ROUTINES
; -----

```

```

;
; These routines have 3 entry points -
; 1) CO-TEMP-2 to handle a series of embedded Graphic colour items.
; 2) CO-TEMP-3 to handle a single embedded print colour item.
; 3) CO TEMP-4 to handle a colour command such as FLASH 1
;
; "Due to a bug, if you bring in a peripheral channel and later use a colour
; statement, colour controls will be sent to it by mistake."
; - Steven Vickers, Pitman Pocket Guide, 1984.
;
; To be fair, this only applies if the last channel was other than 'K', 'S'
; or 'P', which are all that were supported by this ROM, but if that last
; channel was a microdrive file, network channel etc. then
; PAPER 6; CLS will not turn the screen yellow and
; CIRCLE INK 2; 128,88,50 will not draw a red circle.
;
; This bug does not apply to embedded PRINT items as it is quite permissible
; to mix stream altering commands and colour items.
; The fix therefore would be to ensure that CLASS-07 and CLASS-09 make
; channel 'S' the current channel when not checking syntax.
;
; -----
;;; CO_TEMP_1 RST    20H          ; NEXT-CHAR
;
; -> Entry point from CLASS-09. Embedded Graphic colour items.
; e.g. PLOT INK 2; PAPER 8; 128,88
; Loops till all colour items output, finally addressing the coordinates.
CO_TEMP_2 CALL    CO_TEMP_3      ; routine CO-TEMP-3 to output colour control.
              RET     C          ; return if nothing more to output. ->
              CALL    CLASS_0C    ;+ New routine to check for ';' or ',' and
              ;+ advance CH_ADD if so else produce error.
              JR     CO_TEMP_2    ;+ back, if no error to CO_TEMP_2
;;;
;;; RST    18H          ; GET-CHAR
;;; CP     $2C         ; is it ',' separator ?
;;; JR     Z,CO_TEMP_1 ; back, if so, to CO-TEMP-1
;;; CP     $3B         ; is it ';' separator ?
;;; JR     Z,CO_TEMP_1 ; back, if so, to CO-TEMP-1
;;; JR     REPORT_Cb   ; to REPORT-C (REPORT-Cb is within range)
;;; ; 'Nonsense in BASIC'
; -----
; CO-TEMP-3
; -----
; -> this routine evaluates and outputs a colour control and parameter.
; It is called from above and also from PR-ITEM-3 to handle a single embedded
; print item e.g. PRINT PAPER 6; "Hi". In the latter case, the looping for
; multiple items is within the PR-ITEM routine.
; It is quite permissible to send these to any stream.
CO_TEMP_3 CP     $D9          ; compare addressed character to 'INK'
              RET     C          ; return if less.
              CP     $DF          ; compare with 'OUT'
              CCF          ; Complement Carry Flag
              RET     C          ; return if greater than 'OVER' ($DE).
;
; The token expects one parameter so advance CH_ADD
              PUSH    AF          ; save the colour token e.g. 'PAPER'.

```

```

RST 20H ; NEXT-CHAR advances address.
POP AF ; restore token and continue.
; -> This entry point used by CLASS-07. e.g. the command PAPER 6.
CO_TEMP_4 SUB $C9 ; reduce to control character $10 (INK)
; through $15 (OVER) and clears CARRY flag.
PUSH AF ; save control and carry flag.
CALL EXPT_1NUM ; routine EXPT-1NUM stacks addressed parameter
; on the calculator stack.
POP AF ; restore control and clear carry flag.
;;; AND A ; clear carry for success (already clear).
CALL UNSTACK_Z ; routine UNSTACK_Z returns if checking syntax.
; In runtime, output the two control characters. There is no need to
; assimilate the two codes first.
;;; PUSH AF ; save again
RST 10H ;+ outputs the control altering output address.
CALL FIND_INT1 ; routine FIND-INT1 fetches parameter to A.
;;; LD D,A ; transfer now to D
;;; POP AF ; restore control.
;;; RST 10H ; PRINT-A outputs the control to current
; channel.
;;; LD A,D ; transfer parameter to A.
RST 10H ; PRINT-A outputs parameter restoring channel.
RET ; return. ->

```

```

; -----
;
; {fl}{br}{ paper }{ ink } The temporary colour attributes
; system variable.
; ATTR_T |_____|_____|_____|_____|_____|_____|_____|_____|
; |_____|_____|_____|_____|_____|_____|_____|_____|
; 23695 |_____|_____|_____|_____|_____|_____|_____|_____|
; |_____|_____|_____|_____|_____|_____|_____|_____|
; 7 6 5 4 3 2 1 0
;
; {fl}{br}{ paper }{ ink } The temporary mask used for
; transparent colours. Any bit
; MASK_T |_____|_____|_____|_____|_____|_____|_____|_____|
; |_____|_____|_____|_____|_____|_____|_____|_____|
; 23696 |_____|_____|_____|_____|_____|_____|_____|_____|
; |_____|_____|_____|_____|_____|_____|_____|_____|
; 7 6 5 4 3 2 1 0
;
; {paper9 }{ ink9 }{ inv1 }{ over1} The print flags. Even bits are
; temporary flags. The odd bits
; P_FLAG |_____|_____|_____|_____|_____|_____|_____|_____|
; | p | t | p | t | p | t | p | t |
;

```

```

; 23697 |___|___|___|___|___|___|___|___|
;         7   6   5   4   3   2   1   0
;
; -----
; -----
; The colour system variable handler.
; -----
; This is an exit branch from PO-1-OPER, PO-2-OPER
; A holds control $10 (INK) to $15 (OVER)
; D holds parameter 0-9 for ink/paper 0,1 or 8 for bright/flash,
; 0 or 1 for over/inverse.
;
; First consider INK and PAPER.

CO_TEMP_5 SUB    $11            ; reduce range $FF-$04
           LD     E,$00         ;+ Set E to zero.
;;;        ADC   A,$00         ; add in carry if INK
           ADC   A,E           ;+ add in carry if INK
           JR    Z,CO_TEMP_7   ; forward to CO-TEMP-7 with INK and PAPER.

; Now consider FLASH and BRIGHT.

;;;        SUB   $02            ; reduce range $FF-$02
           ADC   A,$00         ; add carry if FLASH
           ADC   A,E           ;+ add carry if FLASH
           JR    Z,CO_TEMP_C   ; forward to CO-TEMP-C with FLASH and BRIGHT.

; Now consider remaining INVERSE and OVER.

;;;        INC   E              ;+ now make E=1
           CP   $01           ; is it 'INVERSE' ?
           CP   E              ; is it 'INVERSE' ?
           LD   A,D           ; fetch parameter for INVERSE/OVER
;;;        LD   B,$01         ; prepare OVER mask setting bit 0.
           LD   B,E           ; prepare OVER mask setting bit 0.
           JR   NZ,CO_TEMP_6  ; forward to CO-TEMP-6 if OVER

; Deal with INVERSE.

           RLCA                ; shift bit 0
           RLCA                ; to bit 2
           LD   B,$04         ; set bit 2 of mask for INVERSE.

; The OVER path rejoins here.

CO_TEMP_6 LD   C,A           ; save the A
           LD   A,D           ; re-fetch parameter
           CP   $02           ; is it less than 2
           JR   NC,REPORT_K   ; to REPORT-K if not 0 or 1.
                               ; 'Invalid colour'.

           LD   A,C           ; restore A
           LD   HL,$5B91      ; address system variable P_FLAG
           JR   CO_CHANGE     ; forward to exit via routine CO-CHANGE

; ---

; the branch was here with INK and PAPER and carry set for INK.

CO_TEMP_7 LD   A,D           ; fetch parameter
           LD   B,$07         ; set ink mask 00000111
           JR   C,CO_TEMP_8   ; forward to CO-TEMP-8 with INK

```

```

        RLCA                ; shift bits 0-2
        RLCA                ; to
        RLCA                ; bits 3-5
        LD    B,$38        ; set PAPER mask 00111000

;   the INK path rejoins here.

CO_TEMP_8 LD    C,A        ; value to C
          LD    A,D        ; fetch parameter
          CP    $0A        ; is it less than 10 decimal ?
          JR    C,CO_TEMP_9 ; forward, if so, to CO-TEMP-9

;   INK 10 etc. is not allowed.

REPORT_K RST    30H        ; ERROR-1
          DEFB  $13        ; Error Report: Invalid colour

; ---

CO_TEMP_9 LD    HL,$5B8F   ; Address system variable ATTR_T initially.
          CP    $08        ; compare with 8
          JR    C,CO_TEMP_B ; forward to CO-TEMP-B with 0-7.

          LD    A,(HL)     ; fetch temporary attribute as no change.
          JR    Z,CO_TEMP_A ; forward to CO-TEMP-A with INK/PAPER 8

;   it is either ink 9 or paper 9 (contrasting)

          OR    B          ; or with mask to make white
          CPL                ; make black and change other to dark
          AND  $24        ; 00100100
          JR    Z,CO_TEMP_A ; forward to CO-TEMP-A if black and
                          ; originally light.

          LD    A,B        ; else just use the mask (white)

CO_TEMP_A LD    C,A        ; save A in C

CO_TEMP_B LD    A,C        ; load colour to A
          CALL CO_CHANGE   ; routine CO-CHANGE addressing ATTR-T

          LD    A,$07      ; put 7 in accumulator
          CP    D          ; compare with parameter
          SBC  A,A        ; $00 if 0-7, $FF if 8
          CALL CO_CHANGE   ; routine CO-CHANGE addressing MASK-T
                          ; mask returned in A.

;   now consider P-FLAG.

          RLCA                ; 01110000 or 00001110
          RLCA                ; 11100000 or 00011100
          AND  $50        ; 01000000 or 00010000 (AND 01010000)
          LD    B,A        ; transfer to mask
          LD    A,$08      ; load A with 8
          CP    D          ; compare with parameter
          SBC  A,A        ; $FF if was 9, $00 if 0-8
                          ; continue while addressing P-FLAG
                          ; setting bit 4 if ink 9
                          ; setting bit 6 if paper 9

; -----
; THE 'COLOUR CHANGE' ROUTINES
; -----
; This routine addresses a system variable ATTR_T, MASK_T or P-FLAG in HL.

```

```

; colour value in A, mask in B.

CO_CHANGE XOR    (HL)          ; impress bits specified
           AND     B            ; by mask
           XOR    (HL)          ; on system variable.
           LD     (HL),A        ; update system variable.
           INC    HL            ; address next location.
           LD     A,B          ; put current value of mask in A
           RET                  ; return.

; ---
;
; ---

; the branch was here with FLASH and BRIGHT

CO_TEMP_C SBC    A,A           ; set zero flag for BRIGHT.
           LD     A,D           ; fetch original parameter 0,1 or 8
           RRCA                   ; rotate bit 0 to bit 7
           LD     B,$80         ; mask for FLASH - %10000000
           JR     NZ,CO_TEMP_D  ; forward, if FLASH, to CO-TEMP-D

           RRCA                   ; rotate bit 7 to bit 6
           LD     B,$40         ; mask for BRIGHT - %01000000

CO_TEMP_D LD     C,A           ; store value in C
           LD     A,D           ; fetch parameter
           CP     $08           ; compare with 8
           JR     Z,CO_TEMP_E   ; forward, if eight, to CO-TEMP-E

           CP     $02           ; test if 0 or 1
           JR     NC,REPORT_K   ; back, if not, to REPORT-K
           ; 'Invalid colour'

CO_TEMP_E LD     A,C           ; value to A
           LD     HL,$5B8F      ; address ATTR_T
           CALL   CO_CHANGE     ; routine CO-CHANGE addressing ATTR_T
           LD     A,C           ; fetch value
           RRCA                   ; for flash8/bright8 complete the
           RRCA                   ; rotations to put set bit in
           RRCA                   ; bit 7 (flash) bit 6 (bright)
           JR     CO_CHANGE     ; back to CO-CHANGE addressing MASK_T
           ; and indirect return.

; -----
; THE 'BORDER' COMMAND
; -----
; Command syntax example: BORDER 7
; This command routine sets the border to one of the eight colours.
; The colours used for the lower screen are based on this.
; This is a CLASS_0 command so syntax is checked by the tables and this
; routine is only invoked in runtime.

BORDER    CALL   FIND_INT1      ; routine FIND-INT1
           CP     $08           ; must be in range 0 (black) to 7 (white)
           JR     NC,REPORT_K   ; back, if not, to REPORT-K
           ; 'Invalid colour'.

           OUT    ($FE),A       ; outputting to port effects an immediate
           ; change.
           RLCA                   ; shift the colour to
           RLCA                   ; the paper bits setting the
           RLCA                   ; ink colour black.
           BIT    5,A           ; is the paper number light coloured ?

```



```

; i.e. in the range green to white.

JR    NZ,BORDER_1    ; skip, if so, to BORDER-1

XOR   $07            ; make the ink white.

BORDER_1 LD    ($5B48),A    ; update BORDCR with new paper/ink

RET                                ; return.

; -----
; THE 'PIXEL ADDRESS' ROUTINE
; -----
;
;
PIXEL_ADD LD    A,$AF        ; load with 175 decimal.
SUB     B        ; subtract the y value.
JR     C,REPORT_Bz    ; jump forward to REPORT-Bc if greater.
; 'Integer out of range'

; the high byte is derived from Y only.
; the first 3 bits are always 010
; the next 2 bits denote in which third of the screen the byte is.
; the last 3 bits denote in which of the 8 scan lines within a third
; the byte is located. There are 24 discrete values.

LD     B,A          ; the line number from top of screen to B.

;;; AND    A          ; clear carry (already clear)

RRA                                ; 0xxxxxxx
SCF                                ; set carry flag
RRA                                ; 10xxxxxxx
AND    A          ; clear carry flag
RRA                                ; 010xxxxxx

XOR   B          ;
AND   $F8        ; keep the top 5 bits 11111000
XOR   B          ; 010xxbbb
LD    H,A        ; transfer high byte to H.

; The low byte of the address is derived from both X and Y.

LD     A,C        ; the x value 0-255.
RLCA                                ;
RLCA                                ;
RLCA                                ;
XOR   B          ; the y value
AND   $C7        ; apply mask 11000111
XOR   B          ; restore unmasked bits xxyyyxxx
RLCA                                ; rotate to xyyyxxxx
RLCA                                ; required position. yyyxxxxx
LD     L,A        ; low byte to L.

; Finally form the pixel position in A.

LD     A,C        ; x value to A
AND   $07        ; mod 8
RET                                ; return

; -----
; THE 'POINT' SUBROUTINE

```

```

; -----
; The point subroutine is called from s_point via the SCANNING functions
; table.
; Error B unless 0<=x<=255 and 0<=y<=175.
; In accordance with the BASIC manual, parameters must now be positive.

POINT_SUB CALL BC_POSTVE ; routine BC_POSTVE but with check on signs.

        CALL PIXEL_ADD ; routine PIXEL-ADD finds address of pixel
        ; producing an error if y is > 175.

        LD B,A ; pixel position to B, 0-7.
        INC B ; increment to give rotation count 1-8.
        LD A,(HL) ; fetch byte from screen.

POINT_LP RLCA ; rotate and loop back
        DJNZ POINT_LP ; to POINT-LP until required pixel at right.

        AND $01 ; test to give zero or one.
        JP STACK_A ; jump forward to STACK-A to save result.

; -----
; THE 'PLOT' COMMAND
; -----
; Command Syntax example: PLOT 128,88
;

PLOT CALL BC_POSTVE ; routine BC_POSTVE

;;; CALL PLOT_SUB ; routine PLOT-SUB

;;; JP TEMPs ;?to TEMPs to impose the permanent attributes
;;; ; onto the temporary ones as they may have been
;;; ; disturbed by embedded colour items ??

; -----
; THE 'PLOT' SUBROUTINE
; -----
; A screen byte holds 8 pixels so it is necessary to rotate a mask
; into the correct position to leave the other 7 pixels unaffected.
; However all 64 pixels in the character cell take any embedded colour
; items.
; A pixel can be reset (inverse 1), toggled (over 1), or set ( with inverse
; and over switches off). With both switches on, the byte is simply put
; back on the screen although the colours may change.

PLOT_SUB LD ($5B7D),BC ; store new x/y values in COORDS

        CALL PIXEL_ADD ; routine PIXEL-ADD gets address in HL,
        ; count from left 0-7 in B.

        LD B,A ; transfer count to B.
        INC B ; increase 1-8.
        LD A,$FE ; 11111110 in A.

PLOT_LOOP RRCA ; rotate mask.
        DJNZ PLOT_LOOP ; to PLOT-LOOP until B circular rotations.

        LD B,A ; load mask to B
        LD A,(HL) ; fetch screen byte to A

        LD C,(IY+$57) ; P_FLAG to C
        BIT 0,C ; is it to be OVER 1 ?
        JR NZ,PL_TST_IN ; forward, if so, to PL-TST-IN

```

```

; was OVER 0.

        AND    B            ; combine with mask to blank pixel.

PL_TST_IN BIT    2,C        ; is it inverse 1 ?
        JR     NZ,PLOT_END  ; forward, if so, to PLOT-END

        XOR    B            ; switch the pixel
        CPL                    ; restore other 7 bits

PLOT_END LD    (HL),A       ; load byte to the screen.
        JP     PO_ATTR     ; exit via PO-ATTR to set colours for cell.

; ---

REPORT_Bz RST    30H        ; ERROR-1
        DEFB  $0A          ; Error Report: Integer out of range

; -----
; THE 'CALCULATOR STACK TO BC REGISTERS' ROUTINE
; -----
;
;
STK_TO_BC CALL  STK_TO_A    ; routine STK-TO-A

        LD    B,A          ;
        PUSH BC            ;

        CALL  STK_TO_A    ; routine STK-TO-A

        LD    E,C          ;
        POP  BC            ;
        LD    D,C          ;
        LD    C,A          ;

        RET                    ; Return.

; -----
; THE 'CALCULATOR STACK TO ACCUMULATOR' ROUTINE
; -----
; This routine puts the last value on the calculator stack into the
; accumulator deleting the last value.

STK_TO_A CALL  FP_TO_A     ; routine FP-TO-A compresses last value into
; accumulator. e.g. PI would become 3.
; zero flag set if positive.

        JR    C,REPORT_Bz  ; forward, if >= 255, to REPORT-Bc
; 'Integer out of range'

        LD    C,$01        ; prepare a positive sign byte.
        RET    Z           ; return if FP-TO-BC indicated positive.

        LD    C,$FF        ; prepare negative sign byte and

        RET                    ; return.

; -----
; THE 'CIRCLE' COMMAND
; -----

```

```

; Syntax has been partly checked using the class for the DRAW command.

CIRCLE RST 18H ; GET-CHAR
CP $2C ; Is character the required comma ?
JP NZ,REPORT_C ; Jump, if not, to REPORT-C

;;; RST 20H ; NEXT-CHAR
;;; CALL EXPT_1NUM ; Routine EXPT-1NUM fetches the radius.
;;; CALL CHECK_END ; Routine CHECK-END will return here

CALL CHK_END_1 ; above 3 routines combined.

; Continue in runtime.

RST 28H ;; FP-CALC
DEFB $2A ;;abs ; make radius positive
DEFB $3D ;;re-stack ; in full floating point form
DEFB $38 ;;end-calc

LD A,(HL) ; Fetch first floating point exponent byte
CP $81 ; Compare to exponent for one
JR NC,C_R_GRE_1 ; Forward to C-R-GRE-1 if circle radius is
; greater than a half.

; If the diameter is no greater than one then delete the radius and plot
; the single point.

RST 28H ;; FP-CALC
DEFB $02 ;;delete ; delete the radius from stack.
DEFB $38 ;;end-calc

JR PLOT ; Back to PLOT to just plot x,y.

; ---

; Continue if the radius is greater than 1.

C_R_GRE_1 RST 28H ;; FP-CALC x, y, r
DEFB $A3 ;;stk-pi/2 x, y, r, pi/2.
DEFB $38 ;;end-calc x, y, r, pi/2.

; Cleverly multiply by four to form the circumference.

LD (HL),$83 ; bump exponent x, y, r, 2*PI

RST 28H ;; FP-CALC x, y, r, 2*PI
DEFB $C5 ;;st-mem-5 store 2*PI in mem-5
DEFB $02 ;;delete x, y, r.
DEFB $38 ;;end-calc x, y, r.

CALL CD_PRMS1 ; routine CD_PRMS1 forms circle parameters.

PUSH BC ;

RST 28H ;; FP-CALC
DEFB $31 ;;duplicate
DEFB $E1 ;;get-mem-1
DEFB $04 ;;multiply
DEFB $38 ;;end-calc

LD A,(HL) ;
CP $80 ;
JR NC,C_ARC_GE1 ; to C-ARC-GE1

```

```

RST 28H          ;; FP-CALC
DEFB $02        ;;delete
DEFB $02        ;;delete
DEFB $38        ;;end-calc

POP BC          ;
;;; JP PLOT      ; JUMP to PLOT
JR PLOT        ;+ use relative jump to PLOT

; ---

C_ARC_GE1 RST 28H          ;; FP-CALC
DEFB $C2        ;;st-mem-2
DEFB $01        ;;exchange
DEFB $C0        ;;st-mem-0
DEFB $02        ;;delete
DEFB $03        ;;subtract
DEFB $01        ;;exchange
DEFB $E0        ;;get-mem-0
DEFB $0F        ;;addition
DEFB $C0        ;;st-mem-0
DEFB $01        ;;exchange
DEFB $31        ;;duplicate
DEFB $E0        ;;get-mem-0
DEFB $01        ;;exchange
DEFB $31        ;;duplicate
DEFB $E0        ;;get-mem-0
DEFB $A0        ;;stk-zero
DEFB $C1        ;;st-mem-1
DEFB $02        ;;delete
DEFB $38        ;;end-calc

INC (IY+$62)    ; MEM-2-1st
CALL FIND_INT1  ; routine FIND-INT1
LD L,A          ;
PUSH HL         ;
CALL FIND_INT1  ; routine FIND-INT1
POP HL          ;
LD H,A          ;
LD ($5B7D),HL   ; COORDS
POP BC          ;
JP DRW_STEPS    ; to DRW-STEPS

; -----
; THE 'DRAW' COMMAND
; -----
; The DRAW command is rather more sophisticated than anything contemplated
; for the ZX80 and ZX81 and, with a third parameter, it can draw an arc.
; At this stage, syntax has been partly checked by the class routines and
; the 'x, y' parameters have been verified.

DRAW RST 18H          ; GET-CHAR
CP $2C           ; is character the optional ',' ?
JR Z,DR_3_PRMS   ; forward, if so, to DR_3_PRMS

CALL CHECK_END   ; routine CHECK-END checks that nothing follows.

JP LINE_DRAW     ; jump forward, in runtime, to LINE-DRAW

; ---

```

```

; The branch was here when a comma indicated a third parameter was expected.
DR_3_PRMS CALL  CHK_END_1          ; following three routines combined.

;;;      RST      20H              ; NEXT-CHAR advances.
;;;      CALL     EXPT_1NUM        ; routine EXPT-1NUM checks for numeric
;;;      CALL     CHECK_END        ; routine CHECK-END

      RST      28H              ;; FP-CALC      x, y, z.
      DEFB     $C5              ;;st-mem-5    x, y, z.
      DEFB     $A2              ;;stk-half   x, y, z, 1/2.
      DEFB     $04              ;;multiply  x, y, z/2.
      DEFB     $1F              ;;sin
      DEFB     $31              ;;duplicate
      DEFB     $30              ;;not
      DEFB     $30              ;;not
      DEFB     $00              ;;jump-true

      DEFB     DR_SIN_NZ - $     ;;to DR_SIN_NZ

      DEFB     $02              ;;delete
      DEFB     $38              ;;end-calc

      JP      LINE_DRAW        ; to LINE-DRAW

; ---

DR_SIN_NZ DEFB     $C0          ;;st-mem-0
          DEFB     $02          ;;delete
          DEFB     $C1          ;;st-mem-1
          DEFB     $02          ;;delete
          DEFB     $31          ;;duplicate
          DEFB     $2A          ;;abs
          DEFB     $E1          ;;get-mem-1
          DEFB     $01          ;;exchange
          DEFB     $E1          ;;get-mem-1
          DEFB     $2A          ;;abs
          DEFB     $0F          ;;addition
          DEFB     $E0          ;;get-mem-0
          DEFB     $05          ;;division
          DEFB     $2A          ;;abs
          DEFB     $E0          ;;get-mem-0
          DEFB     $01          ;;exchange
          DEFB     $3D          ;;re-stack
          DEFB     $38          ;;end-calc

          LD      A, (HL)       ;
          CP      $81          ;
          JR      NC, DR_PRMS   ; to DR-PRMS

          RST      28H          ;; FP-CALC
          DEFB     $02          ;;delete
          DEFB     $02          ;;delete
          DEFB     $38          ;;end-calc

          JP      LINE_DRAW    ; to LINE_DRAW

; ---

DR_PRMS  CALL     CD_PRMS1     ; routine CD_PRMS1 forms draw parameters.

          PUSH    BC           ;

```

```

RST    28H                ;; FP-CALC
DEFB   $02                ;;delete
DEFB   $E1                ;;get-mem-1
DEFB   $01                ;;exchange
DEFB   $05                ;;division
DEFB   $C1                ;;st-mem-1
DEFB   $02                ;;delete
DEFB   $01                ;;exchange
DEFB   $31                ;;duplicate
DEFB   $E1                ;;get-mem-1
DEFB   $04                ;;multiply
DEFB   $C2                ;;st-mem-2
DEFB   $02                ;;delete
DEFB   $01                ;;exchange
DEFB   $31                ;;duplicate
DEFB   $E1                ;;get-mem-1
DEFB   $04                ;;multiply
DEFB   $E2                ;;get-mem-2
DEFB   $E5                ;;get-mem-5
DEFB   $E0                ;;get-mem-0
DEFB   $03                ;;subtract
DEFB   $A2                ;;stk-half
DEFB   $04                ;;multiply
DEFB   $31                ;;duplicate
DEFB   $1F                ;;sin
DEFB   $C5                ;;st-mem-5
DEFB   $02                ;;delete
DEFB   $20                ;;cos
DEFB   $C0                ;;st-mem-0
DEFB   $02                ;;delete
DEFB   $C2                ;;st-mem-2
DEFB   $02                ;;delete
DEFB   $C1                ;;st-mem-1
DEFB   $E5                ;;get-mem-5
DEFB   $04                ;;multiply
DEFB   $E0                ;;get-mem-0
DEFB   $E2                ;;get-mem-2
DEFB   $04                ;;multiply
DEFB   $0F                ;;addition
DEFB   $E1                ;;get-mem-1
DEFB   $01                ;;exchange
DEFB   $C1                ;;st-mem-1
DEFB   $02                ;;delete
DEFB   $E0                ;;get-mem-0
DEFB   $04                ;;multiply
DEFB   $E2                ;;get-mem-2
DEFB   $E5                ;;get-mem-5
DEFB   $04                ;;multiply
DEFB   $03                ;;subtract
DEFB   $C2                ;;st-mem-2
DEFB   $2A                ;;abs
DEFB   $E1                ;;get-mem-1
DEFB   $2A                ;;abs
DEFB   $0F                ;;addition
DEFB   $02                ;;delete
DEFB   $38                ;;end-calc

LD     A, (DE)            ;
CP     $81                ;
POP    BC                 ;
JR     C,LINE_DRAW       ; JUMP to LINE-DRAW

PUSH   BC                 ;

```

```

RST 28H          ;; FP-CALC
DEFB $01        ;;exchange
DEFB $38        ;;end-calc

LD A, ($5B7D)   ; COORDS-x
CALL STACK_A    ; routine STACK-A

RST 28H          ;; FP-CALC
DEFB $C0        ;;st-mem-0
DEFB $0F        ;;addition
DEFB $01        ;;exchange
DEFB $38        ;;end-calc

LD A, ($5B7E)   ; COORDS-y
CALL STACK_A    ; routine STACK-A

RST 28H          ;; FP-CALC
DEFB $C5        ;;st-mem-5
DEFB $0F        ;;addition
DEFB $E0        ;;get-mem-0
DEFB $E5        ;;get-mem-5
DEFB $38        ;;end-calc

POP BC          ;

DRW_STEPS DEC B ;
JR Z,ARC_END    ; to ARC-END

JR ARC_START    ; to ARC-START

; ---

ARC_LOOP RST 28H          ;; FP-CALC
DEFB $E1        ;;get-mem-1
DEFB $31        ;;duplicate
DEFB $E3        ;;get-mem-3
DEFB $04        ;;multiply
DEFB $E2        ;;get-mem-2
DEFB $E4        ;;get-mem-4
DEFB $04        ;;multiply
DEFB $03        ;;subtract
DEFB $C1        ;;st-mem-1
DEFB $02        ;;delete
DEFB $E4        ;;get-mem-4
DEFB $04        ;;multiply
DEFB $E2        ;;get-mem-2
DEFB $E3        ;;get-mem-3
DEFB $04        ;;multiply
DEFB $0F        ;;addition
DEFB $C2        ;;st-mem-2
DEFB $02        ;;delete
DEFB $38        ;;end-calc

ARC_START PUSH BC ;

RST 28H          ;; FP-CALC
DEFB $C0        ;;st-mem-0
DEFB $02        ;;delete
DEFB $E1        ;;get-mem-1
DEFB $0F        ;;addition
DEFB $31        ;;duplicate
DEFB $38        ;;end-calc

```



```

LD      A, ($5B7D)      ; COORDS-x
CALL   STACK_A         ; routine STACK-A

RST    28H              ;; FP-CALC
DEFB   $03              ;;subtract
DEFB   $E0              ;;get-mem-0
DEFB   $E2              ;;get-mem-2
DEFB   $0F              ;;addition
DEFB   $C0              ;;st-mem-0
DEFB   $01              ;;exchange
DEFB   $E0              ;;get-mem-0
DEFB   $38              ;;end-calc

LD      A, ($5B7E)      ; COORDS-y
CALL   STACK_A         ; routine STACK-A

RST    28H              ;; FP-CALC
DEFB   $03              ;;subtract
DEFB   $38              ;;end-calc

CALL   DRAW_LINE       ; routine DRAW-LINE

POP    BC               ;
DJNZ   ARC_LOOP        ; to ARC-LOOP

ARC_END RST    28H              ;; FP-CALC
DEFB   $02              ;;delete
DEFB   $02              ;;delete
DEFB   $01              ;;exchange
DEFB   $38              ;;end-calc

LD      A, ($5B7D)      ; COORDS-x
CALL   STACK_A         ; routine STACK-A

RST    28H              ;; FP-CALC
DEFB   $03              ;;subtract
DEFB   $01              ;;exchange
DEFB   $38              ;;end-calc

LD      A, ($5B7E)      ; COORDS-y
CALL   STACK_A         ; routine STACK-A

RST    28H              ;; FP-CALC
DEFB   $03              ;;subtract
DEFB   $38              ;;end-calc

LINE_DRAW JR    DRAW_LINE       ; routine DRAW-LINE

;;;      CALL   DRAW_LINE       ; routine DRAW_LINE
;;;      JP     TEMPs           ;?to TEMPs

; -----
; THE 'CIRCLE AND DRAW INITIAL PARAMETERS' SUBROUTINE
; -----
;
;
CD_PRMS1 RST    28H              ;; FP-CALC
DEFB   $31              ;;duplicate
DEFB   $28              ;;sqr

```

```

DEFB $34          ;;stk-data
DEFB $32          ;;Exponent: $82, Bytes: 1
DEFB $00          ;;(+00,+00,+00)
DEFB $01          ;;exchange
DEFB $05          ;;division
DEFB $E5          ;;get-mem-5
DEFB $01          ;;exchange
DEFB $05          ;;division
DEFB $2A          ;;abs
DEFB $38          ;;end-calc

CALL FP_TO_A      ; routine FP-TO-A
JR C,USE_252      ; to USE-252

AND $FC          ;
ADD A,$04        ;
JR NC,DRAW_SAVE  ; to DRAW-SAVE

USE_252 LD A,$FC  ;

DRAW_SAVE PUSH AF ;

CALL STACK_A     ; routine STACK-A

RST 28H          ;; FP-CALC
DEFB $E5          ;;get-mem-5
DEFB $01          ;;exchange
DEFB $05          ;;division
DEFB $31          ;;duplicate
DEFB $1F          ;;sin
DEFB $C4          ;;st-mem-4
DEFB $02          ;;delete
DEFB $31          ;;duplicate
DEFB $A2          ;;stk-half
DEFB $04          ;;multiply
DEFB $1F          ;;sin
DEFB $C1          ;;st-mem-1
DEFB $01          ;;exchange
DEFB $C0          ;;st-mem-0
DEFB $02          ;;delete
DEFB $31          ;;duplicate
DEFB $04          ;;multiply
DEFB $31          ;;duplicate
DEFB $0F          ;;addition
DEFB $A1          ;;stk-one
DEFB $03          ;;subtract
DEFB $1B          ;;negate
DEFB $C3          ;;st-mem-3
DEFB $02          ;;delete
DEFB $38          ;;end-calc

POP BC          ;

RET             ;

; -----
; THE 'DRAW LINE' SUBROUTINE
; -----
; B=Y C=X D=signY E=signX
;

DRAW_LINE CALL STK_TO_BC ; routine STK-TO-BC

LD A,C          ; load X to accumulator.

```



```

        DJNZ  D_L_LOOP          ; to D-L-LOOP

        POP   DE                ;
        RET                               ;

; ---

D_L_RANGE JR    Z,D_L_PLOT      ; to D-L-PLOT

REPORT_Bc RST   30H            ; ERROR-1
          DEFB  $0A            ; Error Report: Integer out of range

;*****
;** Part 8. EXPRESSION EVALUATION **
;*****
;
; It is at this stage of the ROM that the Spectrum ceases altogether to be
; just a colourful novelty. One remarkable feature is that in all previous
; commands when the Spectrum is expecting a number or a string then an
; expression of the same type can be substituted ad infinitum.
; This is the routine that evaluates that expression.
; This is what causes 2 + 2 to give the answer 4.
; That is quite easy to understand. However you don't have to make it much
; more complex to start a remarkable juggling act.
; e.g. PRINT 2 * (VAL "2+2" + TAN 3)
; In fact, provided there is enough free RAM, the Spectrum can evaluate
; an expression of unlimited complexity.
; Apart from a couple of minor glitches, which you can now correct, the
; system is remarkably robust.

; -----
; THE 'SCANNING' SUBROUTINE
; -----
; Scan expression or sub-expression
; The routine begins and ends with a RST 18H instruction.

SCANNING RST   18H            ; GET-CHAR
          LD    B,$00          ; Priority marker zero is pushed on stack to
                               ; signify the end of expression when it is
                               ; popped off again.

          PUSH  BC            ; Stack the marker byte and proceed to consider
                               ; the first character of the expression.

S_LOOP_1
;;;      LD    C,A            ; place the search character in C.
          LD    HL,SCAN_FUNC-1 ; Address: scan-func
          CALL  INDEXER_0      ; routine INDEXER is called to see if it is
                               ; part of a limited range '+', '(', 'ATTR' etc.

;;;      LD    A,C            ; fetch the character back
          JP    NC,S_ALPHNUM   ; jump forward to S-ALPHNUM if not in complex
                               ; operators and functions to consider in the
                               ; first instance a digit or a variable and
                               ; then anything else. >>>

;;;      LD    B,$00          ; but here if it was found in table so
;;;      LD    C,(HL)         ; fetch offset from table and make B zero.
;;;      ADD   HL,BC          ; add the offset to position found

          JP    (HL)          ; jump to the routine e.g. S-BIN

```

```

; making an indirect exit from there.

; -----
; The four service subroutines for routines in the scanning function table
; -----

; PRINT ""Hooray!"" he cried."

S_QUOTE_S CALL CH_ADD__1 ; routine CH-ADD+1 points to next character
; and fetches that character.
INC BC ; increase length counter.
CP $0D ; is it carriage return ?
; inside a quote.
JR Z,REPORT-Cs ; jump forward, if so, to REPORT-C
; 'Nonsense in BASIC'.

CP $22 ; is it a quote '"' ?
JR NZ,S_QUOTE_S ; back, if not, to S-QUOTE-S

CALL CH_ADD__1 ; routine CH-ADD+1
CP $22 ; compare with possible adjacent quote
RET ; return. with zero set if two together.

; ---

; This subroutine is used to get two coordinate expressions for the three
; functions SCREEN$, ATTR and POINT that have two fixed parameters and
; therefore require surrounding braces.

S_2_COORD RST 20H ; NEXT-CHAR

CP $28 ; is character the opening '(' ?
JR NZ,REPORT-Cs ; forward, if not, to S-RPORT-C
; 'Nonsense in BASIC'.

CALL NEXT_2NUM ; routine NEXT-2NUM gets two comma-separated
; numeric expressions. Note. this could cause
; many more recursive calls to SCANNING but
; the parent function will be evaluated fully
; before rejoining the main juggling act.

;;; RST 18H ; GET-CHAR was exit route for SCANNING

TST_RBRKT CP $29 ; is it the closing ')' ?

S_RPORT_C JR NZ,REPORT-Cs ; jump forward, if not, to REPORT-Cs

; -----
; THE 'SYNTAX_Z' SUBROUTINE
; -----
; This routine is called on a number of occasions to check if syntax is being
; checked or if the program is being run. To test the flag inline would use
; four bytes of code, but a call instruction only uses 3 bytes of code.

SYNTAX_Z BIT 7,(IY+$01) ; test FLAGS - checking syntax only ?
RET ; return.

; -----
; Scanning SCREEN$
; -----

```

```

; This function returns the code of a bit-mapped character at screen
; position at line C, column B. It is unable to detect the mosaic characters
; which are not bit-mapped but detects the ASCII 32 - 127 range.
; The bit-mapped UDGs are ignored which is curious as it requires only a
; few extra bytes of code. As usual, anything to do with CHARS is weird.
; If no match is found a null string is returned.
; No actual check on ranges is performed - that's up to the BASIC programmer.
; No real harm can come from SCREEN$(255,255) although the BASIC manual
; says that invalid values will be trapped.
; Interestingly, in the Pitman pocket guide, 1984, Vickers says that the
; range checking will be performed.

```

```

S_SCRNs_S CALL STK_TO_LC ; NEW routine STK-TO-LC.

        LD HL,($5B36) ; fetch address of CHARS.

;;; LD DE,$0100 ; fetch offset to chr$ 32
;;; ADD HL,DE ; and find start of bitmaps.
;;; ; Note. not inc h. ??

        INC H ;+ increment high byte to address bitmaps.

        LD A,C ; transfer line to A.
        RRCA ; multiply
        RRCA ; by
        RRCA ; thirty-two.
        AND $E0 ; AND with 11100000
        XOR B ; combine with column $00 - $1F
        LD E,A ; to give the low byte of top line
        LD A,C ; column to A range 00000000 to 00011111
        AND $18 ; AND with 00011000
        XOR $40 ; XOR with 01000000 (high byte screen start)
        LD D,A ; register DE now holds start address of cell.
        LD B,$60 ; there are 96 characters in ASCII set.

S_SCRN_LP PUSH BC ; save count
        PUSH DE ; save screen start address
        PUSH HL ; save bitmap start
        LD A,(DE) ; first byte of screen to A
        XOR (HL) ; XOR with corresponding character byte
        JR Z,S_SC_MTCH ; forward to S-SC-MTCH if they match
        ; if inverse result would be $FF
        ; if any other then mismatch

        INC A ; set to $00 if inverse
        JR NZ,S_SCR_NXT ; forward to S-SCR-NXT if a mismatch

        DEC A ; restore $FF

; a match has been found so seven more to test.

S_SC_MTCH LD C,A ; load C with inverse mask $00 or $FF
        LD B,$07 ; count seven more bytes

S_SC_ROWS INC D ; increment screen address.
        INC HL ; increment bitmap address.
        LD A,(DE) ; byte to A
        XOR (HL) ; will give $00 or $FF (inverse)
        XOR C ; XOR with inverse mask
        JR NZ,S_SCR_NXT ; forward to S-SCR-NXT if no match.

        DJNZ S_SC_ROWS ; back to S-SC-ROWS until all eight matched.

; continue if a match of all eight bytes was found

```

```

        POP    BC            ; discard the
        POP    BC            ; saved
        POP    BC            ; pointers
        LD     A,$80         ; the endpoint of character set
        SUB    B             ; subtract the counter
                               ; to give the code 32-127
;;;      LD     BC,$0001     ; make one space in workspace.

        CALL   BC_SPACE1    ; BC_SPACES creates the 1 space sliding
                               ; the calculator stack upwards.
        LD     (DE),A        ; start is addressed by DE, so insert code
        JR     S_SCR_STO    ; forward to S-SCR-STO

; ----

;   the jump was here if no match and more bitmaps to test.

S_SCR_NXT POP    HL            ; restore the last bitmap start
        LD     DE,$0008      ; and prepare to add 8.
        ADD   HL,DE         ; now addresses next character bitmap.
        POP   DE            ; restore screen address
        POP   BC            ; and character counter in B
        DJNZ  S_SCRN_LP     ; back to S-SCRN-LP if more characters.

        LD     C,B          ; B is now zero, so BC now zero.

S_SCR_STO RET                ; (WAS to STK-STO-$) to store the string in
                               ; workspace or a string with zero length.
                               ; (value of DE doesn't matter in last case)

;   Note. this exit seems correct but the general-purpose routine S-STRING
;   that calls this one will also stack any of its string results so this
;   leads to a double storing of the result in this case.
;   The instruction at S_SCR_STO should just be a RET. (Done! SEP-2002)
;   credit: Stephen Kelly and others, 1982.

; -----
; Scanning ATTR
; -----
;   This function subroutine returns the attributes of a screen location -
;   a numeric result.
;   Again it's up to the BASIC programmer to supply valid values of line/column.

S_ATTR_S  CALL   STK_TO_LC    ; NEW routine STK-TO-BC fetches line to C,
                               ; and column to B.
        LD     A,C          ; line to A $00 - $17 (max 00010111)
        RRCA                ; rotate
        RRCA                ; bits
        RRCA                ; right.
        LD     C,A          ; store in C as an intermediate value.

        AND   $E0           ; pick up bits 11100000 ( was 00011100 )
        XOR   B             ; combine with column $00 - $1F
        LD     L,A          ; low byte is now correct.

        LD     A,C          ; bring back intermediate result from C
        AND   $03           ; mask to give correct third of
                               ; screen $00 - $02
        XOR   $58           ; combine with base address.
        LD     H,A          ; high byte correct.
        LD     A,(HL)       ; pick up the colour attribute.

        JP    STACK_A      ; jump forward to STACK-A to store result

```

```

; and make an indirect exit.

; ---
REPORT_Cs RST    30H          ; ERROR_1
          DEFB   $0B          ; Error Report: Nonsense in BASIC

; -----
; THE 'SCANNING FUNCTION' TABLE
; -----
; This table is used by INDEXER routine to find the offsets to
; four operators and eight functions. e.g. $A8 is the token 'FN'.
; This table is used in the first instance for the first character of an
; expression or by a recursive call to SCANNING for the first character of
; any sub-expression. It eliminates functions that have no argument or
; functions that can have more than one argument and therefore require
; braces. By eliminating and dealing with these now it can later take a
; simplistic approach to all other functions and assume that they have
; one argument.
; Similarly by eliminating BIN and '.' now it is later able to assume that
; all numbers begin with a digit and that the presence of a number or
; variable can be detected by a call to ALPHANUM.
; By default all expressions are positive and the spurious '+' is eliminated
; now as in print +2. This should not be confused with the operator '+'.
; Note. this does allow a degree of nonsense to be accepted as in
; PRINT +"3 is the greatest.".
; An acquired programming skill is the ability to include brackets where
; they are not necessary.
; A bracket at the start of a sub-expression may be spurious or necessary
; to denote that the contained expression is to be evaluated as an entity.
; In either case this is dealt with by recursive calls to SCANNING.
; An expression that begins with a quote requires special treatment.

SCAN_FUNC DEFB   $22, S_QUOTE  -$-1 ; $1C offset to S-QUOTE
          DEFB   '(', S_BRACKET -$-1 ; $4F offset to S-BRACKET
          DEFB   '.', S_DECIMAL -$-1 ; $F2 offset to S-DECIMAL
          DEFB   '+', S_U_PLUS  -$-1 ; $12 offset to S-U-PLUS

          DEFB   $A8, S_FN      -$-1 ; $56 offset to S-FN
          DEFB   $A5, S_RND     -$-1 ; $57 offset to S-RND
          DEFB   $A7, S_PI      -$-1 ; $84 offset to S-PI
          DEFB   $A6, S_INKEYS  -$-1 ; $8F offset to S-INKEY$
          DEFB   $C4, S_DECIMAL -$-1 ; $E6 offset to S-BIN
          DEFB   $AA, S_SCREENs -$-1 ; $BF offset to S-SCREEN$
          DEFB   $AB, S_ATTR    -$-1 ; $C7 offset to S-ATTR
          DEFB   $A9, S_POINT   -$-1 ; $CE offset to S-POINT

          DEFB   $00           ; zero end marker

; -----
; THE 'SCANNING FUNCTION' ROUTINES
; -----
; These are the 11 subroutines accessed by the above table.
; Addresses S-BIN and S-DECIMAL are the same
; The 1-byte offset limits their location to within 255 bytes of their
; entry in the above table.

; ->
S_U_PLUS

          JP     S_NEXT_1      ;+ forward to similar code.

;;;      RST    20H          ; NEXT-CHAR just ignore
;;;      JP     S_LOOP_1     ; back to S-LOOP-1

```



```

; ---

; ->
S_QUOTE  RST    18H          ; GET-CHAR
         INC    HL          ; address next character (first in quotes)
         PUSH   HL          ; save start of quoted text.
         LD     BC,$0000    ; initialize length of string to zero.

         CALL   S_QUOTE_S   ; routine S-QUOTE-S

         JR     NZ,S_Q_PRMS ; forward to S-Q-PRMS if

S_Q_AGAIN CALL  S_QUOTE_S   ; routine S-QUOTE-S copies string until a
         ; quote is encountered

         JR     Z,S_Q_AGAIN ; back to S-Q-AGAIN if two quotes WERE
         ; together.

; but if just an isolated quote then that terminates the string.

         CALL   SYNTAX_Z    ; routine SYNTAX-Z

         JR     Z,S_Q_PRMS  ; forward, if checking syntax, to S-Q-PRMS

; In runtime, build the string expression result.

         CALL   BC_SPACES   ; routine BC_SPACES creates the space for true
         ; copy of string in workspace.

         POP    HL          ; re-fetch start of quoted text.
         PUSH   DE          ; stack DE the start of string in workspace.

S_Q_COPY LD     A,(HL)      ; fetch a character from source.
         INC    HL          ; advance the source address.
         LD     (DE),A      ; place in destination.
         INC    DE          ; advance the destination address.

         CP     $22         ; was it a '"' just copied ?
         JR     NZ,S_Q_COPY ; back, if not, to S-Q-COPY

         LD     A,(HL)      ; fetch adjacent character from source.
         INC    HL          ; advance the source address.

         CP     $22         ; is this '"' ? - i.e. two quotes together ?
         JR     Z,S_Q_COPY  ; to S-Q-COPY if so including just one of the
         ; pair of quotes.

; If not two adjacent quotes then the terminating quote has just been copied.

S_Q_PRMS DEC    BC          ; decrease the count by 1.
         POP    DE          ; restore start of string in workspace.

S_STRING LD     HL,$5B3B    ; Address the FLAGS system variable.
         RES    6,(HL)      ; signal a string result.
         BIT    7,(HL)      ; is syntax being checked ?

         CALL   NZ,STK_STO_s ; routine STK-STO-$ is called in runtime.

         JR     S_INKs_EN   ; jump forward to S-CONT-2          ==>

; ---

```

```

; ->
S_BRACKET RST 20H ; NEXT-CHAR

CALL SCANNING ; routine SCANNING is called recursively.

;;; CP $29 ; is it the closing ')' ?
;;; JR NZ,REPORT-Cs ;.jump back, if not, to REPORT-C

CALL TST_RBRKT ; test for a right bracket ')'

RST 20H ; NEXT-CHAR
JR S_INKs_EN ; jump forward to S-CONT-2 ===>

; ---

; ->
S_FN JP S_FN_SBRN ; jump forward to S-FN-SBRN.

; ---

; ->
S_RND CALL SYNTAX_Z ; routine SYNTAX-Z

JR Z,S_RND_END ; forward to S-RND-END if checking syntax.

LD BC,($5B76) ; fetch system variable SEED

CALL STACK_BC ; routine STACK-BC places on calculator stack

RST 28H ;; FP-CALC ;s.
DEFB $A1 ;;stk-one ;s,1.
DEFB $0F ;;addition ;s+1.
DEFB $34 ;;stk-data ;
DEFB $37 ;;Exponent: $87,
; ;Bytes: 1
DEFB $16 ;;(+00,+00,+00) ;s+1,75.
DEFB $04 ;;multiply ;(s+1)*75 = v
DEFB $34 ;;stk-data ;v.
DEFB $80 ;;Bytes: 3
DEFB $41 ;;Exponent $91
DEFB $00,$00,$80 ;;(+00) ;v,65537.
DEFB $32 ;;n-mod-m ;remainder, result.
DEFB $02 ;;delete ;remainder.
DEFB $A1 ;;stk-one ;remainder, 1.
DEFB $03 ;;subtract ;remainder - 1. = rnd
DEFB $31 ;;duplicate ;rnd,rnd.
DEFB $38 ;;end-calc

CALL FP_TO_BC ; routine FP-TO-BC

LD ($5B76),BC ; store in SEED for next starting point.

LD A,(HL) ; fetch exponent
AND A ; is it zero ?
JR Z,S_RND_END ; forward if so to S-RND-END

SUB $10 ; reduce exponent by 2^16
LD (HL),A ; place back

S_RND_END JR S_PI_END ; forward to S-PI-END

; ---

; the number PI 3.14159...

```

```

; ->
S_PI      CALL  SYNTAX_Z      ; routine SYNTAX-Z
          JR    Z,S_PI_END    ; to S-PI-END if checking syntax.

          RST   28H           ;; FP-CALC
          DEFB  $A3           ;;stk-pi/2                      pi/2.
          DEFB  $38           ;;end-calc

          INC   (HL)          ; increment the exponent leaving PI
                               ; on the calculator stack.

S_PI_END  JR    S_AT_NUM      ;+ forward to similar code ending at S_NUMERIC

;;;      RST   20H           ; NEXT-CHAR
;;;      JP    S_NUMERIC      ; jump forward to S-NUMERIC

; ---

; ->
S_INKEYs  LD    BC,$105A      ; Priority $10, operation code $1A ('read-in')
                               ; +$40 for string result, numeric operand.
                               ; Set this up now in case we need to use the
                               ; calculator.
          RST   20H           ; NEXT-CHAR
          CP    $23           ; '#' ?
          JP    Z,S_PUSH_PO   ; To S-PUSH-PO if so to use the calculator
                               ; single operation to read from network/RS232.

;   else read a key from the keyboard.

          LD    HL,$5B3B      ; fetch FLAGS
          RES   6,(HL)        ; signal string result.
          BIT   7,(HL)        ; checking syntax ?
          JR    Z,S_INKs_EN   ; forward, if so, to S-INK$-EN

          CALL  KEY_SCAN      ; routine KEY-SCAN key in E, shift in D.

          LD    C,$00         ; prepare the length of an empty string
          JR    NZ,S_IKs_STK  ; forward, if no key returned, to S-IK$-STK
                               ; to store empty string.

          CALL  K_TEST        ; routine K-TEST get main code in A

          JR    NC,S_IKs_STK  ; forward, if invalid, to S-IK$-STK
                               ; to stack null string.

          DEC   D             ; D is expected to be FLAGS so set bit 3 $FF
                               ; 'L' Mode so no keywords.

;;;      LD    E,A           ; main key to E
                               ; C is MODE 0 'KLC' from above still.

          CALL  K_DECODE2     ; routine K_DECODE but skip first.

;;;      PUSH  AF           ; save the code

;;;      LD    BC,$0001      ; make room for one character

          CALL  BC_SPACE1     ; routine BC_SPACE1 creates a single space.

;;;      POP   AF           ; bring the code back

```

```

        LD      (DE),A          ; put the key in workspace
;;;     LD      C,$01          ; set C length to one          (BC=1)

S_IKs_STK LD      B,$00        ; set high byte of length to zero
        CALL   STK_STO_s      ; routine STK-STO-$

S_INKs_EN JP      S_CONT_2    ; to S-CONT-2          ==>

; ---

; ->
S_SCREENs CALL   S_2_COORD    ; routine S-2-COORD

        CALL   NZ,S_SCRNs_S  ; routine S-SCRN$-S in runtime.

        RST    20H           ; NEXT-CHAR
        JP     S_STRING      ; Back to S-STRING to stack runtime result

; ---

; ->
S_ATTR    CALL   S_2_COORD    ; routine S-2-COORD

        CALL   NZ,S_ATTR_S   ; routine S-ATTR-S in runtime.

S_AT_NUM  RST    20H         ; NEXT-CHAR
        JR     S_NUMERIC     ; forward to S-NUMERIC

; ---

; ->
S_POINT   CALL   S_2_COORD    ; routine S-2-COORD

        CALL   NZ,POINT_SUB  ; routine POINT-SUB in runtime.

        JR     S_AT_NUM      ;+ back to similar sequence ending at S_NUMERIC

;;;     RST    20H           ; NEXT-CHAR
;;;     JR     S_NUMERIC     ; forward to S-NUMERIC

; -----

; ==> The branch was here if not in table of exceptions.

S_ALPHNUM CALL   ALPHANUM     ; routine ALPHANUM checks if a variable or
                                ; a digit follows.

        JR     NC,S_NEGATE   ; forward, if not, to S-NEGATE
                                ; to consider a '-' character then functions.

        CP     $41          ; compare with 'A'
        JR     NC,S_LETTER   ; forward, if alpha, to S-LETTER      ->

;     else must have been numeric so continue into that routine.

;     This important routine is called during runtime and from LINE-SCAN
;     when a BASIC line is checked for syntax. It is this routine that
;     inserts, during syntax checking, the invisible floating point numbers
;     after the numeric expression. During runtime it just picks these
;     numbers up. It also handles BIN format numbers.

;     ->
S_DECIMAL CALL   SYNTAX_Z     ; routine SYNTAX-Z
        JR     NZ,S_STK_DEC   ; to S-STK-DEC in runtime

```

```

; this route is taken when checking syntax.

        CALL  DEC_TO_FP          ; routine DEC-TO-FP to evaluate number

        RST   18H                ; GET-CHAR to fetch HL

        LD    BC,$0006           ; six locations are required
        CALL  MAKE_ROOM          ; routine MAKE-ROOM
;;;
        INC   HL                  ;
        LD    (HL),$0E           ; insert number marker at first location.
        INC   HL                  ; address next location to receive the 5 bytes.

        EX    DE,HL              ; make DE destination.

        CALL  GET_5              ;+ NEW subroutine below embodies following

;;;
        LD    HL,($5B65)         ; STKEND points to end of stack.
;;;
        LD    C,$05              ; result is five locations lower
;;;
        AND   A                  ; prepare for true subtraction
;;;
        SBC   HL,BC              ; point to start of value.
;;;
        LD    ($5B65),HL         ; update STKEND as we are taking number.
;;;
        LDIR  ;                  ; Copy five bytes to program location
;;;
        EX    DE,HL              ; transfer pointer to HL
;;;
        DEC   HL                  ; adjust

        CALL  TEMP_PTR1          ; routine TEMP-PTR1 sets CH-ADD.

        JR    S_NUMERIC          ; to S-NUMERIC to record nature of result

; ---

GET_5    LD    HL,($5B65)         ;+ STKEND points to end of stack.
        LD    BC,$0005           ;+ There are five bytes to copy.
        AND   A                  ;+ Clear carry flag.
        SBC   HL,BC              ;+ Reduce HL by five.
        LD    ($5B65),HL         ;+ update STKEND as we are taking number.
        LDIR  ;                  ;+ Copy five bytes to location
        EX    DE,HL              ;+ transfer pointer to HL
        DEC   HL                  ;+ adjust
        RET   ;                  ;+ Return

; ---

; S_DECIMAL branches here in runtime to pick up prepared number.

S_STK_DEC RST   18H                ; GET-CHAR positions HL at digit.

S_SD_SKIP INC   HL                  ; advance pointer
        LD    A,(HL)              ; until we find
        CP    $0E                 ; chr 14d - the number indicator
        JR    NZ,S_SD_SKIP        ; loop back, until match found, to S-SD-SKIP
        ; it has to be here.

        INC   HL                  ; point to first byte of number

        CALL  STACK_NUM           ; routine STACK-NUM stacks it.

        LD    ($5B5D),HL         ; update system variable CH_ADD

S_NUMERIC SET   6,(IY+$01)         ; update FLAGS - Signal numeric result
;;;
        JR    S_CONT_1           ; forward to S-CONT-1 ==>
        JR    S_CONT_2           ;+ forward now directly to S-CONT-2

; end of functions accessed from scanning functions table.

```

```

; -----
; Scanning variable routines
; -----
;
;
S_LETTER CALL LOOK_VARS ; routine LOOK-VARS

        JP C,REPORT_2 ; jump back to REPORT-2 if not found
        ; 'Variable not found'
        ; but a variable is always 'found' if syntax
        ; is being checked.

        CALL Z,STK_VAR ; routine STK-VAR considers a subscript/slice
        LD A,($5B3B) ; fetch FLAGS value
        CP $C0 ; compare 11000000
;;; JR C,S_CONT_1 ; step forward to S-CONT-1 if string ===>
    JR C,S_CONT_2 ;+ step forward to S-CONT-2 if string ===>

; The variable is a simple numeric variable.

        INC HL ; advance pointer past last letter.

        CALL STACK_NUM ; routine STACK-NUM

S_CONT_1 JR S_CONT_2 ; forward to S-CONT-2 ===>

; -----
; -> the scanning branch was here if not alphanumeric.
; All the remaining functions will be evaluated by a single call to the
; calculator. The correct priority for the operation has to be placed in
; the B register and the operation code, calculator literal in the C register.
; the operation code has bit 7 set if result is numeric and bit 6 is
; set if operand is numeric. so
; $C0 = numeric result, numeric operand. e.g. 'sin'
; $80 = numeric result, string operand. e.g. 'code'
; $40 = string result, numeric operand. e.g. 'str$'
; $00 = string result, string operand. e.g. 'val$'

S_NEGATE LD BC,$09DB ; prepare priority 09, operation code $C0 +
        ; 'negate' ($1B) - bits 6 and 7 set for numeric
        ; result and numeric operand.

        CP $2D ; is the character '-' ?
        JR Z,S_PUSH_PO ; forward, if so, to S-PUSH-PO

        LD BC,$1018 ; prepare priority $10, operation code 'val$' -
        ; bits 6 and 7 reset for string result and
        ; string operand.

        CP $AE ; is it 'VAL$' ?
        JR Z,S_PUSH_PO ; forward, if so, to S-PUSH-PO

        SUB $AF ; subtract token 'CODE' value to reduce
        ; functions 'CODE' to 'NOT' although the
        ; upper range is, as yet, unchecked.
        ; valid range would be $00 - $14.

        JR C,REPORT_Cw ; forward, with anything else, to REPORT-C
        ; 'Nonsense in BASIC'

        LD BC,$04F0 ; prepare priority $04, operation $C0 +
        ; 'not' ($30)

```

```

CP    $14                ; is it 'NOT'
JR    Z,S_PUSH_PO       ; forward, if so, to S-PUSH-PO

JR    NC,REPORT_Cw      ; forward, if higher, to REPORT-C
                        ; 'Nonsense in BASIC'

LD    B,$10             ; priority $10 for all the rest
ADD   A,$DC             ; make range $DC - $EF
                        ; $C0 + 'code' ($1C) through 'chr$' ($2F)

LD    C,A               ; transfer 'function' to C
CP    $DF               ; compare to 'sin' ?
JR    NC,S_NO_TO_s      ; forward to S-NO-TO-$ with 'sin' through
                        ; 'chr$' as operand is numeric.

; all the rest 'cos' through 'chr$' give a numeric result except 'str$'
; and 'chr$'.

RES   6,C               ; signal string operand for 'code', 'val' and
                        ; 'len'.

S_NO_TO_s CP    $EE      ; compare 'str$'
JR    C,S_PUSH_PO       ; forward to S-PUSH-PO if lower as result
                        ; is numeric.

RES   7,C               ; reset bit 7 of op code for 'str$', 'chr$'
                        ; as result is string.

; >> This is where they were all headed for.
; Push the Priority and Operand.

S_PUSH_PO PUSH  BC      ; push the priority and calculator operation
                        ; code.

JR    S_NEXT_1          ;+ forward to similar looping code.

;;; RST  20H            ; NEXT-CHAR
;;; JP   S_LOOP_1       ; jump back to S-LOOP-1 to go round the loop

; -----

; ==> there were many branches forward to here

S_CONT_2 RST  18H        ; GET-CHAR

S_CONT_3 CP    $28        ; is it '(' ?
JR    NZ,S_OPERTR       ; forward, if not, to S-OPERTR    >

BIT   6,(IY+$01)        ; test FLAGS - numeric or string result ?
JR    NZ,S_LOOP         ; forward to S-LOOP if numeric to evaluate >

; if a string preceded '(' then slice it.

CALL  SLICING           ; routine SLICING

S_CONT_4 RST  20H        ; NEXT-CHAR
JR    S_CONT_3          ; back to S-CONT-3

; -----

; the branch was here when possibility of an operator '(' has been excluded.

```

```

S_OPERTR
;;; LD B,$00 ; prepare to index.
;;; LD C,A ; possible operator to C
LD HL,tbl_ofops-1 ; Address: tbl-of-ops

CALL INDEXER_0 ; routine INDEXER does look up sets B to zero.

JR NC,S_LOOP ; forward to S-LOOP if not in table

; but if found in table the priority has to be looked up.

;;; LD C,(HL) ; operation code to C ( B is still zero )

LD HL,TBL_PRI- $\$C3$  ; address theoretical base of table.

ADD HL,BC ; index into table.
LD B,(HL) ; priority to B.

; -----
; Scanning Operation loop
; -----
; The juggling act.

S_LOOP POP DE ; fetch last priority and operation code.
LD A,D ; priority to A
CP B ; compare with this one
JR C,S_TIGHTER ; forward, with carry, to S-TIGHTER
; to execute the operation before this one as
; it has a higher priority.

; The last priority was greater or equal this one.

AND A ; if it is zero then so is this

JP Z,GET_CHAR ; jump, if zero, to exit via GET-CHAR
; pointing CH_ADD at next character.
; This may be the character after the
; expression or, if exiting a recursive call,
; the next part of the expression to be
; evaluated.

PUSH BC ; save the current priority/operation as it
; must have lower precedence than the one
; now in DE.

; The 'USR' function is special in that it is 'overloaded' to give two types
; of result.

LD HL,$5B3B ; Address the FLAGS system variable.
LD A,E ; new operation to A register
CP  $\$ED$  ; is it  $\$C0$  + 'usr-no' ( $\$2D$ ) ?
JR NZ,S_STK_LST ; forward, if not, to S-STK-LST

BIT 6,(HL) ; is a string result expected ?
; (from the lower priority operand we've
; just pushed on stack )
JR NZ,S_STK_LST ; forward, if numeric, to S-STK-LST
; as the operand bits match.

LD E, $\$99$  ; reset bit 6 and substitute  $\$19$  'usr- $\$$ '
; for a string operand.

S_STK_LST PUSH DE ; now stack this priority/operation code.

```



```

CALL SYNTAX_Z          ; routine SYNTAX-Z

JR    Z,S_SYNTEST     ; forward, if checking syntax, to S-SYNTEST

LD    A,E             ; fetch the operation code.
AND   $3F             ; mask off the result/operand bits to leave
                        ; a calculator literal.
LD    B,A             ; transfer naked 'literal' to B register

; Now use the calculator to perform the single operation - the operand is on
; the calculator stack.
; Note. although the calculator is performing a single operation most
; functions e.g. TAN are written using other functions and literals and
; these in turn are written using further strings of calculator literals so
; another level of magical recursion joins the juggling act for a while as
; the calculator, too, is calling itself.

RST   28H              ;; FP-CALC                operand.
DEFB  $3B              ;;fp-calc-2
DEFB  $38              ;;end-calc                result.

JR    S_RUNTEST      ; forward to S-RUNTEST

; ---

; The branch was here if checking syntax only.
S_SYNTEST LD    A,E          ; fetch the operation code to the accumulator.
          XOR   (IY+$01)     ; XOR with the FLAGS system variable.
          AND   $40          ; bit 6 will be zero now if operand
                        ; matched expected result.

          JR    Z,S_RUNTEST  ; skip forward, if results match.

REPORT_Cw RST   30H         ; ERROR-1
          DEFB  $0B         ; Error Report: Nonsense in BASIC

;;; S_RPRT_C2 JP    NZ,REPORT_C    ; to REPORT-C if mismatch

; else continue to set flags for next operation.
; The branch is to here in runtime after a successful operation.

S_RUNTEST POP    DE          ; fetch the last operation from stack
          LD    HL,$5B3B     ; address FLAGS system variable.
          SET   6,(HL)       ; set default FLAGS result to numeric.
          BIT   7,E          ; test the operational result.
          JR    NZ,S_LOOPEND ; forward, if numeric, to S-LOOPEND

          RES   6,(HL)       ; reset bit 6 of FLAGS to show string result.

S_LOOPEND POP    BC          ; fetch the previous priority/operation

          JR    S_LOOP      ; back to S-LOOP
                        ; to perform these.

; ---

; The branch was here when a stacked priority/operator had higher priority
; than the current one.

S_TIGHTER PUSH   DE          ; save higher priority/operator on stack again.
          LD    A,C          ; fetch the lower priority/operation code.

```

```

        BIT    6,(IY+$01)      ; test FLAGS - numeric or string result ?
        JR     NZ,S_NEXT      ; forward, if numeric, to S-NEXT

; If this is lower priority, yet has a string result, then it must be a
; comparison. Since these can only be evaluated in context and were
; defaulted to numeric at the operator look-up stage, they must be changed
; to their string equivalents.

        AND    $3F            ; mask to give the true calculator literal.
        ADD    A,$08          ; augment numeric literals to their string
                                ; equivalents.
                                ; 'no-&-no' => 'str-&-no'
                                ; 'no-l-eql' => 'str-l-eql'
                                ; 'no-gr-eq' => 'str-gr-eq'
                                ; 'nos-neql' => 'strs-neql'
                                ; 'no-grtr' => 'str-grtr'
                                ; 'no-less' => 'str-less'
                                ; 'nos-eql' => 'strs-eql'
                                ; 'addition' => 'strs-add'

        LD     C,A            ; put modified comparison operator back.
        CP     $10            ; is it now 'str-&-no' ?
        JR     NZ,S_NOT_AND   ; skip forward, if not, to S-NOT-AND

        SET    6,C            ; set numeric operand bit.
        JR     S_NEXT        ; forward to S-NEXT

; ---

; The short branch was to here when string operators had been compared.

S_NOT_AND JR     C,REPORT_Cw  ; back, if less than '&', to S-RPORT-C2
                                ; 'Nonsense in BASIC'
                                ; e.g. with a$ * b$

        CP     $17            ; is it 'strs-add' ?
        JR     Z,S_NEXT      ; forward, if so, to S-NEXT
                                ; as already set for a string result.

        SET    7,C            ; set numeric (Boolean) result for all others.

S_NEXT   PUSH   BC            ; now save this priority/operation on stack.

S_NEXT_1 RST    20H           ; NEXT-CHAR advances the character address.

        JP     S_LOOP_1      ; jump back to S-LOOP-1

; -----
; THE 'OPERATORS' TABLE
; -----
; This table is used to look up the calculator literals associated with the
; operator character. The thirteen calculator operations $03 - $0F have
; bits 6 and 7 set to signify a numeric result. Some of these codes and bits
; may be altered later if the context suggests a string comparison or
; operation was intended. That is '+', '=', '>', '<', '<=', '>=' or '<>'.

tbl_ofops DEFB   '+', $CF      ;          $C0 + 'addition'
          DEFB   '-', $C3      ;          $C0 + 'subtract'
          DEFB   '*', $C4      ;          $C0 + 'multiply'
          DEFB   '/', $C5      ;          $C0 + 'division'
          DEFB   '^', $C6      ;          $C0 + 'to-power'
          DEFB   '=', $CE      ;          $C0 + 'nos-eql'
          DEFB   '>', $CC      ;          $C0 + 'no-grtr'
          DEFB   '<', $CD      ;          $C0 + 'no-less'

```

```

DEFB $C7, $C9      ; '<='  $C0 + 'no-l-eql'
DEFB $C8, $CA      ; '>='  $C0 + 'no-gr-eql'
DEFB $C9, $CB      ; '<>'  $C0 + 'nos-neql'
DEFB $C5, $C7      ; 'OR'  $C0 + 'or'
DEFB $C6, $C8      ; 'AND' $C0 + 'no-&-no'

```

```

DEFB $00           ; zero end-marker.

```

```

; -----
; THE 'PRIORITIES' TABLE
; -----

```

```

; This table is indexed with the operation code obtained from the above
; table, $C3 - $CF, to obtain the priority for the respective operation.

```

```

TBL_PRI  DEFB $06      ; '-'   opcode $C3
          DEFB $08      ; '*'   opcode $C4
          DEFB $08      ; '/'   opcode $C5
          DEFB $0A      ; '^'   opcode $C6
          DEFB $02      ; 'OR'  opcode $C7
          DEFB $03      ; 'AND' opcode $C8
          DEFB $05      ; '<='  opcode $C9
          DEFB $05      ; '>='  opcode $CA
          DEFB $05      ; '<>'  opcode $CB
          DEFB $05      ; '>'   opcode $CC
          DEFB $05      ; '<'   opcode $CD
          DEFB $05      ; '='   opcode $CE
          DEFB $06      ; '+'   opcode $CF

```

```

; -----
; Scanning function (FN)
; -----

```

```

; This routine deals with user-defined functions.
; The definition can be anywhere in the program area but these are best
; placed near the start of the program as we shall see.
; The evaluation process is quite complex as the Spectrum has to parse two
; statements at the same time. Syntax of both has been checked previously
; and hidden locations have been created immediately after each argument
; of the DEF FN statement. Each of the arguments of the FN function is
; evaluated by SCANNING and placed in the hidden locations. Then the
; expression to the right of the DEF FN '=' is evaluated by SCANNING and for
; any variables encountered, a search is made in the DEF FN variable list
; in the program area before searching in the normal variables area.

```

```

; Recursion is not allowed: i.e. the definition of a function should not use
; the same function, either directly or indirectly ( through another
function).

```

```

; You'll normally get error 4, ('Out of memory'), although sometimes the
; system will crash. - Vickers, Pitman 1984.

```

```

; As the definition is just an expression, there would seem to be no means
; of breaking out of such recursion.
; However, by the clever use of string expressions and VAL, such recursion
; is possible.

```

```

; e.g. DEF FN a(n) = VAL "n+FN a(n-1)+0" ((n<1) * 10 + 1 TO )
; will evaluate the full 11-character expression for all values where n is
; greater than zero but just the 11th character, "0", when n drops to zero
; thereby ending the recursion producing the correct result.

```

```

; Recursive string functions are possible using VAL$ instead of VAL and the
; null string as the final addend.

```

```

; - from a turn of the century newsgroup discussion initiated by Mike Wynne.

```

```

S_FN_SBRN CALL SYNTAX_Z      ; routine SYNTAX-Z

```

```

JR      NZ,SF_RUN      ; forward to SF-RUN in runtime

RST     20H            ; NEXT-CHAR
CALL    ALPHA          ; routine ALPHA check for letters [A-Za-z]
JR      NC,REPORT_Cw   ; jump back, if not, to REPORT-C
                        ; 'Nonsense in BASIC'

RST     20H            ; NEXT-CHAR
CP      $24            ; is it '$' ?

PUSH    AF              ; (*) save the flags

JR      NZ,SF_BRKT_1   ; forward, with numeric function, to SF-BRKT-1

RST     20H            ; NEXT-CHAR advances past the '$'.

SF_BRKT_1 CP      $28   ; is character a '(' ?

SF_RPT_C JR      NZ,REPORT_Cw ; forward, if not, to SF-RPRT-C
                        ; 'Nonsense in BASIC'

RST     20H            ; NEXT-CHAR
CP      $29            ; is it ')' ?
JR      Z,SF_FLAG_6    ; forward, if no arguments, to SF-FLAG-6

SF_ARGMTS CALL    SCANNING ; routine SCANNING checks each argument which
                        ; may be an expression and ends with RST 18H.

;;; RST     18H        ; GET-CHAR

CP      $2C            ; is it a ',' ?
JR      NZ,SF_BRKT_2   ; forward if not to SF-BRKT-2 to test bracket

RST     20H            ; NEXT-CHAR if a comma was found
JR      SF_ARGMTS      ; back to SF-ARGMTS to parse all arguments.

; ---

SF_BRKT_2
;;; CP      $29        ; is character the closing ')' ?
;;; JP      NZ,REPORT_C ; Report 'Nonsense in basic' if not.

CALL    TST_RBRKT      ;+ routine to test for right hand bracket.

; at this point any optional arguments have had their syntax checked.

SF_FLAG_6 RST     20H      ; NEXT-CHAR

;;; LD      HL,$5B3B     ; address system variable FLAGS
;;; RES    6,(HL)        ; signal a string result

CALL    STR_RSLT       ;+ set default result to string as 3 byte call.

POP     AF              ; (*) restore test result against '$'.

JP      Z,S_CONT_2     ;+ to S_CONT_2 if string
JP      S_NUMERIC      ;+ else to S_NUMERIC.

```

```

;;;      JR      Z,SF_SYN_EN      ; skip forward to SF-SYN-EN if string function.
;;;      SET      6,(HL)          ; signal a numeric result.
;;; SF_SYN_EN JP  S_CONT_2        ; jump back to S-CONT-2 to continue scanning.

; ---

;   The branch was here in runtime.

SF_RUN   RST     20H              ; NEXT-CHAR fetches name
        AND     $DF              ; AND 11101111 - reset bit 5 - upper-case.
        LD      B,A              ; save in B

        RST     20H              ; NEXT-CHAR
        SUB     $24              ; subtract '$'
        LD      C,A              ; save result in C
        JR      NZ,SF_ARGMT1     ; forward if not '$' to SF-ARGMT1

        RST     20H              ; NEXT-CHAR advances to bracket

SF_ARGMT1 RST     20H             ; NEXT-CHAR advances to start of argument
        PUSH    HL               ; save address
        LD      HL,($5B53)       ; fetch start of program area from PROG
        DEC     HL               ; the search starting point is the previous
        ; location.

SF_FND_DF LD      DE,$00CE       ; search is for token 'DEF FN' in E,
        ; statement count in D.
        PUSH    BC               ; save C the string test, and B the letter.

        CALL    LOOK_PROG        ; routine LOOK-PROG will search for token.

        POP     BC               ; restore BC.
        JR      NC,SF_CP_DEF     ; forward to SF-CP-DEF if a match was found.

REPORT_P RST     30H             ; ERROR-1
        DEFB    $18              ; Error Report: FN without DEF

SF_CP_DEF PUSH    HL             ; save address of DEF FN

        CALL    FN_SKPOVR        ; routine FN-SKPOVR skips over white-space etc.
        ; without disturbing CH-ADD.

        AND     $DF              ; make fetched character upper-case.
        CP      B                ; compare with FN name
        JR      NZ,SF_NOT_FD     ; forward to SF-NOT-FD if no match.

;   the letters match so test the type.

        CALL    FN_SKPOVR        ; routine FN-SKPOVR skips white-space

        SUB     $24              ; subtract '$' from fetched character
        CP      C                ; compare with saved result of same operation
        ; on FN name.
        JR      Z,SF_VALUES      ; forward to SF-VALUES with a match.

;   the letters matched but one was string and the other numeric.

SF_NOT_FD POP     HL             ; restore search point.
        DEC     HL               ; make location before
        LD      DE,$0200         ; the search is to be for the end of the
        ; current definition - 2 statements forward.
        PUSH    BC               ; save the letter/type

        CALL    EACH_STMT        ; routine EACH-STMT steps past the rejected

```

```

; definition.

POP BC ; restore letter/type
JR SF_FND_DF ; back to SF-FND-DF to continue search

; ---

; Success!
; the branch was here with matching letter and numeric/string type.

SF_VALUES AND A ; test A ( will be zero if string '$' - '$' )

CALL Z, FN_SKPOVR ; routine FN-SKPOVR advances HL past '$'.

POP DE ; discard pointer to 'DEF FN'.
POP DE ; restore pointer to first FN argument.
LD ($5B5D), DE ; save address in CH_ADD

CALL FN_SKPOVR ; routine FN-SKPOVR advances HL past the '('

PUSH HL ; save start address in DEF FN ***
CP $29 ; is character a ')' ?
JR Z, SF_R_BR_2 ; forward, if no arguments, to SF-R-BR-2

SF_ARG_LP INC HL ; point to next character.
LD A, (HL) ; fetch it to A.
CP $0E ; is it the number marker ?
LD D, $40 ; signal numeric in D.
JR Z, SF_ARG_VL ; forward, if numeric, to SF-ARG-VL

DEC HL ; back to letter

CALL FN_SKPOVR ; routine FN-SKPOVR skips any white-space

INC HL ; advance past the expected '$' to
; the 'hidden' marker.
LD D, $00 ; signal a string result.

SF_ARG_VL INC HL ; now address first of 5-byte location.
PUSH HL ; save address in DEF FN statement
PUSH DE ; save D - result type

CALL SCANNING ; routine SCANNING evaluates expression in
; the FN statement setting FLAGS and leaving
; result as last value on calculator stack.

POP AF ; restore saved result type to A

XOR (IY+$01) ; XOR with FLAGS
AND $40 ; AND with %01000000 to test bit 6
JR NZ, REPORT_Q ; forward, with type mismatch, to REPORT-Q
; 'Parameter error'

;;; POP HL ; pop the start address in DEF FN statement
;;; EX DE, HL ; transfer to DE ?? pop straight into de ?

POP DE ;+ pop the start address in DEF FN to DE.

CALL GET_5 ;+ NEW subroutine above embodies following

;;; LD HL, ($5B65) ; set HL to STKEND - location after value
;;; LD BC, $0005 ; five bytes to move
;;; SBC HL, BC ; decrease HL by 5 to point to start.
;;; LD ($5B65), HL ; set STKEND thus 'removing' value from stack.

```

```

;;;      LDIR          ; copy value into DEF FN statement
;;;      EX    DE,HL   ; set HL to location after value in DEF FN
;;;      DEC    HL     ; step back one

      CALL  FN_SKPOVR   ; routine FN-SKPOVR gets next valid character
      CP    $29        ; is it ')' end of arguments ?
      JR    Z,SF_R_BR_2 ; forward, if so, to SF-R-BR-2

;   a comma separator has been encountered in the DEF FN argument list.

      PUSH  HL          ; save position in DEF FN statement

      RST   18H        ; GET-CHAR from FN statement
      CP    $2C        ; is character the corresponding ',' ?
      JR    NZ,REPORT_Q ; forward, if not, to REPORT-Q
                        ; 'Parameter error'

      RST   20H        ; NEXT-CHAR in FN statement advances to next
                        ; argument.

      POP   HL         ; restore DEF FN pointer
      CALL  FN_SKPOVR  ; routine FN-SKPOVR advances to corresponding
                        ; argument.

      JR    SF_ARG_LP  ; back to SF-ARG-LP looping until all
                        ; arguments are passed into the DEF FN
                        ; hidden locations.

; ---

;   the branch was here when all arguments passed.

SF_R_BR_2 PUSH  HL          ; save location of ')' in DEF FN

      RST   18H        ; GET-CHAR gets next character in FN
      CP    $29        ; is it a ')' also ?
      JR    Z,SF_VALUE  ; forward, if so, to SF-VALUE

REPORT_Q  RST   30H        ; ERROR-1
          DEFB  $19        ; Error Report: Parameter error

SF_VALUE  POP   DE         ; restore location of ')' in DEF FN to DE.
          EX    DE,HL      ; now to HL, FN ')' pointer to DE.
          LD    ($5B5D),HL ; initialize CH_ADD to this value.

;   At this point the start of the DEF FN argument list is on the machine stack.
;   We also have to consider that this defined function may form part of the
;   definition of another defined function (though not itself).
;   As this defined function may be part of a hierarchy of defined functions
;   currently being evaluated by recursive calls to SCANNING, then we have to
;   preserve the original value of DEFADD and not assume that it is zero.

      LD    HL,($5B0B)    ; get original DEFADD address
      EX    (SP),HL      ; swap with DEF FN address on stack ***
      LD    ($5B0B),HL   ; set DEFADD to point to this argument list
                        ; during scanning.

      PUSH  DE          ; save FN ')' pointer.

      RST   20H        ; NEXT-CHAR advances past ')' in define

      RST   20H        ; NEXT-CHAR advances past '=' to expression

```

```

CALL SCANNING ; routine SCANNING evaluates but searches
; initially for variables at DEFADD

POP HL ; pop the FN ')' pointer
LD ($5B5D),HL ; set CH_ADD to this
POP HL ; pop the original DEFADD value
LD ($5B0B),HL ; and re-insert into DEFADD system variable.

JP S_CONT_4 ;+ back to similar code.

;;; RST 20H ; NEXT-CHAR advances to character after ')'
;;; JP S_CONT_2 ; jump back to S-CONT-2

; -----
; THE 'DEF FN SKIPOVER' SUBROUTINE
; -----
; Used to parse DEF FN
;
; e.g. DEF FN s $ ( x ) = b $ ( TO x ) : REM exaggerated
;
; This routine is used 10 times to advance along a DEF FN statement skipping
; spaces and colour control codes. It is similar to NEXT-CHAR which is, at
; the same time, used to skip along the corresponding FN function, except
; that the latter has to deal with AT and TAB characters in string
; expressions. These cannot occur in a program area so this routine is
; simpler, as both colour controls and their parameters collate to less than
; the space character.

FN_SKPOVR INC HL ; increase pointer.
LD A,(HL) ; fetch the addressed character.

CP $21 ; compare with space + 1
JR C, FN_SKPOVR ; back to FN-SKPOVR if space or less.

RET ; return pointing to a significant character.

; -----
; THE 'SEARCH VARIABLES AREA' SUBROUTINE
; -----
;
;
LOOK_VARS SET 6,(IY+$01) ; update FLAGS - presume numeric result

RST 18H ; GET-CHAR

CALL ALPHA ; routine ALPHA tests for [A-Za-z]

JP NC,REPORT_C ; jump back, if not, to REPORT-C
; 'Nonsense in BASIC'

; The first character in BASIC is alphabetic

PUSH HL ; save pointer to first character ^1
AND $1F ; mask lower bits, 1 - 26 decimal 000xxxxx
LD C,A ; store in C as descriptor.

RST 20H ; NEXT-CHAR points to second character.
PUSH HL ; save pointer to second character ^2
CP $28 ; is it '(' - an array ?
JR Z,V_RUN_SYN ; forward, if so, to V-RUN/SYN. with 000xxxxx

SET 6,C ; preset bit 6 signaling string 010xxxxx
CP $24 ; is character a '$' ?

```



```

        JR      Z,V_STR_VAR      ; forward, if so, to V-STR-VAR

        SET     5,C              ; signal simple numeric          011xxxxxx

        CALL    ALPHANUM        ; routine ALPHANUM sets carry if second
                                ; character is also alphanumeric.

        JR      NC,V_TEST_FN     ; forward to V-TEST-FN if just one character

; It is more than one character but re-test current character so that 6 reset
; Subsequent characters have the character reduced to 1-26 or 33-58 if lower
; case. Deceptively clever.

V_CHAR     CALL    ALPHANUM      ; routine ALPHANUM
           JR      NC,V_RUN_SYN   ; to V_RUN_SYN when no more

           RES     6,C           ; make long named type          001

           RST     20H           ; NEXT-CHAR
           JR      V_CHAR        ; loop back to V-CHAR

; ---

; The jump was here when second character was '$'.

V_STR_VAR  RST     20H           ; NEXT-CHAR advances past '$'
;;         RES     6,(IY+$01)    ; update FLAGS - signal string result.
           CALL    STR_RSLT      ;+

V_TEST_FN  LD      A,($5B0C)     ; load A with DEFADD_hi
           AND     A             ; and test for zero.
           JR      Z,V_RUN_SYN   ; forward to V_RUN_SYN if a defined function
                                ; is not being evaluated.

; Note.

           CALL    SYNTAX_Z      ; routine SYNTAX-Z

           JR      NZ,STK_F_ARG   ; JUMP to STK-F-ARG in runtime and then
                                ; back to this point if no variable found.

; All paths converge here with bits 5 and 6 describing variable.

V_RUN_SYN  LD      B,C           ; save flags in B
           CALL    SYNTAX_Z      ; routine SYNTAX-Z
           JR      NZ,V_RUN      ; to V-RUN to look for the variable in runtime

; If checking syntax the letter is not returned

           LD      A,C           ; copy letter/flags to A
           AND     $E0           ; AND with 11100000 to get rid of the letter
           SET     7,A           ; use spare bit to signal checking syntax.
           LD      C,A           ; and transfer back to C.

           JR      V_SYNTAX      ; forward to V-SYNTAX

; ---

; In runtime search for the variable.

V_RUN      LD      HL,($5B4B)    ; set HL to start of variables from VARS

V_EACH     LD      A,(HL)        ; get first variable letter

```

```

AND    $7F                ; AND with %01111111
                        ; ignoring bit 7 which distinguishes
                        ; arrays or for/next variables.

JR     Z,V_80_BYTE        ; forward, if zero, to V-80-BYTE
                        ; as must be 10000000 the variables end-marker.

CP     C                  ; compare with supplied value.
JR     NZ,V_NEXT         ; forward, with no match, to V-NEXT

RLA                    ; destructively test
ADD    A,A               ; bits 5 and 6 of A
                        ; jumping if bit 5 reset or 6 set

JP     P,V_FOUND_2       ; to V-FOUND-2 strings and arrays

JR     C,V_FOUND_2       ; to V-FOUND-2 simple and for next

; This leaves long name variables.  x01xxxxx

POP    DE                ; pop pointer to BASIC 2nd. character.
PUSH   DE                ; save it again

PUSH   HL                ; save variable first letter pointer

V_MATCHES INC    HL      ; address next letter in VARS area

V_SPACES LD    A,(DE)    ; pick up character from BASIC area
INC     DE            ; and advance character address
CP     $20           ; is character a space ?
JR     Z,V_SPACES    ; back to V-SPACES until non-space

OR     $20           ; convert character to reduced lower case.33-58
CP     (HL)          ; compare with addressed variables letter
JR     Z,V_MATCHES  ; loop back to V-MATCHES if a match on an
                        ; intermediate letter.

; the last letter won't match.

OR     $80           ; now set bit 7 as last character of long names
                        ; is inverted.
CP     (HL)          ; compare again
JR     NZ,V_GET_PTR  ; forward to V-GET-PTR if no match

; but if they match check that this is also last letter in prog area

LD     A,(DE)        ; fetch next BASIC character

CALL   ALPHANUM      ; routine ALPHANUM sets carry if not alphanum

JR     NC,V_FOUND_1  ; forward to V-FOUND-1 with a full match.

V_GET_PTR POP    HL    ; pop saved pointer to 1st BASIC character.

V_NEXT PUSH   BC      ; save flags

CALL   NEXT_ONE      ; routine NEXT-ONE gets next variable in DE

EX     DE,HL         ; transfer VARS address to HL.
POP    BC            ; restore the flags

JR     V_EACH        ; loop back to V-EACH
                        ; to compare each variable

```

```

; ---
V_80_BYTE SET    7,B           ; signals not found in runtime.

;   the branch was here when checking syntax

V_SYNTAX  POP    DE           ; discard the pointer to 2nd. character  v2
                                           ; in BASIC line/workspace.
                                           ; Note HL addresses 2nd BASIC character also

                RST    18H           ; GET-CHAR gets character after variable name.

                CP     $28           ; is it '(' ?
                                           ; from a string array e.g. a$(

;;;         JR     Z,V_PASS        ; forward, with string array, to V-PASS
;;;         ; Note. could go straight to V-END ?

                JR     Z,V_END      ;+ forward, with string array, to V-END

                SET    5,B           ; signal not an array
                JR     V_END        ; forward to V-END

; -----

;   the jump was here when a long name matched and HL pointing to last character
;   in variables area.

V_FOUND_1 POP    DE           ; discard pointer to first var letter

;   the jump was here with all other matches HL points to first var char.

V_FOUND_2 POP    DE           ; discard pointer to 2nd BASIC char      v2
                POP    DE           ; drop pointer to 1st BASIC char      v1
                PUSH   HL           ; save pointer to last letter in VARS

                RST    18H           ; GET-CHAR

;;; V_PASS  CALL   ALPHANUM        ; Routine ALPHANUM
;;;         JR     NC,V_END        ; Forward, if not, to V-END

;   but it never will be as we advanced past long-named variables earlier.

;;;         RST    20H           ; NEXT-CHAR
;;;         JR     V_PASS        ; Back to V-PASS

; ---

V_END     POP    HL           ; Pop the pointer to last or only letter in
                                           ; the VARS area.

                RL     B           ; Rotate the B register left, bit 7 to carry.

                BIT    6,B           ; Test the array indicator bit.

                RET                    ; Return.

; -----
; THE 'STACK FUNCTION ARGUMENT' SECTION
; -----
;   This branch is taken from LOOK-VARS when a defined function is currently
;   being evaluated.
;   Scanning is evaluating the expression after the '=' and the variable
;   found could be in the argument list to the left of the '=' or in the
;   normal place after the program. Preference will be given to the former.

```

```

; The variable name to be matched is in C.

STK_F_ARG LD HL, ($5B0B) ; set HL to DEFADD
          LD A, (HL) ; load the first character
          CP $29 ; is it ')' ?
SFA_VRSYN JR Z, V_RUN_SYN ; JUMP back to V-RUN/SYN, if so, as there are
          ; no arguments.

; but proceed to search argument list of defined function first if not empty.

SFA_LOOP LD A, (HL) ; fetch character again.
         OR $60 ; or with 01100000 presume a simple variable.
         LD B, A ; save result in B.
         INC HL ; address next location.
         LD A, (HL) ; pick up byte.
         CP $0E ; is it the number marker ?
         JR Z, SFA_CP_VR ; forward, if so, to SFA-CP-VR

; it was a string. White-space may be present but syntax has been checked.

         DEC HL ; point back to letter.
         CALL FN_SKPOVR ; routine FN-SKPOVR skips to the '$'
         INC HL ; now address the hidden marker.
         RES 5, B ; signal a string variable.

SFA_CP_VR LD A, B ; transfer found variable letter to A.
          CP C ; compare with expected.
          JR Z, SFA_MATCH ; forward to SFA-MATCH with a match.

;;; INC HL ; step
;;; INC HL ; past
;;; INC HL ; the
;;; INC HL ; five
;;; INC HL ; bytes.

         CALL NUMBER_5 ;+ new entry point to increment HL by 5.

         CALL FN_SKPOVR ; routine FN-SKPOVR skips to next character
         CP $29 ; is it ')' ?
         JR Z, SFA_VRSYN ; jump back, if so, to V-RUN/SYN
          ; to look in the normal variables area.

         CALL FN_SKPOVR ; routine FN-SKPOVR skips past the ','
          ; all syntax has been checked and these
          ; things can be taken as read.

         JR SFA_LOOP ; back, until bracket encountered, to SFA-LOOP

; ---

SFA_MATCH BIT 5, C ; test if numeric
          JR NZ, SFA_END ; forward, if so, to SFA-END
          ; as will be stacked by scanning.

         INC HL ; point to start of string descriptor

;;; LD DE, ($5B65) ; set DE to STKEND
;;; CALL MOVE_FP ; routine MOVE_FP puts parameters on stack.
;;; EX DE, HL ; new free location to HL.
;;; LD ($5B65), HL ; use it to set STKEND system variable.

         CALL STACK_NUM ;+ subroutine embodies 3 of above instructions
         EX DE, HL ;+ HL must address STKEND

```

```

SFA_END   POP    DE           ; discard
          POP    DE           ; pointers.
          XOR    A            ; clear carry flag.
          INC    A            ; and zero flag.

          RET                ; Return.

; -----
; Stack variable component
; -----
; This is called to evaluate a complex structure that has been found, in
; runtime, by LOOK-VARS in the variables area.
; In this case HL points to the initial letter, bits 7-5
; of which indicate the type of variable.
; 010 - simple string, 110 - string array, 100 - array of numbers.
;
; It is called from CLASS-01 when assigning to a string or array including
; a slice.
; It is called from SCANNING to isolate the required part of the structure.
;
; An important part of the runtime process is to check that the number of
; dimensions of the variable match the number of subscripts supplied in the
; BASIC line.
;
; If checking syntax,
; the B register, which counts dimensions is set to zero (256) to allow
; the loop to continue till all subscripts are checked. While doing this it
; is reading dimension sizes from some arbitrary area of memory. Although
; these are meaningless it is of no concern as the limit is never checked by
; int-exp during syntax checking.
;
; The routine is also called from the syntax path of DIM command to check the
; syntax of both string and numeric arrays definitions except that bit 6 of C
; is reset so both are checked as numeric arrays. This ruse avoids a terminal
; slice being accepted as part of the DIM command.
; All that is being checked is that there are a valid set of comma-separated
; expressions before a terminal ')', although, as above, it will still go
; through the motions of checking dummy dimension sizes.

STK_VAR   XOR    A            ; clear A
          LD     B,A          ; and B, the syntax dimension counter (256)
          BIT    7,C          ; checking syntax ?
          JR     NZ,SV_COUNT  ; forward, if so, to SV-COUNT

; runtime evaluation.

          BIT    7,(HL)       ; will be reset if a simple string.
          JR     NZ,SV_ARRAYS ; forward to SV-ARRAYS otherwise

          INC    A            ; set A to 1, simple string.

SV_SIMPLE INC    HL           ; address length low
          LD     C,(HL)       ; place in C
          INC    HL           ; address length high
          LD     B,(HL)       ; place in B
          INC    HL           ; address start of string
          EX     DE,HL        ; DE = start now.
          CALL   STK_STO_s    ; routine STK-STO-$ stacks string parameters
                               ; DE start in variables area,
                               ; BC length, A=1 indicates a simple string

; the only thing now is to consider if a slice is required.

```

```

RST 18H ; GET-CHAR puts character at CH_ADD in A
JP SV_SLICEq ; jump forward to SV-SLICE? to test for '('

; -----

; the branch was here with string and numeric arrays in runtime.

SV_ARRAYS INC HL ; step past
INC HL ; the total length
INC HL ; to address Number of dimensions.
LD B, (HL) ; transfer to B overwriting zero.
BIT 6,C ; a numeric array ?
JR Z,SV_PTR ; forward to SV-PTR with numeric arrays

DEC B ; ignore the final element of a string array
; the fixed string size.

JR Z,SV_SIMPLE ; back to SV-SIMPLE$ if result is zero as has
; been created with DIM a$(10) for instance
; and can be treated as a simple string.

; proceed with multi-dimensioned string arrays in runtime.

EX DE,HL ; save pointer to dimensions in DE

RST 18H ; GET-CHAR looks at the BASIC line
CP $28 ; is character '(' ?
JR NZ,REPORT_3 ; forward, if not, to REPORT-3
; 'Subscript wrong'

EX DE,HL ; dimensions pointer to HL to synchronize
; with next instruction.

; runtime numeric arrays path rejoins here.

SV_PTR EX DE,HL ; save dimension pointer in DE
JR SV_COUNT ; forward to SV-COUNT with true no of dims
; in B. As there is no initial comma the
; loop is entered at the midpoint.

; -----

; the dimension counting loop which is entered at mid-point.

SV_COMMA PUSH HL ; save counter

RST 18H ; GET-CHAR

POP HL ; pop counter
CP $2C ; is character ',' ?
JR Z,SV_LOOP ; forward, if so, to SV-LOOP

; in runtime the variable definition indicates a comma should appear here

BIT 7,C ; checking syntax ?
JR Z,REPORT_3 ; forward, if not, to REPORT-3
; 'Subscript wrong'

; proceed if checking syntax of an array?

BIT 6,C ; array of strings ?
JR NZ,SV_CLOSE ; forward, if so, to SV-CLOSE

; an array of numbers.

```



```

EX    DE,HL          ;
INC   HL             ;
LD    E,(HL)        ;
INC   HL             ;
LD    D,(HL)        ;

;;;    CALL  DEDEplus1    ; routine DE,(DE+1) gets next dimension in DE
                                ; and HL points to it.
EX    (SP),HL        ; dim pointer to stack, data pointer to HL (*)
EX    DE,HL          ; data pointer to DE, dim size to HL.

CALL  INT_EXP1       ; routine INT-EXP1 checks integer expression
                                ; and gets result in BC in runtime.
JR    C,REPORT_3     ; to REPORT-3 if > HL
                                ; 'Subscript wrong'

DEC   BC             ; adjust returned result from 1-x to 0-x
CALL  GET_HLxDE      ; routine GET-HL*DE multiplies data pointer by
                                ; dimension size.
ADD   HL,BC          ; add the integer returned by expression.
POP   DE             ; pop the dimension pointer.

***

POP   BC             ; pop dimension counter.
DJNZ  SV_COMMA       ; back to SV-COMMA if more dimensions
                                ; Note. during syntax checking, unless there
                                ; are more than 256 subscripts, the branch
                                ; back to SV-COMMA is always taken.

BIT   7,C            ; are we checking syntax ?
                                ; then we've got a joker here.

SV_RPT_C  JP    NZ,REPORT_Cw    ; forward, if so, to SL-RPT-C
                                ; 'Nonsense in BASIC'
                                ; more than 256 subscripts in BASIC line.

;   but in runtime the number of subscripts are at least the same as dims

PUSH  HL             ; save data pointer.
BIT   6,C            ; is it a string array ?
JR    NZ,SV_ELEMS    ; forward, if so, to SV-ELEMS$

;   a runtime numeric array subscript.

LD    B,D            ; register DE has advanced past all dimensions
LD    C,E            ; and points to start of data in variable.
                                ; transfer it to BC.

RST   18H            ; GET-CHAR checks BASIC line
CP    $29            ; must be a ')' ?
JR    Z,SV_NUMBER    ; skip, if so, to SV-NUMBER

;   else more subscripts in BASIC line than the variable definition.

REPORT_3  RST   30H            ; ERROR-1
        DEFB  $02            ; Error Report: Subscript wrong

;   continue if subscripts matched the numeric array.

SV_NUMBER RST   20H            ; NEXT-CHAR moves CH_ADD to next statement
                                ; - finished parsing.

POP   HL             ; pop the data pointer.
LD    DE,$0005       ; each numeric element is 5 bytes.
CALL  GET_HLxDE      ; routine GET-HL*DE multiplies.

```



```

        ADD    HL,BC          ; now add to start of data in the variable.

        RET                ; return with HL pointing at the numeric
                           ; array subscript.                                ->

; -----

;   the branch was here for string subscripts when the number of subscripts
;   in the BASIC line was one less than in variable definition.

SV_ELEMs
        EX     DE,HL          ;
        INC    HL             ;
        LD     E,(HL)         ;
        INC    HL             ;
        LD     D,(HL)         ;

;;;
        CALL   DEDEplus1     ; routine DE,(DE+1) gets next dimension in DE
                           ; the length of strings in this array.
        EX     (SP),HL        ; start pointer to stack, data pointer to HL.
        CALL   GET_HLxDE     ; routine GET-HL*DE multiplies by element
                           ; size.
        POP    BC             ; the start of data pointer is added
        ADD    HL,BC          ; in - now points to location before.
        INC    HL             ; point to start of required string.
        LD     B,D            ; transfer the length (final dimension size)
        LD     C,E            ; from DE to BC.
        EX     DE,HL         ; put start in DE.
        CALL   STK_ST_0      ; routine STK-ST-0 stores the string parameters
                           ; with A=0 indicating a slice or subscript.

;   now check that there were no more subscripts in the BASIC line.

        RST    18H           ; GET-CHAR
        CP     $29           ; is it ')' ?
        JR     Z,SV_DIM      ; forward to SV-DIM to consider a separate
                           ; subscript or/and a slice.

        CP     $2C           ; a comma is allowed if the final subscript
                           ; is to be sliced e.g. a$(2,3,4 TO 6).
        JR     NZ,REPORT_3   ; to REPORT-3 with anything else
                           ; 'Subscript wrong'

SV_SLICE CALL   SLICING      ; routine SLICING slices the string.

;   but a slice of a simple string can itself be sliced.

SV_DIM   RST    20H          ; NEXT-CHAR

SV_SLICEq CP     $28         ; is character '(' ?
          JR     Z,SV_SLICE  ; loop back if so to SV-SLICE

STR_RSLT RES    6,(IY+$01)   ; update FLAGS - signal string result
          RET                ; and return.

; ---

;   The above section deals with the flexible syntax allowed.
;   DIM a$(3,3,10) can be considered as two dimensional array of ten-character
;   strings or a 3-dimensional array of characters.
;   a$(1,1) will return a 10-character string as will a$(1,1,1 TO 10)
;   a$(1,1,1) will return a single character.
;   a$(1,1) (1 TO 6) is the same as a$(1,1,1 TO 6)
;   A slice can itself be sliced ad infinitum

```

; b\$() () () () () (2 TO 10) (2 TO 9) (3) is the same as b\$(5)

; -----
; THE 'STRING SLICING' SUBROUTINE
; -----

; The syntax of string slicing is very natural and it is as well to reflect
; on the permutations possible.
; a\$() and a\$(TO) indicate the entire string although just a\$ would do
; and would avoid coming here.
; h\$(16) indicates the single character at position 16.
; a\$(TO 32) indicates the first 32 characters.
; a\$(257 TO) indicates all except the first 256 characters.
; a\$(19000 TO 19999) indicates the thousand characters at position 19000.
; Also a\$(9 TO 5) returns a null string not an error.
; This enables a\$(2 TO) to return a null string if the passed string is
; of length zero or 1.
; A string expression in brackets can be sliced. e.g. (STR\$ PI) (3 TO)
; We arrived here from SCANNING with CH-ADD pointing to the initial '('
; or from above.

SLICING CALL SYNTAX_Z ; routine SYNTAX-Z

CALL NZ,STK_FETCH ; routine STK-FETCH fetches parameters of
; string at runtime, start in DE, length
; in BC. This could be an array subscript.

RST 20H ; NEXT-CHAR
CP \$29 ; is it ')' ? e.g. a\$()
JR Z,SL_STORE ; forward to SL-STORE to store entire string.

PUSH DE ; else save start address of string

XOR A ; clear accumulator to use as a running flag.

PUSH AF ; and save on stack before any branching.

PUSH BC ; save length of string to be sliced.

LD DE,\$0001 ; default the start point to position 1.

RST 18H ; GET-CHAR

POP HL ; pop length to HL as default end point
; and limit.

CP \$CC ; is it 'TO' ? e.g. a\$(TO 10000)
JR Z,SL_SECOND ; to SL-SECOND to evaluate second parameter.

POP AF ; pop the running flag.

CALL INT_EXP2 ; routine INT-EXP2 fetches first parameter.

PUSH AF ; save flag (will be \$FF if parameter>limit)

LD D,B ; transfer the start
LD E,C ; to DE overwriting 0001.
PUSH HL ; save original length.

RST 18H ; GET-CHAR
POP HL ; pop the limit length.
CP \$CC ; is it 'TO' after a start ?
JR Z,SL_SECOND ; to SL-SECOND to evaluate second parameter

```

;;;      CP      $29          ; is it ')' ?          e.g. a$(365)
;;; SL_RPT_C JP      NZ,REPORT_C ; jump to REPORT-C with anything else

      CALL  TST_RBRKT      ;+ test for a right-hand bracket.

      LD    H,D            ; copy start
      LD    L,E            ; to end - just a one character slice.
      JR    SL_DEFINE     ; forward to SL-DEFINE.

; -----

SL_SECOND PUSH  HL          ; save limit length.

      RST   20H            ; NEXT-CHAR

      POP   HL            ; pop the length.

      CP   $29            ; is character ')' ?          e.g. a$(7 TO )
      JR   Z,SL_DEFINE    ; to SL-DEFINE using length as end point.

      POP   AF            ; else restore flag.

      CALL INT_EXP2        ; routine INT-EXP2 gets second expression.

      PUSH  AF            ; save the running flag.

      RST   18H            ; GET-CHAR

      LD    H,B            ; transfer second parameter
      LD    L,C            ; to HL.          e.g. a$(42 to 99)

;;;      CP      $29          ; is character a ')' ?
;;;      JR      NZ,SL_RPT_C  ; back, if not, to SL-RPT-C

      CALL  TST_RBRKT      ;+ Test for a right-hand bracket.

; we now have start in DE and an end in HL.

SL_DEFINE POP  AF          ; pop the running flag.
      EX   (SP),HL        ; put end point on stack, start address to HL
      ADD  HL,DE          ; add address of string to the start point.
      DEC  HL            ; point to first character of slice.
      EX   (SP),HL        ; start address to stack, end point to HL (*)
      AND  A              ; prepare to subtract.
      SBC  HL,DE          ; subtract start point from end point.
      LD   BC,$0000       ; default the length result to zero.
      JR   C,SL_OVER     ; forward to SL-OVER if start > end.

      INC  HL            ; increment the length for inclusive byte.

      AND  A              ; now test the running flag.
      JP   M,REPORT_3     ; jump back to REPORT-3 if $FF.
                          ; 'Subscript wrong'

      LD   B,H            ; transfer the length
      LD   C,L            ; to BC.

SL_OVER  POP  DE          ; restore start address from machine stack ***
;;;      RES   6,(IY+$01)    ; update FLAGS - signal string result for the
;;;                          ; syntax path.
      CALL STR_RSLT      ;+

;;; SL_STORE CALL  SYNTAX_Z ; routine SYNTAX_Z (UNSTACK_Z?)

```

```

;;;          RET    Z          ; return if checking syntax.
SL_STORE CALL  UNSTACK_Z      ;+ return early if checking syntax.

;   Continue to store the string in runtime.

; -----
;   other than from above, this routine is called from STK-VAR to stack
;   a known string array element.
; -----

STK_ST_0 XOR   A              ; clear to signal a sliced string or element.

; -----
;   this routine is called from chr$, scrn$ etc. to store a simple string
;   result.
; -----

;;; STK_STO_s RES    6,(IY+$01) ; update FLAGS - signal string result.
STK_STO_s CALL  STR_RSLT      ;+
                               ; and continue to store parameters of string.

; -----
;   THE 'STACK STORE' SUBROUTINE
; -----
;   This subroutine puts five registers AEDCB on the calculator stack.

STK_STORE PUSH  BC           ; preserve two registers

                CALL  TEST_5_SP ; routine TEST-5-SP checks room

                POP   BC       ; fetch the saved registers.

                LD    HL,($5B65) ; make HL point to first empty location STKEND

                LD    (HL),A     ; place the 5 registers.
                INC   HL         ;
                LD    (HL),E     ;
                INC   HL         ;
                LD    (HL),D     ;
                INC   HL         ;
                LD    (HL),C     ;
                INC   HL         ;
                LD    (HL),B     ;
                INC   HL         ;
                LD    ($5B65),HL ; update system variable STKEND.

                RET              ; and return.

; -----
;   THE 'INTEGER EXPRESSION EVALUATION' ROUTINE
; -----
;   This clever routine is used to check and evaluate an integer expression
;   which is returned in BC, setting A to $FF, if greater than a limit supplied
;   in HL. It is used to check array subscripts, parameters of a string slice
;   and the arguments of the DIM command. In the latter case, the limit check
;   is not required and H is set to $FF. When checking optional string slice
;   parameters, it is entered at the second entry point so as not to disturb
;   the running flag A, which may be $00 or $FF from a previous invocation.

INT_EXP1 XOR   A              ; set result flag to zero.

;   -> The entry point is here if A is used as a running flag.

```

```

INT_EXP2  PUSH  DE          ; preserve DE register throughout.
          PUSH  HL          ; save the supplied limit.

          PUSH  AF          ; save the flag.

          CALL  EXPT_1NUM    ; routine EXPT-1NUM evaluates expression
          ; at CH_ADD returning if numeric result,
          ; with value on calculator stack.

          POP   AF          ; pop the flag.

          CALL  SYNTAX_Z     ; routine SYNTAX-Z
          JR    Z,I_RESTORE  ; forward, if checking syntax to I-RESTORE
          ; so avoiding a comparison with supplied limit.

```

```

; The runtime path.

```

```

          PUSH  AF          ; save the flag.

          CALL  FIND_INT2    ; routine FIND-INT2 fetches value from
          ; calculator stack to BC producing an error
          ; if too high.

          POP   DE          ; pop the flag to D.
          LD   A,B          ; test value for zero and reject
          OR   C            ; as arrays and strings begin at 1.
          SCF             ; set carry flag.
          JR   Z,I_CARRY    ; forward, if zero, to I-CARRY

          POP   HL          ; restore the limit.
          PUSH  HL          ; and save.
          AND  A            ; prepare to subtract.
          SBC  HL,BC       ; subtract value from limit.

I_CARRY   LD   A,D          ; move flag to accumulator $00 or $FF.
          SBC  A,$00       ; will set to $FF if carry set.

I_RESTORE POP   HL          ; restore the limit.
          POP  DE          ; and DE register.
          RET                ; return.

```

```

; -----
; LD DE,(DE+1) Subroutine
; -----

```

```

; This routine just loads the DE register with the contents of the two
; locations following the location addressed by DE.
; It is used to step along the 16-bit dimension sizes in array definitions.
; Note. Such code is made into subroutines to make programs easier to
; write and it would use less space to include the five instructions in-line.
; However, there are so many exchanges going on at the places this is invoked
; that to implement it in-line would make the code hard to follow.
; It probably had a zippier label though as the intention is to simplify the
; program. Note. this will probably have to go.

```

```

; DEDEplus1 EX   DE,HL      ;
;           INC   HL        ;
;           LD   E,(HL)     ;
;           INC   HL        ;
;           LD   D,(HL)     ;
;           RET              ;

```

```

; -----

```

```

; HL=HL*DE Subroutine
; -----
; This routine calls the mathematical routine to multiply HL by DE in runtime.
; It is called from STK-VAR and from DIM. In the latter case syntax is not
; being checked so the entry point could have been at the second CALL
; instruction to save a few clock-cycles.
; Note. UNSTACK_Z can't be used at start as HL would be corrupted :-)

GET_HLxDE CALL SYNTAX_Z      ; routine SYNTAX-Z.
          RET  Z              ; return if checking syntax.

          CALL HL_HLxDE      ; routine HL-HL*DE.

          JP  C,REPORT_4     ; jump back to REPORT-4 if over 65535.
                          ; 'Out of memory'

          RET                ; else return with 16-bit result in HL.

; -----
; THE 'LET' COMMAND
; -----
; Sinclair BASIC adheres to the ANSI-78 standard and a LET is required in
; assignments e.g. LET a = 1 : LET h$ = "hat".
;
; Long names may contain spaces but not colour controls (when assigned).
; a substring can appear to the left of the equals sign.
;
; An earlier mathematician Lewis Carroll may have been pleased that
;
; 10 LET Babies cannot manage crocodiles = Babies are illogical AND
; Nobody is despised who can manage a crocodile AND Illogical persons
; are despised
;
; does not give the 'Nonsense..' error if the three variables exist.
; I digress.

LET      LD  HL,($5B4D)      ; fetch system variable DEST to HL.

          BIT 1,(IY+$37)    ; test FLAGX - handling a new variable ?
          JR  Z,L_EXISTS    ; forward, if not, to L-EXISTS

; continue for a new variable. DEST points to start in BASIC line.
; from the CLASS routines.

          LD  BC,$0005      ; assume numeric and assign an initial 5 bytes

L_EACH_CH INC  BC          ; increase byte count for each relevant
                          ; character

L_NO_SP  INC  HL          ; increase pointer.
          LD  A,(HL)       ; fetch character.
          CP  $20          ; is it a space ?
          JR  Z,L_NO_SP    ; back to L-NO-SP is so.

          JR  NC,L_TEST_CH ; forward to L-TEST-CH if higher.

          CP  $10          ; is it $00 - $0F ?
          JR  C,L_SPACES   ; forward, if so, to L-SPACES

          CP  $16          ; is it $10 - $1F ?
          JR  NC,L_SPACES  ; forward, if so, to L-SPACES

; it was $10 - $15 so step over a colour code.

```

```

        INC    HL                ; increase pointer.
        JR     L_NO_SP          ; loop back to L-NO-SP.

; ---

;   the branch was to here if higher than space.

L_TEST_CH CALL  ALPHANUM        ; routine ALPHANUM sets carry if alphanumeric
        JR     C,L_EACH_CH      ; loop back, if so, for more to L-EACH-CH

        CP     $24              ; is it '$' ?
        JP     Z,L_NEWS         ; jump forward if so, to L-NEWS$
                                ; with a new string.

L_SPACES  LD     A,C            ; save length lo in A.

        CALL   MK_RM_EL        ;+ MAKE_ROOM at E_LINE -1

;;;      LD     HL,($5B59)      ; fetch E_LINE to HL.
;;;      DEC    HL              ; point to location before, the variables
;;;      CALL   MAKE_ROOM       ; routine MAKE-ROOM creates BC spaces
;;;      INC    HL              ; advance to first new location.

        INC    HL              ; then to second.
        EX    DE,HL            ; set DE to second location.
        PUSH  DE                ; save this pointer.
        LD    HL,($5B4D)        ; reload HL with DEST.
        DEC   DE                ; point to first.
        SUB   $06               ; subtract six from length_lo.
        LD    B,A              ; save count in B.
        JR    Z,L_SINGLE        ; forward to L-SINGLE if it was just
                                ; one character.

;   Register HL points to start of variable name after 'LET' in BASIC line.

L_CHAR    INC    HL            ; increase pointer.
        LD    A,(HL)           ; pick up character.
        CP    $21              ; is it space or higher ?
        JR    C,L_CHAR         ; back to L-CHAR with space and less.

        OR    $20              ; make variable lower-case.
        INC   DE                ; increase destination pointer.
        LD    (DE),A           ; and load to edit line.
        DJNZ L_CHAR           ; loop back to L-CHAR until B is zero.

        OR    $80              ; invert the last character.
        LD    (DE),A           ; and overwrite that in edit line.

;   now consider first character which has bit 6 set

        LD    A,$C0            ; set A 11000000 is XOR mask for a long name.
                                ; %101      is XOR/or result

;   single character numerics rejoin here with %00000000 in mask.
;
;                                     %011      will be XOR/or result

L_SINGLE  LD    HL,($5B4D)      ; fetch DEST - HL addresses first character.
        XOR   (HL)             ; apply variable type indicator mask (above).
        OR    $20              ; make lowercase - set bit 5.
        POP   HL               ; restore pointer to 2nd character.

        CALL  L_FIRST           ; routine L-FIRST puts A in first character.
                                ; and returns with HL holding
                                ; new E_LINE-1 the $80 vars end-marker.

```

```

L_NUMERIC PUSH HL ; save the pointer.

; the value of variable is deleted but remains after calculator stack.

RST 28H ;; FP-CALC
DEFB $02 ;;delete ; delete variable value
DEFB $38 ;;end-calc

; Register DE (STKEND) points to start of value.

POP HL ; restore the pointer.
LD BC,$0005 ; start of number is five bytes before.
AND A ; prepare for true subtraction.
SBC HL,BC ; HL points to start of value.
JR L_ENTER ; forward to L-ENTER ==>

; ---

; the jump was to here if the variable already existed.

L_EXISTS BIT 6,(IY+$01) ; test FLAGS - numeric or string result ?
JR Z,L_DELETE$ ; skip forward to L-DELETE$ *->
; if string result.

; A numeric variable could be simple or an array element.
; They are treated the same and the old value is overwritten.

LD DE,$0006 ; six bytes forward points to loc past value.
ADD HL,DE ; add to start of number.
JR L_NUMERIC ; back to L-NUMERIC to overwrite value.

; ---

; *-> the branch was here if a string existed.

;;; L_DELETE$ LD HL,($5B4D) ; fetch DEST to HL.
; (still set from first instruction)

L_DELETE$ LD BC,($5B72) ; fetch STRLEN to BC.
BIT 0,(IY+$37) ; test FLAGX - handling a complete simple
; string ?
JR NZ,L_ADD$ ; forward, if so, to L-ADD$

; must be a string array or a slice in workspace.
; Note. LET a$(3 TO 6) = h$ will assign "hat " if h$ = "hat"
; and "hats" if h$ = "hatstand".
;
; This is known as Procrustian lengthening and shortening after a
; character Procrustes in Greek legend who made travelers sleep in his bed,
; cutting off their feet or stretching them so they fitted the bed perfectly.
; The bloke was hatstand and slain by Theseus.

LD A,B ; test if length
OR C ; is zero and
RET Z ; return if zero.

PUSH HL ; save pointer to start.

CALL BC_SPACES ; BC_SPACES creates room.

PUSH DE ; save pointer to first new location.
PUSH BC ; and length (*)

```



```

LD      D,H          ; set DE to point to last location.
LD      E,L          ;
INC     HL           ; set HL to next location.
LD      (HL), $20    ; place a space there.

LDDR                                ; block copy bytes filling area with spaces.

PUSH   HL            ; save pointer to start.

CALL   STK_FETCH     ; routine STK-FETCH start to DE,
                    ; length to BC.

POP    HL            ; restore the pointer.
EX     (SP),HL       ; (*) length to HL, pointer to stack.
AND    A             ; prepare for true subtraction.
SBC   HL,BC          ; subtract old length from new.
ADD   HL,BC          ; and add back.
JR    NC,L_LENGTH    ; forward if it fits to L-LENGTH.

LD     B,H           ; otherwise set
LD     C,L           ; length to old length.
                    ; "hatstand" becomes "hats"

L_LENGTH EX  (SP),HL   ; (*) length to stack, pointer to HL.
        EX  DE,HL     ; pointer to DE, start of string to HL.

;;;     LD     A,B     ; is the length zero ?
;;;     OR     C       ;
;;;     JR    Z,L_IN_W_S ; forward, if so, to L-IN-W/S
;;;                               ; leaving the prepared spaces.
;;;     LDIR                                ; else copy bytes overwriting some spaces.

        CALL  COND_MV ;+ a Conditional (NZ) ldir routine

L_IN_W_S POP  BC      ; pop the new length.  (*)
        POP  DE      ; pop pointer to new area.
        POP  HL      ; pop pointer to variable in assignment.
                    ; and continue copying from workspace
                    ; to variables area.

; ==> branch here from L-NUMERIC

L_ENTER  EX    DE,HL   ; exchange pointers HL=STKEND DE=end of vars.

COND_MV  LD    A,B     ; test the length
        OR    C       ; and make a
        RET   Z       ; return if zero (strings only).

        PUSH  DE      ; save start of destination.

        LDIR                                ; block copy bytes.

        POP   HL      ; address the start.
        RET                                ; Return.

; ---

; the branch was here from L-DELETE$ if an existing simple string.
; register HL addresses start of string in variables area.

L_ADDS  DEC   HL      ; point to high byte of length.
        DEC   HL      ; to low byte.
        DEC   HL      ; to letter.
        LD    A,(HL)  ; fetch masked letter to A.

```

```

PUSH HL          ; save the pointer on stack.
PUSH BC         ; save new length.

CALL L_STRING   ; routine L-STRING adds new string at end
                ; of variables area.
                ; if no room we still have old one.

POP  BC         ; restore length.
POP  HL         ; restore start.
INC  BC         ; increase
INC  BC         ; length by three
INC  BC         ; to include character and length bytes.

JP   RECLAIM_2 ; jump to indirect exit via RECLAIM-2
                ; deleting old version and adjusting pointers.

; ---

; the jump was here with a new string variable.

L_NEWs  LD      A,$DF          ; indicator mask %11011111 for
                ;                %010xxxxx will be result
        LD      HL,($5B4D)    ; address DEST first character.
        AND     (HL)          ; combine mask with character.

L_STRING PUSH AF             ; save first character and mask.

        CALL   STK_FETCH     ; routine STK-FETCH fetches parameters of
                ; the string. Start in DE, length in BC.

        EX     DE,HL         ; transfer start to HL.
        ADD    HL,BC         ; add to length.
        PUSH   BC            ; save the length.
        DEC    HL            ; point to end of string.
        LD     ($5B4D),HL    ; save pointer in DEST.
                ; (updated by POINTERS if in workspace)
        INC    BC            ; extra byte for letter.
        INC    BC            ; two bytes
        INC    BC            ; for the length of string.

        CALL   MK_RM_EL      ;+ MAKE_ROOM at E_LINE -1

;;;        LD     HL,($5B59)  ; address E_LINE.
;;;        DEC    HL          ; now end of VARS area.
;;;        CALL   MAKE_ROOM   ; routine MAKE-ROOM makes room for string.
;;;                ; updating pointers including DEST.

        LD     HL,($5B4D)    ; pick up pointer to end of string from DEST.
        POP    BC            ; restore length from stack.
        PUSH   BC            ; and save again on stack.
        INC    BC            ; add a byte.

LDDR                                ; copy bytes from end to start.

        EX     DE,HL         ; HL addresses length low
        INC    HL            ; increase to address high byte
        POP    BC            ; restore length to BC
        LD     (HL),B        ; insert high byte
        DEC    HL            ; address low byte location
        LD     (HL),C        ; insert that byte

        POP    AF            ; restore character and mask

L_FIRST DEC    HL            ; address variable name

```

```

        LD      (HL),A          ; and insert character.
L_EL_DHL LD      HL, ($5B59)    ; load HL with E_LINE.
        DEC    HL              ; now end of VARS area.
        RET                      ; return

; -----
; THE 'STACK FETCH' SUBROUTINE
; -----
;
;
STK_FETCH LD      HL, ($5B65)    ; STKEND
        DEC    HL              ;
        LD      B, (HL)         ;
        DEC    HL              ;
        LD      C, (HL)         ;
        DEC    HL              ;
        LD      D, (HL)         ;
        DEC    HL              ;
        LD      E, (HL)         ;
        DEC    HL              ;
        LD      A, (HL)         ;
        LD      ($5B65),HL      ; STKEND
        RET                      ;

; -----
; THE 'DIM' COMMAND
; -----
;
; e.g. DIM a(2,3,4,7): DIM a$(32) : DIM b$(20,2,768) : DIM c$(20000)
; the only limit to dimensions is memory so, for example,
; DIM a(2,2,2,2,2,2,2,2,2,2,2,2,2,2,2,2) is possible and creates a multi-
; dimensional array of zeros. String arrays are initialized to spaces.
; It is not possible to erase an array, but it can be re-dimensioned to
; a minimal size of 1, after use, to free up memory.

DIM      CALL    LOOK_VARS      ; routine LOOK-VARS

D_REPORT_C JP    NZ,REPORT_C    ; jump to REPORT-C if a long-name variable.
; DIM lottery numbers(49) doesn't work.

        CALL    SYNTAX_Z       ; routine SYNTAX-Z
        JR      NZ,D_RUN       ; forward, in runtime, to D-RUN

        RES     6,C            ; signal 'numeric' array even if of type string
; as this simplifies the syntax checking.

        CALL    STK_VAR        ; routine STK-VAR checks syntax.
        CALL    CHECK_END      ; routine CHECK-END performs early exit ->

; ---

; the branch was here in runtime.

D_RUN    JR      C,D_LETTER     ; skip to D-LETTER if variable did not exist.
; else reclaim the old one.

        PUSH   BC              ; save type in C.

;;;     CALL    NEXT_ONE       ; routine NEXT-ONE find following variable
;;;     ; or position of $80 end-marker.
;;;     CALL    RECLAIM_2      ; routine RECLAIM-2 reclaims the
;;;     ; space between.

```

```

        CALL  NXT_1_RC2          ;+ routine combines above 2 routines.

        POP   BC                ; pop the type.

D_LETTER SET    7,C             ; signal array.
        LD    B,$00            ; initialize dimensions to zero and
        PUSH BC                ; save with the type.
        LD    HL,$0001         ; make elements one character presuming string
        BIT   6,C              ; is it a string ?
        JR    NZ,D_SIZE        ; forward, if so, to D-SIZE

        LD    L,$05            ; make elements 5 bytes as is numeric.

D_SIZE   EX    DE,HL           ; save the element size in DE.

;   now enter a loop to parse each of the integers in the list.

D_NO_LOOP RST   20H            ; NEXT-CHAR
        LD    H,$FF           ; disable limit check by setting HL high

        CALL  INT_EXP1         ; routine INT-EXP1

        JP    C,REPORT_3       ; to REPORT-3 if > 65280 and then some
        ; 'Subscript wrong'

        POP   HL                ; pop dimension counter, array type
        PUSH BC                ; save dimension size
        INC   H                 ; increment the dimension counter
        PUSH HL                ; save the dimension counter
        LD    H,B              ; transfer size
        LD    L,C              ; to HL
        CALL  GET_HLxDE        ; routine GET-HL*DE multiplies dimension by
        ; running total of size required initially
        ; 1 or 5.
        EX   DE,HL            ; save running total in DE

        RST   18H              ; GET-CHAR
        CP    $2C              ; is it ',' ?
        JR    Z,D_NO_LOOP      ; loop back to D-NO-LOOP until all dimensions
        ; have been considered

;   when loop complete continue.

;;;     CP    $29              ; is it ')' ?
;;;     JR    NZ,D_RPORT_C     ; to D-RPORT-C with anything else
;;;     RST   20H              ; NEXT-CHAR advances to next statement/CR

        CALL  RBRKT_NXT        ;+ Test for a right hand bracket and advance.

        POP   BC                ; pop dimension counter/type
        LD    A,C              ; type to A

;   now calculate space required for array variable

        LD    L,B              ; dimensions to L since these require 16 bits
        ; then this value will be doubled
        LD    H,$00            ; set high byte to zero

;   another four bytes are required for letter(1), total length(2), number of
;   dimensions(1) but since we have yet to double allow for two.

        INC   HL                ; increment
        INC   HL                ; increment

```

```

ADD    HL,HL           ; now double giving 4 + dimensions * 2

ADD    HL,DE           ; add to space required for array contents

JP     C,REPORT_4      ; to REPORT-4 if > 65535
                          ; 'Out of memory'

PUSH   DE              ; save data space
PUSH   BC              ; save dimensions/type
PUSH   HL              ; save total space
LD     B,H             ; total space
LD     C,L             ; to BC

CALL   MK_RM_EL        ;+ MAKE_ROOM at E_LINE -1

;;;   LD     HL,($5B59) ; address E_LINE - first location after
;;;   DEC    HL         ; point to location before - the $80 end-marker
;;;   CALL   MAKE_ROOM  ; routine MAKE-ROOM creates the space if
;;;   INC    HL         ; point to first new location and

LD     (HL),A          ; store letter/type

POP    BC              ; pop total space
DEC    BC              ; exclude name
DEC    BC              ; exclude the 16-bit
DEC    BC              ; counter itself
INC    HL              ; point to next location the 16-bit counter
LD     (HL),C          ; insert low byte
INC    HL              ; address next
LD     (HL),B          ; insert high byte

POP    BC              ; pop the number of dimensions.
LD     A,B             ; dimensions to A
INC    HL              ; address next
LD     (HL),A          ; and insert "No. of dims"

LD     H,D             ; transfer DE space + 1 from make-room
LD     L,E             ; to HL
DEC    DE              ; set DE to next location down.
LD     (HL),$00        ; presume numeric and insert a zero
BIT    6,C             ; test bit 6 of C. numeric or string ?
JR     Z,DIM_CLEAR     ; skip to DIM-CLEAR if numeric

LD     (HL),$20        ; place a space character in HL

DIM_CLEAR POP    BC    ; pop the data length

LDDR                                ; LDDR sets to zeros or spaces

;   The number of dimensions is still in A.
;   A loop is now entered to insert the size of each dimension that was pushed
;   during the D-NO-LOOP working downwards from position before start of data.

DIM_SIZES POP    BC    ; pop a dimension size          ***
LD     (HL),B          ; insert high byte at position
DEC    HL              ; next location down
LD     (HL),C          ; insert low byte
DEC    HL              ; next location down
DEC    A               ; decrement dimension counter
JR     NZ,DIM_SIZES    ; back to DIM-SIZES until all done.

RET                                ; return.
; -----

```

```

; THE 'ALPHANUM' SUBROUTINE
; -----
; This routine checks that the character in A is alphanumeric returning,
; if so, with carry set.

ALPHANUM CALL NUMERIC ; Routine NUMERIC resets carry if a number.

        CCF ; Complement Carry Flag.
        RET C ; Return if numeric else continue into next
            ; routine.

; This routine checks that the character in A is alphabetic setting the carry
; flag if it is.

ALPHA CP $41 ; less than 'A' ?
      CCF ; Complement Carry Flag
      RET NC ; return if less.

      CP $5B ; less than 'Z'+1 ?
      RET C ; is within first range

      CP $61 ; less than 'a' ?
      CCF ; Complement Carry Flag
      RET NC ; return if less.

      CP $7B ; less than 'z'+1 ?
      RET ; carry set if within a-z.

; -----
; THE 'DECIMAL TO FLOATING POINT' SUBROUTINE
; -----
; This routine finds the floating point number represented by an expression
; beginning with BIN, '.' or a digit.
; Note that BIN need not have any '0's or '1's after it.
; BIN is really just a notational symbol and not a function.

DEC_TO_FP CP $C4 ; 'BIN' token ?
          JR NZ,NOT_BIN ; forward, if not, to NOT-BIN

          LD DE,$0000 ; initialize 16 bit buffer register.

BIN_DIGIT RST 20H ; NEXT-CHAR
          SUB $31 ; '1'
          ADC A,$00 ; will be zero if '1' or '0'
                ; carry will be set if was '0'
          JR NZ,BIN_END ; forward to BIN-END if result not zero

          EX DE,HL ; buffer to HL
          CCF ; Carry now set if originally '1'
          ADC HL,HL ; shift the carry into HL
          JP C,REPORT_6 ; to REPORT-6 if overflow - too many digits
                ; after first '1'. There can be an unlimited
                ; number of leading zeros.
                ; 'Number too big' - raise an error

          EX DE,HL ; save the buffer
          JR BIN_DIGIT ; back to BIN-DIGIT for more digits

; ---

BIN_END LD B,D ; transfer 16 bit buffer
        LD C,E ; to BC register pair.
        JR STACK_BC ; JUMP to STACK-BC to put on calculator stack

```

```

; ---

; continue here with .1, 42, 3.14, 5., 2.3 E -4
NOT_BIN CP $2E ; '.' - leading decimal point ?
JR Z,DECIMAL ; skip, if so, to DECIMAL

CALL INT_TO_FP ; routine INT-TO-FP to evaluate all digits
; This number 'x' is placed on stack.
CP $2E ; '.' - mid decimal point ?

JR NZ,E_FORMAT ; to E-FORMAT if not to consider that format

RST 20H ; NEXT-CHAR
CALL NUMERIC ; routine NUMERIC returns carry reset if 0-9

JR C,E_FORMAT ; to E-FORMAT if not a digit e.g. '1.'

JR DEC_STO_1 ; to DEC-STO-1 to add the decimal part to 'x'

; ---

; a leading decimal point has been found in a number.
DECIMAL RST 20H ; NEXT-CHAR
CALL NUMERIC ; routine NUMERIC will reset carry if digit

DEC_RPT_C JP C,REPORT_C ; to REPORT-C if just a '.'
; raise 'Nonsense in BASIC'

; since there is no leading zero put one on the calculator stack.

RST 28H ;; FP-CALC
DEFB $A0 ;;stk-zero ; 0.
DEFB $38 ;;end-calc

; If rejoining from earlier there will be a value 'x' on stack.
; If continuing from above the value zero will be stacked.
; Now store 1 in mem-0.
; Note. At each pass of the digit loop this will be divided by ten.

DEC_STO_1 RST 28H ;; FP-CALC
DEFB $A1 ;;stk-one ;x or 0,1.
DEFB $C0 ;;st-mem-0 ;x or 0,1.
DEFB $02 ;;delete ;x or 0.
DEFB $38 ;;end-calc

NXT_DGT_1 RST 18H ; GET-CHAR

CALL STK_DIGIT ; routine STK-DIGIT stacks single digit 'd'

JR C,E_FORMAT ; exit to E-FORMAT when digits exhausted >

; Note. by switching division and multiply .5 will evaluate as 5/10 instead
; of 5 * .1. The values 5/10 and 1/2 are therefore equal.

RST 28H ;; FP-CALC ;x or 0,d. first pass.
DEFB $E0 ;;get-mem-0 ;x or 0,d,1.
DEFB $A4 ;;stk-ten ;x or 0,d,1,10.
;;; DEFB $05 ;;division ;obsolete
DEFB $04 ;+multiply ;x or 0,d,10.
DEFB $C0 ;;st-mem-0 ;x or 0,d,10.
;;; DEFB $04 ;;multiply ;obsolete

```

```

DEFB $05          ;+division  ;x or 0,d/10.
DEFB $0F          ;;addition  ;x or 0 + d/10.
DEFB $38          ;;end-calc  last value.

RST  20H          ; NEXT-CHAR  moves to next character
JR   NXT_DGT_1    ; back to NXT-DGT-1

; ---

;   Although only the first pass is shown, it can be seen that at each pass
;   the new less significant digit is divided by an increasingly larger
;   factor (100, 1000, 10000 ... ) before being added to the previous
;   last value to form a new last value.

;   Finally see if an exponent has been input.

E_FORMAT CP  $45          ; is character 'E' ?
JR       Z,SIGN_FLAG     ; forward, if so, to SIGN-FLAG

CP  $65          ; 'e' is acceptable as well.
RET  NZ          ; return as no exponent.

SIGN_FLAG LD  B,$FF      ; initialize temporary sign byte to $FF

RST  20H          ; NEXT-CHAR
CP  $2B          ; is character '+' ?
JR  Z,SIGN_DONE   ; to SIGN-DONE

CP  $2D          ; is character '-' ?
JR  NZ,ST_E_PART  ; to ST-E-PART as no sign

INC  B           ; set sign to zero

;   now consider digits of exponent.
;   Note. incidentally this is the only occasion in Spectrum BASIC when an
;   expression may not be used when a number is expected.

SIGN_DONE RST  20H      ; NEXT-CHAR

ST_E_PART CALL  NUMERIC    ; routine NUMERIC

JR  C,DEC_RPT_C      ; back, if not, to DEC-RPT-C
;   'Nonsense in BASIC'.

PUSH  BC           ; save sign (in B)

CALL  INT_TO_FP     ; routine INT-TO-FP places exponent on stack

CALL  FP_TO_A       ; routine FP-TO-A transfers it to A

POP   BC           ; restore sign
JP   C,REPORT_6     ; to REPORT-6 if overflow (over 255)
;   raise 'Number too big'.

AND  A             ; set flags
JP  M,REPORT_6     ; to REPORT-6 if over '127'.
;   raise 'Number too big'.
;   127 is still way too high and it is
;   impossible to enter an exponent greater
;   than 39 from the keyboard. The error gets
;   raised later in E-TO-FP so two different
;   error messages depending how high A is.

INC  B           ; $FF to $00 or $00 to $01 - expendable now.

```



```

        JR      Z,E_FP_JUMP      ; forward to E-FP-JUMP if exponent positive

        NEG                                ; Negate the exponent.

E_FP_JUMP JR      E_TO_FP      ; JUMP forward to E-TO-FP to assign to
                                ; last value x on stack x * 10 to power A
                                ; a relative jump would have done.

; -----
; THE 'NUMERIC' SUBROUTINE
; -----
; This routine checks that the ASCII character in A is numeric
; returning, if so, with carry reset.

NUMERIC CP      $30              ; '0'
        RET      C              ; return if less than zero character.

        CP      $3A              ; The upper test is '9'
        CCF                                ; Complement Carry Flag
        RET                                ; Return - carry clear if character '0' - '9'

; -----
; THE 'STACK BC and SET IY' ROUTINE
; -----
;

STK_BC_IY LD      IY,$5B3A      ;+ re-initialize the IY register to access the
                                ;+ system variables. (14 clock cycles)
        JR      STACK_BC      ;+ forward to stack the result of USR function.

; -----
; THE 'STACK DIGIT' SUBROUTINE
; -----
; This subroutine is called from INT-TO-FP and DEC-TO-FP to stack a digit
; on the calculator stack.

STK_DIGIT CALL   NUMERIC        ; routine NUMERIC
        RET      C              ; return if not numeric character

        SUB     $30              ; convert from ASCII to digit

; -----
; THE 'STACK A' SUBROUTINE
; -----
;
;

STACK_A LD      C,A              ; transfer to C
        LD      B,$00           ; and make B zero

; -----
; THE 'STACK BC' SUBROUTINE
; -----
;

;;; STACK_BC LD      IY,$5B3A    ; re-initialize ERR_NR

STACK_BC XOR     A              ; Clear accumulator to signal small integer
        LD      E,A              ; Place in E for the sign byte.
        LD      D,C              ; LSB to D
        LD      C,B              ; MSB to C
        LD      B,A              ; last byte not used

        CALL   STK_STORE        ; routine STK-STORE stacks number AEDCB

```

```

; and sets carry.

; Note. HL now points to new STKEND. The requirement is that it should point
; to the 'result' and DE should point at STKEND as this is the terminating
; routine for some calculator functions. This can be done by simply entering
; and leaving the calculator but that uses many clock cycles if only two
; bytes.

        AND  A           ;+ Clear carry.
        JP   STK_PNTRS   ;+ set HL to result and DE to STKEND also
                           ;+ the carry flag is unaffected.

;;;     RST   28H        ;; FP-CALC
;;;     DEFB  $38        ;;end-calc  make HL = STKEND-5 and DE = STKEND
;;;     AND   A          ; clear the carry flag.
;;;     RET                    ; Return.

; -----
; THE 'INTEGER TO FLOATING POINT' SUBROUTINE
; -----
; This routine places one or more digits found in a BASIC line
; on the calculator stack multiplying the previous value by ten each time
; before adding in the new digit to form a last value on calculator stack.

INT_TO_FP PUSH  AF           ; save first character

        RST   28H          ;; FP-CALC
        DEFB  $A0          ;;stk-zero   ; v=0. initial value
        DEFB  $38          ;;end-calc

        POP   AF           ; fetch first character back.

NXT_DGT_2 CALL  STK_DIGIT   ; routine STK-DIGIT puts 0-9 on stack

        RET   C            ; will return when character is not numeric >

        RST   28H          ;; FP-CALC      ; v, d.
        DEFB  $01          ;;exchange     ; d, v.
        DEFB  $A4          ;;stk-ten      ; d, v, 10.
        DEFB  $04          ;;multiply     ; d, v*10.
        DEFB  $0F          ;;addition     ; d + v*10 = newvalue
        DEFB  $38          ;;end-calc     ; v.

        CALL  CH_ADD__1    ; routine CH-ADD+1 get next character
        JR   NXT_DGT_2    ; back to NXT-DGT-2 to process as a digit

;*****
;** Part 9. ARITHMETIC ROUTINES **
;*****

; -----
; THE 'E-FORMAT TO FLOATING POINT' SUBROUTINE
; -----
; This subroutine is used by the PRINT-FP routine and the decimal to FP
; routines to stack a number expressed in exponent format.
; Note. Though not used by the ROM as such, it has also been set up as a
; unary calculator literal but this will not work as the accumulator is not
; available from within the calculator.

; On entry, there is a value x on the calculator stack and an exponent of ten
; in A. The required value is x + 10 ^ A

E_TO_FP  RLCA              ; this will set the          x.

```

```

RRCA                ; carry if bit 7 is set

JR    NC,E_SAVE     ; to E-SAVE  if positive.

CPL
INC    A            ; make negative positive
                        ; without altering carry.

E_SAVE    PUSH    AF            ; save positive exp and sign in carry

LD    HL,$5B92      ; address MEM-0

CALL    FP_0_1      ; routine FP-0/1
                        ; places an integer zero, if no carry,
                        ; else a one in mem-0 as a sign flag

RST    28H          ;; FP-CALC
DEFB   $A4          ;;stk-ten                x, 10.
DEFB   $38          ;;end-calc

POP    AF           ; pop the exponent.

;   now enter a loop

E_LOOP    SRL    A            ; 0>76543210>C

JR    NC,E_TST_END   ; forward to E-TST-END if no bit

PUSH    AF           ; save shifted exponent.

RST    28H          ;; FP-CALC
DEFB   $C1          ;;st-mem-1                x, 10.
DEFB   $E0          ;;get-mem-0              x, 10, (0/1).
DEFB   $00          ;;jump-true

DEFB   E_DIVSN - $   ;;to E-DIVSN

DEFB   $04          ;;multiply                x*10.
DEFB   $33          ;;jump

DEFB   E_FETCH - $   ;;to E-FETCH

E_DIVSN    DEFB   $05          ;;division                x/10.

E_FETCH    DEFB   $E1          ;;get-mem-1                x/10 or x*10, 10.
DEFB   $38          ;;end-calc                new x, 10.

POP    AF           ; restore shifted exponent

;   the loop branched to here with no carry

E_TST_END  JR    Z,E_END     ; forward to E-END  if A emptied of bits

PUSH    AF           ; re-save shifted exponent

RST    28H          ;; FP-CALC
DEFB   $31          ;;duplicate                new x, 10, 10.
DEFB   $04          ;;multiply                new x, 100.
DEFB   $38          ;;end-calc

POP    AF           ; restore shifted exponent
JR    E_LOOP        ; back to E-LOOP  until all bits done.

; ---

```

```
; although only the first pass is shown it can be seen that for each set bit
; representing a power of two, x is multiplied or divided by the
; corresponding power of ten.
```

```
E_END    RST    28H            ;; FP-CALC            final x, factor.
          DEFB  $02            ;;delete         final x.
          DEFB  $38            ;;end-calc        x.

          RET                ; return
```

```
; -----
; THE 'FETCH INTEGER' SUBROUTINE
; -----
```

```
; This routine is called by the mathematical routines - FP-TO-BC, PRINT-FP,
; mult, re-stack and negate to fetch an integer from address HL. Register
; HL points to the stack, or a location in MEM, and no 'deletion' occurs.
; If the number is negative then a similar process to that used in INT-STORE
; is used to restore the twos-complement number to normal in DE and a sign
; in C. The contents of the B register are not affected.
```

```
INT_FETCH INC    HL            ; skip zero indicator.
          LD     C,(HL)        ; fetch sign to C

          INC    HL            ; address low byte
          LD     A,(HL)        ; fetch to A
          XOR    C            ; two's complement
          SUB    C            ;
          LD     E,A          ; place in E

          INC    HL            ; address high byte
          LD     A,(HL)        ; fetch to A
          ADC    A,C          ; two's complement
          XOR    C            ;
          LD     D,A          ; place in D

          RET                ; return
```

```
; -----
; THE 'Store a positive integer' ROUTINE
; -----
```

```
;;; This entry point is not used in this ROM but would store any integer as
;;; a positive number.
```

```
;;; p-int-sto
;;; L2D8C:    LD     C,$00            ; make sign byte positive and continue
```

```
; -----
; THE 'STORE INTEGER' SUBROUTINE
; -----
```

```
; This routine stores an integer in DE at address HL.
; It is called from mult, truncate, negate and sgn.
; The sign byte $00 +ve or $FF -ve is in C.
; If negative, the number is stored in 2's complement form so that it is
; ready to be added.
```

```
INT_STORE PUSH   HL            ; Preserve HL throughout.

;;;      LD     (HL),$00        ; first byte zero shows integer not exponent

          INC    HL            ;
          LD     (HL),C        ; then store the sign byte
```

```

        INC    HL                ;
        ; e.g.                  +1          -1
        LD     A,E              ; fetch low byte 00000001      00000001
        XOR    C                ; XOR sign      00000000      or 11111111
        ; gives                  00000001      or 11111110
        SUB    C                ; sub sign      00000000      or 11111111
        ; gives                  00000001>0 or 11111111>C
        LD     (HL),A          ; store 2's complement.
        INC    HL                ;
        LD     A,D              ; high byte      00000000      00000000
        ADC    A,C              ; sign          00000000<0    11111111<C
        ; gives                  00000000      or 00000000
        XOR    C                ; XOR sign      00000000      11111111
        LD     (HL),A          ; store 2's complement.

        INC    HL                ;
;;;     LD     (HL),$00         ; The last byte always zero for integers.
        XOR    A                ;+ Set A to zero.
        LD     (HL),A          ;+ Make fifth byte zero.
        POP    HL              ; Restore the original HL result pointer.
        LD     (HL),A          ;+ Make first byte zero.
        RET                    ; Return.

; -----
; THE 'FLOATING POINT TO BC REGISTER' ROUTINE
; -----
; This routine gets a floating point number e.g. 127.4 from the calculator
; stack to the BC register.
; Begin by using two bytes of instruction to make HL address the last 5-byte
; number on the calculator stack.
; Note. at the expense of one byte a call to STK_PNTRS would be quicker.

FP_TO_BC
;;;     RST    28H              ;; FP-CALC          set HL to
;;;     DEFB   $38              ;;end-calc          point to 'last value'.

        CALL   STK_PNTRS        ;+ set HL to STKEND -5

        LD     A,(HL)           ; get first of the 5 bytes
        AND    A                ; and test for zero.
        JR     Z,FP_DELETE     ; forward, if a small integer, to FP-DELETE

; The floating point value is first rounded up and then converted to integer.

        RST    28H              ;; FP-CALC          x.
        DEFB   $A2              ;;stk-half        x. 1/2.
        DEFB   $0F              ;;addition        x + 1/2.
        DEFB   $27              ;;int            int(x + .5)
        DEFB   $38              ;;end-calc

; Now delete but leave DE pointing at integer.

FP_DELETE RST    28H              ;; FP-CALC
        DEFB   $02              ;;delete
        DEFB   $38              ;;end-calc

        PUSH   HL               ; preserve pointer to 'last value'.
        PUSH   DE               ; preserve pointer to STKEND.

        EX     DE,HL            ; make HL point to old exponent/zero indicator
        LD     B,(HL)           ; indicator to B

        CALL   INT_FETCH        ; Routine INT-FETCH

```

```

; gets int in DE sign byte to C
; but meaningless values if a large integer.

XOR  A          ; Clear A
SUB  B          ; Subtract indicator byte setting the carry flag
; if not a small integer.

BIT  7,C        ; Test a bit of the sign byte setting zero flag
; if integer is positive.

LD   B,D        ; transfer integer
LD   C,E        ; to BC
LD   A,E        ; low byte to A also as a useful return value.

POP  DE         ; Retrieve pointer to new STKEND
POP  HL         ; Retrieve pointer to new 'last value'

RET            ; Return.

; if carry is set, then the number was too big to fit into BC.

; -----
; LOG(2^A)
; -----
; This routine is used when printing floating point numbers to calculate
; the number of digits before the decimal point.

; first convert a one-byte signed integer to its five byte form.

LOG_2powA LD    D,A          ; store a copy of A in D the LSB.
          RLA          ; test sign bit of A.
          SBC  A,A        ; now $FF if negative or $00 if positive.
          LD   E,A        ; sign byte to E the stack sign byte.
          LD   C,A        ; and also to C the MSB.
          XOR  A          ; clear A to indicate an integer.
          LD   B,A        ; and B the unused fifth byte.

          CALL STK_STORE   ; routine STK-STORE stacks number AEDCB

; So 00 00 XX 00 00 (positive) or 00 FF XX FF 00 (negative).
; i.e. integer indicator, sign byte, low, high, unused.

; now multiply the exponent by log to the base 10 of two.

          RST    28H      ;; FP-CALC

          DEFB  $34      ;;stk-data .30103 (log 2)
          DEFB  $EF      ;;Exponent: $7F, Bytes: 4
          DEFB  $1A,$20,$9A,$85 ;;
          DEFB  $04      ;;multiply

          DEFB  $27      ;;int

          DEFB  $38      ;;end-calc

; -----
; THE 'FLOATING POINT TO A' SUBROUTINE
; -----
; This routine collects a floating point number from the stack into the
; accumulator returning carry set if not in range 0 - 255.
; Not all the calling routines raise an error with overflow so no attempt
; is made to produce an error report here.

FP_TO_A  CALL  FP_TO_BC   ; routine FP-TO-BC returns with C in A also.

```

```

RET    C                ; return with carry set if > 65535, overflow

PUSH  AF                ; save the value and flags

DEC   B                ; and test that
INC   B                ; the high byte is zero.
JR    Z,FP_A_END       ; forward FP-A-END if zero

;   else there has been 8-bit overflow so set the carry flag.

POP   AF                ; retrieve the value

SCF                   ; set carry flag to show overflow
RET                   ; and return.

; ---

FP_A_END POP   AF       ; restore value and success flag and

RET                   ; return.

; -----
; THE 'PRINT A FLOATING POINT NUMBER' SUBROUTINE
; -----
;   Not a trivial task.
;   Begin by considering whether to print a leading sign for negative numbers.

PRINT_FP RST    28H          ;; FP-CALC
        DEFB   $31          ;;duplicate
        DEFB   $36          ;;less-0
        DEFB   $00          ;;jump-true

        DEFB   PF_NEGTVE - $ ;;to PF-NEGTV E

        DEFB   $31          ;;duplicate
        DEFB   $37          ;;greater-0
        DEFB   $00          ;;jump-true

        DEFB   PF_POSTVE - $ ;;to PF-POSTVE

;   must be zero itself

        DEFB   $02          ;;delete
        DEFB   $38          ;;end-calc

        LD     A,$30        ; prepare the character '0'

        RST    10H          ; PRINT-A
        RET                    ; Return.                ->

; ---

PF_NEGTVE DEFB   $2A          ;;abs
        DEFB   $38          ;;end-calc

        LD     A,$2D        ; the character '-'

        RST    10H          ; PRINT-A

;   and continue to print the now positive number.

        RST    28H          ;; FP-CALC

PF_POSTVE DEFB   $A0          ;;stk-zero      x,0.      begin by
        DEFB   $C3          ;;st-mem-3      x,0.      clearing a temporary

```

```

DEFB $C4          ;;st-mem-4      x,0.      output buffer to
DEFB $C5          ;;st-mem-5      x,0.      fifteen zeros.
DEFB $02          ;;delete        x.
DEFB $38          ;;end-calc      x.

EXX              ; in case called from 'str$' then save the
PUSH HL          ; pointer to whatever comes after
EXX              ; str$ as H'L' will be used.

; now enter a loop?

PF_LOOP  RST 28H          ;; FP-CALC
DEFB $31          ;;duplicate      x,x.
DEFB $27          ;;int           x,int x.
DEFB $C2          ;;st-mem-2      x,int x.
DEFB $03          ;;subtract     x-int x.      fractional part.
DEFB $E2          ;;get-mem-2    x-int x, int x.
DEFB $01          ;;exchange     int x, x-int x.
DEFB $C2          ;;st-mem-2      int x, x-int x.
DEFB $02          ;;delete        int x.
DEFB $38          ;;end-calc      int x.
;
; mem-2 holds the fractional part.

; HL points to last value int x

LD A,(HL)        ; fetch exponent of int x.
AND A            ; test
JR NZ,PF_LARGE  ; forward to PF-LARGE if a large integer
; > 65535

; continue with small positive integer components in range 0 - 65535
; if original number was say .999 then this integer component is zero.

CALL INT_FETCH   ; routine INT-FETCH gets x in DE
; (but x is not deleted)

LD B,$10         ; set B, bit counter, to 16d

LD A,D           ; Register A equals D from above call. ;;;

AND A           ; test if high byte is zero
JR NZ,PF_SAVE   ; forward to PF-SAVE if 16-bit integer.

; and continue with integer in range 0 - 255.

OR E            ; test the low byte for zero
; i.e. originally just point something or other.
JR Z,PF_SMALL   ; forward if so to PF-SMALL

;

LD D,E          ; transfer E to D
LD B,$08        ; and reduce the bit counter to 8.

PF_SAVE  PUSH DE          ; save the part before decimal point.
EXX      ;
POP DE         ; and pop in into D'E'
EXX      ;
JR PF_BITS    ; forward to PF-BITS

; -----

; The branch was here when 'int x' was found to be zero as in say 0.5.

```



```

; The zero has been fetched from the calculator stack but not deleted and
; this should occur now. This omission leaves the stack unbalanced and while
; that causes no problems with a simple PRINT statement, it will if str$ is
; being used in an expression e.g. "2" + STR$ 0.5 gives the result "0.5"
; instead of the expected result "20.5" as the number zero is read as the
; null string by the concatenate routine.
; credit: Tony Stratton, 1982.
; A DEFB $02 - 'delete' is required immediately on using the calculator.

```

```

PF_SMALL  RST    28H          ;; FP-CALC      int x = 0.
          DEFB   $02          ;+delete      .
          DEFB   $E2          ;;get-mem-2    x-int x.
          DEFB   $38          ;;end-calc

          LD     A,(HL)       ; fetch exponent of positive fractional number
          SUB   $7E          ; subtract

          CALL  LOG_2powA    ; routine LOG(2^A) calculates leading digits.

          LD     D,A          ; transfer count to D
          LD     A,($5BAC)    ; fetch total MEM-5-1
          SUB   D             ;
          LD     ($5BAC),A    ; MEM-5-1
          LD     A,D          ;

          CALL  E_TO_FP      ; routine E-TO-FP

          RST    28H          ;; FP-CALC
          DEFB   $31          ;;duplicate
          DEFB   $27          ;;int
          DEFB   $C1          ;;st-mem-1
          DEFB   $03          ;;subtract
          DEFB   $E1          ;;get-mem-1
          DEFB   $38          ;;end-calc

          CALL  FP_TO_A      ; routine FP-TO-A

          PUSH  HL           ; save HL
          LD     ($5BA1),A    ; MEM-3-1
          DEC   A            ;
          RLA           ;
          SBC   A,A          ;
          INC   A            ;

          LD     HL,$5BAB     ; address MEM-5-1 leading digit counter
          LD     (HL),A       ; store counter
          INC   HL           ; address MEM-5-2 total digits
          ADD   A,(HL)        ; add counter to contents
          LD     (HL),A       ; and store updated value
          POP   HL           ; restore HL

          JR     PF_FRACTN   ; JUMP forward to PF-FRACTN

```

```

; ---

```

```

; Note. while it would be pedantic to comment on every occasion a JP
; instruction could be replaced with a JR instruction, this applies to the
; above, which is useful if you wish to correct the unbalanced stack error
; by inserting a 'DEFB 02 delete' at L2E25, and maintain main addresses.

```

```

; the branch was here with a large positive integer > 65535 e.g. 123456789
; the accumulator holds the exponent.

```

```

PF_LARGE  SUB     $80          ; make exponent positive

```

```

CP      $1C                ; compare to 28
JR      C,PF_MEDIUM       ; to PF-MEDIUM if integer <= 2^27

CALL    LOG_2powA         ; routine LOG(2^A)
SUB     $07                ;
LD      B,A               ;
LD      HL,$5BAC          ; address MEM-5-1 the leading digits counter.
ADD     A,(HL)             ; add A to contents
LD      (HL),A            ; store updated value.
LD      A,B               ;
NEG     ;                 ; negate

CALL    E_TO_FP           ; routine E-TO-FP

JR      PF_LOOP           ; back to PF-LOOP

; -----

PF_MEDIUM EX    DE,HL      ;
CALL    FETCH_TWO        ; routine FETCH-TWO
EXX    ;
SET     7,D              ;
LD      A,L              ;
EXX    ;
SUB     $80              ;
LD      B,A              ;

; the branch was here to handle bits in DE with 8 or 16 in B if small int
; and integer in D'E', 6 nibbles will accommodate 065535 but routine does
; 32-bit numbers as well from above

PF_BITS  SLA    E          ; C<xxxxxxxx<0
RL      D                ; C<xxxxxxxx<C
EXX    ;
RL      E                ; C<xxxxxxxx<C
RL      D                ; C<xxxxxxxx<C
EXX    ;

LD      HL,$5BAA         ; set HL to mem-4-5th last byte of buffer
LD      C,$05            ; set byte count to 5 - 10 nibbles

PF_BYTES LD    A,(HL)     ; fetch 0 or prev value
ADC     A,A              ; shift left add in carry C<xxxxxxxx<C

DAA     ; Decimal Adjust Accumulator.
; if greater than 9 then the left hand
; nibble is incremented. If greater than
; 99 then adjusted and carry set.
; so if we'd built up 7 and a carry came in
; 0000 0111 < C
; 0000 1111
; daa 1 0101 which is 15 in BCD

LD      (HL),A          ; put back
DEC     HL              ; work down thru mem 4
DEC     C               ; decrease the 5 counter.
JR      NZ,PF_BYTES     ; back to PF-BYTES until the ten nibbles rolled

DJNZ   PF_BITS          ; back to PF-BITS until 8 or 16 (or 32) done

; at most 9 digits for 32-bit number will have been loaded with digits
; each of the 9 nibbles in mem 4 is placed into ten bytes in mem-3 and mem 4
; unless the nibble is zero as the buffer is already zero.
; ( or in the case of mem-5 will become zero as a result of RLD instruction )

```

```

XOR  A                ; clear to accept
LD   HL,$5BA6        ; address MEM-4-0 byte destination.
LD   DE,$5BA1        ; address MEM-3-0 nibble source.
LD   B,$09           ; the count is 9 (not ten) as the first
                    ; nibble is known to be blank.

RLD                ; shift RH nibble to left in (HL)
                    ;   A                (HL)
                    ; 0000 0000 < 0000 3210
                    ; 0000 0000   3210 0000
                    ; A picks up the blank nibble

LD   C,$FF           ; set a flag to indicate when a significant
                    ; digit has been encountered.

PF_DIGITS RLD        ; pick up leftmost nibble from (HL)
                    ;   A                (HL)
                    ; 0000 0000 < 7654 3210
                    ; 0000 7654   3210 0000

JR   NZ,PF_INSERT   ; to PF-INSERT if non-zero value picked up.

DEC  C                ; test
INC  C                ; flag
JR   NZ,PF_TEST_2    ; skip forward to PF-TEST-2 if flag still $FF
                    ; indicating this is a leading zero.

;   but if the zero is a significant digit e.g. 10 then include in digit totals.
;   the path for non-zero digits rejoins here.

PF_INSERT LD   (DE),A ; insert digit at destination
          INC  DE      ; increase the destination pointer
          INC  (IY+$71) ; increment MEM-5-1st digit counter
          INC  (IY+$72) ; increment MEM-5-2nd leading digit counter
          LD   C,$00    ; set flag to zero indicating that any
                    ; subsequent zeros are significant and not
                    ; leading.

PF_TEST_2 BIT  0,B     ; test if the nibble count is even
          JR   Z,PF_ALL_9 ; skip to PF-ALL-9 if so to deal with the
                    ; other nibble in the same byte

          INC  HL       ; point, if not, to next source byte.

PF_ALL_9 DJNZ  PF_DIGITS ; decrement the nibble count, back to PF-DIGITS
                    ; if all nine not done.

;   For 8-bit integers there will be at most 3 digits.
;   For 16-bit integers there will be at most 5 digits.
;   but for larger integers there could be nine leading digits.
;   If nine digits complete then the last one is rounded up as the number will
;   be printed using E-format notation

LD   A,($5BAB)      ; fetch digit count from MEM-5-1st
SUB  $09             ; subtract 9 - max possible
JR   C,PF_MORE      ; forward if less to PF-MORE

DEC  (IY+$71)        ; decrement digit counter MEM-5-1st to 8
LD   A,$04           ; load A with the value 4.
CP   (IY+$6F)        ; compare with MEM-4-4th - the ninth digit
JR   PF_ROUND        ; forward to PF-ROUND

```

; to consider rounding.

; -----

; now delete int x from calculator stack and fetch fractional part.

```
PF_MORE   RST    28H           ;; FP-CALC      int x.
          DEFB   $02           ;;delete      .
          DEFB   $E2           ;;get-mem-2   x - int x = f.
          DEFB   $38           ;;end-calc    f.
```

```
PF_FRACTN EX    DE,HL         ;
          CALL  FETCH_TWO      ; routine FETCH-TWO
          EXX                    ;
          LD    A,$80          ;
          SUB   L              ;
          LD    L,$00          ;
          SET   7,D            ;
          EXX                    ;
          CALL  SHIFT_FP       ; routine SHIFT-FP
```

```
PF_FRN_LP LD    A,(IY+$71)     ; MEM-5-1st
          CP    $08            ;
          JR    C,PF_FR_DGT    ; to PF-FR-DGT

          EXX                    ;
          RL    D              ;
          EXX                    ;
          JR    PF_ROUND       ; to PF-ROUND
```

; ---

```
PF_FR_DGT LD    BC,$0200      ;

PF_FR_EXX LD    A,E           ;
          CALL  CA_10xA_C      ; routine CA-10*A+C
          LD    E,A           ;
          LD    A,D           ;
          CALL  CA_10xA_C      ; routine CA-10*A+C
          LD    D,A           ;
          PUSH  BC            ;
          EXX                    ;
          POP   BC            ;
          DJNZ PF_FR_EXX      ; to PF-FR-EXX

          LD    HL,$5BA1       ; MEM-3
          LD    A,C           ;
          LD    C,(IY+$71)     ; MEM-5-1st
          ADD   HL,BC          ;
          LD    (HL),A         ;
          INC  (IY+$71)       ; MEM-5-1st
          JR    PF_FRN_LP     ; to PF-FRN-LP
```

; -----

```
; 1) with 9 digits but 8 in mem-5-1 and A holding 4, carry set if rounding up.
; e.g.
; 999999999 is printed as 1E+9
; 100000001 is printed as 1E+8
; 100000009 is printed as 1.0000001E+8
```

```
PF_ROUND  PUSH  AF           ; save A and flags

          LD    HL,$5BA1       ; address MEM-3 start of digits
```

```

        LD    C, (IY+$71)      ; MEM-5-1st No. of digits to C
        LD    B, $00          ; prepare to add
        ADD   HL, BC          ; address last digit + 1
        LD    B, C            ; No. of digits to B counter

        POP   AF              ; restore A and carry flag from comparison.

PF_RND_LP DEC    HL          ; address digit at rounding position.
        LD    A, (HL)         ; fetch it
        ADC   A, $00         ; add carry from the comparison
        LD    (HL), A        ; put back result even if $0A.
        AND   A              ; test A
        JR    Z, PF_R_BACK   ; skip to PF-R-BACK if ZERO?

        CP    $0A            ; compare to 'ten' - overflow
        CCF                      ; complement carry flag so that set if ten.
        JR    NC, PF_COUNT   ; forward to PF-COUNT with 1 - 9.

PF_R_BACK DJNZ  PF_RND_LP    ; loop back to PF-RND-LP

;   if B counts down to zero then we've rounded right back as in 999999995.
;   and the first 8 locations all hold $0A.

        INC   B              ; make B hold 1 also.

        LD    (HL), B        ; load first location with digit 1.

        INC   (IY+$72)       ; make MEM-5-2nd hold 1.
                                ; and proceed to initialize total digits to 1.

PF_COUNT LD    (IY+$71), B    ; MEM-5-1st

;   now balance the calculator stack by deleting it

        RST   28H            ;; FP-CALC
        DEFB  $02            ;; delete
        DEFB  $38            ;; end-calc

;   note if used from str$ then other values may be on the calculator stack.
;   we can also restore the next literal pointer from its position on the
;   machine stack.

        EXX                      ;
        POP   HL              ; restore next literal pointer.
        EXX                      ;

        LD    BC, ($5BAB)     ; set C to MEM-5-1st digit counter.
                                ; set B to MEM-5-2nd leading digit counter.
        LD    HL, $5BA1       ; set HL to start of digits at MEM-3-1
        LD    A, B            ;
        CP    $09            ;
        JR    C, PF_NOT_E    ; to PF-NOT-E

        CP    $FC            ;
        JR    C, PF_E_FRMT   ; to PF-E-FRMT

PF_NOT_E AND    A            ; test for zero leading digits as in .123

        CALL  Z, OUT_CODE     ; routine OUT-CODE prints a zero e.g. 0.123

PF_E_SBRN XOR    A          ;
        SUB   B              ;
        JP    M, PF_OUT_LP   ; skip forward to PF-OUT-LP if originally +ve

```

```

        LD    B,A          ; else negative count now +ve
        JR    PF_DC_OUT   ; forward to PF-DC-OUT      ->

; ----

PF_OUT_LP LD    A,C          ; fetch total digit count
          AND    A          ; test for zero
          JR    Z,PF_OUT_DT ; forward, if so, to PF-OUT-DT

          LD    A,(HL)      ; fetch digit
          INC    HL        ; address next digit
          DEC    C          ; decrease total digit counter

PF_OUT_DT CALL  OUT_CODE    ; routine OUT-CODE outputs it.
          DJNZ  PF_OUT_LP   ; loop back to PF-OUT-LP until B leading
                          ; digits output.

PF_DC_OUT LD    A,C          ; fetch total digits and
          AND    A          ; test if also zero
          RET    Z          ; return if so          -->

;

          INC    B          ; increment B
          LD    A,$2E      ; prepare the character '.'

PF_DEC_0S RST   10H        ; PRINT-A outputs the character '.' or '0'

          LD    A,$30      ; prepare the character '0'
                          ; (for cases like .000012345678)
          DJNZ  PF_DEC_0S  ; loop back to PF-DEC-0$ for B times.

          LD    B,C          ; load B with now trailing digit counter.
          JR    PF_OUT_LP   ; back to PF-OUT-LP

; -----

; the branch was here for E-format printing e.g. 123456789 => 1.2345679e+8

PF_E_FRMT LD    D,B          ; counter to D
          DEC    D          ; decrement
          LD    B,$01      ; load B with 1.

          CALL  PF_E_SBRN   ; routine PF-E-SBRN above

          LD    A,$45      ; prepare character 'e'
          RST   10H        ; PRINT-A

          LD    C,D          ; exponent to C
          LD    A,C          ; and to A
          AND    A          ; test exponent
          JP    P,PF_E_POS  ; to PF-E-POS if positive

          NEG                    ; negate
          LD    C,A          ; positive exponent to C
          LD    A,$2D      ; prepare character '-'
          JR    PF_E_SIGN   ; skip to PF-E-SIGN

; ----

PF_E_POS  LD    A,$2B      ; prepare character '+'

PF_E_SIGN RST   10H        ; PRINT-A outputs the sign

```

```

;;;      LD      B,$00          ; make the high byte zero.

      JP      OUT_NUM_0      ;+ exit via OUT-NUM-0 to print exponent in BC

; -----
; THE 'CA = 10 x A + C' SUBROUTINE
; -----
; This subroutine is called twice from PRINT_FP when printing floating-point
; numbers. It returns 10 * A + C in registers C and A (16 bytes)

CA_10xA_C PUSH  DE          ; preserve DE.

      LD      L,A           ; transfer A to L
      LD      H,$00        ; zero high byte.
      LD      E,L          ; copy HL
      LD      D,H          ; to DE.
      ADD    HL,HL         ; double (*2)
      ADD    HL,HL         ; double (*4)
      ADD    HL,DE         ; add DE (*5)
      ADD    HL,HL         ; double (*10)
      LD      E,C          ; copy C to E (D is 0)
      ADD    HL,DE         ; and add to give required result.
      LD      C,H          ; transfer to
      LD      A,L          ; destination registers.

      POP    DE           ; restore DE
      RET                    ; return with result.

; -----
; THE 'PREPARE TO ADD' SUBROUTINE
; -----
; This routine is called twice by addition to prepare the two numbers. The
; exponent is picked up in A and the location made zero. Then the sign bit
; is tested before being set to the implied state. Negative numbers are twos
; complemented.

PREP_ADD LD      A,(HL)      ; pick up exponent
      LD      (HL),$00      ; make location zero
      AND    A             ; test if number is zero
      RET    Z             ; return if zero.

      INC    HL            ; address mantissa
      BIT    7,(HL)        ; test the sign bit
      SET    7,(HL)        ; set it to implied state
      DEC    HL            ; point to exponent
      RET    Z             ; return if positive number.

      PUSH   BC            ; preserve BC
      LD     BC,$0005      ; length of number
      ADD   HL,BC          ; point HL past end
      LD    B,C            ; set B to 5 counter
      LD    C,A            ; store exponent in C
      SCF                    ; set carry flag

NEG_BYTE DEC    HL          ; work from LSB to MSB
      LD    A,(HL)          ; fetch byte
      CPL                    ; complement
      ADC    A,$00          ; add in initial carry or from prev operation
      LD    (HL),A          ; put back
      DJNZ  NEG_BYTE        ; loop to NEG-BYTE till all 5 done

      LD    A,C            ; stored exponent to A
      POP   BC             ; restore original BC
      RET                    ; return

```

```

; -----
; THE 'FETCH TWO NUMBERS' SUBROUTINE
; -----
; This routine is called twice when printing floating point numbers and also
; to fetch two numbers by the addition, multiply and division routines.
; HL addresses the first number, DE addresses the second number.
; For arithmetic only, A holds the sign of the result which is stored in
; the second location.

```

```

FETCH_TWO PUSH HL ; save pointer to first number, result if math.

        PUSH AF ; save result sign.

        LD C, (HL) ;
        INC HL ;

        LD B, (HL) ;
        LD (HL), A ; store the sign at correct location in
        ; destination 5 bytes for arithmetic only.
        INC HL ;

        LD A, C ;
        LD C, (HL) ;
        PUSH BC ;
        INC HL ;
        LD C, (HL) ;
        INC HL ;
        LD B, (HL) ;
        EX DE, HL ;
        LD D, A ;
        LD E, (HL) ;
        PUSH DE ;
        INC HL ;
        LD D, (HL) ;
        INC HL ;
        LD E, (HL) ;
        PUSH DE ;
        EXX ;
        POP DE ;
        POP HL ;
        POP BC ;
        EXX ;
        INC HL ;
        LD D, (HL) ;
        INC HL ;
        LD E, (HL) ;

        POP AF ; restore possible result sign.

        POP HL ; and pointer to possible result.

        RET ; return.

```

```

; -----
; THE 'SHIFT FP' SUBROUTINE
; -----
;
;

```

```

SHIFT_FP AND A ;
        RET Z ;

        CP $21 ;

```



```

        JR    NC,ADDEND_0      ; to ADDEND-0

        PUSH BC                ;
        LD   B,A              ;

ONE_SHIFT EXX                  ;
        SRA L                  ;
        RR  D                  ;
        RR  E                  ;
        EXX                    ;
        RR  D                  ;
        RR  E                  ;
        DJNZ ONE_SHIFT        ; to ONE-SHIFT

        POP  BC                ;
        RET  NC                ;

        CALL ADD_BACK          ; routine ADD-BACK
        RET  NZ                ;

ADDEND_0 EXX                    ;
        XOR  A                  ;

ZEROS_4_5 LD  L,$00           ;
        LD  D,A                ;
        LD  E,L                ;
        EXX                    ;
        LD  DE,$0000          ;
        RET                    ;

; -----
; THE 'ADD BACK' SUBROUTINE
; -----
;   Called twice to increment D'E'DE as a pseudo 32-bit register.

ADD_BACK INC  E                ;
        RET  NZ                ;

        INC  D                ;
        RET  NZ                ;

        EXX                    ;
        INC  E                ;
        JR  NZ,ALL_ADDED      ; to ALL-ADDED

        INC  D                ;

ALL_ADDED EXX                    ;
        RET                    ;

; -----
; THE 'SUBTRACTION' OPERATION
; -----
; (offset: $03 'subtract')
;   Subtraction is done by switching the sign byte/bit of the second number,
;   which may be integer of floating point, and continuing into addition.

subtract EX  DE,HL              ; address second number with HL

        CALL negate            ; routine NEGATE switches sign

        EX  DE,HL              ; address first number again
; and continue.

```

```

; -----
; THE 'ADDITION' OPERATION
; -----
; (offset: $0F 'addition')
; HL points to first number, DE to second.
; If they are both integers, then go for the easy route.

addition LD    A,(DE)          ; fetch first byte of second
          OR    (HL)           ; combine with first byte of first
          JR    NZ,FULL_ADDN   ; forward to FULL-ADDN if at least one was
                                ; in floating point form.

; Continue if both were both small integers.

          PUSH  DE              ; save pointer to second number for new STKEND.

          INC   HL              ; address sign byte of first number and
          PUSH  HL              ; push the pointer.

          INC   HL              ; address low byte
          LD    E,(HL)          ; to E
          INC   HL              ; address high byte
          LD    D,(HL)          ; to D
          INC   HL              ; address unused byte

          INC   HL              ; address known zero indicator of 1st number
          INC   HL              ; address sign byte

          LD    A,(HL)          ; sign to A, $00 or $FF

          INC   HL              ; address low byte
          LD    C,(HL)          ; to C
          INC   HL              ; address high byte
          LD    B,(HL)          ; to B

          POP   HL              ; pop result sign pointer
          EX   DE,HL            ; integer to HL

; Now perform the actual addition.

          ADD   HL,BC           ; add to the other one in BC
                                ; setting carry if overflow.

          EX   DE,HL            ; save result in DE bringing back sign pointer

          ADC   A,(HL)          ; if pos/pos A=01 with overflow else 00
                                ; if neg/neg A=FF with overflow else FE
                                ; if mixture A=00 with overflow else FF

          RRCA                    ; bit 0 to (C)

          ADC   A,$00            ; both acceptable signs now zero

          JR    NZ,ADDN_OFLW    ; forward, if not, to ADDN-OFLW

          SBC   A,A              ; restore a negative result sign

; -----
; THE 'INT -65536 FIX' credit: Dr. Ian Logan, 1983
; -----
; Note. the following is a modification of Dr. Ian Logan's suggested fix
; for the -65536 problem. At this point, the BC register pair is expendable
; and this solution is optimized for speed by avoiding the machine stack.

```

```

LD    C,A          ;+ Make a copy of the sign byte in C.

INC   A            ;+ Make any $FF in A into $00.
OR    E            ;+ Test all three
OR    D            ;+ bytes now for zero.

LD    A,C          ;+ Restore true sign byte of integer.

JR    NZ,ADD_STORE ;+ forward, if not -65536, to ADD_STORE

; The number, in the registers, is -65536 i.e. 00 FF 00 00 00 and must be
; made 91 80 00 00 00 on the calculator stack. At this stage only the
; fifth byte on the calculator stack is as required.

```

```

DEC   HL          ;+ Point to the first byte.
LD    (HL),$91    ;+ Enter exponent $91 in first byte.

INC   HL          ;++ Point to the second byte

AND   $80         ;++ set A to $80

```

; -----

```

ADD_STORE LD    (HL),A      ; insert second byte
          INC   HL          ;
          LD    (HL),E      ; insert third byte
          INC   HL          ;
          LD    (HL),D      ; insert fourth byte

          DEC   HL          ; back to third.
          DEC   HL          ; back to second.
          DEC   HL          ; point to result.

          POP   DE          ; restore value of STKEND

          RET              ; Return.

```

; ---

; The branch was here when simple register addition overflowed.

```

ADDN_OFLW DEC   HL          ;
          POP   DE          ;

FULL_ADDN CALL  RE_ST_TWO   ; routine RE-ST-TWO

          EXX              ;
          PUSH  HL          ;
          EXX              ;
          PUSH  DE          ;
          PUSH  HL          ;
          CALL  PREP_ADD     ; routine PREP-ADD
          LD    B,A         ;
          EX   DE,HL        ;
          CALL  PREP_ADD     ; routine PREP-ADD
          LD    C,A         ;
          CP   B            ;
          JR   NC,SHIFT_LEN ; to SHIFT-LEN

          LD    A,B         ;
          LD    B,C         ;
          EX   DE,HL        ;

SHIFT_LEN PUSH  AF          ;

```

```

SUB      B                ;
CALL    FETCH_TWO        ; routine FETCH-TWO
CALL    SHIFT_FP         ; routine SHIFT-FP

POP      AF                ;

POP      HL                ;
LD      (HL),A            ;
PUSH    HL                ;
LD      L,B               ;
LD      H,C               ;
ADD     HL,DE             ;
EXX                    ;
EX      DE,HL             ;
ADC     HL,BC             ;
EX      DE,HL             ;
LD      A,H               ;
ADC     A,L               ;
LD      L,A               ;
RRA                    ;
XOR     L                 ;
EXX                    ;
EX      DE,HL             ;
POP      HL                ;
RRA                    ;
JR      NC,TEST_NEG      ; to TEST-NEG

LD      A,$01            ;
CALL    SHIFT_FP         ; routine SHIFT-FP
INC     (HL)              ;
JR      Z,ADD_REP_6      ; to ADD-REP-6

TEST_NEG EXX                ;
LD      A,L               ;
AND     $80               ;
EXX                    ;
INC     HL                ;
LD      (HL),A            ;
DEC     HL                ;
JR      Z,GO_NC_MLT      ; to GO-NC-MLT

LD      A,E               ;
NEG                    ; Negate
CCF                    ; Complement Carry Flag
LD      E,A               ;
LD      A,D               ;
CPL                    ;
ADC     A,$00             ;
LD      D,A               ;
EXX                    ;
LD      A,E               ;
CPL                    ;
ADC     A,$00             ;
LD      E,A               ;
LD      A,D               ;
CPL                    ;
ADC     A,$00             ;
JR      NC,END_COMPL     ; to END-COMPL

RRA                    ;
EXX                    ;
INC     (HL)              ;

```

```

ADD_REP_6 JP      Z,REPORT_6      ; to REPORT-6
                                           ; 'Number too big'

      EXX                          ;

END_COMPL LD      D,A            ;
      EXX                          ;

GO_NC_MLT XOR     A              ;
      JP      TEST_NORM          ; to TEST-NORM

; -----
; THE 'HL = HL * DE' SUBROUTINE
; -----
; This routine is used, in the first instance, by the multiply calculator
; literal to perform an integer multiplication in preference to
; 32-bit multiplication to which it will resort if this overflows.
;
; It is also used by STK-VAR to calculate array subscripts and by DIM to
; calculate the space required for multi-dimensional arrays.

HL_HLxDE  PUSH    BC              ; preserve BC throughout
      LD      B,$10              ; set B to 16
      LD      A,H                ; save H in A high byte
      LD      C,L                ; save L in C low byte
      LD      HL,$0000           ; initialize result to zero

; now enter a loop.

HL_LOOP   ADD     HL,HL            ; double result
      JR      C,HL_END           ; to HL-END if overflow

      RL      C                  ; shift AC left into carry
      RLA                          ;
      JR      NC,HL_AGAIN        ; to HL-AGAIN to skip addition if no carry

      ADD     HL,DE              ; add in DE
      JR      C,HL_END           ; to HL-END if overflow

HL_AGAIN  DJNZ   HL_LOOP          ; back to HL-LOOP for all 16 bits

HL_END    POP     BC              ; restore preserved BC
      RET                          ; return with carry reset if successful
                                           ; and result in HL.

; -----
; THE 'PREPARE TO MULTIPLY OR DIVIDE' SUBROUTINE
; -----
; This routine is called in succession from multiply and divide to prepare
; two mantissas by setting the leftmost bit that is used for the sign.
; On the first call A holds zero and picks up the sign bit. On the second
; call the two bits are XORed to form the result sign - minus * minus giving
; plus etc. If either number is zero then this is flagged.
; HL addresses the exponent.

PREP_M_D  CALL   TEST_ZERO        ; routine TEST-ZERO preserves accumulator.
      RET     C                  ; return carry set if zero

      INC     HL                 ; address first byte of mantissa
      XOR     (HL)               ; pick up the first or XOR with first.
      SET     7,(HL)             ; now set to give true 32-bit mantissa
      DEC     HL                 ; point to exponent
      RET                          ; return with carry reset

```

```

; -----
; THE 'MULTIPLICATION' OPERATION
; -----
; (offset: $04 'multiply')
; Begin by trying integer multiplication as used on the Sinclair ZX80.
; If that overflows then use floating point multiplication.

multiply LD    A,(DE)      ; fetch exponent byte of second number.
OR      (HL)      ; combine with that of first number.
JR      NZ,MULT_LONG  ; forward, if either not integer, to MULT-LONG

        PUSH DE      ; save pointer to second number - new STKEND.
        PUSH HL      ; save pointer to first number - result pointer.

        PUSH DE      ; save pointer to second number on stack again.

        CALL INT_FETCH ; routine INT-FETCH integer to DE, sign to C.

        EX  DE,HL     ; transfer first integer from DE to HL
        EX  (SP),HL   ; integer to stack and second pointer to HL.
        LD  B,C       ; place first sign byte in B.

        CALL INT_FETCH ; routine INT-FETCH integer to DE, sign to C
                          ; and B preserved.

; Now manipulate sign bytes so that minus times a minus gives a plus result.

        LD  A,B       ; fetch first sign byte      $00 or $FF.
        XOR C         ; XOR with second sign byte.  $00 or $FF.
        LD  C,A       ; transfer sign of result to C.

        POP HL        ; pop first integer off the machine stack.

        CALL HL_HLxDE ; routine HL-HL*DE multiplies the two integers.

        EX  DE,HL     ; transfer the result to DE.

        POP HL        ; restore the result pointer to HL.

        JR  C,MULT_OFLW ; forward, with overflow, to MULT-OFLW

; Note. these next 5 bytes ensure that -zero (00 FF 00 00 00) is replaced
; by zero (00 00 00 00 00). They are required in the case of say,
; 0 * -1 which gives the result -0. This would be printed as -1E-38.
; Note. Contrary to the view expressed in The Complete Spectrum ROM
; Disassembly, these 5 bytes should not be deleted.

        LD  A,D       ; test 3rd
        OR  E         ; and 4th bytes for zero.

        JR  NZ,MULT_RSLT ; skip forward, if not, to MULT-RSLT

        LD  C,A       ; make 2nd byte, possibly $FF, zero also.

MULT_RSLT JP  INT_STO_3 ;+ jump to similar code.

;;;      CALL INT_STORE ; routine INT-STORE stores result at HL.
;;;      POP  DE       ; retrieve the new pointer to STKEND.
;;;      RET                ; Return.

; ---

; The branch was here when simple register-based multiplication overflowed.

```

```

MULT_OFLW POP    DE            ;

MULT_LONG CALL  RE_ST_TWO     ; routine RE-ST-TWO
            XOR   A            ;
            CALL  PREP_M_D     ; routine PREP-M/D
            RET   C            ;

            EXX                ;
            PUSH  HL           ;
            EXX                ;
            PUSH  DE           ;
            EX   DE,HL        ;
            CALL  PREP_M_D     ; routine PREP-M/D
            EX   DE,HL        ;
            JR    C,ZERO_RSLT  ; to ZERO-RSLT

            PUSH  HL           ;
            CALL  FETCH_TWO    ; routine FETCH-TWO
            LD   A,B           ;
            AND  A            ;
            SBC  HL,HL        ;
            EXX                ;
            PUSH  HL           ;
            SBC  HL,HL        ;
            EXX                ;
            LD   B,$21        ;
            JR   STRT_MLT     ; to STRT-MLT

; ---

MLT_LOOP  JR    NC,NO_ADD     ; to NO-ADD

            ADD  HL,DE        ;
            EXX                ;
            ADC  HL,DE        ;
            EXX                ;

NO_ADD    EXX                ;
            RR   H            ;
            RR   L            ;
            EXX                ;
            RR   H            ;
            RR   L            ;

STRT_MLT  EXX                ;
            RR   B            ;
            RR   C            ;
            EXX                ;
            RR   C            ;
            RRA                ;
            DJNZ MLT_LOOP     ; to MLT-LOOP

            EX   DE,HL        ;
            EXX                ;
            EX   DE,HL        ;
            EXX                ;
            POP  BC           ;
            POP  HL           ;
            LD   A,B         ;
            ADD  A,C         ;
            JR   NZ,MAKE_EXPT ; to MAKE-EXPT

            AND  A            ;

```

```

MAKE_EXPT DEC   A           ;
          CCF           ; Complement Carry Flag

DIVN_EXPT RLA           ;
          CCF           ; Complement Carry Flag
          RRA           ;
          JP    P,OFLW1_CLR ; to OFLW1-CLR

          JR    NC,REPORT_6 ; to REPORT-6
          ; 'Number too big'

          AND   A           ;

OFLW1_CLR INC   A           ;
          JR    NZ,OFLW2_CLR ; to OFLW2-CLR

          JR    C,OFLW2_CLR  ; to OFLW2-CLR

          EXX           ;
          BIT   7,D         ;
          EXX           ;
          JR    NZ,REPORT_6 ; to REPORT-6

OFLW2_CLR LD    (HL),A      ;
          EXX           ;
          LD    A,B         ;
          EXX           ;

TEST_NORM JR    NC,NORMALIZE ; to NORMALISE

          LD    A,(HL)      ;
          AND   A           ;

NEAR_ZERO LD    A,$80      ;
          JR    Z,SKIP_ZERO ; to SKIP-ZERO

ZERO_RSLT XOR   A           ;

SKIP_ZERO EXX           ;
          AND   D           ;
          CALL ZEROS_4_5    ; routine ZEROS-4/5
          RLCA           ;
          LD    (HL),A      ;
          JR    C,OFLOW_CLR ; to OFLOW-CLR

          INC   HL          ;
          LD    (HL),A      ;
          DEC   HL          ;
          JR    OFLOW_CLR   ; to OFLOW-CLR

; ---

NORMALIZE LD    B,$20      ;

SHIFT_ONE EXX           ;
          BIT   7,D         ;
          EXX           ;
          JR    NZ,NORML_NOW ; to NORML-NOW

          RLCA           ;
          RL    E           ;
          RL    D           ;
          EXX           ;

```



```

        RL    E            ;
        RL    D            ;
        EXX                      ;
        DEC   (HL)         ;
        JR    Z,NEAR_ZERO  ; to NEAR-ZERO

        DJNZ  SHIFT_ONE   ; to SHIFT-ONE

        JR    ZERO_RSLT    ; to ZERO-RSLT

; ---

NORML_NOW RLA            ;
          JR    NC,OFLOW_CLR ; to OFLOW-CLR

          CALL  ADD_BACK   ; routine ADD-BACK
          JR    NZ,OFLOW_CLR ; to OFLOW-CLR

          EXX                      ;
          LD    D,$80        ;
          EXX                      ;
          INC   (HL)         ;
          JR    Z,REPORT_6   ; to REPORT-6

OFLOW_CLR PUSH  HL        ;
          INC  HL           ;
          EXX                      ;
          PUSH DE          ;
          EXX                      ;
          POP  BC          ;
          LD   A,B         ;
          RLA                    ;
          RL   (HL)        ;
          RRA                    ;
          LD   (HL),A      ;
          INC  HL          ;
          LD   (HL),C      ;
          INC  HL          ;
          LD   (HL),D      ;
          INC  HL          ;
          LD   (HL),E      ;
          POP  HL          ;
          POP  DE          ;
          EXX                      ;
          POP  HL          ;
          EXX                      ;
          RET                    ;

; ---

REPORT_6 RST   30H        ; ERROR-1
          DEFB  $05        ; Error Report: Number too big

; -----
; THE 'DIVISION' OPERATION
; -----
; (offset: $05 'division')
;
;

division CALL  RE_ST_TWO  ; routine RE-ST-TWO

          EX   DE,HL      ;
          XOR  A          ;

```

```

CALL PREP_M_D      ; routine PREP-M/D
JR   C,REPORT_6   ; to REPORT-6

EX   DE,HL        ;
CALL PREP_M_D     ; routine PREP-M/D
RET  C            ;

EXX                                     ;
PUSH HL          ;
EXX                                     ;

PUSH DE          ;
PUSH HL          ;
CALL FETCH_TWO  ; routine FETCH-TWO
EXX                                     ;
PUSH HL          ;
LD   H,B         ;
LD   L,C         ;
EXX                                     ;
LD   H,C         ;
LD   L,B         ;
XOR  A           ;
LD   B,$DF       ;
JR   DIV_START  ; to DIV-START

; ---

DIV_LOOP  RLA          ;
        RL   C        ;
        EXX         ;
        RL   C        ;
        RL   B        ;
        EXX         ;

div_34th  ADD   HL,HL  ;
        EXX         ;
        ADC  HL,HL    ;
        EXX         ;
        JR   C,SUBN_ONLY ; to SUBN-ONLY

DIV_START SBC   HL,DE  ;
        EXX         ;
        SBC  HL,DE    ;
        EXX         ;
        JR   NC,NO_RSTORE ; to NO-RSTORE

        ADD  HL,DE    ;
        EXX         ;
        ADC  HL,DE    ;
        EXX         ;
        AND  A        ;
        JR   COUNT_ONE ; to COUNT-ONE

; ---

SUBN_ONLY AND   A      ;
        SBC  HL,DE    ;
        EXX         ;
        SBC  HL,DE    ;
        EXX         ;

NO_RSTORE SCF          ; Set Carry Flag

COUNT_ONE INC   B    ;

```

```

        JP      M,DIV_LOOP      ; to DIV-LOOP

        PUSH   AF              ;

        JR     Z,DIV_START     ; to DIV-START

;
;
;
;

        LD     E,A            ;
        LD     D,C            ;
        EXX                   ;
        LD     E,C            ;
        LD     D,B            ;

        POP    AF             ;

        RR     B              ;

        POP    AF             ;

        RR     B              ;
        EXX                   ;
        POP    BC             ;
        POP    HL             ;
        LD     A,B            ;
        SUB    C              ;

        JP     DIVN_EXPT     ; jump back to DIVN-EXPT

; -----
; THE 'INTEGER TRUNCATION TOWARDS ZERO' SUBROUTINE
; -----
; (offset: $3A 'truncate')
; This routine returns the integer of the 'last value' truncated towards zero
; so that, for example, the result for PI would be 3 and the result for -PI
; would be -3 (and not -4 as returned by the BASIC INT function).

truncate LD     A,(HL)        ; Fetch the first byte.
        AND    A              ; Test for zero which indicates an integer.
        RET    Z              ; return if a small integer.

        CP     $81            ; compare exponent to +1
        JR     NC,T_GR_ZERO   ; forward, if 1 or more, to T-GR-ZERO

; The number is smaller than plus or minus one and can be made zero.

        LD     (HL),$00        ; insert zero in first byte.
        LD     A,$20          ; prepare to reset all 32 bits of 'mantissa'
        JR     NIL_BYTES      ; forward to NIL-BYTES

; ---

T_GR_ZERO CP     $91          ; compare exponent to +16

; Note. the next section is designed to convert 91 80 00 00 00 to the
; integer 00 FF 00 00 00 . "This is a pity since the number would have
; been perfectly all right if left alone. The remedy would seem to be
; simply to omit the 28 bytes [below] from the program."
; credit: Dr. Ian Logan 1983.

;;;        JR     NZ,T_SMALL   ; to T-SMALL

```

```

;;;
;;; INC HL ;
;;; INC HL ;
;;; INC HL ;
;;; LD A,$80 ;
;;; AND (HL) ;
;;; DEC HL ;
;;; OR (HL) ;
;;; DEC HL ;
;;; JR NZ,T_FIRST ; to T-FIRST

;;; LD A,$80 ;
;;; XOR (HL) ;

;;; T_FIRST DEC HL ;
;;; JR NZ,T_EXPONENT ; to T-EXPONENT

;;; LD (HL),A ;
;;; INC HL ;
;;; LD (HL),$FF ;
;;; DEC HL ;
;;; LD A,$18 ;
;;; JR NIL_BYTES ; to NIL-BYTES

T_SMALL JR NC,X_LARGE ; forward if more than 16-bit integer to X-LARGE
; The number is a small integer +/- 1-65535 and can be held in two bytes.

PUSH DE ; Preserve the STKEND pointer.

; The exponent ($81 to $90) is converted to a shift count - one to sixteen.

CPL ; Complement - range $7F - $70
ADD A,$91 ; Add to give shift count $10 - $01

INC HL ; Point to first mantissa byte.
LD D,(HL) ; Load to high-order byte.
INC HL ; Point to next byte of mantissa.
LD E,(HL) ; Load to low-order byte.

DEC HL ; Restore pointer
DEC HL ; to position at first byte.

LD C,$00 ; prepare a positive sign byte.
BIT 7,D ; test sign bit of mantissa byte.

JR Z,T_NUMERIC ; skip, if positive, to T-NUMERIC

DEC C ; make $FF - negative sign byte.

T_NUMERIC SET 7,D ; put back the 'implied' bit.

; Now see if 8 bits can be right-shifted at once (if number < 256)

LD B,$08 ; prepare 8 in B
SUB B ; subtract from shift counter in A.
ADD A,B ; and add back.
JR C,T_TEST ; forward, if number > 255, to T-TEST

LD E,D ; Transfer MSB to LSB
LD D,$00 ; Make MSB zero.
SUB B ; subtract 8 from the shift counter.

```

```

T_TEST    JR      Z,T_STORE      ; forward, if no more shifts, to T-STORE

          LD      B,A            ; Transfer count to B.

T_SHIFT   SRL     D              ; 0 -> 76543210 -> C
          RR      E              ; C -> 76543210 -> C
          DJNZ   T_SHIFT        ; back for count to T-SHIFT

T_STORE   JP      INT_STO_3      ;+ jump to similar code.

;;;      CALL   INT_STORE        ; routine INT-STORE stores integer DE at HL.
;;;      POP    DE              ; Restore the STKEND value from the stack.
;;;      RET    RET              ; Return.

; ---

; The next instruction is made redundant by Dr. Logan's fix.

;;; T_EXPONENT LD    A,(HL)      ; This instruction is never reached.

; ---

; The branch was here when the number was a large number e.g. 1000000.567
; The accumulator holds the exponent.

X_LARGE   SUB     $A0            ; Subtract +32 decimal from the exponent.
          RET     P              ; Return if the result is positive as 32 bits
          ; of the mantissa relate to the integer part.
          ; The radix point is somewhere to the right of
          ; the mantissa.

          NEG     NEG            ; else negate to form number of rightmost bits
          ; to be blanked.

; For instance, disregarding the sign bit, the number 3.5 is held as
; exponent $82 mantissa .11100000 00000000 00000000 00000000.
; We need to reset $82 - $A0 = $E2, which negated = $1E (thirty) bits to
; form the integer of 3.5.

NIL_BYTES PUSH  DE              ; Save pointer to STKEND.

          EX     DE,HL          ; Register HL now points to STKEND
          DEC    HL              ; Now at last byte of mantissa.

          LD     B,A            ; Transfer the bit count to register B,

; Now look into the possibility of blanking eight bits at a time.

          SRL   B                ; Divide
          SRL   B                ; by
          SRL   B                ; eight.

          JR    Z,BITS_ZERO      ; forward, if zero, to BITS-ZERO

BYTE_ZERO LD     (HL),$00        ; set eight bits to zero.
          DEC    HL              ; point to more significant byte of mantissa.
          DJNZ  BYTE_ZERO        ; loop back for all to BYTE-ZERO

BITS_ZERO AND    $07            ; mask the remaining bits from original count.
          JR    Z,IX_END         ; forward, if none, to IX-END

          LD     B,A            ; transfer bit count to B counter.

```

```

        LD    A,$FF          ; form an initial mask %11111111
LESS_MASK SLA    A          ; 1 <- 76543210 <- 0 slide mask leftwards.
        DJNZ  LESS_MASK    ; loop back, for bit count, to LESS-MASK

        AND   (HL)         ; lose the unwanted rightmost bits.
        LD    (HL),A       ; and place in the mantissa byte.

IX_END   EX     DE,HL      ; Restore the result pointer.

        POP   DE           ; Restore STKEND value from stack.

        RET                ; Return.

```

```

; -----
; THE 'STORAGE OF NUMBERS IN 5 BYTE FORM'
; =====
; Both integers and floating-point numbers can be stored in five bytes.
; Zero is a special case stored as 5 zeros.
; For integers the form is
; Byte 1 - zero,
; Byte 2 - sign byte, $00 +ve, $FF -ve.
; Byte 3 - Low byte of integer.
; Byte 4 - High byte
; Byte 5 - unused but always zero.
;
; It seems unusual to store the low byte first but it is just as easy either
; way. Statistically it just increases the chances of trailing zeros which
; is an advantage elsewhere in saving ROM code.
;
;          zero      sign      low      high      unused
; So +1 is  00000000 00000000 00000001 00000000 00000000
;
; and -1 is 00000000 11111111 11111111 11111111 00000000
;
; much of the arithmetic found in BASIC lines can be done using numbers
; in this form using the Z80's 16 bit register operation ADD.
; (multiplication is done by a sequence of additions).
;
; Storing -ve integers in two's complement form, means that they are ready for
; addition and you might like to add the numbers above to prove that the
; answer is zero. If, as in this case, the carry is set then that denotes that
; the result is positive. This only applies when the signs don't match.
; With positive numbers a carry denotes the result is out of integer range.
; With negative numbers a carry denotes the result is within range.
; The exception to the last rule is when the result is -65536
;
; Floating point form is an alternative method of storing numbers which can
; be used for integers and larger (or fractional) numbers.
;
; In this form 1 is stored as
;          10000001 00000000 00000000 00000000 00000000
;
; When a small integer is converted to a floating point number the last two
; bytes are always blank so they are omitted in the following steps
;
; first make exponent +1 +16d (bit 7 of the exponent is set if positive)
;
; 10010001 00000000 00000001
; 10010000 00000000 00000010 <- now shift left and decrement exponent
;
; ...
; 10000010 01000000 00000000 <- until a 1 abuts the imaginary point
; 10000001 10000000 00000000 to the left of the mantissa.
;

```

```

; however since the leftmost bit of the mantissa is always set then it can
; be used to denote the sign of the mantissa and put back when needed by the
; PREP routines which gives
;
; 10000001 00000000 00000000

; -----
; THE 'RE-STACK TWO "SMALL" INTEGERS' SUBROUTINE
; -----
; This routine is called to re-stack two numbers in full floating point form
; e.g. from mult when integer multiplication has overflowed.

RE_ST_TWO CALL  RESTK_SUB      ; routine RESTK-SUB below and continue
; into the routine to do the other one.

RESTK_SUB EX   DE,HL          ; swap pointers and continue into same routine.

; -----
; THE 'RE-STACK ONE "SMALL" INTEGER' SUBROUTINE
; -----
; (offset: $3D 're-stack')
; This routine re-stacks an integer, usually on the calculator stack, in full
; floating point form. HL points to the first byte.

re_stack LD    A,(HL)         ; Fetch Exponent byte to A
        AND   A              ; test it
        RET   NZ             ; return if first byte is not zero as number
; is already in floating-point form.

        PUSH  DE             ; preserve DE.

        CALL  INT_FETCH      ; routine INT-FETCH integer to DE, sign to C.

; Note. the above routine returns HL pointing to 4th byte.

        XOR   A              ; clear the accumulator.

; Note. The fifth byte of an integer is always zero for neatness so the next
; step is, I imagine, unnecessary.

;;;      INC   HL             ; point to 5th.
;;;      LD   (HL),A          ; and blank.
;;;      DEC   HL             ; point to 4th.

        LD   (HL),A          ; blank the 4th byte.

        LD   B,$91           ; set exponent byte +ve $81.
; and imaginary radix point 16 bits to right
; of first bit.

; we could skip to normalize now but it's quicker to avoid normalizing
; through an empty D.

        LD   A,D             ; fetch the high order byte D
        AND  A              ; is it zero ?
        JR   NZ,RS_NRMLSE   ; skip, if not, to RS-NRMLSE

; Check if the number is zero in which case no modification is required.
; However, by updating first three bytes we convert minus zero to plus
; zero although I'm not sure if it can arise. It is eliminated in mult.

        OR   E              ; Fetch low byte E to A and test for zero.
        LD   B,D            ; set B, the exponent, to 0
        JR   Z,RS_STORE     ; forward, if value is zero, to RS-STORE

```

```

; Move the significant bits eight places to the left.

        LD    D,E          ; transfer E to D
        LD    E,B          ; set E to 0
        LD    B,$89        ; reduce the initial exponent by eight.

RS_NRMLSE EX    DE,HL      ; integer to HL, addr of 4th byte to DE.

RSTK_LOOP DEC   B          ; decrease exponent
        ADD   HL,HL        ; shift HL left
        JR    NC,RSTK_LOOP ; loop back to RSTK-LOOP
                        ; until a set bit pops into carry

        RRC   C            ; Now rotate the sign byte $00 or $FF
                        ; into carry to give a sign bit.

        RR   H            ; rotate the sign bit to left of H
        RR   L            ; rotate any carry into L

        EX   DE,HL        ; address 4th byte, normalized int to DE

RS_STORE DEC   HL         ; address 3rd byte
        LD   (HL),E        ; place E
        DEC  HL           ; address 2nd byte
        LD   (HL),D        ; place D
        DEC  HL           ; address 1st byte
        LD   (HL),B        ; store the exponent

; Register HL now points at result.

        POP   DE          ; restore initial DE.
        RET                    ; return.

;*****
;** Part 10. FLOATING-POINT CALCULATOR **
;*****

; As a general rule the calculator avoids using the IY register.
; Exceptions are val, val$ and str$.
; So an assembly language programmer who has disabled interrupts to use IY
; for other purposes can still use the calculator for mathematical purposes.

; -----
; THE 'TABLE OF CONSTANTS'
; -----
; These five constants are now held in full five byte integer or
; floating-point form as it makes it much easier to pass them to the
; calculator stack when required.

;;; used 11 times
;;; stk-zero                                00 00 00 00 00
;;; L32C5:  DEFB  $00          ;;Bytes: 1
;;;         DEFB  $B0          ;;Exponent $00
;;;         DEFB  $00          ;; (+00,+00,+00)

;;; used 19 times
;;; stk-one                                00 00 01 00 00
;;; L32C8:  DEFB  $40          ;;Bytes: 2
;;;         DEFB  $B0          ;;Exponent $00
;;;         DEFB  $00,$01      ;; (+00,+00)

```



```

;;; used 9 times
;;; stk-half                                     80 00 00 00 00
;;; L32CC:    DEFB  $30                          ;;Exponent: $80, Bytes: 1
;;;          DEFB  $00                          ;; (+00,+00,+00)

;;; used 4 times.
;;; stk-pi/2                                     81 49 0F DA A2
;;; L32CE:    DEFB  $F1                          ;;Exponent: $81, Bytes: 4
;;;          DEFB  $49,$0F,$DA,$A2 ;;

;;; used 3 times.
;;; stk-ten                                       00 00 0A 00 00
;;; L32D3:    DEFB  $40                          ;;Bytes: 2
;;;          DEFB  $B0                          ;;Exponent $00
;;;          DEFB  $00,$0A                      ;; (+00,+00)

TAB_CNST  DEFB  $00                          ;+ the value zero.
          DEFB  $00                          ;+
          DEFB  $00                          ;+
          DEFB  $00                          ;+
          DEFB  $00                          ;+

          DEFB  $00                          ;+ the integer value 1.
          DEFB  $00                          ;+
          DEFB  $01                          ;+
          DEFB  $00                          ;+
          DEFB  $00                          ;+

          DEFB  $80                          ;+ the floating point value a half.
          DEFB  $00                          ;+
          DEFB  $00                          ;+
          DEFB  $00                          ;+
          DEFB  $00                          ;+

          DEFB  $81                          ;+ the floating point value pi/2
          DEFB  $49                          ;+
          DEFB  $0F                          ;+
          DEFB  $DA                          ;+
          DEFB  $A2                          ;+

          DEFB  $00                          ;+ the integer value ten.
          DEFB  $00                          ;+
          DEFB  $0A                          ;+
          DEFB  $00                          ;+
          DEFB  $00                          ;+

; -----
; THE 'TABLE OF ADDRESSES'
; -----
;
; Starts with binary operations which have two operands and one result.
; Three pseudo binary operations first.

tbl_addr  DEFW  jump_true                    ; $00 Address: $368F - jump-true
          DEFW  exchange                    ; $01 Address: $343C - exchange
          DEFW  delete                      ; $02 Address: $33A1 - delete

; True binary operations.

          DEFW  subtract                    ; $03 Address: $300F - subtract
          DEFW  multiply                    ; $04 Address: $30CA - multiply
          DEFW  division                    ; $05 Address: $31AF - division
          DEFW  to_power                    ; $06 Address: $3851 - to-power

```

```

DEFW or ; $07 Address: $351B - or

DEFW no_v_no ; $08 Address: $3524 - no-&-no
DEFW multcmp ; $09 Address: $353B - no-l-eql
DEFW multcmp ; $0A Address: $353B - no-gr-eql
DEFW multcmp ; $0B Address: $353B - nos-neql
DEFW multcmp ; $0C Address: $353B - no-grtr
DEFW multcmp ; $0D Address: $353B - no-less
DEFW multcmp ; $0E Address: $353B - nos-eql
DEFW addition ; $0F Address: $3014 - addition

DEFW str_v_no ; $10 Address: $352D - str-&-no
DEFW multcmp ; $11 Address: $353B - str-l-eql
DEFW multcmp ; $12 Address: $353B - str-gr-eql
DEFW multcmp ; $13 Address: $353B - str-neql
DEFW multcmp ; $14 Address: $353B - str-grtr
DEFW multcmp ; $15 Address: $353B - str-less
DEFW multcmp ; $16 Address: $353B - str-eql
DEFW str_add ; $17 Address: $359C - str-add

```

; Unary follow.

```

DEFW val_s ; $18 Address: $35DE - val$
DEFW usr_str ; $19 Address: $34BC - usr-$
DEFW read_in ; $1A Address: $3645 - read-in
DEFW negate ; $1B Address: $346E - negate

DEFW code ; $1C Address: $3669 - code
DEFW val ; $1D Address: $35DE - val
DEFW len ; $1E Address: $3674 - len
DEFW sin ; $1F Address: $37B5 - sin
DEFW cos ; $20 Address: $37AA - cos
DEFW tan ; $21 Address: $37DA - tan
DEFW asn ; $22 Address: $3833 - asn
DEFW acs ; $23 Address: $3843 - acs
DEFW atn ; $24 Address: $37E2 - atn
DEFW ln ; $25 Address: $3713 - ln
DEFW exp ; $26 Address: $36C4 - exp
DEFW int ; $27 Address: $36AF - int
DEFW sqr ; $28 Address: $384A - sqr
DEFW sgn ; $29 Address: $3492 - sgn
DEFW abs ; $2A Address: $346A - abs
DEFW peek ; $2B Address: $34AC - peek
DEFW in ; $2C Address: $34A5 - in
DEFW usr_no ; $2D Address: $34B3 - usr-no
DEFW str_s ; $2E Address: $361F - str$
DEFW chrs ; $2F Address: $35C9 - chrs
DEFW not ; $30 Address: $3501 - not

```

; End of true unary.

```

DEFW MOVE_FP ; $31 Address: $33C0 - duplicate
DEFW n_mod_m ; $32 Address: $36A0 - n-mod-m
DEFW JUMP ; $33 Address: $3686 - jump
DEFW stk_data ; $34 Address: $33C6 - stk-data
DEFW dec_jr_nz ; $35 Address: $367A - dec-jr-nz
DEFW less_0 ; $36 Address: $3506 - less-0
DEFW greater_0 ; $37 Address: $34F9 - greater-0
DEFW end_calc ; $38 Address: $369B - end-calc
DEFW get_argt ; $39 Address: $3783 - get-argt
DEFW truncate ; $3A Address: $3214 - truncate
DEFW fp_calc_2 ; $3B Address: $33A2 - fp-calc-2
DEFW E_TO_FP ; $3C Address: $2D4F - e-to-fp
DEFW re_stack ; $3D Address: $3297 - re-stack

```

```

; The following are just the next available slots for the 128 compound
; literals which are in range $80 - $FF.

        DEFW  seriesg_x      ; Address: $3449 - series-xx    $80 - $9F.
        DEFW  stk_con_x      ; Address: $341B - stk-const-xx $A0 - $BF.
        DEFW  sto_mem_x      ; Address: $342D - st-mem-xx    $C0 - $DF.
        DEFW  get_mem_x      ; Address: $340F - get-mem-xx   $E0 - $FF.

; Aside: 3E - 3F are therefore unused calculator literals.
; If the literal has to be also usable as a function then bits 6 and 7 are
; used to show type of arguments and result.

; -----
; THE 'CALCULATE' SUBROUTINE
; -----
;
;
CALCULATE CALL  STK_PNTRS      ; routine STK-PNTRS is called to set up the
                               ; calculator stack pointers for a default
                               ; unary operation. HL = last value on stack.
                               ; DE = STKEND first location after stack.

; the calculate routine is called at this point by the series generator...

GEN_ENT_1 LD    A,B           ; fetch the Z80 B register to A
          LD    ($5B67),A     ; and store value in system variable BREG.
                               ; this will be the counter for dec-jr-nz
                               ; or if used from fp-calc2 the calculator
                               ; instruction.

; ... and again later at this point

GEN_ENT_2 EXX                ; switch sets
          EX    (SP),HL      ; and store the address of next instruction,
                               ; the return address, in H'L'.
                               ; If this is a recursive call the H'L'
                               ; of the previous invocation goes on stack.
                               ; c.f. end-calc.
          EXX                ; switch back to main set

; this is the re-entry looping point when handling a string of literals.

RE_ENTRY LD    ($5B65),DE    ; save end of stack in system variable STKEND
          EXX                ; switch to alt
          LD    A,(HL)       ; get next literal
          INC   HL           ; increase pointer'

; single operation jumps back to here

SCAN_ENT PUSH  HL           ; save pointer on stack
          AND   A            ; now test the literal
          JP   P,FIRST_3D    ; forward to FIRST-3D if in range $00 - $3D
                               ; anything with bit 7 set will be one of
                               ; 128 compound literals.

; compound literals have the following format.
; bit 7 set indicates compound.
; bits 6-5 the subgroup 0-3.
; bits 4-0 the embedded parameter $00 - $1F.
; The subgroup 0-3 needs to be manipulated to form the next available four
; address places after the simple literals in the address table.

```

```

LD    D,A          ; save literal in D
AND   $60          ; and with 01100000 to isolate subgroup
RRCA          ; rotate bits
RRCA          ; 4 places to right
RRCA          ; not five as we need offset * 2
RRCA          ; 00000xx0
ADD   A,$7C        ; add ($3E * 2) to give correct offset.
                ; alter above if you add more literals.

LD    L,A          ; store in L for later indexing.
LD    A,D          ; bring back compound literal
AND   $1F          ; use mask to isolate parameter bits
JR    ENT_TABLE    ; forward to ENT-TABLE

; ---

; the branch was here with simple literals.

FIRST_3D CP    $18          ; compare with first unary operations.
JR    NC,DOUBLE_A    ; to DOUBLE-A with unary operations

; it is binary so adjust pointers.

EXX          ;

;;; LD    BC,$FFFB          ; the value -5
;;; LD    D,H              ; transfer HL, the last value, to DE.
;;; LD    E,L              ;
;;; ADD   HL,BC            ; subtract 5 making HL point to second value.

CALL   STK_PTRS2    ; Routine to perform the above.

EXX          ; switch to alternate set of registers.

DOUBLE_A RLCA          ; double the literal
LD    L,A           ; and store in L for indexing

ENT_TABLE LD    DE,tbl_addr ; Address: tbl-addr
LD    H,$00         ; prepare to index
ADD   HL,DE         ; add to point to address of routine

LD    E,(HL)        ; low byte of address to E
INC   HL            ;
LD    D,(HL)        ; high byte of address to D

LD    HL,RE_ENTRY   ; Address: RE-ENTRY
EX    (SP),HL       ; goes to stack and address of 'next literal'
                ; goes to HL'

PUSH  DE            ; now stack the address of the routine

EXX          ; switch back to 'main' set

; Avoid using the IY register.

LD    BC,($5B66)    ; STKEND_hi
                ; nothing much goes to C but BREG to B
                ; and continue into next ret instruction
                ; which has a dual identity

; -----
; THE 'DELETE' OPERATION
; -----
; (offset: $02 'delete')
; A simple return but when used as a calculator literal this

```

```

; deletes the last value from the calculator stack.
; On entry, as always with binary operations,
; HL = first number, DE = second number
; On exit, HL = result, DE = STKEND.
; So nothing to do

delete    RET                                ; return - indirect jump if from above.

; -----
; THE 'SINGLE OPERATION' ROUTINE
; -----
; (offset: $3B 'fp_calc2')
; This single operation is used, in the first instance, to evaluate most
; of the mathematical and string functions found in BASIC expressions.

fp_calc_2 POP    AF                          ; drop return address.
           LD     A,($5B67)                   ; load accumulator from system variable BREG
                                           ; value will be literal e.g. 'tan'
           EXX                                ; switch to alt
           JR     SCAN_ENT                    ; back to SCAN-ENT
                                           ; next literal will be end-calc at L2758

; -----
; THE 'TEST FIVE SPACES' SUBROUTINE
; -----
; This routine is called from MOVE-FP, STK-CONST and STK-STORE to test that
; there is enough space between the calculator stack and the machine stack
; for another five-byte value.

TEST_5_SP PUSH   DE                          ; preserve.
           PUSH  HL                          ; registers
           LD     BC,$0005                    ; an overhead of eighty five bytes

           CALL  TEST_ROOM                    ; routine TEST_ROOM checks space for 5 bytes.

           POP   HL                          ; (balance)
           POP   DE                          ;
           RET                                ; then return - OK.

; -----
; THE 'STACK NUMBER' SUBROUTINE
; -----
; This routine is called to stack a hidden floating point number found in
; a BASIC line. It is also called to stack a numeric variable value, and
; from BEEP, to stack an entry in the semi-tone table. It is not part of the
; calculator suite of routines. On entry, HL points to the number to be
; stacked.

STACK_NUM LD     DE,($5B65)                   ; Load destination from STKEND system variable.

           CALL  MOVE_FP                       ; Routine MOVE-FP puts on calculator stack
                                           ; with a memory check.
           LD     ($5B65),DE                   ; Set STKEND to next free location.

           RET                                ; Return.

; -----
; THE 'DUPLICATE' OPERATION
; -----
; (offset: $31 'duplicate')

; This simple routine is a 5-byte LDIR instruction
; that incorporates a memory check.
; When used as a calculator literal it duplicates the last value on the

```

```

; calculator stack.
; Unary so on entry HL points to last value, DE to STKEND

duplicate
MOVE_FP CALL TEST_5_SP ; routine TEST-5-SP test free memory
; and sets B to zero.
BLK_MV LDIR ; copy the five bytes.
RET ; return with DE addressing new STKEND
; and HL addressing new last value.

; -----
; THE 'STACK LITERALS' OPERATION
; -----
; (offset: $34 'stk_data')
; When a calculator subroutine needs to put a value on the calculator
; stack that is not a regular constant this routine is called with a
; variable number of following data bytes that convey to the routine
; the integer or floating point form as succinctly as is possible.

stk_data LD H,D ; transfer STKEND
LD L,E ; to HL for result.

STK_CONST CALL TEST_5_SP ; routine TEST-5-SP tests that room exists
; and sets BC to $05.

EXX ; switch to alternate set
PUSH HL ; save the pointer to next literal on stack
EXX ; switch back to main set

EX (SP),HL ; pointer to HL, destination to stack.

;;; PUSH BC ; save BC - value 5 from test room ??.

LD A,(HL) ; fetch the byte following 'stk-data'
AND $C0 ; isolate bits 7 and 6
RLCA ; rotate
RLCA ; to bits 1 and 0 range $00 - $03.
LD C,A ; transfer to C
INC C ; and increment to give the number of bytes
; to read. $01 - $04

LD A,(HL) ; reload the first byte
AND $3F ; mask off bits 5 - 0 to give possible exponent.
JR NZ,FORM_EXP ; Forward to FORM-EXP if it was possible to
; include the exponent and count in one byte.

; else byte is just a byte count and reduced exponent comes next.

INC HL ; address next byte and
LD A,(HL) ; pick up the exponent ( -$50 ).

FORM_EXP ADD A,$50 ; now add $50 to form actual exponent
LD (DE),A ; and load into first destination byte.
LD A,$05 ; load accumulator with $05 and
SUB C ; subtract C to give count of trailing
; zeros plus one.
INC HL ; increment source
INC DE ; increment destination
;;; LD B,$00 ; prepare to copy (B=0, fr test5sp)

LDIR ; copy C bytes

;;; POP BC ; restore 5 counter to BC ??.

EX (SP),HL ; put HL on stack as next literal pointer

```

```

; and the stack value - result pointer -
; to HL.

EXX          ; switch to alternate set.
POP  HL      ; restore next literal pointer from stack
              ; to H'L'.
EXX          ; switch back to main set.

LD  B,A      ; zero count to B
XOR A        ; clear accumulator

STK_ZEROS DEC B      ; decrement B counter
RET  Z        ; return if zero.          >>
              ; DE points to new STKEND
              ; HL to new number.

LD  (DE),A   ; else load zero to destination
INC DE       ; increase destination
JR  STK_ZEROS ; loop back to STK-ZEROS until done.

; -----
; THE REDUNDANT 'SKIP CONSTANTS' SUBROUTINE
; -----
; This routine traversed variable-length entries in the table of constants,
; stacking intermediate, unwanted constants onto a dummy calculator stack,
; in the first five bytes of ROM. The destination DE normally points to the
; end of the calculator stack which might be in the normal place or in the
; system variables area during E-LINE-NO; INT-TO-FP; stk-ten. In any case,
; it would be simpler all round if the routine just shoved unwanted values
; where it is going to stick the wanted value. The instruction LD DE, $0000
; can be removed.

;;; SKIP-CONS
;;; L33F7:  AND  A          ; test if initially zero.

;;; SKIP-NEXT
;;; L33F8:  RET  Z          ; return if zero.          >>

;;;          PUSH  AF      ; save count.
;;;          PUSH  DE      ; and normal STKEND

;;;          LD    DE,$0000 ; dummy value for STKEND at start of ROM
;;;          ; Note. not a fault but this has to be
;;;          ; moved elsewhere when running in RAM.
;;;          ; e.g. with Expandor Systems 'Soft ROM'.
;;;          ; Better still, write to the normal place.
;;;          CALL  STK_CONST ; routine STK-CONST works through variable
;;;          ; length records.

;;;          POP  DE      ; restore real STKEND
;;;          POP  AF      ; restore count
;;;          DEC  A        ; decrease
;;;          JR   SKIP_NEXT ; loop back to SKIP-NEXT

; -----
; THE 'LOCATE MEMORY' SUBROUTINE
; -----
; This routine, when supplied with a base address in HL and an index in A,
; will calculate the address of the A'th entry, where each entry occupies
; five bytes. It is used for reading the semi-tone table and addressing
; floating-point numbers in the calculator's memory area.
;;; It is not possible to use this routine for the table of constants as these
;;; six values are held in compressed format.

```

```

LOC_MEM  LD    C,A          ; store the original number $00-$1F.
         RLCA          ; X2 - double.
         RLCA          ; X4 - quadruple.
         ADD   A,C          ; X5 - now add original to multiply by five.

         LD    C,A          ; place the result in the low byte.
         LD    B,$00        ; set high byte to zero.
         ADD   HL,BC        ; add to form address of start of number in HL.

         RET             ; return.

```

```

; -----
; THE 'GET FROM MEMORY AREA' OPERATION
; -----
; Literals $E0 to $FF
; A holds $00-$1F offset.
; The calculator stack increases by 5 bytes.

```

```

get_mem_x LD    HL,($5B68)  ; MEM is base address of the memory cells.

INDEX_5  PUSH  DE          ; save STKEND

         CALL  LOC_MEM      ; routine LOC-MEM so that HL = first byte
         CALL  MOVE_FP      ; routine MOVE-FP moves 5 bytes with necessary
                           ; memory check.
                           ; DE now points to new STKEND.

         POP   HL          ; original STKEND is now RESULT pointer.
         RET             ; return.

```

```

; -----
; THE 'STACK A CONSTANT' OPERATION
; -----
; Offsets $A0 to $A4
; This routine allows a one-byte instruction to stack up to 32 constants
; held in short form in a table of constants. In fact only 5 constants are
; required. On entry the A register holds the literal ANDed with 1F.
;;; It isn't very efficient and it would have been better to hold the
;;; numbers in full, five byte form and stack them in a similar manner
;;; to that used for semi-tone table values.

```

```

stk_con_x LD    HL,TAB_CNST ; Address table of five byte expanded constants

         JR    INDEX_5     ; back to common code in routine above.

```

```

;;; stk-con-x
;;; L341B:  LD    H,D          ; save STKEND - required for result
;;;          LD    L,E          ;
;;;          EXX             ; swap
;;;          PUSH  HL          ; save pointer to next literal
;;;          LD    HL,TAB_CNST ; Address: stk-zero - start of table of
;;;                               ; constants
;;;          EXX             ;
;;;          CALL  SKIP_CONS   ; routine SKIP-CONS
;;;          CALL  STK_CONST   ; routine STK-CONST
;;;          EXX             ;
;;;          POP   HL          ; restore pointer to next literal.
;;;          EXX             ;
;;;          RET             ; return.

```

```

; -----
; THE 'STORE IN MEMORY' OPERATION
; -----
; Offsets $C0 to $DF

```



```

; Although 32 memory storage locations can be addressed, only six
; $C0 to $C5 are required by the ROM and only the thirty bytes (6*5)
; required for these are allocated. Spectrum programmers who wish to
; use the floating point routines from assembly language may wish to
; alter the system variable MEM to point to 160 bytes of RAM to have
; use the full range available.
; A holds the derived offset $00-$1F.
; This is a unary operation, so on entry HL points to the last value and DE
; points to STKEND.

```

```

sto_mem_x PUSH HL ; save the result pointer.
          EX DE,HL ; transfer to DE.
          LD HL,($5B68) ; fetch MEM the base of memory area.
          CALL LOC_MEM ; routine LOC-MEM sets HL to the destination.
          EX DE,HL ; swap - HL is start, DE is destination.
;;; CALL MOVE_FP ; routine MOVE-FP.
;;; ; Note. a short ld bc,5; ldir
;;; ; the embedded memory check is not required
;;; ; so these instructions would be faster.

          LD C,$05 ;+ Set number of bytes to five, B is zero.
          LDIR ;+ Block copy the bytes avoiding RAM check.

          EX DE,HL ; DE = STKEND
          POP HL ; restore original result pointer
          RET ; return.

```

```

; -----
; THE 'EXCHANGE' SUBROUTINE
; -----
; (offset: $01 'exchange')
; This routine swaps the last two values on the calculator stack.
; On entry, as always with binary operations,
; HL=first number, DE=second number
; On exit, HL=result, DE=STKEND.

```

```

exchange LD B,$05 ; there are five bytes to be swapped

; Start of loop.

SWAP_BYTE LD A,(DE) ; Each byte of second
;;; LD C,(HL) ; Each byte of first
;;; EX DE,HL ; Swap pointers
          LD C,A ;+
          LD A,(HL) ;+
          LD (DE),A ; Store each byte of first
          LD (HL),C ; Store each byte of second
          INC HL ; Advance both
          INC DE ; pointers.
          DJNZ SWAP_BYTE ; Loop back to SWAP-BYTE until all 5 done.

;;; EX DE,HL ; Even up the exchanges so that DE addresses
;;; ; system variable STKEND.

          RET ; Return.

```

```

; -----
; THE 'SERIES GENERATOR' ROUTINE
; -----
; (offset: $86 'series-06')
; (offset: $88 'series-08')
; (offset: $8C 'series-0C')
; The Spectrum uses Chebyshev polynomials to generate approximations for
; SIN, ATN, LN and EXP. These are named after the Russian mathematician

```

```

; Pafnuty Chebyshev, born in 1821, who did much pioneering work on numerical
; series. As far as calculators are concerned, Chebyshev polynomials have an
; advantage over other series, for example the Taylor series, as they can
; reach an approximation in just six iterations for SIN, eight for EXP and
; twelve for LN and ATN. The mechanics of the routine are interesting but
; for full treatment of how these are generated with demonstrations in
; Sinclair BASIC see "The Complete Spectrum ROM Disassembly" by Dr Ian Logan
; and Dr Frank O'Hara, published 1983 by Melbourne House.

```

```

seriesg_x LD    B,A                ; parameter $00 - $1F to B counter

        CALL   GEN_ENT_1          ; routine GEN-ENT-1 is called.
                                        ; A recursive call to a special entry point
                                        ; in the calculator that puts the B register
                                        ; in the system variable BREG. The return
                                        ; address is the next location and where
                                        ; the calculator will expect its first
                                        ; instruction - now pointed to by HL'.
                                        ; The previous pointer to the series of
                                        ; five-byte numbers goes on the machine stack.

```

```

; The initialization phase.

```

```

        DEFB   $31                ;;duplicate      x,x
        DEFB   $0F                ;;addition      x+x
        DEFB   $C0                ;;st-mem-0     x+x
        DEFB   $02                ;;delete      .
        DEFB   $A0                ;;stk-zero     0
        DEFB   $C2                ;;st-mem-2     0

```

```

; A loop is now entered to perform the algebraic calculation for each of
; the numbers in the series

```

```

G_LOOP  DEFB   $31                ;;duplicate      v,v.
        DEFB   $E0                ;;get-mem-0     v,v,x+2
        DEFB   $04                ;;multiply     v,v*x+2
        DEFB   $E2                ;;get-mem-2     v,v*x+2,v
        DEFB   $C1                ;;st-mem-1
        DEFB   $03                ;;subtract
        DEFB   $38                ;;end-calc

```

```

; The previous pointer is fetched from the machine stack to H'L' where it
; addresses one of the numbers of the series following the series literal.

```

```

        CALL   stk_data           ; routine STK-DATA is called directly to
                                        ; push a value and advance H'L'.
        CALL   GEN_ENT_2          ; routine GEN-ENT-2 recursively re-enters
                                        ; the calculator without disturbing
                                        ; system variable BREG
                                        ; H'L' value goes on the machine stack and is
                                        ; then loaded as usual with the next address.

```

```

        DEFB   $0F                ;;addition
        DEFB   $01                ;;exchange
        DEFB   $C2                ;;st-mem-2
        DEFB   $02                ;;delete

        DEFB   $35                ;;dec-jr-nz
        DEFB   G_LOOP - $         ;;back to G-LOOP

```

```

; When the counted loop is complete the final subtraction yields the result
; for example SIN X.

```

```

        DEFB   $E1                ;;get-mem-1

```

```

        DEFB $03          ;;subtract
        DEFB $38          ;;end-calc

        RET              ; return with H'L' pointing to location
                        ; after last number in series.

; -----
; THE 'ABSOLUTE MAGNITUDE' FUNCTION
; -----
; (offset: $2A 'abs')
; This calculator literal finds the absolute value of the last value,
; integer or floating point, on the calculator stack.

abs      LD      B,$FF          ; signal abs
        JR      NEG_TEST       ; forward to NEG-TEST

; -----
; THE 'UNARY MINUS' OPERATION
; -----
; (offset: $1B 'negate')
; e.g. LET balance = -2
; Unary, so on entry HL points to last value, DE to STKEND.

negate   CALL    TEST_ZERO      ; call routine TEST-ZERO and
        RET     C              ; return if so leaving zero unchanged.

        LD      B,$00          ; signal negate required before joining
        ; common code.

NEG_TEST LD      A,(HL)         ; load first byte and
        AND     A              ; test for zero which indicates a small integer.
        JR      Z,INT_CASE     ; forward, if so, to INT-CASE

; for the FLOATING POINT CASE a single bit denotes the sign.

        INC     HL              ; address the first byte of mantissa.
        LD      A,B            ; action flag $FF=abs, $00=neg.
        AND     $80            ; now      $80      $00
        OR      (HL)           ; sets bit 7 for abs

        RLA                    ; sets carry for abs and if number negative
        CCF                    ; complement carry flag
        RRA                    ; and rotate back in altering sign

        LD      (HL),A         ; put the altered adjusted number back
        DEC     HL              ; HL points to result
        RET                    ; return with DE unchanged

; ---

; for integer numbers an entire byte denotes the sign.

INT_CASE PUSH    DE            ; save STKEND.

        PUSH   HL              ; save pointer to the last value/result.

        CALL  INT_FETCH        ; routine INT-FETCH puts integer in DE
        ; and the sign in C.

        POP   HL              ; restore the result pointer.

        LD    A,B              ; $FF=abs, $00=neg
        OR    C                ; $FF for abs, no change neg
        CPL                    ; $00 for abs, switched for neg

```

```

        JR     INT_STO_2      ;+ Forward to similar code.

;;;     LD     C,A           ; transfer result to sign byte.
;;;     CALL  INT_STORE     ; routine INT-STORE to re-write the integer.
;;;     POP   DE            ; restore STKEND.
;;;     RET                      ; return.

; -----
; THE 'SIGNUM' FUNCTION
; -----
; (offset: $29 'sgn')
; This routine replaces the last value on the calculator stack,
; which may be in floating point or integer form, with the integer values
; zero if zero, with one if positive and with -minus one if negative.

sgn     CALL  TEST_ZERO     ; call routine TEST-ZERO and
        RET   C             ; exit if zero as no change is required.

        PUSH  DE           ; save pointer to STKEND.

        LD   DE,$0001     ; the result will be 1.
        INC  HL           ; skip over the exponent.
        RL   (HL)        ; rotate the sign bit into the carry flag.
        DEC  HL           ; step back to point to the result.
        SBC  A,A         ; byte will be $FF if negative, $00 if positive.

INT_STO_2 LD   C,A        ; store the sign byte in the C register.

INT_STO_3 CALL INT_STORE  ; routine INT-STORE to overwrite the last
                        ; value with 0001 and sign.

        POP   DE           ; restore STKEND.
        RET                      ; return.

; -----
; THE 'IN' FUNCTION
; -----
; (offset: $2C 'in')
; This function reads a byte from an input port.

in      CALL  FIND_INT2    ; Routine FIND-INT2 puts port address in BC.
                        ; All 16 bits are put on the address line.

        IN   A,(C)        ; Read the port.

        JR   IN_PK_STK    ; exit to STACK-A (via IN-PK-STK to save a byte
                        ; of instruction code).

; -----
; THE 'PEEK' FUNCTION
; -----
; (offset: $2B 'peek')
; This function returns the contents of a memory address.
; The entire address space can be examined including the ROM.

peek    CALL  FIND_INT2    ; routine FIND-INT2 puts the address in BC.
        LD   A,(BC)       ; load the contents into A register.

IN_PK_STK JP   STACK_A    ; exit via STACK-A to put the value on the
                        ; calculator stack.

; -----
; THE 'USR' FUNCTION

```

```

; -----
; (offset: $2d 'usr-no')
; The USR function followed by a number 0-65535 is the method by which
; the Spectrum invokes machine code programs. This function returns the
; contents of the BC register pair.
; Note. that STACK-BC re-initializes the IY register if a user-written
; program has altered it.

usr_no    CALL    FIND_INT2        ; routine FIND-INT2 to fetch the
; supplied address into BC.

        LD      HL,STK_BC_IY      ; NEW address: STK_BC_IY is
        PUSH   HL                ; pushed onto the machine stack.
        PUSH   BC                ; then the address of the machine code
; routine.

        RET                    ; make an indirect jump to the routine
; and, hopefully, to STACK-BC also.

; -----
; THE 'USR STRING' FUNCTION
; -----
; (offset: $19 'usr-$')
; The user function with a one-character string argument, calculates the
; address of the User Defined Graphic character that is in the string.
; As an alternative, the ASCII equivalent, upper or lower case,
; may be supplied. This provides a user-friendly method of redefining
; the 21 User Definable Graphics e.g.
; POKE USR "a", BIN 10000000 will put a dot in the top left corner of the
; character 144.
; Note. the curious double check on the range. With 26 UDGs the first check
; only is necessary. With anything less the second check only is required.
; It is highly likely that the first check was written by Steven Vickers.

usr_str
;;;     CALL    STK_FETCH          ; routine STK-FETCH fetches the string
;;;                                     ; parameters.
;;;     DEC     BC                ; decrease BC by
;;;     LD      A,B              ; one to test
;;;     OR      C                ; the length.
;;;     JR      NZ,REPORT_A      ; to REPORT-A if not a single character.
;;;
;;;     LD      A,(DE)           ; fetch the character

        CALL   EXPT_SPEC        ;+ fetch a single char

        CALL   ALPHA            ; routine ALPHA sets carry if 'A-Z' or 'a-z'.
        JR     C,USR_RANGE      ; forward, if ASCII, to USR-RANGE

        SUB    $90              ; make UDGs range 0-20d
        JR     C,REPORT_A      ; to REPORT-A if too low. e.g. usr " ".

;;;     CP     $15              ; Note. this test is not necessary.
;;;     JR     NC,REPORT_A      ; to REPORT-A if higher than 20.

        INC    A                ; make range 1-21d to match LSBs of ASCII

USR_RANGE DEC    A              ; make range of bits 0-4 start at zero
        ADD    A,A              ; multiply by eight
        ADD    A,A              ; and lose any set bits
        ADD    A,A              ; range now 0 - 25*8
        CP     $A8              ; compare to 21*8
        JR     NC,REPORT_A      ; to REPORT-A if originally higher
; than 'U','u' or graphics U.

```

```

        LD     BC,($5B7B)      ; fetch the UDG system variable value.
        ADD    A,C             ; add the offset to character
        LD     C,A            ; and store back in register C.
        JR     NC,USR_STACK   ; forward to USR-STACK if no overflow.

        INC    B              ; increment high byte.

USR_STACK JP     STACK_BC     ; jump back and exit via STACK-BC to store
; ---

REPORT_A  RST    30H          ; ERROR-1
          DEFB   $09          ; Error Report: Invalid argument

; -----
; THE 'TEST FOR ZERO' SUBROUTINE
; -----
; Test if top value on calculator stack is zero. The carry flag is set if
; the last value is zero but no registers are altered. All five bytes will
; be zero but only the first four bytes need be tested.
; On entry, HL points to the exponent the first byte of the value.

TEST_ZERO PUSH   HL          ; preserve HL which is used to address.
          PUSH   BC          ; preserve BC which is used as a store.

          LD     B,A          ; preserve A in B.

          LD     A,(HL)       ; load first byte to accumulator
          INC    HL           ; advance.
          OR     (HL)         ; OR with second byte and clear carry.
          INC    HL           ; advance.
          OR     (HL)         ; OR with third byte.
          INC    HL           ; advance.
          OR     (HL)         ; OR with fourth byte setting zero flag.

          LD     A,B          ; restore A without affecting flags.
          POP    BC          ; restore the saved
          POP    HL          ; registers.

          RET    NZ          ; return if not zero and with carry reset.

          SCF                ; set the carry flag.
          RET                ; return with carry set if zero.

; -----
; THE 'GREATER THAN ZERO' OPERATOR
; -----
; (offset: $37 'greater-0' )
; Test if the last value on the calculator stack is greater than zero.
; This routine is also called directly from the end-tests of the comparison
; routine.

greater_0 CALL   TEST_ZERO   ; routine TEST-ZERO
          RET    C            ; return if was zero as this
                              ; is also the Boolean 'false' value.

          LD     A,$FF        ; prepare XOR mask for sign bit
          JR     SIGN_TO_C    ; forward to SIGN-TO-C
                              ; to put sign in carry
                              ; (carry will become set if sign is positive)
                              ; and then overwrite location with 1 or 0
                              ; as appropriate.

```

```

; -----
; THE 'NOT' FUNCTION
; -----
; (offset: $30 'not')
; This overwrites the last value with 1 if it was zero else with zero
; if it was any other value.
;
; e.g. NOT 0 returns 1, NOT 1 returns 0, NOT -3 returns 0.
;
; The subroutine is also called directly from the end-tests of the comparison
; operator.

not      CALL  TEST_ZERO      ; routine TEST-ZERO sets carry if zero

        JR    FP_0_1        ; to FP-0/1 to overwrite operand with
                            ; 1 if carry is set else to overwrite with zero.

; -----
; THE 'LESS THAN ZERO' OPERATION
; -----
; (offset: $36 'less-0' )
; Destructively test if last value on calculator stack is less than zero.
; Bit 7 of the second byte will be set if it is. This will either be the
; first bit of a 32-bit mantissa or part of the sign byte if an integer.

less_0   XOR   A            ; set XOR mask to zero
                            ; (carry will become set if sign is negative).

; transfer sign of mantissa to Carry Flag.

SIGN_TO_C INC   HL          ; address 2nd byte.
          XOR   (HL)        ; bit 7 of HL will be set if number is negative.
          DEC   HL          ; address 1st byte again.
          RLCA             ; rotate bit 7 of A to carry.

; -----
; THE 'ZERO OR ONE' SUBROUTINE
; -----
; This routine places an integer value of zero or one at the addressed
; location of the calculator stack or MEM area. The value one is written if
; carry is set on entry else zero.

FP_0_1   PUSH  HL          ; save pointer to the first byte
          LD   A,$00        ; load accumulator with zero - without
                            ; disturbing flags.
          LD   (HL),A       ; zero to first byte
          INC  HL          ; address next
          LD   (HL),A       ; zero to 2nd byte
          INC  HL          ; address low byte of integer
          RLA             ; carry to bit 0 of A
          LD   (HL),A       ; load one or zero to low byte.
          RRA             ; restore zero to accumulator.
          INC  HL          ; address high byte of integer.
          LD   (HL),A       ; put a zero there.
          INC  HL          ; address fifth byte.
          LD   (HL),A       ; put a zero there for neatness.

          POP  HL          ; restore pointer to the first byte.
          RET              ; return.

; -----
; THE 'OR' OPERATOR
; -----
; (offset: $07 'or' )

```

```

; The Boolean OR operator. e.g. X OR Y
; The result is zero if both values are zero else a non-zero value.
;
; e.g.    0 OR 0  returns 0.
;        -3 OR 0  returns -3.
;         0 OR -3 returns 1.
;        -3 OR 2  returns 1.
;
; A binary operation.
; On entry HL points to first operand (X) and DE to second operand (Y).

or      EX    DE,HL          ; make HL point to second number

        CALL  TEST_ZERO     ; routine TEST-ZERO

        EX    DE,HL          ; restore pointers
        RET   C              ; return if result was zero - first operand,
                               ; now the last value, is the result.

        SCF                    ; set carry flag
        JR    FP_0_1          ; back to FP-0/1 to overwrite the first operand
                               ; with the value 1.

; -----
; THE 'NUMBER AND NUMBER' OPERATION
; -----
; (offset: $08 'no-&-no')
; The Boolean AND operator.
;
; e.g.    -3 AND 2  returns -3.
;         -3 AND 0  returns 0.
;          0 and -2 returns 0.
;          0 and 0  returns 0.
;
; Compare with OR routine above.

no_v_no EX    DE,HL          ; make HL address second operand.

        CALL  TEST_ZERO     ; routine TEST-ZERO sets carry if zero.

        EX    DE,HL          ; restore pointers.
        RET   NC             ; return if second non-zero, first is result.

;

        AND   A              ; else clear carry.
        JR    FP_0_1          ; back to FP-0/1 to overwrite first operand
                               ; with zero for return value.

; -----
; THE 'STRING AND NUMBER' OPERATION
; -----
; (offset: $10 'str-&-no')
; e.g. "You Win" AND score>99 will return the string if condition is true
; or the null string if false.

str_v_no EX    DE,HL          ; make HL point to the number.

        CALL  TEST_ZERO     ; routine TEST-ZERO.

        EX    DE,HL          ; Restore the two pointers.
        RET   NC             ; Return if number was not zero - the string
                               ; is the result.

```



```
; If the number was zero (false) then the null string must be returned by
; altering the length of the string on the calculator stack to zero.
```

```
;;;      PUSH  DE                ; save pointer to the now obsolete number
;;;      ; (which will become the new STKEND)

      DEC  DE                ; point to the 5th byte of string descriptor.
      XOR  A                  ; clear the accumulator.
      LD   (DE),A            ; place zero in high byte of length.
      DEC  DE                ; address low byte of length.
      LD   (DE),A            ; place zero there - now the null string.

;;;      POP   DE                ; restore pointer - new STKEND.

      INC  DE                ;+ Restore DE using two increments which
      INC  DE                ;+ is quicker than using the machine stack.

      RET                     ; return.
```

```
; -----
; THE 'COMPARISON' OPERATIONS
; -----
```

```
; (offset: $0A 'no-gr-eql')
; (offset: $0B 'nos-neql')
; (offset: $0C 'no-grtr')
; (offset: $0D 'no-less')
; (offset: $0E 'nos-eql')
; (offset: $11 'str-l-eql')
; (offset: $12 'str-gr-eql')
; (offset: $13 'strs-neql')
; (offset: $14 'str-grtr')
; (offset: $15 'str-less')
; (offset: $16 'strs-eql')
```

```
; True binary operations.
; A single entry point is used to evaluate six numeric and six string
; comparisons. On entry, the calculator literal is in the B register and
; the two numeric values, or the two string parameters, are on the
; calculator stack.
; The individual bits of the literal are manipulated to group similar
; operations although the SUB 8 instruction does nothing useful and merely
; alters the string test bit.
; Numbers are compared by subtracting one from the other, strings are
; compared by comparing every character until a mismatch, or the end of one
; or both, is reached.
```

```
; Numeric Comparisons.
```

```
; -----
; The 'x>y' example is the easiest as it employs straight-thru logic.
; Number y is subtracted from x and the result tested for greater-0 yielding
; a final value 1 (true) or 0 (false).
; For 'x<y' the same logic is used but the two values are first swapped on the
; calculator stack.
; For 'x=y' NOT is applied to the subtraction result yielding true if the
; difference was zero and false with anything else.
; The first three numeric comparisons are just the opposite of the last three
; so the same processing steps are used and then a final NOT is applied.
```

	NO																		
; literal	Test	No	[sub 8]	ExOrNot	1st RRCA	exch	sub	?	End-Tests										
=====	=====	==	=====	===	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====	=====
; no-l-eql	x<=y	09	00001001	dec	00001000	00000100	----	x-y	?	---	>0?	NOT							
; no-gr-eql	x>=y	0A	00001010	dec	00001001	10000100c	swap	y-x	?	---	>0?	NOT							
; nos-neql	x<>y	0B	00001011	dec	00001010	00000101	----	x-y	?	NOT	---	NOT							

```

; no-grtr    x>y    0C 00001100 - 00001100 00000110 ---- x-y ? --- >0? ---
; no-less   x<y    0D 00001101 - 00001101 10000110c swap y-x ? --- >0? ---
; nos-eql   x=y    0E 00001110 - 00001110 00000111 ---- x-y ? NOT --- ---
;
;
;                                     comp -> C/F
;                                     =====
; str-l-eql  x$<=y$ 11 00010001 dec 00010000 00001000 ---- x$y$ 0 !or >0? NOT
; str-gr-eql x$>=y$ 12 00010010 dec 00010001 10001000c swap y$x$ 0 !or >0? NOT
; str-neql   x$<>y$ 13 00010011 dec 00010010 00001001 ---- x$y$ 0 !or >0? NOT
; str-grtr   x$>y$  14 00010100 - 00010100 00001010 ---- x$y$ 0 !or >0? ---
; str-less   x$<y$  15 00010101 - 00010101 10001010c swap y$x$ 0 !or >0? ---
; str-eql    x$=y$  16 00010110 - 00010110 00001011 ---- x$y$ 0 !or >0? ---
;
; String comparisons are a little different in that the eql/neql carry flag
; from the 2nd RRCA is, as before, fed into the first of the end tests but
; along the way it gets modified by the comparison process. The result on the
; stack always starts off as zero and the carry fed in determines if NOT is
; applied to it. So the only time the greater-0 test is applied is if the
; stack holds zero which is not very efficient as the test will always yield
; zero. The most likely explanation is that there were once separate end tests
; for numbers and strings.

multcmp    LD      A,B          ; transfer literal to accumulator.

;;;       SUB      $08          ; subtract eight - which is not useful.

          BIT      2,A          ; isolate '>', '<', '='.

          JR      NZ,EX_OR_NOT  ; skip to EX-OR-NOT with these.

          DEC     A             ; else make $00-$02, $08-$0A to match bits 0-2.

EX_OR_NOT RRCA                ; the first RRCA sets carry for a swap.
          JR      NC,NU_OR_STR  ; forward to NU-OR-STR with other 8 cases

; for the other 4 cases the two values on the calculator stack are exchanged.

          PUSH   AF             ; save A and carry.
          PUSH   HL             ; save HL - pointer to first operand.
                                ; (DE points to second operand).

          CALL   exchange       ; routine exchange swaps the two values.
                                ; (HL = second operand, DE = STKEND)

          POP    DE             ; DE = first operand
          EX     DE,HL          ; as we were.
          POP    AF             ; restore A and carry.

NU_OR_STR RRCA                ;+ causes 'eql'/'neql' to set carry.
          PUSH   AF             ;+ save carry flag.

; Note. it would be better if the 2nd RRCA preceded the string test.
; It would save two duplicate bytes and if we also got rid of that sub 8
; at the beginning we wouldn't have to alter which bit we test.

          BIT    2,A           ; test if a string comparison.
          JR    NZ,STRINGS     ; forward, if so, to STRINGS

; continue with numeric comparisons.

;;;       RRCA                ; 2nd RRCA causes eql/neql to set carry.

;;;       PUSH   AF           ; save A and carry

```

```

        CALL subtract      ; routine subtract leaves result on stack.
        JR   END_TESTS    ; forward to END-TESTS

; ---

;;;      RRCA              ; 2nd RRCA causes eql/neql to set carry.

;;;      PUSH  AF          ; save A and carry.

STRINGS  CALL  STK_FETCH   ; routine STK-FETCH gets 2nd string params
          PUSH  DE          ; save start2 *.
          PUSH  BC          ; and the length.

          CALL  STK_FETCH   ; routine STK-FETCH gets 1st string
          ; parameters - start in DE, length in BC.
          POP   HL          ; restore length of second to HL.

;   A loop is now entered to compare, by subtraction, each corresponding
;   character of the strings. For each successful match, the pointers are
;   incremented and the lengths decreased and the branch taken back to here.
;   If both string remainders become null at the same time, then an exact
;   match exists.

BYTE_COMP LD   A,H        ; test if the second string
          OR   L           ; is the null string and hold flags.

          EX   (SP),HL     ; put length2 on stack, bring start2 to HL *.
          LD   A,B         ; hi byte of length1 to A

          JR   NZ,SEC_PLUS ; forward to SEC-PLUS if second not null.

          OR   C           ; test length of first string.

SECND_LOW POP  BC         ; pop the second length off stack.
          JR   Z,BOTH_NULL ; forward to BOTH-NULL if first string is also
          ; of zero length.

;   the true condition - first is longer than second (SECND-LESS)

          POP  AF          ; restore carry (set if eql/neql)
          CCF              ; complement carry flag.
          ; Note. equality becomes false.
          ; Inequality is true. By swapping or applying
          ; a terminal 'not', all comparisons have been
          ; manipulated so that this is success path.
          JR   STR_TEST    ; forward to leave via STR-TEST

; ---
;   the branch was here with a match

BOTH_NULL POP  AF          ; restore carry - set for eql/neql
          JR   STR_TEST    ; forward to STR-TEST

; ---
;   the branch was here when 2nd string not null and low byte of first is yet
;   to be tested.

SEC_PLUS  OR   C           ; test the length of first string.
          JR   Z,FRST_LESS ; forward to FRST-LESS if length is zero.

;   both strings have at least one character left.

          LD   A,(DE)      ; fetch character of first string.

```

```

SUB    (HL)                ; subtract with that of 2nd string.
JR     C,FRST_LESS        ; forward to FRST-LESS if carry set

JR     NZ,SECND_LOW       ; back to SECND-LOW and then STR-TEST
                        ; if not exact match.

DEC    BC                 ; decrease length of 1st string.
INC    DE                 ; increment 1st string pointer.

INC    HL                 ; increment 2nd string pointer.
EX     (SP),HL            ; swap with length on stack
DEC    HL                 ; decrement 2nd string length
JR     BYTE_COMP          ; back to BYTE-COMP

; ---
;   the false condition.

FRST_LESS POP    BC        ; discard length
        POP     AF        ; pop A
        AND    A          ; clear the carry for false result.

; ---
;   exact match and x$>y$ rejoin here

STR_TEST  PUSH   AF        ; save A and carry

        RST    28H        ;; FP-CALC
        DEFB  $A0        ;;stk-zero      an initial false value.
        DEFB  $38        ;;end-calc

;   both numeric and string paths converge here.

END_TESTS POP    AF        ; pop carry - will be set if eql/neql
        PUSH   AF        ; save it again.

        CALL  C,not        ; routine NOT sets true(1) if equal(0)
                        ; or, for strings, applies true result.

        POP    AF        ; pop carry and
        PUSH   AF        ; save A

        CALL  NC,greater_0 ; routine GREATER-0 tests numeric subtraction
                        ; result but also needlessly tests the string
                        ; value for zero - it must be.

        POP    AF        ; pop A
        RRCA          ; the third RRCA - test for '<=', '>=' or '<>'.

        CALL  NC,not        ; if comparison then apply a terminal NOT

        RET              ; return.

; -----
; THE 'STRING CONCATENATION' OPERATION
; -----
; (offset: $17 'strs-add')
; This literal combines two strings into one e.g. LET a$ = b$ + c$
; The two parameters of the two strings to be combined are on the stack.

strs_add  CALL    STK_FETCH ; routine STK-FETCH fetches string parameters
                        ; and deletes calculator stack entry.
        PUSH   DE        ; save start address.
        PUSH   BC        ; and length.

```

```

CALL STK_FETCH      ; routine STK-FETCH for the first string

POP  HL             ; re-fetch first length
PUSH HL            ; and save again

PUSH DE            ; save start of second string
PUSH BC            ; and its length.

ADD  HL,BC          ; add the two lengths.
LD   B,H           ; transfer result to BC
LD   C,L           ;

CALL BC_SPACES     ; routine BC_SPACES creates room in workspace.
                        ; DE points to start of space.

CALL STK_STO_s     ; routine STK-STO-$ stores parameters
                        ; of new string updating STKEND.

POP  BC            ; length of first
POP  HL            ; address of start

;;; LD   A,B        ; test for
;;; OR   C          ; zero length.
;;; JR   Z,OTHER_STR ; to OTHER-STR if null string
;;; LDIR                ; copy the first string to workspace.

CALL COND_MV       ; A three-byte call to ldir saves a byte.

OTHER_STR POP  BC   ; now second length
          POP  HL   ; and start of string

;;; LD   A,B        ; test this one
;;; OR   C          ; for zero length
;;; JR   Z,STK_PNTRS ; skip forward to STK-PNTRS if so as complete.
;;; LDIR                ; else copy the bytes.

CALL COND_MV       ; A three-byte call to ldir saves a byte.

; Continue into next routine which sets the calculator stack pointers.

; -----
; THE 'SET STACK POINTERS' SUBROUTINE
; -----
; Register DE is set to STKEND and HL, the result pointer, is set to five
; locations below this.
; This routine is used when it is inconvenient to save these values at the
; time the calculator stack is manipulated due to other activity on the
; machine stack.
; This routine is also used to terminate the VAL and READ-IN routines for
; the same reason and to initialize the calculator stack at the start of
; the CALCULATE routine.

STK_PNTRS LD   HL,($5B65) ; fetch STKEND value from system variable.

;;; LD   DE,$FFFB        ; the value -5
;;; PUSH HL              ; push STKEND value.
;;; ADD  HL,DE           ; subtract 5 from HL.
;;; POP  DE              ; pop STKEND to DE.

STK_PTRS2 LD   D,H       ; transfer to DE
          LD   E,L       ;
          DEC  HL        ; Make HL 5 locations lower.
          DEC  HL        ;
          DEC  HL        ;

```

```

        DEC    HL            ;
        DEC    HL            ;
        RET                                ; return.

; -----
; THE 'CHR$' FUNCTION
; -----
; (offset: $2f 'chr$')
; This function returns a single character string that is a result of
; converting a number in the range 0-255 to a string e.g. CHR$ 65 = "A".

chr$    CALL   FP_TO_A        ; routine FP-TO-A puts the number in A.

        JR    C,REPORT_Bd    ; forward to REPORT-Bd if overflow
        JR    NZ,REPORT_Bd   ; forward to REPORT-Bd if negative

;;;     PUSH   AF            ; save the argument.

;;;     LD     BC,$0001      ; one space required.

        CALL  BC_SPACE1      ; BC_SPACE1 makes DE point to start

;;;     POP   AF            ; restore the number.

        LD    (DE),A         ; and store in workspace
        JR    str_STK        ;+ forward to similar code.

;;;     CALL  STK_STO_$     ; routine STK-STO-$ stacks descriptor.
;;;     EX   DE,HL         ; make DE point to STKEND.
;;;     RET                                ; return.

; ---

REPORT_Bd RST    30H        ; ERROR-1
          DEFB   $0A        ; Error Report: Integer out of range

; -----
; THE 'VAL and VAL$' FUNCTIONS
; -----
; (offset: $1d 'val')
; (offset: $18 'val$')
; VAL treats the characters in a string as a numeric expression.
; e.g. VAL "2.3" = 2.3, VAL "2+4" = 6, VAL ("2" + "4") = 24.
;
; VAL$ treats the characters in a string as a string expression.
; e.g. VAL$ (z$+"(2)") = a$(2) if z$ happens to be "a$".

val

val_s    RST    18H        ;;;
;;;     LD    HL,($5B5D)    ; fetch value of system variable CH_ADD
          PUSH  HL         ; and save on the machine stack.
          LD    A,B         ; fetch the literal (either $1D or $18).
          ADD  A,$E3        ; add $E3 to form $00 (setting carry) or $FB.
          SBC  A,A         ; now form $FF bit 6 = numeric result
          ; or $00 bit 6 = string result.
          PUSH AF          ; save this mask on the stack

          CALL  STK_FETCH   ; routine STK-FETCH fetches the string operand
          ; from the calculator stack.

          PUSH DE          ; save the address of the start of the string.
          INC  BC          ; increment the length for a carriage return.

```

```

CALL BC_SPACES      ; BC_SPACES creates the space in workspace.

POP HL              ; restore start of string to HL.
LD ($5B5D),DE      ; load CH_ADD with start DE in workspace.

PUSH DE            ; save the start in workspace
LDIR               ; copy string from program or variables or
                  ; workspace to the workspace area.

EX DE,HL           ; end of string + 1 to HL
DEC HL             ; decrement HL to point to end of new area.
LD (HL), $0D       ; insert a carriage return at end.
RES 7, (IY+$01)    ; update FLAGS - signal checking syntax.
CALL SCANNING      ; routine SCANNING evaluates string
                  ; expression and result.

;;;
RST 18H           ; GET-CHAR fetches next character.  ???

CP $0D            ; is next char the expected carriage return ?
JR NZ, V_RPORT_C ; forward, if not, to V-RPORT-C
                  ; 'Nonsense in BASIC'.

POP HL            ; restore start of string in workspace.

POP AF           ; restore expected result flag (bit 6).

XOR (IY+$01)     ; XOR with FLAGS now updated by SCANNING.
AND $40          ; test bit 6 - should be zero if result types
                  ; match.

V_RPORT_C JP NZ, REPORT_C ; .jump back to REPORT-C with a result mismatch.

LD ($5B5D),HL    ; set CH_ADD to the start of the string again.
SET 7, (IY+$01)  ; update FLAGS - signal running program.

CALL SCANNING    ; routine SCANNING evaluates the string
                  ; in full leaving result on calculator stack.

POP HL           ; restore saved character address in program.
LD ($5B5D),HL   ; and reset the system variable CH_ADD.

V_ST_PTRS JR STK_PNTRS ; back to exit via STK-PNTRS.
                  ; resetting the calculator stack pointers
                  ; HL and DE from STKEND as it wasn't possible
                  ; to preserve them during this routine.

; -----
; THE 'STR$' FUNCTION
; -----
; (offset: $2e 'str$')
; This function produces a string comprising the characters that would appear
; if the numeric argument were printed.
; e.g. STR$ (1/10) produces "0.1".

;;; str_s LD BC, $0001 ; create an initial byte in workspace
;;; RST 30H ; using BC_SPACES restart.

str_s CALL BC_SPACE1 ;+ create an initial byte in workspace.

LD ($5B5B),HL ; set system variable K_CUR to new location.
PUSH HL ; and save start on machine stack also.

LD HL, ($5B51) ; fetch value of system variable CURCHL
PUSH HL ; and save that too.

```

```

LD      A,$FF          ; select system channel 'R'.

CALL    CHAN_SLCT      ; routine CHAN-OPEN opens it.
CALL    PRINT_FP       ; routine PRINT-FP outputs the number to
                       ; workspace updating K-CUR.

POP     HL              ; restore current channel.
CALL    CHAN_FLAG      ; routine CHAN-FLAG resets flags.

POP     DE              ; fetch saved start of string to DE.
LD      HL,($5B5B)     ; load HL with end of string from K_CUR.

AND     A              ; prepare for true subtraction.
SBC     HL,DE          ; subtract start from end to give length.
LD      B,H            ; transfer the length to
LD      C,L            ; the BC register pair.

str_STK CALL STK_STO_s  ; routine STK-STO-$ stores string parameters
                       ; on the calculator stack.

EX      DE,HL          ; Make DE point to STKEND.
RET                                           ; return.

; -----
; THE 'READ-IN' SUBROUTINE
; -----
; (offset: $1a 'read-in')
; This is the calculator literal used by the INKEY$ function when a '#'
; is encountered after the keyword. It appears to provide for the reading
; of data through different streams from those available on the standard
; Spectrum.
; INKEY$ # does not interact correctly with the keyboard, #0 or #1, and
; its uses are for other channels - Steven Vickers, Pitman Pocket Book.

read_in
LD      HL,($5B51)     ; fetch current channel CURCHL
PUSH    HL             ; save it

;;; CALL FIND_INT1     ; routine FIND-INT1 fetches stream to A
;;; CP $10             ; compare with 16 decimal.
;;; JP NC,REPORT_B    ; JUMP to REPORT-B if not in range 0 - 15.
;;; CALL CHAN_SLCT     ; routine CHAN-OPEN opens channel

CALL    CHAN_CHK       ;+ natural routine opens, if valid, else errors
                       ;+ with 'Invalid stream' instead of 'Integer
                       ;+ out of range'

CALL    IN_CHAN_K      ;+ keyboard ?

JR      NZ,READ_IT     ;+ Forward if not

HALT                                           ;+ Read the keyboard.

READ_IT CALL INPUT_AD   ; routine INPUT-AD - the channel must have an
                       ; input stream or else error here from stream
                       ; stub.
LD      BC,$0000       ; initialize length of string to zero
JR      NC,R_I_STORE   ; forward to R-I-STORE if no key detected.

;;; INC C              ; increase length to one.

CALL    BC_SPACE1     ; NEW routine BC_SPACE1 creates space for one
                       ; character in workspace.
LD      (DE),A         ; the character is inserted.

```



```

R_I_STORE CALL STK_STO_s      ; routine STK-STO-$ stacks the string
                                ; parameters.

        POP  HL                ; Restore current channel address

        CALL CHAN_FLAG        ; Routine CHAN-FLAG resets current channel
                                ; system variable and flags.

        JR   V_ST_PTRS       ; jump back indirectly to STK_PNTRS

; -----
; THE 'CODE' FUNCTION
; -----
; (offset: $1c 'code')
; Returns the ASCII code of a character or first character of a string
; e.g. CODE "Aardvark" = 65, CODE "" = 0.

code    CALL STK_FETCH        ; routine STK-FETCH to fetch and delete the
                                ; string parameters.
                                ; DE points to the start, BC holds the length.

        LD   A,B              ; test length
        OR   C                ; of the string.
        JR   Z,STK_CODE      ; skip to STK-CODE with zero if the null string.

        LD   A,(DE)          ; else fetch the first character.

STK_CODE JP   STACK_A        ; jump back to STACK-A (with memory check)

; -----
; THE 'LEN' FUNCTION
; -----
; (offset: $1e 'len')
; Returns the length of a string.
; In Sinclair BASIC, workable strings can be more than twenty thousand
; characters long so a sixteen-bit register is required to store the length.

len     CALL STK_FETCH        ; Routine STK-FETCH to fetch and delete the
                                ; string parameters from the calculator stack.
                                ; Register BC now holds the length of string.

        JP   STACK_BC        ; Jump back to STACK-BC to save result on the
                                ; calculator stack (with memory check).

; -----
; THE 'DECREASE THE COUNTER' SUBROUTINE
; -----
; (offset: $35 'dec-jr-nz')
; The calculator has an instruction that decrements a single-byte
; pseudo-register and makes consequential relative jumps just like
; the Z80's DJNZ instruction.

dec_jr_nz EXX                ; switch in set that addresses code

        PUSH HL               ; save pointer to offset byte
        LD   HL,$5B67         ; address BREG in system variables
        DEC  (HL)            ; decrement it
        POP  HL               ; restore pointer

        JR   NZ,JUMP_2       ; forward, if not zero, to JUMP_2

        INC  HL               ; step past the jump length.
        EXX                    ; switch in the main set.

```

```

        RET                ; return.

; Note. as a general rule the calculator avoids using the IY register
; otherwise the cumbersome 4 instructions in the middle could be replaced by
; dec (IY+$2d) - three bytes instead of six.

; -----
; THE 'JUMP' SUBROUTINE
; -----
; (offset: $33 'jump')
; This enables the calculator to perform relative jumps just like the Z80
; chip's JR instruction.

JUMP     EXX                ; switch in pointer set

JUMP_2   LD     E,(HL)      ; the jump byte 0-127 forward, 128-255 back.
         LD     A,E         ; transfer to accumulator.
         RLA                ; if backward jump, carry is set.
         SBC   A,A         ; will be $FF if backward or $00 if forward.
         LD     D,A         ; transfer to high byte.
         ADD   HL,DE        ; advance calculator pointer forward or back.

         EXX                ; switch back.
         RET                ; return.

; -----
; THE 'JUMP-TRUE' SUBROUTINE
; -----
; (offset: $00 'jump-true')
; This enables the calculator to perform conditional relative jumps dependent
; on whether the last test gave a true result.

jump_true INC  DE           ; Collect the
         INC  DE           ; third byte
         LD   A,(DE)       ; of the test
         DEC  DE           ; result and
         DEC  DE           ; backtrack.

         AND  A            ; Is result 0 or 1 ?
         JR   NZ,JUMP      ; Back to JUMP if true (1).

         EXX                ; else switch in the pointer set.
         INC  HL           ; Step past the jump length.
         EXX                ; Switch in the main set.
         RET                ; Return.

; -----
; THE 'END-CALC' SUBROUTINE
; -----
; (offset: $38 'end-calc')
; The end-calc literal terminates a mini-program written in the Spectrum's
; internal language.
; Note. this short 5-byte routine has been moved to space between the
; restarts to exploit spare space.

; -----
; THE 'MODULUS' SUBROUTINE
; -----
; (offset: $32 'n-mod-m')
; (n1,n2 -- r,q)
; Similar to FORTH's 'divide mod' /MOD
; On the Spectrum, this is only used internally by the RND function and could

```

```
; have been implemented inline. On the ZX81, this calculator routine was also
; used by PRINT-FP.
```

```
n_mod_m  RST    28H          ;; FP-CALC          17, 3.
          DEFB   $C0          ;;st-mem-0    17, 3.
          DEFB   $02          ;;delete      17.
          DEFB   $31          ;;duplicate   17, 17.
          DEFB   $E0          ;;get-mem-0   17, 17, 3.
          DEFB   $05          ;;division    17, 17/3.
          DEFB   $27          ;;int         17, 5.
          DEFB   $E0          ;;get-mem-0   17, 5, 3.
          DEFB   $01          ;;exchange    17, 3, 5.
          DEFB   $C0          ;;st-mem-0    17, 3, 5.
          DEFB   $04          ;;multiply    17, 15.
          DEFB   $03          ;;subtract    2.
          DEFB   $E0          ;;get-mem-0   2, 5.
          DEFB   $38          ;;end-calc    2, 5.

          RET                ; return.
```

```
; -----
; THE 'INT' FUNCTION
; -----
; (offset $27: 'int' )
; This function returns the integer of x, which is just the same as truncate
; for positive numbers. The truncate literal truncates negative numbers
; upwards so that -3.4 gives -3 whereas the BASIC INT function has to
; truncate negative numbers down so that INT -3.4 is -4.
; It is best to work through using, say, +-3.4 as examples.
```

```
int      RST    28H          ;; FP-CALC          x. (= 3.4 or -3.4).
          DEFB   $31          ;;duplicate        x, x.
          DEFB   $36          ;;less-0           x, (1/0)
          DEFB   $00          ;;jump-true        x, (1/0)
          DEFB   X_NEG - $    ;;to X-NEG

          DEFB   $3A          ;;truncate        trunc 3.4 = 3.
          DEFB   $38          ;;end-calc         3.

          RET                ; return with + int x on stack.
```

```
; ---
```

```
X_NEG   DEFB   $31          ;;duplicate        -3.4, -3.4.
          DEFB   $3A          ;;truncate        -3.4, -3.
          DEFB   $C0          ;;st-mem-0        -3.4, -3.
          DEFB   $03          ;;subtract        -.4
          DEFB   $E0          ;;get-mem-0        -.4, -3.
          DEFB   $01          ;;exchange        -3, -.4.
          DEFB   $30          ;;not             -3, (0).
          DEFB   $00          ;;jump-true        -3.
          DEFB   EXIT - $    ;;to EXIT         -3.

          DEFB   $A1          ;;stk-one         -3, 1.
          DEFB   $03          ;;subtract        -4.

EXIT    DEFB   $38          ;;end-calc        -4.

          RET                ; return.
```

```
; -----
```

```

; THE 'EXP' FUNCTION
; -----
; (offset $26: 'exp')
; The exponential function EXP x is equal to e^x, where e is the mathematical
; name for a number approximated to 2.718281828.
; ERROR 6 if argument is more than about 88.

```

```

exp      RST      28H          ;; FP-CALC
        DEFB     $3D          ;;re-stack
        DEFB     $34          ;;stk-data
        DEFB     $F1          ;;Exponent: $81, Bytes: 4
        DEFB     $38,$AA,$3B,$29 ;;
        DEFB     $04          ;;multiply
        DEFB     $31          ;;duplicate
        DEFB     $27          ;;int
        DEFB     $C3          ;;st-mem-3
        DEFB     $03          ;;subtract
        DEFB     $31          ;;duplicate
        DEFB     $0F          ;;addition
        DEFB     $A1          ;;stk-one
        DEFB     $03          ;;subtract

        DEFB     $88          ;;series-08
        DEFB     $13          ;;Exponent: $63, Bytes: 1
        DEFB     $36          ;;(+00,+00,+00)
        DEFB     $58          ;;Exponent: $68, Bytes: 2
        DEFB     $65,$66      ;;(+00,+00)
        DEFB     $9D          ;;Exponent: $6D, Bytes: 3
        DEFB     $78,$65,$40   ;;(+00)
        DEFB     $A2          ;;Exponent: $72, Bytes: 3
        DEFB     $60,$32,$C9   ;;(+00)
        DEFB     $E7          ;;Exponent: $77, Bytes: 4
        DEFB     $21,$F7,$AF,$24 ;;
        DEFB     $EB          ;;Exponent: $7B, Bytes: 4
        DEFB     $2F,$B0,$B0,$14 ;;
        DEFB     $EE          ;;Exponent: $7E, Bytes: 4
        DEFB     $7E,$BB,$94,$58 ;;
        DEFB     $F1          ;;Exponent: $81, Bytes: 4
        DEFB     $3A,$7E,$F8,$CF ;;

        DEFB     $E3          ;;get-mem-3
        DEFB     $38          ;;end-calc

        CALL     FP_TO_A      ; routine FP-TO-A
        JR      NZ,N_NEGTV    ; to N-NEGTV

        JR      C,REPORT_6b   ; to REPORT-6b
                                ; 'Number too big'

        ADD     A,(HL)        ;
        JR      NC,RESULT_OK  ; to RESULT-OK

REPORT_6b RST      30H          ; ERROR-1
        DEFB     $05          ; Error Report: Number too big

; ---

N_NEGTV  JR      C,RSLT_ZERO  ; to RSLT-ZERO

        SUB     (HL)          ;
        JR      NC,RSLT_ZERO  ; to RSLT-ZERO

        NEG     ; Negate

```

```

RESULT_OK LD      (HL),A          ;
          RET                ; return.

; ---

RSLT_ZERO RST     28H             ;; FP-CALC
          DEFB     $02           ;;delete
          DEFB     $A0           ;;stk-zero
          DEFB     $38           ;;end-calc

          RET                ; return.

; -----
; THE 'NATURAL LOGARITHM' FUNCTION
; -----
; (offset $25: 'ln')
; Function to calculate the natural logarithm (to the base e ).
; e.g. LN EXP 5.3 = 5.3
; Error A if the argument is 0 or negative.

ln        RST     28H             ;; FP-CALC
          DEFB     $3D           ;;re-stack
          DEFB     $31           ;;duplicate
          DEFB     $37           ;;greater-0
          DEFB     $00           ;;jump-true
          DEFB     VALID - $     ;;to VALID

INV_ARG   DEFB     $38           ;;end-calc

REPORT_Ab RST     30H             ; ERROR-1
          DEFB     $09           ; Error Report: Invalid argument

VALID
;;;      DEFB     $A0           ;;stk-zero           This is unnecessary
;;;      DEFB     $02           ;;delete
          DEFB     $38           ;;end-calc
          LD      A,(HL)         ;

          LD      (HL),$80       ;
          CALL   STACK_A        ; routine STACK-A

          RST     28H             ;; FP-CALC
          DEFB     $34           ;;stk-data
          DEFB     $38           ;;Exponent: $88, Bytes: 1
          DEFB     $00           ;;(+00,+00,+00)
          DEFB     $03           ;;subtract
          DEFB     $01           ;;exchange
          DEFB     $31           ;;duplicate
          DEFB     $34           ;;stk-data
          DEFB     $F0           ;;Exponent: $80, Bytes: 4
          DEFB     $4C,$CC,$CC,$CD ;;
          DEFB     $03           ;;subtract
          DEFB     $37           ;;greater-0
          DEFB     $00           ;;jump-true
          DEFB     GRE_v_8 - $   ;;to GRE.8

          DEFB     $01           ;;exchange
          DEFB     $A1           ;;stk-one
          DEFB     $03           ;;subtract
          DEFB     $01           ;;exchange

```

```

DEFB $38 ;;end-calc

INC (HL) ;

RST 28H ;; FP-CALC

GRE_v_8 DEFB $01 ;;exchange
DEFB $34 ;;stk-data
DEFB $F0 ;;Exponent: $80, Bytes: 4
DEFB $31,$72,$17,$F8 ;;
DEFB $04 ;;multiply
DEFB $01 ;;exchange
DEFB $A2 ;;stk-half
DEFB $03 ;;subtract
DEFB $A2 ;;stk-half
DEFB $03 ;;subtract
DEFB $31 ;;duplicate
DEFB $34 ;;stk-data
DEFB $32 ;;Exponent: $82, Bytes: 1
DEFB $20 ;; (+00,+00,+00)
DEFB $04 ;;multiply
DEFB $A2 ;;stk-half
DEFB $03 ;;subtract

DEFB $8C ;;series-0C
DEFB $11 ;;Exponent: $61, Bytes: 1
DEFB $AC ;; (+00,+00,+00)
DEFB $14 ;;Exponent: $64, Bytes: 1
DEFB $09 ;; (+00,+00,+00)
DEFB $56 ;;Exponent: $66, Bytes: 2
DEFB $DA,$A5 ;; (+00,+00)
DEFB $59 ;;Exponent: $69, Bytes: 2
DEFB $30,$C5 ;; (+00,+00)
DEFB $5C ;;Exponent: $6C, Bytes: 2
DEFB $90,$AA ;; (+00,+00)
DEFB $9E ;;Exponent: $6E, Bytes: 3
DEFB $70,$6F,$61 ;; (+00)
DEFB $A1 ;;Exponent: $71, Bytes: 3
DEFB $CB,$DA,$96 ;; (+00)
DEFB $A4 ;;Exponent: $74, Bytes: 3
DEFB $31,$9F,$B4 ;; (+00)
DEFB $E7 ;;Exponent: $77, Bytes: 4
DEFB $A0,$FE,$5C,$FC ;;
DEFB $EA ;;Exponent: $7A, Bytes: 4
DEFB $1B,$43,$CA,$36 ;;
DEFB $ED ;;Exponent: $7D, Bytes: 4
DEFB $A7,$9C,$7E,$5E ;;
DEFB $F0 ;;Exponent: $80, Bytes: 4
DEFB $6E,$23,$80,$93 ;;

DEFB $04 ;;multiply
DEFB $0F ;;addition
DEFB $38 ;;end-calc

RET ; return.

```

```

; -----
; THE 'TRIGONOMETRIC' FUNCTIONS
; -----

```

```

; Trigonometry is rocket science. It is also used by carpenters and pyramid
; builders. Some uses can be quite abstract but the principles can be seen
; in simple right-angled triangles. Triangles have some special properties -
;

```

```

; 1) The sum of the three angles is always PI radians (180 degrees).
; Very helpful if you know two angles and wish to find the third.
; 2) In any right-angled triangle the sum of the squares of the two shorter
; sides is equal to the square of the longest side opposite the right-
angle.
; Very useful if you know the length of two sides and wish to know the
; length of the third side.
; 3) Functions sine, cosine and tangent enable one to calculate the length
; of an unknown side, of a right-angled triangle, when the length of one
; other side and an angle is known.
; 4) Functions arcsin, arccosine and arctan enable one to calculate an unknown
; angle of a right-angled triangle when the length of two of the sides is
; known.

```

```

; -----
; THE 'REDUCE ARGUMENT' SUBROUTINE
; -----

```

```


; (offset $39: 'get-argt')
;

```

```

; This routine performs two functions on the angle, in radians, that forms
; the argument to the sine and cosine functions.
; First it ensures that the angle 'wraps round'. That if a ship turns through
; an angle of, say, 3*PI radians (540 degrees) then the net effect is to turn
; through an angle of PI radians (180 degrees).
; Secondly it converts the angle in radians to a fraction of a right angle,
; depending within which quadrant the angle lies, with the periodicity
; resembling that of the desired sine value.
; The result lies in the range -1 to +1.
;

```



```

get_argt  RST    28H          ;; FP-CALC          X.
          DEFB   $3D          ;;re-stack
          DEFB   $34          ;;stk-data
          DEFB   $EE          ;;Exponent: $7E,
          ;;Bytes: 4
          DEFB   $22,$F9,$83,$6E ;;          X, 1/(2*PI)
          DEFB   $04          ;;multiply      X/(2*PI) = fraction
          DEFB   $31          ;;duplicate
          DEFB   $A2          ;;stk-half
          DEFB   $0F          ;;addition
          DEFB   $27          ;;int
          DEFB   $03          ;;subtract      now range -.5 to .5

```

```

DEFB $31          ;;duplicate
DEFB $0F          ;;addition    now range -1 to 1.
DEFB $31          ;;duplicate
DEFB $0F          ;;addition    now range -2 to +2.

; quadrant I (0 to +1) and quadrant IV (-1 to 0) are now correct.
; quadrant II ranges +1 to +2.
; quadrant III ranges -2 to -1.

DEFB $31          ;;duplicate    Y, Y.
DEFB $2A          ;;abs          Y, abs(Y).    range 1 to 2
DEFB $A1          ;;stk-one     Y, abs(Y), 1.
DEFB $03          ;;subtract    Y, abs(Y)-1.  range 0 to 1
DEFB $31          ;;duplicate    Y, Z, Z.
DEFB $37          ;;greater-0   Y, Z, (1/0).

DEFB $C0          ;;st-mem-0     store as possible sign
;;                                for cosine function.

DEFB $00          ;;jump-true
DEFB ZPLUS - $    ;;to ZPLUS    with quadrants II and III.

; else the angle lies in quadrant I or IV and value Y is already correct.

DEFB $02          ;;delete      Y.    delete the test value.
DEFB $38          ;;end-calc    Y.

RET              ; return.      with Q1 and Q4          >>>

; ---

; The branch was here with quadrants II (0 to 1) and III (1 to 0).
; Y will hold -2 to -1 if this is quadrant III.

ZPLUS DEFB $A1          ;;stk-one     Y, Z, 1.
DEFB $03          ;;subtract    Y, Z-1.    Q3 = 0 to -1
DEFB $01          ;;exchange    Z-1, Y.
DEFB $36          ;;less-0     Z-1, (1/0).
DEFB $00          ;;jump-true    Z-1.
DEFB YNEG - $     ;;to YNEG
;;if angle in quadrant III

; else angle is within quadrant II (-1 to 0)

DEFB $1B          ;;negate      range +1 to 0.

YNEG DEFB $38          ;;end-calc    quadrants II and III correct.

RET              ; return.

; -----
; THE 'COSINE' FUNCTION
; -----
; (offset $20: 'cos')
; Cosines are calculated as the sine of the opposite angle rectifying the
; sign depending on the quadrant rules.
;
;
;
;      /|
;     h /y|
;      /  |o
;     /x  |
;    /----|

```



```

;           a
;
; The cosine of angle x is the adjacent side (a) divided by the hypotenuse 1.
; However if we examine angle y then a/h is the sine of that angle.
; Since angle x plus angle y equals a right-angle, we can find angle y by
; subtracting angle x from pi/2.
; However it's just as easy to reduce the argument first and subtract the
; reduced argument from the value 1 (a reduced right-angle).
; It's even easier to subtract 1 from the angle and rectify the sign.
; In fact, after reducing the argument, the absolute value of the argument
; is used and rectified using the test result stored in mem-0 by 'get-argt'
; for that purpose.
;

```

```

cos          RST    28H          ;; FP-CALC          angle in radians.
            DEFB   $39          ;;get-argt          X      reduce -1 to +1

            DEFB   $2A          ;;abs              ABS X.   0 to 1
            DEFB   $A1          ;;stk-one          ABS X, 1.
            DEFB   $03          ;;subtract         now opposite angle
            ;;              although sign is -ve.

            DEFB   $E0          ;;get-mem-0        fetch the sign indicator
            DEFB   $00          ;;jump-true
            DEFB   C_ENT - $    ;;fwd to C-ENT
            ;;forward to common code if in QII or QIII.

            DEFB   $1B          ;;negate           else make sign +ve.
            DEFB   $33          ;;jump
            DEFB   C_ENT - $    ;;fwd to C-ENT
            ;; with quadrants I and IV.

```

```

; -----
; THE 'SINE' FUNCTION
; -----
; (offset $1F: 'sin')

```

```

; This is a fundamental transcendental function from which others such as cos
; and tan are directly, or indirectly, derived.
; It uses the series generator to produce Chebyshev polynomials.
;
;

```

```

;
;
;      / |
;     1 / |
;      /  |x
;     /a  |
;    /----|
;     y
;

```

```

; The 'get-argt' function is designed to modify the angle and its sign
; in line with the desired sine value and afterwards it can launch straight
; into common code.

```

```

sin          RST    28H          ;; FP-CALC          angle in radians
            DEFB   $39          ;;get-argt          reduce - sign now correct.

C_ENT       DEFB   $31          ;;duplicate
            DEFB   $31          ;;duplicate
            DEFB   $04          ;;multiply
            DEFB   $31          ;;duplicate
            DEFB   $0F          ;;addition
            DEFB   $A1          ;;stk-one
            DEFB   $03          ;;subtract

            DEFB   $86          ;;series-06

```

```

DEFB $14          ;;Exponent: $64, Bytes: 1
DEFB $E6          ;; (+00,+00,+00)
DEFB $5C          ;;Exponent: $6C, Bytes: 2
DEFB $1F,$0B      ;; (+00,+00)
DEFB $A3          ;;Exponent: $73, Bytes: 3
DEFB $8F,$38,$EE  ;; (+00)
DEFB $E9          ;;Exponent: $79, Bytes: 4
DEFB $15,$63,$BB,$23 ;;
DEFB $EE          ;;Exponent: $7E, Bytes: 4
DEFB $92,$0D,$CD,$ED ;;
DEFB $F1          ;;Exponent: $81, Bytes: 4
DEFB $23,$5D,$1B,$EA ;;
DEFB $04          ;;multiply
DEFB $38          ;;end-calc

RET              ; return.

```

```

; -----
; THE 'TANGENT' FUNCTION
; -----

```

```

; (offset $21: 'tan')
;

```

```

; Evaluates tangent x as      sin(x) / cos(x).
;
;

```

```

;
;      /|
;     h / |
;      /  |o
;     /x  |
;    /----|
;     a
;

```

```

; the tangent of angle x is the ratio of the length of the opposite side
; divided by the length of the adjacent side. As the opposite length can
; be calculates using sin(x) and the adjacent length using cos(x) then
; the tangent can be defined in terms of the previous two functions.

```

```

; Error 6 if the argument, in radians, is too close to one like pi/2
; which has an infinite tangent. e.g. PRINT TAN (PI/2) evaluates as 1/0.
; Similarly PRINT TAN (3*PI/2), TAN (5*PI/2) etc.

```

```

tan      RST      28H          ;; FP-CALC          x.
DEFB    $31          ;;duplicate        x, x.
DEFB    $1F          ;;sin            x, sin x.
DEFB    $01          ;;exchange       sin x, x.
DEFB    $20          ;;cos            sin x, cos x.
DEFB    $05          ;;division       sin x/cos x (= tan x).
DEFB    $38          ;;end-calc        tan x.

RET      ; return.

```

```

; -----
; THE 'ARCTAN' FUNCTION
; -----

```

```

; (Offset $24: 'atn')
;

```

```

; the inverse tangent function with the result in radians.
; This is a fundamental transcendental function from which others such as asn
; and acs are directly, or indirectly, derived.
; It uses the series generator to produce Chebyshev polynomials.

```

```

atn      CALL     re_stack      ; routine re-stack
LD       A,(HL)                ; fetch exponent byte.
CP       $81                   ; compare to that for 'one'
JR       C,SMALL               ; forward, if less, to SMALL

```

```

RST    28H                ;; FP-CALC
DEFB   $A1                ;;stk-one
DEFB   $1B                ;;negate
DEFB   $01                ;;exchange
DEFB   $05                ;;division
DEFB   $31                ;;duplicate
DEFB   $36                ;;less-0
DEFB   $A3                ;;stk-pi/2
DEFB   $01                ;;exchange
DEFB   $00                ;;jump-true
DEFB   CASES - $         ;;to CASES

DEFB   $1B                ;;negate
DEFB   $33                ;;jump
DEFB   CASES - $         ;;to CASES

SMALL  RST    28H                ;; FP-CALC
DEFB   $A0                ;;stk-zero

CASES  DEFB   $01                ;;exchange
DEFB   $31                ;;duplicate
DEFB   $31                ;;duplicate
DEFB   $04                ;;multiply
DEFB   $31                ;;duplicate
DEFB   $0F                ;;addition
DEFB   $A1                ;;stk-one
DEFB   $03                ;;subtract

DEFB   $8C                ;;series-0C
DEFB   $10                ;;Exponent: $60, Bytes: 1
DEFB   $B2                ;; (+00,+00,+00)
DEFB   $13                ;;Exponent: $63, Bytes: 1
DEFB   $0E                ;; (+00,+00,+00)
DEFB   $55                ;;Exponent: $65, Bytes: 2
DEFB   $E4,$8D           ;; (+00,+00)
DEFB   $58                ;;Exponent: $68, Bytes: 2
DEFB   $39,$BC           ;; (+00,+00)
DEFB   $5B                ;;Exponent: $6B, Bytes: 2
DEFB   $98,$FD           ;; (+00,+00)
DEFB   $9E                ;;Exponent: $6E, Bytes: 3
DEFB   $00,$36,$75       ;; (+00)
DEFB   $A0                ;;Exponent: $70, Bytes: 3
DEFB   $DB,$E8,$B4       ;; (+00)
DEFB   $63                ;;Exponent: $73, Bytes: 2
DEFB   $42,$C4           ;; (+00,+00)
DEFB   $E6                ;;Exponent: $76, Bytes: 4
DEFB   $B5,$09,$36,$BE  ;;
DEFB   $E9                ;;Exponent: $79, Bytes: 4
DEFB   $36,$73,$1B,$5D  ;;
DEFB   $EC                ;;Exponent: $7C, Bytes: 4
DEFB   $D8,$DE,$63,$BE  ;;
DEFB   $F0                ;;Exponent: $80, Bytes: 4
DEFB   $61,$A1,$B3,$0C  ;;

DEFB   $04                ;;multiply
DEFB   $0F                ;;addition
DEFB   $38                ;;end-calc

RET                                ; return.

```

```

; -----
; THE 'ARCSIN' FUNCTION

```

```

; -----
; (Offset $22: 'asn')
; the inverse sine function with result in radians.
; derived from arctan function above.
; Error A unless the argument is between -1 and +1 inclusive.
; uses an adaptation of the formula  $asn(x) = atn(x/sqr(1-x*x))$ 
;
;
;      /|
;     1 / |
;      /  |x
;     /a  |
;    /----|
;     y
;
; e.g. we know the opposite side (x) and hypotenuse (1)
; and we wish to find angle a in radians.
; we can derive length y by Pythagoras and then use ATN instead.
; since  $y*y + x*x = 1*1$  (Pythagoras Theorem) then
;  $y=sqr(1-x*x)$  - no need to multiply 1 by itself.
; so,  $asn(a) = atn(x/y)$ 
; or more fully,
;  $asn(a) = atn(x/sqr(1-x*x))$ 
;
; Close but no cigar.
;
; While PRINT ATN (x/SQR (1-x*x)) gives the same results as PRINT ASN x,
; it leads to division by zero when x is 1 or -1.
; To overcome this, 1 is added to y giving half the required angle and the
; result is then doubled.
; That is PRINT ATN (x/(SQR (1-x*x) +1)) *2
; A value higher than 1 gives the required error as attempting to find the
; square root of a negative number generates an error in Sinclair BASIC.

```

```

asn      RST    28H          ;; FP-CALC      x.
         DEFB   $31          ;;duplicate   x, x.
         DEFB   $31          ;;duplicate   x, x, x.
         DEFB   $04          ;;multiply    x, x*x.
         DEFB   $A1          ;;stk-one     x, x*x, 1.
         DEFB   $03          ;;subtract    x, x*x-1.
         DEFB   $1B          ;;negate      x, 1-x*x.
         DEFB   $28          ;;sqr         x, sqr(1-x*x) = y
         DEFB   $A1          ;;stk-one     x, y, 1.
         DEFB   $0F          ;;addition    x, y+1.
         DEFB   $05          ;;division    x/y+1.
         DEFB   $24          ;;atn         a/2      (half the angle)
         DEFB   $31          ;;duplicate   a/2, a/2.
         DEFB   $0F          ;;addition    a.
         DEFB   $38          ;;end-calc    a.

         RET                ; return.

```

```

; -----
; THE 'ARCCOS' FUNCTION
; -----
; (Offset $23: 'acs')
; the inverse cosine function with the result in radians.
; Error A unless the argument is between -1 and +1.
; Result in range 0 to pi.
; Derived from asn above which is in turn derived from the preceding atn.
; It could have been derived directly from atn using
;  $acs(x) = atn(sqr(1-x*x)/x)$ .
; However, as sine and cosine are horizontal translations of each other,

```

```

; uses  $\text{acs}(x) = \pi/2 - \text{asn}(x)$ 

; e.g. the arccosine of a known x value will give the required angle b in
; radians.
; We know, from above, how to calculate the angle a using  $\text{asn}(x)$ .
; Since the three angles of any triangle add up to 180 degrees, or  $\pi$  radians,
; and the largest angle in this case is a right-angle ( $\pi/2$  radians), then
; we can calculate angle b as  $\pi/2$  (both angles) minus  $\text{asn}(x)$  (angle a).
;
;

```

```

;
;      /|
;     1 /b|
;      /  |x
;     /a  |
;    /----|
;     y
;

```

```

acs      RST    28H          ;; FP-CALC      x.
         DEFB   $22          ;;asn       $\text{asn}(x)$ .
         DEFB   $A3          ;;stk-pi/2    $\text{asn}(x), \pi/2$ .
         DEFB   $03          ;;subtract   $\text{asn}(x) - \pi/2$ .
         DEFB   $1B          ;;negate     $\pi/2 - \text{asn}(x) = \text{acs}(x)$ .
         DEFB   $38          ;;end-calc   $\text{acs}(x)$ .

         RET                ; return.

```

```

; -----
; THE NEW 'SQUARE ROOT' FUNCTION
; -----

```

```

; (Offset $28: 'sqr')
; "If I have seen further, it is by standing on the shoulders of giants" -
; Sir Isaac Newton, Cambridge 1676.
; The sqr function has been re-written to use the Newton-Raphson method.
; Although the method is centuries old, this one, appropriately, is based
; on a FORTH word written by Steven Vickers in the Jupiter Ace manual.
; Whereas that algorithm always used an initial guess of one, this one
; manipulates the exponent byte to obtain a better guess.
; First test for zero and return zero, if so, as the result.
; If the argument is negative, then produce an error.

```

```

sqr      RST    28H          ;; FP-CALC      x
         DEFB   $3D          ;;re-stack    x. (in f.p. form)
         DEFB   $C3          ;;st-mem-3    x. (seed for guess)
         DEFB   $38          ;;end-calc

```

```

; The HL register now addresses the exponent byte

```

```

         LD     A,(HL)       ; fetch exponent to A
         AND   A            ; test for zero.
         RET   Z            ; return if so - with zero on calculator stack.

         INC   HL           ; address the byte with the sign bit.
         BIT   7,(HL)       ; test the sign bit

         JP    NZ,REPORT_Ab ; REPORT_A: 'Invalid argument'

```

```

; This guess is based on a Usenet discussion.
; Halve the exponent to achieve a good guess.(accurate with .25 16 64 etc.)

```

```

         LD     HL,$5BA1     ; Address system variable mem-3
         LD     A,(HL)       ; fetch exponent of mem-3
         XOR   $80          ; toggle sign of exponent of mem-3

```

```

SRA  A          ; shift right, bit 7 unchanged.
INC  A          ;
JR   Z,ASIS    ; forward with say .25 -> .5
JP   P,ASIS    ; leave increment if value > .5
DEC  A          ; restore to shift only.

ASIS  XOR  $80   ; restore sign.
      LD   (HL),A ; and put back 'halved' exponent.

```

```

; Now re-enter the calculator.

```

```

      RST  28H          ;; FP-CALC          x
SLOOP DEFB  $31        ;;duplicate          x,x.
      DEFB  $E3        ;;get-mem-3         x,x,guess
      DEFB  $C4        ;;st-mem-4         x,x,guess
      DEFB  $05        ;;div              x,x/guess.
      DEFB  $E3        ;;get-mem-3         x,x/guess,guess
      DEFB  $0F        ;;addition          x,x/guess+guess
      DEFB  $A2        ;;stk-half          x,x/guess+guess,.5
      DEFB  $04        ;;multiply         x,(x/guess+guess)*.5
      DEFB  $C3        ;;st-mem-3         x,newguess
      DEFB  $E4        ;;get-mem-4         x,newguess,oldguess
      DEFB  $03        ;;subtract         x,newguess-oldguess
      DEFB  $2A        ;;abs              x,difference.
      DEFB  $37        ;;greater-0        x,(0/1).
      DEFB  $00        ;;jump-true        x.

      DEFB  SLOOP - $   ;;to sloop        x.

      DEFB  $02        ;;delete            .
      DEFB  $E3        ;;get-mem-3         retrieve final guess.
      DEFB  $38        ;;end-calc         sqr x.

      RET              ; return with square root on stack

```

```

; -----
; THE OLD SLOW 'SQUARE ROOT' FUNCTION
; -----

```

```

; (Offset $28: 'sqr')

```

```

; This is the old 7-byte method of calculating square roots which has been
; re-introduced at various stages during the development of this ROM due to
; lack of space.

```

```

;;; sqr      RST  28H          ;; FP-CALC
;;;          DEFB  $31        ;;duplicate
;;;          DEFB  $30        ;;not
;;;          DEFB  $00        ;;jump-true
;;;          DEFB  LAST - $   ;;to LAST
;;;
;;;          DEFB  $A2        ;;stk-half
;;;          DEFB  $38        ;;end-calc

```

```

; -----
; THE 'EXPONENTIATION' OPERATION
; -----

```

```

; (Offset $06: 'to-power')

```

```

; This raises the first number X to the power of the second number Y.
; As with the ZX80,
; 0 ^ 0 = 1.
; 0 ^ +n = 0.
; 0 ^ -n = arithmetic overflow.
;

```

```

to_power  RST    28H          ;; FP-CALC          X, Y.
          DEFB   $01          ;;exchange          Y, X.
          DEFB   $31          ;;duplicate         Y, X, X.
          DEFB   $30          ;;not              Y, X, (1/0).
          DEFB   $00          ;;jump-true
          DEFB   XISO - $     ;;to XISO          if X is zero.

;   else X is non-zero. Function 'ln' will catch a negative value of X.

          DEFB   $25          ;;ln              Y, LN X.
          DEFB   $04          ;;multiply         Y * LN X.
          DEFB   $38          ;;end-calc

          JP     exp          ; jump back to EXP routine  ->

; ---

;   these routines form the three simple results when the number is zero.
;   begin by deleting the known zero to leave Y the power factor.

XISO      DEFB   $02          ;;delete          Y.
          DEFB   $31          ;;duplicate         Y, Y.
          DEFB   $30          ;;not              Y, (1/0).
          DEFB   $00          ;;jump-true
          DEFB   ONE - $     ;;to ONE          if Y is zero.

          DEFB   $A0          ;;stk-zero        Y, 0.
          DEFB   $01          ;;exchange         0, Y.
          DEFB   $37          ;;greater-0       0, (1/0).
          DEFB   $00          ;;jump-true        0.
          DEFB   LAST - $    ;;to LAST         if Y was any positive
          ;;                                     number.

;   else force division by zero thereby raising an Arithmetic overflow error.
;   There are some one and two-byte alternatives but perhaps the most formal
;   might have been to use end-calc; rst 08; defb 05.

          DEFB   $A1          ;;stk-one          0, 1.
          DEFB   $01          ;;exchange         1, 0.
          DEFB   $05          ;;division         1/0      ouch!

; ---

ONE        DEFB   $02          ;;delete          .
          DEFB   $A1          ;;stk-one          1.

LAST       DEFB   $38          ;;end-calc        last value is 1 or 0.

          RET                ; return.          Whew!

; -----
; THE 'SPARE LOCATIONS' PART 3
; -----

TAG7

SPARE      DEFB   $FF, $FF, $FF          ;

ORG $3D00

```

```

; -----
; THE 'ZX SPECTRUM CHARACTER SET'
; -----

; $20 - Character: ' '          CHR$(32)

char_set  DEFB  %00000000
LINE_ZERO DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000

; $21 - Character: '!'        CHR$(33)

          DEFB  %00000000
          DEFB  %00010000
          DEFB  %00010000
          DEFB  %00010000
          DEFB  %00010000
          DEFB  %00010000
          DEFB  %00000000
          DEFB  %00010000
          DEFB  %00000000

; $22 - Character: '"'        CHR$(34)

          DEFB  %00000000
          DEFB  %00100100
          DEFB  %00100100
          DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000
          DEFB  %00000000

; $23 - Character: '#'        CHR$(35)

          DEFB  %00000000
          DEFB  %00100100
          DEFB  %01111110
          DEFB  %00100100
          DEFB  %00100100
          DEFB  %01111110
          DEFB  %00100100
          DEFB  %00000000

; $24 - Character: '$'        CHR$(36)

          DEFB  %00000000
          DEFB  %00001000
          DEFB  %00111110
          DEFB  %00101000
          DEFB  %00111110
          DEFB  %00001010
          DEFB  %00111110
          DEFB  %00001000

; $25 - Character: '%'        CHR$(37)

          DEFB  %00000000
          DEFB  %01100010

```


DEFB %01100100
DEFB %00001000
DEFB %00010000
DEFB %00100110
DEFB %01000110
DEFB %00000000

; \$26 - Character: '&' CHR\$(38)

DEFB %00000000
DEFB %00010000
DEFB %00101000
DEFB %00010000
DEFB %00101010
DEFB %01000100
DEFB %00111010
DEFB %00000000

; \$27 - Character: ''' CHR\$(39)

DEFB %00000000
DEFB %00001000
DEFB %00010000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000

; \$28 - Character: '(' CHR\$(40)

DEFB %00000000
DEFB %00000100
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00000100
DEFB %00000000

; \$29 - Character: ')' CHR\$(41)

DEFB %00000000
DEFB %00100000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00100000
DEFB %00000000

; \$2A - Character: '*' CHR\$(42)

DEFB %00000000
DEFB %00000000
DEFB %00010100
DEFB %00001000
DEFB %00111110
DEFB %00001000
DEFB %00010100
DEFB %00000000

; \$2B - Character: '+' CHR\$(43)

```
DEFB %00000000
DEFB %00000000
DEFB %00001000
DEFB %00001000
DEFB %00111110
DEFB %00001000
DEFB %00001000
DEFB %00000000
```

; \$2C - Character: ',' CHR\$(44)

```
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00001000
DEFB %00001000
DEFB %00010000
```

; \$2D - Character: '-' CHR\$(45)

```
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00111110
DEFB %00000000
DEFB %00000000
DEFB %00000000
```

; \$2E - Character: '.' CHR\$(46)

```
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00011000
DEFB %00011000
DEFB %00000000
```

; \$2F - Character: '/' CHR\$(47)

```
DEFB %00000000
DEFB %00000000
DEFB %00000010
DEFB %00000100
DEFB %00001000
DEFB %00010000
DEFB %00100000
DEFB %00000000
```

; \$30 - Character: '0' CHR\$(48)

```
DEFB %00000000
DEFB %00111100
DEFB %01000110
DEFB %01001010
DEFB %01010010
DEFB %01100010
DEFB %00111100
DEFB %00000000
```

; \$31 - Character: '1' CHR\$(49)

DEFB %00000000
DEFB %00011000
DEFB %00101000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00111110
DEFB %00000000

; \$32 - Character: '2' CHR\$(50)

DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %00000010
DEFB %00111100
DEFB %01000000
DEFB %01111110
DEFB %00000000

; \$33 - Character: '3' CHR\$(51)

DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %00001100
DEFB %00000010
DEFB %01000010
DEFB %00111100
DEFB %00000000

; \$34 - Character: '4' CHR\$(52)

DEFB %00000000
DEFB %00001000
DEFB %00011000
DEFB %00101000
DEFB %01001000
DEFB %01111110
DEFB %00001000
DEFB %00000000

; \$35 - Character: '5' CHR\$(53)

DEFB %00000000
DEFB %01111110
DEFB %01000000
DEFB %01111100
DEFB %00000010
DEFB %01000010
DEFB %00111100
DEFB %00000000

; \$36 - Character: '6' CHR\$(54)

DEFB %00000000
DEFB %00111100
DEFB %01000000
DEFB %01111100
DEFB %01000010
DEFB %01000010
DEFB %00111100

DEFB %00000000

; \$37 - Character: '7' CHR\$(55)

DEFB %00000000
DEFB %01111110
DEFB %00000010
DEFB %00000100
DEFB %00001000
DEFB %00010000
DEFB %00010000
DEFB %00000000

; \$38 - Character: '8' CHR\$(56)

DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %00111100
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %00111100
DEFB %00000000

; \$39 - Character: '9' CHR\$(57)

DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %01000010
DEFB %00111110
DEFB %00000010
DEFB %00111100
DEFB %00000000

; \$3A - Character: ':' CHR\$(58)

DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00010000
DEFB %00000000
DEFB %00000000
DEFB %00010000
DEFB %00000000

; \$3B - Character: ';' CHR\$(59)

DEFB %00000000
DEFB %00000000
DEFB %00010000
DEFB %00000000
DEFB %00000000
DEFB %00010000
DEFB %00010000
DEFB %00100000

; \$3C - Character: '<' CHR\$(60)

DEFB %00000000
DEFB %00000000
DEFB %00000100
DEFB %00001000
DEFB %00010000

```
DEFB %00001000
DEFB %00000100
DEFB %00000000
```

```
; $3D - Character: '='          CHR$(61)
```

```
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00111110
DEFB %00000000
DEFB %00111110
DEFB %00000000
DEFB %00000000
```

```
; $3E - Character: '>'          CHR$(62)
```

```
DEFB %00000000
DEFB %00000000
DEFB %00010000
DEFB %00001000
DEFB %00000100
DEFB %00001000
DEFB %00010000
DEFB %00000000
```

```
; $3F - Character: '?'          CHR$(63)
```

```
DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %00000100
DEFB %00001000
DEFB %00000000
DEFB %00001000
DEFB %00000000
```

```
; $40 - Character: '@'          CHR$(64)
```

```
DEFB %00000000
DEFB %00111100
DEFB %01001010
DEFB %01010110
DEFB %01011110
DEFB %01000000
DEFB %00111100
DEFB %00000000
```

```
; $41 - Character: 'A'          CHR$(65)
```

```
DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %01000010
DEFB %01111110
DEFB %01000010
DEFB %01000010
DEFB %00000000
```

```
; $42 - Character: 'B'          CHR$(66)
```

```
DEFB %00000000
DEFB %01111100
DEFB %01000010
```

DEFB %01111100
DEFB %01000010
DEFB %01000010
DEFB %01111100
DEFB %00000000

; \$43 - Character: 'C' CHR\$(67)

DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %01000000
DEFB %01000000
DEFB %01000010
DEFB %00111100
DEFB %00000000

; \$44 - Character: 'D' CHR\$(68)

DEFB %00000000
DEFB %01111000
DEFB %01000100
DEFB %01000010
DEFB %01000010
DEFB %01000100
DEFB %01111000
DEFB %00000000

; \$45 - Character: 'E' CHR\$(69)

DEFB %00000000
DEFB %01111110
DEFB %01000000
DEFB %01111100
DEFB %01000000
DEFB %01000000
DEFB %01111110
DEFB %00000000

; \$46 - Character: 'F' CHR\$(70)

DEFB %00000000
DEFB %01111110
DEFB %01000000
DEFB %01111100
DEFB %01000000
DEFB %01000000
DEFB %01000000
DEFB %00000000

; \$47 - Character: 'G' CHR\$(71)

DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %01000000
DEFB %01001110
DEFB %01000010
DEFB %00111100
DEFB %00000000

; \$48 - Character: 'H' CHR\$(72)

DEFB %00000000

DEFB %01000010
DEFB %01000010
DEFB %01111110
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %00000000

; \$49 - Character: 'I' CHR\$(73)

DEFB %00000000
DEFB %00111110
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00111110
DEFB %00000000

; \$4A - Character: 'J' CHR\$(74)

DEFB %00000000
DEFB %00000010
DEFB %00000010
DEFB %00000010
DEFB %01000010
DEFB %01000010
DEFB %00111100
DEFB %00000000

; \$4B - Character: 'K' CHR\$(75)

DEFB %00000000
DEFB %01000100
DEFB %01001000
DEFB %01110000
DEFB %01001000
DEFB %01000100
DEFB %01000010
DEFB %00000000

; \$4C - Character: 'L' CHR\$(76)

DEFB %00000000
DEFB %01000000
DEFB %01000000
DEFB %01000000
DEFB %01000000
DEFB %01000000
DEFB %01111110
DEFB %00000000

; \$4D - Character: 'M' CHR\$(77)

DEFB %00000000
DEFB %01000010
DEFB %01100110
DEFB %01011010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %00000000

; \$4E - Character: 'N' CHR\$(78)

```
DEFB %00000000
DEFB %01000010
DEFB %01100010
DEFB %01010010
DEFB %01001010
DEFB %01000110
DEFB %01000010
DEFB %00000000
```

; \$4F - Character: 'O' CHR\$(79)

```
DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %00111100
DEFB %00000000
```

; \$50 - Character: 'P' CHR\$(80)

```
DEFB %00000000
DEFB %01111100
DEFB %01000010
DEFB %01000010
DEFB %01111100
DEFB %01000000
DEFB %01000000
DEFB %00000000
```

; \$51 - Character: 'Q' CHR\$(81)

```
DEFB %00000000
DEFB %00111100
DEFB %01000010
DEFB %01000010
DEFB %01010010
DEFB %01001010
DEFB %00111100
DEFB %00000000
```

; \$52 - Character: 'R' CHR\$(82)

```
DEFB %00000000
DEFB %01111100
DEFB %01000010
DEFB %01000010
DEFB %01111100
DEFB %01000100
DEFB %01000010
DEFB %00000000
```

; \$53 - Character: 'S' CHR\$(83)

```
DEFB %00000000
DEFB %00111100
DEFB %01000000
DEFB %00111100
DEFB %00000010
DEFB %01000010
DEFB %00111100
DEFB %00000000
```


; \$54 - Character: 'T' CHR\$(84)

DEFB %00000000
DEFB %11111110
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00000000

; \$55 - Character: 'U' CHR\$(85)

DEFB %00000000
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %00111100
DEFB %00000000

; \$56 - Character: 'V' CHR\$(86)

DEFB %00000000
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %00100100
DEFB %00011000
DEFB %00000000

; \$57 - Character: 'W' CHR\$(87)

DEFB %00000000
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01000010
DEFB %01011010
DEFB %00100100
DEFB %00000000

; \$58 - Character: 'X' CHR\$(88)

DEFB %00000000
DEFB %01000010
DEFB %00100100
DEFB %00011000
DEFB %00011000
DEFB %00100100
DEFB %01000010
DEFB %00000000

; \$59 - Character: 'Y' CHR\$(89)

DEFB %00000000
DEFB %10000010
DEFB %01000100
DEFB %00101000
DEFB %00010000
DEFB %00010000

DEFB %00010000
DEFB %00000000

; \$5A - Character: 'Z' CHR\$(90)

DEFB %00000000
DEFB %01111110
DEFB %00000100
DEFB %00001000
DEFB %00010000
DEFB %00100000
DEFB %01111110
DEFB %00000000

; \$5B - Character: '[' CHR\$(91)

DEFB %00000000
DEFB %00001110
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001110
DEFB %00000000

; \$5C - Character: '\' CHR\$(92)

DEFB %00000000
DEFB %00000000
DEFB %01000000
DEFB %00100000
DEFB %00010000
DEFB %00001000
DEFB %00000100
DEFB %00000000

; \$5D - Character: ']' CHR\$(93)

DEFB %00000000
DEFB %01110000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %01110000
DEFB %00000000

; \$5E - Character: '^' CHR\$(94)

DEFB %00000000
DEFB %00010000
DEFB %00111000
DEFB %01010100
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00000000

; \$5F - Character: '_' CHR\$(95)

DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000

```
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %11111111
```

; \$60 - Character: 'ukp' CHR\$(96)

```
DEFB %00000000
DEFB %00011100
DEFB %00100010
DEFB %01111000
DEFB %00100000
DEFB %00100000
DEFB %01111110
DEFB %00000000
```

; \$61 - Character: 'a' CHR\$(97)

```
DEFB %00000000
DEFB %00000000
DEFB %00111000
DEFB %00000100
DEFB %00111100
DEFB %01000100
DEFB %00111100
DEFB %00000000
```

; \$62 - Character: 'b' CHR\$(98)

```
DEFB %00000000
DEFB %00100000
DEFB %00100000
DEFB %00111100
DEFB %00100010
DEFB %00100010
DEFB %00111100
DEFB %00000000
```

; \$63 - Character: 'c' CHR\$(99)

```
DEFB %00000000
DEFB %00000000
DEFB %00011100
DEFB %00100000
DEFB %00100000
DEFB %00100000
DEFB %00011100
DEFB %00000000
```

; \$64 - Character: 'd' CHR\$(100)

```
DEFB %00000000
DEFB %00000100
DEFB %00000100
DEFB %00111100
DEFB %01000100
DEFB %01000100
DEFB %00111100
DEFB %00000000
```

; \$65 - Character: 'e' CHR\$(101)

```
DEFB %00000000
DEFB %00000000
```

```
DEFB %00111000
DEFB %01000100
DEFB %01111000
DEFB %01000000
DEFB %00111100
DEFB %00000000
```

; \$66 - Character: 'f' CHR\$(102)

```
DEFB %00000000
DEFB %00001100
DEFB %00010000
DEFB %00011000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00000000
```

; \$67 - Character: 'g' CHR\$(103)

```
DEFB %00000000
DEFB %00000000
DEFB %00111100
DEFB %01000100
DEFB %01000100
DEFB %00111100
DEFB %00000100
DEFB %00111000
```

; \$68 - Character: 'h' CHR\$(104)

```
DEFB %00000000
DEFB %01000000
DEFB %01000000
DEFB %01111000
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %00000000
```

; \$69 - Character: 'i' CHR\$(105)

```
DEFB %00000000
DEFB %00010000
DEFB %00000000
DEFB %00110000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00111000
DEFB %00000000
```

; \$6A - Character: 'j' CHR\$(106)

```
DEFB %00000000
DEFB %00000100
DEFB %00000000
DEFB %00000100
DEFB %00000100
DEFB %00000100
DEFB %00000100
DEFB %00100100
DEFB %00011000
```

; \$6B - Character: 'k' CHR\$(107)

```
DEFB %00000000
DEFB %00100000
DEFB %00101000
DEFB %00110000
DEFB %00110000
DEFB %00101000
DEFB %00100100
DEFB %00000000
```

```
; $6C - Character: 'l'          CHR$(108)
```

```
DEFB %00000000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00001100
DEFB %00000000
```

```
; $6D - Character: 'm'          CHR$(109)
```

```
DEFB %00000000
DEFB %00000000
DEFB %01101000
DEFB %01010100
DEFB %01010100
DEFB %01010100
DEFB %01010100
DEFB %00000000
```

```
; $6E - Character: 'n'          CHR$(110)
```

```
DEFB %00000000
DEFB %00000000
DEFB %01111000
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %00000000
```

```
; $6F - Character: 'o'          CHR$(111)
```

```
DEFB %00000000
DEFB %00000000
DEFB %00111000
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %00111000
DEFB %00000000
```

```
; $70 - Character: 'p'          CHR$(112)
```

```
DEFB %00000000
DEFB %00000000
DEFB %01111000
DEFB %01000100
DEFB %01000100
DEFB %01111000
DEFB %01000000
DEFB %01000000
```

; \$71 - Character: 'q' CHR\$(113)

DEFB %00000000
DEFB %00000000
DEFB %00111100
DEFB %01000100
DEFB %01000100
DEFB %00111100
DEFB %00000100
DEFB %00000110

; \$72 - Character: 'r' CHR\$(114)

DEFB %00000000
DEFB %00000000
DEFB %00011100
DEFB %00100000
DEFB %00100000
DEFB %00100000
DEFB %00100000
DEFB %00100000
DEFB %00000000

; \$73 - Character: 's' CHR\$(115)

DEFB %00000000
DEFB %00000000
DEFB %00111000
DEFB %01000000
DEFB %00111000
DEFB %00000100
DEFB %01111000
DEFB %00000000

; \$74 - Character: 't' CHR\$(116)

DEFB %00000000
DEFB %00010000
DEFB %00111000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00010000
DEFB %00001100
DEFB %00000000

; \$75 - Character: 'u' CHR\$(117)

DEFB %00000000
DEFB %00000000
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %00111000
DEFB %00000000

; \$76 - Character: 'v' CHR\$(118)

DEFB %00000000
DEFB %00000000
DEFB %01000100
DEFB %01000100
DEFB %00101000
DEFB %00101000
DEFB %00010000

DEFB %00000000

; \$77 - Character: 'w' CHR\$(119)

DEFB %00000000
DEFB %00000000
DEFB %01000100
DEFB %01010100
DEFB %01010100
DEFB %01010100
DEFB %01010100
DEFB %00101000
DEFB %00000000

; \$78 - Character: 'x' CHR\$(120)

DEFB %00000000
DEFB %00000000
DEFB %01000100
DEFB %00101000
DEFB %00010000
DEFB %00101000
DEFB %01000100
DEFB %00000000

; \$79 - Character: 'y' CHR\$(121)

DEFB %00000000
DEFB %00000000
DEFB %01000100
DEFB %01000100
DEFB %01000100
DEFB %00111100
DEFB %00000100
DEFB %00111000

; \$7A - Character: 'z' CHR\$(122)

DEFB %00000000
DEFB %00000000
DEFB %01111100
DEFB %00001000
DEFB %00010000
DEFB %00100000
DEFB %01111100
DEFB %00000000

; \$7B - Character: '{' CHR\$(123)

DEFB %00000000
DEFB %00001110
DEFB %00001000
DEFB %00110000
DEFB %00001000
DEFB %00001000
DEFB %00001110
DEFB %00000000

; \$7C - Character: '|' CHR\$(124)

DEFB %00000000
DEFB %00001000
DEFB %00001000
DEFB %00001000
DEFB %00001000

```

DEFB %00001000
DEFB %00001000
DEFB %00000000

; $7D - Character: '}'          CHR$(125)

DEFB %00000000
DEFB %01110000
DEFB %00010000
DEFB %00001100
DEFB %00010000
DEFB %00010000
DEFB %01110000
DEFB %00000000

; $7E - Character: '~'        CHR$(126)

DEFB %00000000
DEFB %00010100
DEFB %00101000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000
DEFB %00000000

; $7F - Character: '(c)'      CHR$(127)

DEFB %00111100
DEFB %01000010
DEFB %10011001
DEFB %10100001
DEFB %10100001
DEFB %10011001
DEFB %01000010
DEFB %00111100

#end                                ; generic cross-assembler directive

; Acknowledgements
; -----
; Sean Irvine                      for default list of section headings
; Dr. Ian Logan                    for labels and functional disassembly.
; Dr. Frank O'Hara                 for labels and functional disassembly.
; Gianluca Carri                   for labels and functional disassembly.
;
; Credits
; -----
; Alex Pallero Gonzales            for corrections.
; Mike Dailly                      for comments.
; Alvin Albrecht                   for comments.
; Andy Styles                      for full relocatability implementation and testing.
; Andrew Owen                      for ZASM compatibility and format improvements.
; Philip Kendall                   for help with Newton Raphson square root theory.
; James Smith                      for optimizing some ROM routines to save space
;                                  and the FORMAT routine.
;
; -----
; THE 'SYSTEM VARIABLES'
; -----

; 5B00 (IY-$3A) 23296 KSTATE_0      $FF (free) else raw key value.
; 5B01 (IY-$39) 23297 KSTATE_1      The 5-counter

```



```

; 5B02 (IY-$38) 23298 KSTATE_2
; 5B03 (IY-$37) 23299 KSTATE_3
; -----
; 5B04 (IY-$36) 23300 KSTATE_4
; 5B05 (IY-$35) 23301 KSTATE_5
; 5B06 (IY-$34) 23302 KSTATE_6
; 5B07 (IY-$33) 23303 KSTATE_7
; -----
; 5B08 (IY-$32) 23304 LASTK
; 5B09 (IY-$31) 23305 REPDEL
; 5B0A (IY-$30) 23306 REPPER
; 5B0B (IY-$2F) 23307 DEFADD
; 5B0C (IY-$2E) 23308 DEFADD_hi
; 5B0D (IY-$2D) 23309 KDATA
; 5B0E (IY-$2C) 23310 TVDATA
; 5B0F (IY-$2B) 23311 TVDATA
; -----
; 5B10 (IY-$2A) 23312 STRMS_FD
; 5B11 (IY-$29) 23313 STRMS_FD_hi
; 5B12 (IY-$28) 23314 STRMS_FE
; 5B13 (IY-$27) 23315 STRMS_FE_hi
; 5B14 (IY-$26) 23316 STRMS_FF
; 5B15 (IY-$25) 23317 STRMS_FF_hi
; 5B16 (IY-$24) 23318 STRMS_00
; 5B17 (IY-$23) 23319 STRMS_00_hi
; 5B18 (IY-$22) 23320 STRMS_01
; 5B19 (IY-$21) 23321 STRMS_01_hi
; 5B1A (IY-$20) 23322 STRMS_02
; 5B1B (IY-$1F) 23323 STRMS_02_hi
; 5B1C (IY-$1E) 23324 STRMS_03
; 5B1D (IY-$1D) 23325 STRMS_03_hi
; 5B1E (IY-$1C) 23326 STRMS_04
; 5B1F (IY-$1B) 23327 STRMS_04_hi
; 5B20 (IY-$1A) 23328 STRMS_05
; 5B21 (IY-$19) 23329 STRMS_05_hi
; 5B22 (IY-$18) 23330 STRMS_06
; 5B23 (IY-$17) 23331 STRMS_06_hi
; 5B24 (IY-$16) 23332 STRMS_07
; 5B25 (IY-$15) 23333 STRMS_07_hi
; 5B26 (IY-$14) 23334 STRMS_08
; 5B27 (IY-$13) 23335 STRMS_08_hi
; 5B28 (IY-$12) 23336 STRMS_09
; 5B29 (IY-$11) 23337 STRMS_09_hi
; 5B2A (IY-$10) 23338 STRMS_0A
; 5B2B (IY-$0F) 23339 STRMS_0A_hi
; 5B2C (IY-$0E) 23340 STRMS_0B
; 5B2D (IY-$0D) 23341 STRMS_0B_hi
; 5B2E (IY-$0C) 23342 STRMS_0C
; 5B2F (IY-$0B) 23343 STRMS_0C_hi
; 5B30 (IY-$0A) 23344 STRMS_0D
; 5B31 (IY-$09) 23345 STRMS_0D_hi
; 5B32 (IY-$08) 23346 STRMS_0E
; 5B33 (IY-$07) 23347 STRMS_0E_hi
; 5B34 (IY-$06) 23348 STRMS_0F
; 5B35 (IY-$05) 23349 STRMS_0F_hi
; -----
; 5B36 (IY-$04) 23350 CHARS
; 5B37 (IY-$03) 23351 CHARS_hi
; 5B38 (IY-$02) 23352 RASP
; 5B39 (IY-$01) 23353 PIP
; 5B3A (IY+$00) 23354 ERR_NR
; -----
; 5B3B (IY+$01) 23355 FLAGS
;

```

Initially REPDEL value then REPPER
This location holds the decoded key.

The second key map is arranged
exactly as the first above and it is
in fact this map that is considered
first by the Keyboard routines.

Value of last key read from keyboard.

0 - Set to suppress a leading space.
1 - Set if ZX Printer is in use.

```

;
;
;
;
;
;
; -----
; 5B3C (IY+$02) 23356 TV_FLAG
;
;
;
;
;
;
; -----
; 5B3D (IY+$03) 23357 ERR_SP
; 5B3E (IY+$04) 23358 ERR_SP_hi
; 5B3F (IY+$05) 23359 LIST_SP
; 5B40 (IY+$06) 23360 LIST_SP_hi
; 5B41 (IY+$07) 23361 MODE
; 5B42 (IY+$08) 23362 NEWPPC
; 5B43 (IY+$09) 23363 NEWPPC_hi
; 5B44 (IY+$0A) 23364 NSPPC
; 5B45 (IY+$0B) 23365 PPC
; 5B46 (IY+$0C) 23366 PPC_hi
; 5B47 (IY+$0D) 23367 SUBPPC
; 5B48 (IY+$0E) 23368 BORDCR
; 5B49 (IY+$0F) 23369 E_PPC
; 5B4A (IY+$10) 23370 E_PPC_hi
;
; -----
; 5B4B (IY+$11) 23371 VARS
; 5B4C (IY+$12) 23372 VARS_hi
; 5B4D (IY+$13) 23373 DEST
; 5B4E (IY+$14) 23374 DEST_hi
; 5B4F (IY+$15) 23375 CHANS
; 5B50 (IY+$16) 23376 CHANS_hi
; 5B51 (IY+$17) 23377 CURCHL
; 5B52 (IY+$18) 23378 CURCHL_hi
; 5B53 (IY+$19) 23379 PROG
; 5B54 (IY+$1A) 23380 PROG_hi
; 5B55 (IY+$1B) 23381 NXTLIN
; 5B56 (IY+$1C) 23382 NXTLIN_hi
; 5B57 (IY+$1D) 23383 DATADD
; 5B58 (IY+$1E) 23384 DATADD_hi
; 5B59 (IY+$1F) 23385 E_LINE
; 5B5A (IY+$20) 23386 E_LINE_hi
; 5B5B (IY+$21) 23387 K_CUR
; 5B5C (IY+$22) 23388 K_CUR_hi
; 5B5D (IY+$23) 23389 CH_ADD
; 5B5E (IY+$24) 23390 CH_ADD_hi
; 5B5F (IY+$25) 23391 X_PTR
; 5B60 (IY+$26) 23392 X_PTR_hi
; 5B61 (IY+$27) 23393 WORKSP
; 5B62 (IY+$28) 23394 WORKSP_hi
; 5B63 (IY+$29) 23395 STKBOT
; 5B64 (IY+$2A) 23396 STKBOT_hi
; 5B65 (IY+$2B) 23397 STKEND
; 5B66 (IY+$2C) 23398 STKEND_hi
;
; -----
; 5B67 (IY+$2D) 23399 BREG
; 5B68 (IY+$2E) 23400 MEM
; 5B69 (IY+$2F) 23401 MEM_hi
;
; -----

```

```

2 - Set if 'L' mode, temporary value.
3 - Set if 'L' mode, reset for 'K' perm.
4 - Unused by 48K BASIC.
5 - Set in a new key has been pressed.
6 - Set if scanning result is numeric.
7 - Reset if checking syntax.

```

```

0 - Set if lower screen in use.
1 - unused.
2 - unused.
3 - Set if edit key has been pressed.
4 - Set if an automatic listing.
5 - Set if lower screen to be cleared.
6 - unused.
7 - unused.

```

Values 0, 1 or 2

```

; 5B6A (IY+$30) 23402 FLAGS2      0 - Set if main screen to be cleared.
;                                     1 - Not used - held state of ZX buffer.
;                                     2 - Set if a ':' is within quotes.
;                                     3 - Set if Caps Lock on.
;                                     4 - Set if "K" channel is use.
;                                     5 - unused.
;                                     6 - unused.
;                                     7 - unused.
; -----
; 5B6B (IY+$31) 23403 DF_SZ
; 5B6C (IY+$32) 23404 S_TOP
; 5B6D (IY+$33) 23405 S_TOP_hi
; 5B6E (IY+$34) 23406 OLDPPC
; 5B6F (IY+$35) 23407 OLDPPC_hi
; 5B70 (IY+$36) 23408 OSPPC
; -----
; 5B71 (IY+$37) 23409 FLAGX      0 - Set if handling a simple string.
;                                     1 - Set if handling a new variable.
;                                     2 - unused.
;                                     3 - unused.
;                                     4 - unused.
;                                     5 - Set if in input mode.
;                                     6 - unused.
;                                     7 - Set if handling INPUT LINE.
; -----
; 5B72 (IY+$38) 23410 STRLEN
; 5B73 (IY+$39) 23411 STRLEN_hi
; 5B74 (IY+$3A) 23412 T_ADDR
; 5B75 (IY+$3B) 23413 T_ADDR_hi
; 5B76 (IY+$3C) 23414 SEED
; 5B77 (IY+$3D) 23415 SEED_hi
; 5B78 (IY+$3E) 23416 FRAMES1
; 5B79 (IY+$3F) 23417 FRAMES2
; 5B7A (IY+$40) 23418 FRAMES3
; 5B7B (IY+$41) 23419 UDG
; 5B7C (IY+$42) 23420 UDG_hi
; 5B7D (IY+$43) 23421 COORDS_x
; 5B7E (IY+$44) 23422 COORDS_y
; 5B7F (IY+$45) 23423 P_POSN (unused)
; 5B80 (IY+$46) 23424 PR_CC (unused)
; 5B81 (IY+$47) 23425 PR_CC (unused)
; 5B82 (IY+$48) 23426 ECHO_E
; 5B83 (IY+$49) 23427 ECHO_E_hi
; 5B84 (IY+$4A) 23428 DF_CC
; 5B85 (IY+$4B) 23429 DF_CC_hi
; 5B86 (IY+$4C) 23430 DFCCCL
; 5B87 (IY+$4D) 23431 DFCCCL_hi
; 5B88 (IY+$4E) 23432 S_POSN
; 5B89 (IY+$4F) 23433 S_POSN_hi
; 5B8A (IY+$50) 23434 SPOSNL
; 5B8B (IY+$51) 23435 SPOSNL_hi
; 5B8C (IY+$52) 23436 SCR_CT
; 5B8D (IY+$53) 23437 ATTR_P
; 5B8E (IY+$54) 23438 MASK_P
; 5B8F (IY+$55) 23439 ATTR_T
; 5B90 (IY+$56) 23440 MASK_T
; 5B91 (IY+$57) 23441 P_FLAG
; -----
; 5B92 (IY+$58) 23442 MEM_0
; 5B93 (IY+$59) 23443 MEM_0
; 5B94 (IY+$5A) 23444 MEM_0
; 5B95 (IY+$5B) 23445 MEM_0
; 5B96 (IY+$5C) 23446 MEM_0
; 5B97 (IY+$5D) 23447 MEM_1

```

```

; 5B98 (IY+$5E) 23448 MEM_1
; 5B99 (IY+$5F) 23449 MEM_1
; 5B9A (IY+$60) 23450 MEM_1
; 5B9B (IY+$61) 23451 MEM_1
; 5B9C (IY+$62) 23452 MEM_2
; 5B9D (IY+$63) 23453 MEM_2
; 5B9E (IY+$64) 23454 MEM_2
; 5B9F (IY+$65) 23455 MEM_2
; 5BA0 (IY+$66) 23456 MEM_2
; 5BA1 (IY+$67) 23457 MEM_3
; 5BA2 (IY+$68) 23458 MEM_3
; 5BA3 (IY+$69) 23459 MEM_3
; 5BA4 (IY+$6A) 23460 MEM_3
; 5BA5 (IY+$6B) 23461 MEM_3
; 5BA6 (IY+$6C) 23462 MEM_4
; 5BA7 (IY+$6D) 23463 MEM_4
; 5BA8 (IY+$6E) 23464 MEM_4
; 5BA9 (IY+$6F) 23465 MEM_4
; 5BAA (IY+$70) 23466 MEM_4
; 5BAB (IY+$71) 23467 MEM_5
; 5BAC (IY+$72) 23468 MEM_5
; 5BAD (IY+$73) 23469 MEM_5
; 5BAE (IY+$74) 23470 MEM_5
; 5BAF (IY+$75) 23471 MEM_5
;
; -----
; 5BB0 (IY+$76) 23472 NMI_ADD
; 5BB1 (IY+$77) 23473 NMI_ADD_hi
; 5BB2 (IY+$78) 23474 RAMTOP
; 5BB3 (IY+$79) 23475 RAMTOP_hi
; 5BB4 (IY+$7A) 23476 P_RAMT
; 5BB5 (IY+$7B) 23477 P_RAMT_hi
;
; -----
; 5BB6 (IY+$7C) 23478 FLAGS3 unused - holds FF to show no Interfacel
; 5BB7 (IY+$7D) 23479 WIDTH RS232 Printer column variable
; 5BB8 (IY+$7E) 23480 WIDTH Printer width as set by FORMAT "t"
; 5BB9 (IY+$7F) 23481 MAXIY unused
; 5BBA 23482 BAUD_lo Two Byte number determining the BAUD
; 5BBB 23483 BAUD_hi rate. BAUD=(3500000/(26*baud rate))-2
; 5BBC 23484 NTSTAT Own Network station number
; 5BBD 23485 IOBORD Border colour used during I/O
; 5BBE 23486 SER_FL 2-byte workspace used by RS232
; 5BBF 23487 SER_FL holds second character if first is one
; 5BC0 23488 NTRESP Store for the network response code.
; 5BC1 23489 NTDEST Destination station number.
; 5BC2 23490 NTSRCE Source station number.
; 5BC3 23491 NTNUMB_lo Network block number - two bytes
; 5BC4 23492 NTNUMB_hi as received over the network
; 5BC5 23493 NTTYPE Header type code as received.
; 5BC6 23494 NTLEN Data block length 0-255.
; 5BC7 23495 NTDCS Data block checksum.
; 5BC8 23496 NTHCS Header block checksum.
;
;
; Revision History
; -----
;
; 25-AUG-2002
; All references to System Variables changed from $5C to $5B.
; Changed byte in CHAN-OPEN from $5C to $5B.
; The COPY command re-written so as not to clear the ZX Printer Buffer.
; Channel "P" removed from INITIAL CHANNEL DATA
; Reduced number of bytes copied during initialization from 21 to 16.
; Stream 3 entry removed from INITIAL STREAM DATA
; Reduced number of bytes copied during initialization from 14 to 12.

```

```

; Reduced offset in expression within CLOSE from 14 to 12.
; Modify CLOSE routine to error if stream offset is already closed (zero).
; Add new Error report 'Stream is closed' to error message table.
; Modify DE offset in CLOSE from $A3E2 to $A4E4 to reflect new STRMS location
; and fewer system streams.
; Substantially alter CLOSE-2 so that IX used to access letter and offset saved
; in DE. Start of channel saved in IX.
; (Noticed for the first time pointer to letter was previously saved in DE).
; Create new INITIAL P CHANNEL DATA (8 bytes) for channel creation. Contains
; usual 5 bytes plus + 2-byte length + P_POSN (column position). The output
; address PR_CC can't be held as this would vary as channels are deleted.
;
; 26-AUG-2002
; Modify OPEN-1 so that a stream associated with "P" can't be re-attached.
; Modify OPEN-K so that LD E,$01 becomes LD DE,$0001.
; Modify OPEN-S so that LD E,$06 becomes LD DE,$0006.
; Completely re-write OPEN-P (which was no more sophisticated) so that it
; creates a 264 byte "P" channel at end of CHANS area.
; Remove line in OPEN-END that set high byte of offset to zero.??
; Remove call to CLEAR-PRB during initialization.
; Remove call to COPY-BUFF at MAIN-4 [ * This will have to be re-visited ]
; Modify print routine so that FLAGS2 is not updated when a ZX buffer used.
; Modify PR-ALL-6 so that address can cross a 256-byte page boundary.
; Modify CLEAR-PRB so that FLAGS2 not cleared when buffer cleared.
; Modify CLEAR-PRB so that superfluous PR_CC reference removed.
; Modify CLEAR_PRB so that address of buffer is calculated from CURCHL.
; Modify COPY-LINE so that CLEAR-PRB only invoked when outputting to a channel
; and BREAK is pressed.
; Realising that CLEAR-PRB can only be used as such, go back to OPEN-P and
; clear the buffer bytes directly.
; Modify COPY_BUFF so that address of buffer is calculated from CURCHL.
; Remove "LD HL,$5B00" from start of CL-SET. Still works for ZX path.
; Modify PO-STORE so that IX from CURCHL used to update P_POSN (channel var).
; Substantially modify PO-FETCH so that the print address within the channel
; buffer is formed from the column position P_POSN.
;
; 27-AUG-2002
; Write routine CLOSE-P so that channel reclaimed.
; Although not intended as such, this routine turns out to be generic.
; Adapt routine REST-STRM (from Interface 1) so that all other streams that
; have offsets beyond a closed stream have their offsets reduced by the
; reclaimed amount.
; Boot using VBSpec and test that channels open and close OK.
; Switch to RealSpec to test printing. Crash due to A not being preserved
; during new PO-FETCH. Trace and rectify using debugger and notice all OK.
; Switch to DOS Z80 emulator for final paper output tests. Brilliant as always.
; Re-locate FREE-MEM routine to spare space between restarts as address was
; moving around as code was added and removed.
; Free memory has increased from 41472 to 41733
; ROM space has reduced alarmingly. Only 1040 bytes spare.
; Embark on a spree to remove redundant code.
; Routines ZX81 name routine, REC-EDIT and P-INT-STO commented out.

; 28-AUG-2002
; Table of constants expanded to five bytes.
; SKIP-CONS commented out - no longer writes to ROM.
; First two instructions of get-mem swapped to provide entry point from
; the stk-con-x routine which is now just 5 bytes.
; To inhibit all writes to ROM, limit scroll routine to 23 lines (not 24).
; Interrupt routine re-written to avoid IY register use. (saves one byte)
; Applied fixes to KEYBOARD so that keywords don't repeat and only valid keys
; return a graphic key code i.e. only A-U.
; Generally, comment out unnecessary stack saves, double loads etc.
; Since labels have no relation to address, change them to use legalized

```

```

; disassembly labels.

; 31-AUG-2002
; Square Root function rewritten to use the Newton-Raphson method.
; Can be improved further by finding a better initial guess than 1.

; 01-SEP-2002
; Use better initial guess than '1' for Newton Raphson SQR function.
; Works even better when integers are immediately re-stacked as floating point
; numbers.

; 03-SEP-2002
; More fixes - allow SAVE "program" LINE without number as per BASIC manual.
; ROM space pruning - use UNSTACK_Z to full potential.

; 04-SEP-2002
; For consistency, use the words "CONTINUE" and "GO SUB" in error messages
; instead of the ZX81 tokens used in the production ZX Spectrum ROM.
; This was a mistake as both messages were at the maximum length. Reverted.
; The INT -65536 bug fixed as per Dr. Ian Logan's guidelines ensuring that the
; 3rd, 4th and 5th bytes were zero.

; 05-SEP-2002
; All quirks, features and bugs removed. Details as follows.

; Source: Understanding Your Spectrum by Dr. Ian Logan
; (12 bugs listed in appendix)
; i. The 'division' error - is a misnomer. The inaccuracy mentioned occurs
; in the DEC_TO_FP routine and by switching the multiply and division
; operations then 0.5 is given the floating point form 80 00 00 00 00.
; The suggested fix is ignored.
; ii. The '-65536' error e.g. PRINT INT -65536 gives -1.
; Dr. Ian Logan's fix applied (with mods) and other code sections removed
; as suggested.
; iii. The 'program name' routine removed along with REC_EDIT and P_INT_STO.
; iv. The 'CHR$ 9' error corrected by calling PO_ABLE in preference to a
; terminal jump to CL_SET/PO_STORE.
; v. The 'scroll?' and 'Start tape' errors corrected by new routine CONS_IN.
; Later KEY_INPUT modified to recognize prompt (2 extra bytes).
; vi. The current cursor error corrected by updating E_PPC with valid line
; number while it is in the registers at an earlier stage.
; vii. The 'leading space error' resembles more a successful attempt to
; maximise the text that will fit within a 32 character display and has
; not been corrected. Ignored. (On second thoughts, this needs fixing)
; viii. The 'K-mode' error has been corrected by preventing keywords repeating
; when held down.
; ix. The 'CHR$ 8' error has been corrected as suggested by Dr. Frank O'Hara.
; x. The 'SCREEN$' error has been corrected by substituting the suggested RET
; instruction.
; xi. The 'STR$' error has been corrected by removing the extra zero from
; the calculator stack as suggested.
; xii. The 'CLOSE' error has been corrected by checking the status of the
; stream and issuing a new error message if it is already closed.
; The suggested fix - adding a zero end-marker to the Close Stream Look-up
; Table - is ignored.
;
; Source: The Complete Spectrum ROM Disassembly. by Dr. Ian Logan and
; Dr. Frank O'Hara (various additional features listed).
; 1) The NMI bug has been corrected and the logic changed as suggested on
; Page 2. The new default set-up is to produce a new informative message.
; 2) Simple strings are not excluded when saving DATA - on Page 22.
; e.g. 10 LET a$ = "dodo" : SAVE "animal" DATA a$()
; These are now rejected as they won't load back in.
; (credit: First fixed by Dr. Ian Logan in the Interface 1 ROM).

```

```

; 3) There is no end-marker for the CLOSE STREAM LOOK UP table nor should
; there be. Ignored.
;
; Source: ZX Spectrum BASIC programming by Steven Vickers. (discrepancies)
; 1) Line number should be optional in SAVE "some name" LINE - Page 133.
; Fixed.
; 2) CLEAR does a RESTORE (Page 124).
; Error in BASIC manual rather than ROM - ignored. Difficult to decide.
; 3) "Notice that the numbers in a DRAW statement can be negative, although
; those in a PLOT statement can't" - Page 92
; Fixed. 0<=x<=255. 0<=y<=175 else Error B.
; 4) Similarly the POINT (x,y) function allowed negative coordinates.
; Fixed. Error B unless 0<=x<=255. 0<=y<=175. Page 153.
; 5) The ATTR (y,x) function allows negative and invalid coordinates.
; Fixed. Error B unless 0<=x<=31 and 0<=y<=23. Page 152.
; 6) The SCREEN$ (y,x) function allows negative and invalid parameters.
; Fixed. Error B unless 0<=x<=31 and 0<=y<=23. Page 154.
;
; Source: The Pitman Pocket Guide to the Sinclair Spectrum by Steven Vickers.
; (discrepancies not previously mentioned.)
; 1) RESTORE. "Don't specify numbers > 9999, as the program may crash."
; To be pedantic > 16383 - see below. Page 25.
; 2) 'Statement lost' can occur with RUN, GO TO and GO SUB when the line
; number is between 32768 and 61439. Page 67.
; Fixed by new routine which checks SAVE LINE, LIST, LLIST, RUN, GO TO,
; GO SUB and RESTORE for invalid line numbers.
; 3) Due to a bug, if you bring in a peripheral channel and later use a
; colour statement, colour controls will be sent to it by mistake Page 59.
; Fixed by ensuring that the screen is first selected.
; 4) EDITING KEYS TABLE Page 58.
; When inputting from the network or RS232 or microdrive file,
; code 6 (comma separator): inserted in buffer.
; ("This is a bug. It should work like CHR$ 14"). Fixed.
;
; Source: www.nonowt.com "Bugs in the ROM"
; ( many already covered. Some are Programming Guides rather than errors. )
; 1) The Monopolizing of IY Error.
; Although not strictly an error, the manual does not mention the
; restriction as did the ZX81 manual. Also some effort has gone into
; ensuring that the calculator avoids IY mathematically and it is restored
; following a USR function.
; Fixed - the interrupt routine uses HL to access system variables.
; Saves a few bytes too.
; 2) The PR_CC error (credit: Dilwyn Jones 1983).
; Fixed - No ZX printer system variables remain. The print position is
; recalculated every time from a single new channel variable.
; 3) The CLEAR PRINTER BUFFER Bug.
; Fixed - COPY no longer clears the buffer at the end of the statement or
; when BREAK pressed.
; 4) The Main-4 COPY-BUFF Error.
; Partly fixed as routine is no longer called but unprinted output is not
; yet flushed. ( To revisit at end ) (Done.)
; 5) The MAIN-4 HALT instruction not corrected as not really an error.
; The fault was with programmers and also with the Interface 1.
; The NMI fix provides a clean means of exit should the situation arise.
; i.e. Should a programmer forget to enable interrupts before returning
; to BASIC. However I have to admit I don't know why it is there. If you
; press BREAK it ensures the message remains a while longer.
; 6) The WRITE TO ROM at $0000 by SKIP_CONS has been avoided by improving
; the way constants are stored and indexed.
; The WRITE TO ROM by the SCROLL routine (credit: P.Giblin) has been
; avoided, as suggested, by ensuring that the full 24 lines are never
; scrolled.
; 7) The unimplemented e-to-fp calculator instruction could be removed by

```

```

; assigning $3C to 're-stack'. Five calculator routines would require
; alteration. This would gain two extra bytes of ROM space but has not
; yet been done.
; 8) The INKEY$#0 Error. This could apply to any stream although streams 0
; and 1 read from the keyboard by default. If the selected stream has
; been attached to the keyboard then the null string is almost always
; returned. The read_in routine correctly cancels any keypress as we are
; not interested in what was pressed, perhaps, half an hour ago. However
; there is hardly anytime for an interrupt to occur before the channel
; is read. Fixed by testing for channel 'K' and executing a HALT if so.
; INKEY$#0 is not the same as INKEY$ as the latter always reads the
; keyboard directly whereas using streams has to take REPDEL and REPPER
; into account e.g. 10 PRINT ; CODE INKEY$#0 ; " " ; : GO TO 10
;
; Miscellaneous BUGS and features.
;
; 1) In graphics mode, keys V, W, X, Y and Z give inappropriate keywords.
; Fixed by not storing key if higher than 'U'.
; 2) USR-$ contains a double check on number of UDGs. First check removed.
; It would be required if there were 26 UDGs and so it may be put back.
; 4) A typo like LIST 40000 was silently changed to LIST 7232. As an error
; is now given, the modifying code (AND $3F) has been removed.
; 3) ZX81 keywords were used in Spectrum error messages. Fixed in error.
; Not possible to add a space to GOSUB without exceeding 32 characters.
;
; -----
; 06-SEP-2002
; RST 30H vacated by making BC_SPACES a subroutine.
; The ERROR restart is moved to $0030 to avoid paging in Interface 1 while,
; at the same time, allowing access to its hardware.
; RST 08H made a User Restart with a JP to three unused system variables
; starting at the old P-POSN. This idea later scotched.
; The NMI handler is located in the other 5 bytes.
; Routine PO_ATTR has an EX DE,HL instruction added to return the attribute
; address in DE. (see next)
; Routine OUT_FLASH rewritten to print the character and then set the FLASH
; bit of the attribute address.
; Routine CL_ATTR rearranged to perform attribute calculation last - providing
; a new subroutine CL_ATTR2 which is called twice where a similar sequence
; of instructions used to be.

; 07-SEP-2002
; ROM usage reduced by reducing absolute jumps. etc.
; The same RASP routine was used in two places and this has been made a
; subroutine.
; Note. there is now one MORE spare byte than in the standard ZX Spectrum.
; There are 1172 unused bytes.
; 16 spare bytes moved to area before Cassette Interface to make addresses
; 04D8 and 056A the same as standard ROM as these are trapped by emulators
; to SAVE and LOAD to tape.
; 240 spare bytes moved to area surrounding $1708 to prevent Interface 1 paging.

; 08-SEP-2002
; There are now 20 more bytes of free ROM space than in the standard Spectrum
; and that is despite writing an optimized TEST_5_SP routine.
; Optimized STACK_BC so IY not initialized every time. Result pointer set by
; a faster method.
; Optimized sto_mem_x so that memory not checked when removing a value from the
; calculator stack.

; 09-SEP-2002
; Optimize FP_TO_BC and all routines that call it - FP_TO_A etc. by setting HL
; to the initial value by a faster method.

```



```
; Optimize FP_TO_A too. Anything involving the calculator stack has to be
; optimal.

; 10-SEP-2002
; Noticed EX AF,AF' is little used outside the cassette interface and in some
; places it would be faster than PUSH/POP AF. Not very many.
; Corrected error introduced by pruning in GET_HLxDE.

; 11-SEP-2002
; remove redundant code from -65536 fix and optimize to avoid machine stack.
; Spare locations = 1207 bytes

; 12-SEP-2002
; Put back the five bytes before MULT_RSLT and document so I don't remove again.
; Concentrate on testing this stage.

; 13-SEP-2002
; superfluous instruction removed from PIXEL_ADD
; 50 more bytes of spare ROM space than standard ROM.

; 14-SEP-2002
; THE OPEN_P routine made generic and called OPEN_ALL. It is only necessary
; to set IX to the channel data before calling it.

; 15-SEP-2002
; Add RS232 and Network channels. i.e. "B", "T" and "N".
; Less than fourteen bytes spare.
; Requires some tidying up. Stuff like OPEN #7,"N:64" requires implementation.
; Also a few flag setting routines. Looks promising though.
; It is possible to use PRINT, LIST, INPUT and INKEY$ with new channels but
; not SAVE, LOAD, MERGE and VERIFY. Yet.
; The microdrives don't stand a chance but this was all the adverts ever
; promised. Only one machine on the network requires a mass storage device.
; Commands MOVE, ERASE, CAT and FORMAT are not implemented.
; The FORMAT command would be useful for altering the BAUD rate and setting
; the network station number.

; 16-SEP-2002
; Some problems when breaking into INPUT. Debugging code is in lower case.
; Document to help trace what's happening.

; 17-SEP-2002
; Discover minor bug in the Interface 1 (and Discovery Disk Interface) at the
; end of GET_NBLK but my own bug eludes me. (BREAK message not being cleared)
; Find the bug in this ROM. Hurrah! I need to reset bit 3 of TV_FLAG before
; entering the editor.

; 18-SEP-2002
; Complete the documentation of text channel.
; I've worked out where the new string syntax should be enforced. e.g. OPEN "N2"
; In the CLASS-0A routine. The runtime path would populate D_STR1. A lot easier
; than what I was contemplating and the effect is global. i.e. on all CLASS_0A
; strings.

; 19-SEP-2002
; Alter 'sqr' so that IY not used. Improve comments. Start FILE_DESC.

; 20-SEP-2002
; Clarify documentation and increase ROM space.

; 21-SEP-2002
; Removed the 'SUB 08' from multi comparisons calculator routine.
; Re-arranged space between restarts.
; FREE memory is now PRINT 65536 - USR 93.
```

```
; 22-SEP-2002
; Documented 'truncate'. Found a redundant byte and managed to save another.
; Incorporate the network SEND_EOF routine. Also flush ZX Printer buffer.
; Use 2 as default Iris instead of 0 (broadcast). Input gives a satisfying
; 'End of File' report now.

; 23-SEP-2002
; Test flags before branching in ED-KEYS saves 8 bytes.

; 24-SEP-2002
; Modify KEY-INPUT so it recognizes the prompt situation. Get rid of temporary
; routine CONS_IN. Incorporate FILE_SPEC into CLASS_0A.
; 3 ROM bytes spare. Some syntax improvements to do. For instance
; OPEN #7,"printer" now passes through which it shouldn't.
; OPEN #7,"n:64" etc. now works.

; 25-SEP-2002
; Pressed ahead and made syntax rock-solid. OPEN works fine. Did the FORMAT
; command while in the mood. Well there are now 53 bytes over the 16K limit.
; Always amazing. Found some nice similarities in the T_CHAN/TV_DATA code.
;
; The only way I could get under 16K was to go back to the old sqr routine :-(
; This was, however, merely an indulgence as I believe this was once in
; the ZX81 until the exact same situation arose as has occurred now.
;
; Unless there are bugs, I doubt there will be any more updates for months.
;
; The only outstanding task is to SAVE/LOAD programs using the new channels.
;
; I stuck the 2-byte STOP command between the restarts eventually. I still
; have 5-byte and 3-byte unused sections in there. Mail me if you can think of
; a use for them - geoff{at}wearmouth{dot}demon{dot}co{dot}uk
;
; Somewhat belatedly PEEK 9 gives release number - currently 31.

; 26-SEP-2002
; Corrected errors in proposed syntax.

; 01-OCT-2002
; Abandoned Interface 1 compatible SAVE/LOAD syntax
; The "new" syntax will be OPEN #7,"n:2" : SAVE #7; "prognam" : CLOSE #7

; 02-OCT-2002
; Implemented SAVE/LOAD/MERGE/VERIFY from network and RS232 (both untested).
; Changed Error message for error code R: to just 'Loading error'
; Fixed Graphics mode bug caused by ROM space pruning (credit: Andrew Owen).

; 03-OCT-2002
; Saving and Listing to RS232 seems to work OK but not Loading.
; This update contains a partial fix.

; 06-OCT-2002
; This version has 10 spare ROM bytes.

; 08-OCT-2002
; This has about 20 spare bytes and isolates $1708.

; 13-OCT-2002
; Improve documentation.
; Apply ROM space saving techniques from James Smith.

; 17-OCT-2002
; Apply more ROM space saving techniques from James Smith.
```

```

; MAKE_ROOM now increments HL which was almost always the next instruction.
; Trying to get enough room to bring back the fast square roots and tidy up.

; 18-OCT-2002
; Isolate location $1708 again.

; 27-OCT-2002
; Add the FORMAT routines of James Smith.
; About seven bytes overdrawn.

; 28-OCT-2002
; reduce object code to 16384 bytes using techniques provided by James.

; 09-NOV-2002
; Simplify K-DECODE to solve repeating key problem. (Reported by Andrew Owen)
; Rectify CLOSE_A to support 13 ZX printer buffers.

; 10-NOV-2002
; Change FORMAT command to use FORMAT "channel specifier"; number
; Created new class routine CLASS_OC to allow choice of separators.
; Make OPEN a CLASS-05 routine and allow OPEN #3,"p" and
; OPEN #8,"n",6 with full syntax checking
; This creates almost enough room to bring back the fast square roots.

; 11-NOV-2002
; Exploit the new CLASS_OC and EXPT_SEP routines to conserve ROM space.

; 13-NOV-2002
; Optimize Newton Raphson square roots but use old ones for now, as although
; the new ones fit, they leave little room for development. 59 bytes spare.

; 15-NOV-2002
; At the suggestion of James Smith, now that everything is in one ROM, use
; the PO_SAVE routine for recursive printing of spaces in the text channel TAB
; and comma control routines. So create new routine PO_SV_SP as the preceding
; instruction loads A with a space. What James can save I can squander.
; Rejoice in FORMAT "k",<pip> to set the keyboard beep. On second thoughts...

; Output from the RealSpec emulator SERIAL.BIN file.
; 10 OPEN #4,"t"
; 20 LIST #4
; 30 PRINT #4,, "Hi"
; 40 PRINT #4;TAB 17;"There"
; 50 CLOSE #4
;
;           Hi
;           There
; -----
;
; 17-NOV-2002
; PO_RIGHT shortened. FORMAT_K removed :-)
;
; 22-NOV-2002
; 'exchange' shortened, Some new routines to modularize common code.
; 100 bytes free

; 24-NOV-2002
; Added verification from RS232 and Network.
; ED-RIGHT feature fixed. Reported by Andrew Owen.
; Emulator tape support abandoned. Just snapshots (.SNA) and not those from a
; normal Spectrum.

; 27-NOV-2002
; Fixed a ZX Printer 'feature' revealed by the new VBSpec emulator .

```

```
; 30-NOV-2002
; ZX Printer location $0F24 made standard for new SPIN emulator (fast mode).

; 01-DEC-2002
; Add 'CLEAR #' command to clear all streams.
; Any ZX Spectrum buffers are flushed first which is interesting in the new
; paperless ZX environment.

; 03-DEC-2002
; Woohoo! a CAT command. The Spectrum should have had this as standard.
; This version catalogs the streams to the screen.
; Not a lot of detail but give me the space. Ten bytes free.

; 04-DEC-2002
; Banner above the CAT

; 07-DEC-2002
; CAT with free memory report. Looks good.
; Once you've used this, it is difficult to give it up.
; I wonder...

; 08-DEC-2002
; OPEN #7,"n" is now rejected, as previously, without a station but there is
; no room for a 'Missing station number' report.

; 10-DEC-2002
; Minor improvements. ERASE gives error and not CAT.

; 14-DEC-2002
; More tweaks and document flags. Enter test phase.

; 15-DEC-2002
; Enough room for the fast square roots. Even 'ln' has been optimized.

; 22-DEC-2002
; Tidy and format code.

; 23-DEC-2002
; Trim COPY-BUFF by one byte and clean up.

; 25-DEC-2002
; Fix bug in standard ROM at start of INPUT. Stream 1 is designated as the
; user's input stream as per original designer's comments.

; 26-DEC-2002
; Allow OPEN #0,"n";2 so that commands can be accepted from another Spectrum
; as per Steven Vickers's remarks in the Pitman Pocket Guide.
; The network now sends the buffer on receipt of a carriage return.
; Scrapped the FREE MEMORY TEST - CAT will do just fine.

; 28-DEC-2002
; The NMI service routine now closes stream 1 in a proper fashion without
; incurring a memory leak.

; 29-DEC-2002
; Correct a pathing error in the revised scrolling routine.
; Tidy up initialization of BAUD rate. More testing.
; Correct stack corruption in DISP_MSG. Loads from network with messages now.
; Continue testing LOAD and SAVE.
; Commands LOAD, MERGE, VERIFY and SAVE all work ok from streams.

; 01-JAN-2003
; Free up some spare space. TAG important labels.
```

```
; 09-JAN-2003
; Remove RST 18H after scanning because it's there. Freed bytes not used.
; Tidy up CO_TEMP some of which had been made obsolete earlier.

; 10-JAN-2003
; Found a natural subroutine to check for a right-hand bracket.

; 23-JAN-2003
; Correct letter in BCHAN_DAT.
; Correct label in BCHAN_OUT - Saves and Loads OK to RS232 "B" in WinZ80.
; Note. this only works if the Interfacel hardware is selected - the Interface
; ROM paging has been avoided for this reason.

; 02-FEB-2003
; Network header checksum created (accidentally omitted) one less byte of RAM.
; Cleaner NMI handler written performs a warm reset regaining standard memory.
; Restores all initial channels without memory leaks.
; Reclaims any dynamic buffers attached to them.
; It then performs a warm reset by joining at the initialization of CHARS.
; This code which appears clumsy in the standard Spectrum finally makes sense.
; Then invokes MAIN_G directly. Tested WinZ80.
; Also ROM tested in new Spectaculator 4.0 and ZX Printer routines work fine.
; Also NMI Warm Reset tested with SPIN emulator - F5 key - works great.

; 23-FEB-2002
; Fixed INKEY$#0 Error. Credit Toni Baker.
; Although Vickers says that this is intended for channels other than the
; keyboard, it should really give some functionality when used with any device.
; The returned key value is of little use and subject to the values of REPPER
; and REPDEL and not the same as INKEY$ which always reads the keyboard
; directly.
```